

Installation and Maintenance

EDACS®
Data Advantage™

TABLE OF CONTENTS

TABLE OF CONTENTS.....	2
PREFACE.....	4
OVERVIEW.....	5
VME CHASSIS.....	6
RF CONTROL STATIONS.....	6
RF CONTROL STATION POWER SUPPLY	6
NETWORK PLANNING	7
ADDRESS TYPES	7
<i>IP Addresses.....</i>	7
<i>EDACS Addresses</i>	8
<i>Ethernet Addresses</i>	8
IP HOST CONFIGURATIONS.....	9
<i>Assigning Network IP Addresses.....</i>	9
<i>Assigning Individual IP Addresses.....</i>	11
<i>Assigning LIDs to IP Hosts</i>	11
<i>Sample SYSTEM.TXT File with Network Layer RDTs</i>	12
<i>Sample SYSTEM.TXT File with Non-Network Layer RDTs</i>	13
<i>Sample SYSTEM.TXT File with Eight Port Data Advantage</i>	14
<i>Sample SYSTEM.TXT File with commands under [system] heading.....</i>	15
INSTALLATION.....	16
DATA ADVANTAGE CONTENTS	16
INSTALLATION ORDER	17
MVME147 BOARD SETUP	18
VCOM24 BOARD SETUP.....	19
CONNECTING IP HOST COMPUTERS.....	21
MODIFYING THE CONFIGURATION OF HOSTS	21
TIGHTENING THE DATA ADVANTAGE'S PASSWORD SECURITY (OPTIONAL)	21
CONNECTING THE DIAGNOSTIC TERMINAL	21
CONNECTING THE PRINTER (OPTIONAL).....	22
CONNECTING WNI SERIAL PORTS TO THE RF CONTROL STATIONS	22
CONNECTING RF CONTROL STATIONS TO THE POWER SUPPLY	23
CUSTOMIZING THE DATA ADVANTAGE CONFIGURATION	23
CONNECTING TO AN AC SOURCE.....	24
TURNING ON THE DATA ADVANTAGE EQUIPMENT AND LOADING THE SOFTWARE AND CONFIGURATION	24
PROGRAMMING	24
<i>REQUIRED EQUIPMENT.....</i>	25
<i>PROGRAMMING STEPS.....</i>	25
MAINTENANCE.....	31
MODIFYING PASSWORDS	31
HARD DISK CLEANUP	31
LOADING NEW SOFTWARE RELEASES.....	31
DATA ADVANTAGE BOOT SEQUENCE	32
VCOM24 BOOT ERROR CODES.....	33
TROUBLESHOOTING GUIDE.....	34
<i>Troubleshooting tools.....</i>	34

<i>RF Control Station Statistics</i>	36
<i>System Startup</i>	37
<i>Network Connections</i>	39
<i>RF Control Stations</i>	40
<i>Radios / RDTs</i>	41
<i>Excessive Error Rate</i>	42
ICMP MESSAGES RETURNED BY DATA ADVANTAGE.....	43
FORCING A HARD DISK REFORMAT	43
FUSES	44
<i>CAP Board Fuse</i>	44
<i>SCSI Fuse</i>	44
<i>VCOM24 Fuses</i>	45
PIN OUT FOR THE DIAGNOSTIC TERMINAL CABLE.....	46
PIN OUT FOR DATA INTERFACE CABLE	46
PIN OUT FOR RADIO SHELF HARNESS / DATA INTERFACE.....	46
PIN OUT FOR THE PROGRAMMING CABLE	47
PIN OUT FOR RADIO SHELF HARNESS / RADIO PROGRAMMING.....	47

PREFACE

This is one of four manuals for Data Advantage. It contains instructions for installing and maintaining the Data Advantage equipment. Network planning and the boot sequence are also documented in this manual. Other relevant documents are:

Data Advantage Technical Description (LBI-39188):

This manual contains a detailed description of the Data Advantage capabilities, interfaces, and hardware.

Data Advantage User's Reference Manual (LBI-39191):

This manual contains information for using the Data Advantage command shell. This command shell services the Diagnostic Terminal and Telnet logins.

Data Advantage Configuration Reference Manual (LBI-39189):

This manual contains the information required to configure the Data Advantage.

Internetworking with TCP/IP, Volume I, by Douglas E. Comer:

This is an excellent (but unofficial) source of information about Internet Protocol.

EDACS CommServ Programmers Guide (LBI-38835):

This manual documents the CommServ product. CommServ provides an application program interface that simplifies **Radio Data Terminal (RDT)** programming by providing an RDI Data Link Layer. It is for use with MS-DOS (trademark of Microsoft Corporation) and PC-DOS.

Mobile Data Terminal Interface, Hardware and Protocol, Version 1.92

This manual documents the RDI Interface.

If you are unable to resolve a problem or need additional technical assistance, contact Ericsson's Technical Assistance Center (TAC) at the number shown on the last page of this manual.

OVERVIEW

Ericsson's EDACS® Data Advantage™ is a data gateway that provides services for data communication between the Radio Data Terminals (RDTs) on a EDACS trunked radio network and computer hosts on a wired network.

Data Advantage provides an Ethernet host interface using Internet Protocol (IP), and supports EDACS Network Header in the data messages to and from a Radio Data Terminal (RDT) so that the applications on both the hosts and the RDTs can use off-the-shelf software and hardware.

Data Advantage connects to the EDACS Network through multiple serial ports operating at 19,200 bps. Depending on the configuration, Data Advantage can contain four or eight ports. Each port is connected to an EDACS mobile radio with built-in Radio Data capability. Each radio connected to a Data Advantage port is programmed as "Data Host" and "Data Only" radio. All data calls are between a Data Host radio and a Terminal radio connected to an RDT.

By using RF data and standard IP protocol, Data Advantage provides an Open System solution for wireless data on a single site EDACS system.

Data Advantage consists of several subassemblies housed in a standard 19" wide x 69" tall cabinet. These include the RF control station shelves, the 4U VME Chassis with microprocessor boards and IO modules, and a power system for supplying DC power to the radios. Data Advantage can be configured to have four or eight RF control stations.




Figure 1 - Data Advantage Rack

VME CHASSIS

The 4U VME Chassis consists of the following components:

- VME bus backplane
- MVME147 microprocessor board
- One or two VCOM24 microprocessor board(s) depending on configuration.
- 3.5" hard disk drive
- 3.5" floppy disk drive

The MVME147 board and VCOM24 board(s) are connected to IO modules at the back of chassis which have connection points for console terminal, a printer, the Ethernet LAN and RF control stations. The microprocessor boards and IO modules are mounted horizontally in the chassis. Each VCOM24 board has four DB25 type female connectors providing four RS-232 serial communication channels. Each channel is connected to a single RF control station in a radio shelf.

The VME chassis has an internal power supply system. The AC input circuitry of the power supply is auto ranging, capable of using 90 - 132 VAC at 47 - 65 Hz or 180 - 264 VAC at 47 - 65 Hz. The power supply has remote sense lines for all three DC outputs (+5V, +12V, -12V), and includes an AC "POWER ON" solid state LED indicator.

RF CONTROL STATIONS

An RF control station is an EDACS mobile radio with a built-in Radio Data Interface (RDI). Data Advantage uses RF control stations to transmit and receive data calls on an EDACS RF channel. Each RF control station is housed in a shelf, and each shelf contains two RF control stations.

There are two or four RF control station shelves which are rack mountable shelf assemblies. The control heads of radios are visible from the front of the shelf when the cabinet door is open. Also, the front of the shelf has a DB9 connector and a two position switch for programming purposes. The rear of the shelf has a power connector, an 8-pin modular connector and an antenna connector for each radio in that shelf.

RF CONTROL STATION POWER SUPPLY

One or two external power supplies power the RF control stations in Data Advantage. The power system performs AC/DC conversion. The output of each power supply is connected to a power distribution panel which provides up to seven 13.6 VDC outputs to RF control stations (only four are used).

NETWORK PLANNING

Prior to configuring and installing the Data Advantage equipment, it is important to determine the addresses that will be used. In addition to this document, the *Data Advantage Technical Description Manual* (see Preface) explains the concepts behind the Data Advantage.

ADDRESS TYPES

There are three main types of addresses used when configuring the Data Advantage equipment: IP Addresses, EDACS Addresses and Ethernet Addresses. This section provides basic information on the address types.

IP Addresses

IP Addresses are made up of four octets separated by periods. The addresses are typically written in decimal, but can be hexadecimal. 1.0.0.2 is an example of an IP Address. Each octet can range from decimal 0 to 255 or hex 0x00 to 0xff.

IP Addresses contain a **Network ID** portion and a **Host ID** portion. The number of octets in each portion of the address is based on the **Class** of the address. The Class of the address is determined by the value of the first octet.

CLASS	First Octet	Network ID Portion	Host ID Portion	Number of Host IDs
A	1-126	First octet	Last three octets	16M
B	128-191	First two octets	Last two octets	65K
C	192-223	First three octets	Last octet	254
D	224-239	N/A	N/A	N/A
E	240-255	N/A	N/A	N/A

Several conventions and special cases should be noted:

1. If the IP Address is all zeros, it refers to this host.
2. If the IP Address is all ones, the destination is all hosts on the local network.
3. If the Network ID is all zeros, the IP Address refers to a host on this network. This is only valid at system startup and is not a valid destination address.
4. If the Host ID is all zeros, the IP Address refers to the Network ID.
5. If the Host ID is all ones, the IP Address refers to all hosts on the specified network (not valid on the EDACS Network).
6. If the first octet is 127, then this is a local loop-back.
7. Class D addresses are multicast.
8. Class E addresses are reserved.

EDACS Addresses

There are two types of EDACS Addresses, **Logical IDs (LIDs)**, and **Group IDs (GIDs)**. LIDs are used to reference a single radio. GIDs are used to reference a group of radios. LIDs and GIDs are programmed into radios and can be changed as desired.

TYPE	Range
LID	1 - 16,382
GID	1 - 2047

In Data Advantage, there are two categories of radios: Data Host Radio and RDT radio. A Data Host Radio is fixed RF equipment housed in the Data Advantage cabinet called RF control station. An RDT radio is connected to a Radio Data Terminal which is mobile RF equipment. A Data Host Radio must be assigned a LID in the range 1-63. The LID assigned to an RDT should be in the range 64-16382. It is not recommended to assign a LID in the range 1-63 to an RDT radio, even though it is allowed in the EDACS.

TYPE	Range
LID for Data Host Radio	1 - 63
LID for Terminal Radio	64 - 16,382

Ethernet Addresses

Ethernet Addresses are 48-bit addresses assigned by hardware vendors. Normally, an Ethernet Address is permanently assigned to a hardware device. The **Address Resolution Protocol (ARP)** that is built into the Internet Protocol allows devices to query each other for their Ethernet Address. For these reasons, Ethernet Addresses are of minor importance when setting up a network, and are not discussed in detail.

IP HOST CONFIGURATIONS

Assigning Network IP Addresses

An **internet** consists of multiple networks connected together, with each network on the internet assigned a unique network address. The first step in setting up an internet is to determine the IP Network Addresses that will be used. In the simplest case, three network addresses will be used: one each for the IP Host Network, the Internal Data Advantage Network, and the EDACS Network. A Class A, B, or C address can be used for any of the addresses. Class D and E addresses can not be used. **A Network Address can only be used once in an internet.**




Figure 2 - An IP host internet with no IP Addresses

If the IP Host Network already exists, its Network Address will have already been assigned. Otherwise it will need to be assigned. For this example, the IP Host Network is an existing network with an address of 1.0.0.0.

Next, the Internal Data Advantage Network Address needs to be assigned. Since the number of individual addresses required on this network is small (one address per board), a Class C address is recommended. Data Advantage will default its internal Network Address to 192.168.100.0. If this Network Address isn't available, another one can be used.

Finally, an available Network Address needs to be chosen for the EDACS Network. A Class C address typically isn't used since each radio must be assigned an address, and even a single site EDACS System can have more than 254 radios. A Class B address can be used to conserve Class A Network IDs. If an EDACS network ID is not specified, Data Advantage will default to a value of 172.16.0.0. For this example, it is assumed that you have chosen to assign Network Address 128.1.0.0 to your EDACS Network.

Remember that since each Network Address must be unique, the addresses selected should be reserved with the Network Administrator so that they are not used elsewhere on the internet.




Figure 3 - An IP Host internet with Network Addresses assigned

Assigning Individual IP Addresses

After the Network Addresses have been decided upon, individual addresses within each network should be assigned.

For the purposes of this example, Host A has previously been assigned an address of 1.0.15.12 and Host B has previously been assigned an address of 1.0.15.13. The CAP's External Interface must be assigned an individual address on Network 1.0.0.0. For this example, it is assumed that address 1.0.15.14 has been chosen.

Data Advantage can auto-configure the individual IP addresses for its Internal Network and the EDACS Network. While the defaults can be overridden by explicitly assigning individual addresses, it is simplest to let Data Advantage do the work.




Figure 4 - An IP host internet with individual addresses assigned

NOTE

If a radio's LID is changed, a new unit IP Address will be associated with the radio. If this is not desired, the mapping can be changed.

In this configuration Data Advantage and the Hosts are on the same network. In a more complex configuration, there could be multiple gateways between Data Advantage and the Hosts. In this case, additional entries need to be installed in the Data Advantage routing table to enable communication between the IP hosts and RDTs. Regardless of the configuration, the CAP's external IP Address must be a valid address on the network to which it is connected.

Assigning LIDs to IP Hosts

In Data Advantage there is no need to assign an EDACS address to an IP host. If the EDACS Network Layer is used, the EDACS Network Layer header includes the IP address of an IP host. If the EDACS Network Layer is not used, Data Advantage obtains the IP address of the IP host using port-to-IP address mapping in the configuration file. A None-Network Layer RDT must know which port(s) to send messages to in order to reach a particular IP Host. Refer to the *Data Advantage Technical Description Manual* (see Preface) for detailed information.

Sample SYSTEM.TXT File with Network Layer RDTs

The following SYSTEM.TXT configuration file matches the example configuration if all RDTs use the network layer. Since there is no [device_config_table] specified , Data Advantage creates default entries for all LIDs from 64 to 16382. The IP address for the RDT defaults use the network ID of the defined EDACS Network, and the range of the host IDs is from 0.64 to 63.255. Data Advantage also creates default entries for all GIDs from 1 to 2047, using the same network ID, with the range of the host IDs from 64.0 to 71.255.

```
#####
# SYSTEM.TXT configuration file.
#####

[board 1]
type cap
load 01.02/loads/DACAP.SX

[board 2]
type wni
load 01.02/loads/WNI.SX

[ip]
cap_ext_address 1.0.15.14

[edacs_network]
ip_network_id 128.1.0.0
```

In the above example there is no “port_dir” command specified under the board 2. Data Advantage will default ports 0 and 1 to be Input ports and ports 2 and 3 to be Output ports. Note that if the [device_config_table] is not specified, the Data Advantage will default all RDTs to Network Layer RDTs.

Sample SYSTEM.TXT File with Non-Network Layer RDTs

In the following SYSTEM.TXT, the same IP addresses are assigned to LIDs 64 - 16382, except that all RDTs are without Network Layer. In addition, there are four port commands that associate ports 0 and 1 to Host A, and ports 2 and 3 to Host B. All messages received at port 0 would be forwarded to Host A if the originating RDT does not have the EDACS Network Layer. The *Data Advantage Configuration Reference Manual* (See Preface) contains a detailed explanation of each command.

```
#####
# SYSTEM.TXT configuration file.
#####

[board 1]
type cap
load 01.02/loads/DACAP.SX

[board 2]
type wni
load 01.02/loads/WNI.SX
port_dir 0 in
port_dir 1 in
port_dir 2 bi
port_dir 3 bi

[ip]
cap_ext_address 1.0.15.14

[edcas_network]
ip_network_id 128.1.0.0

[device_config_table]
rdt 64 - 16382 128.1.0.64 FALSE
port 0          1.0.15.12
port 1          1.0.15.12
port 2          1.0.15.13
port 3          1.0.15.13
```

Sample SYSTEM.TXT File with Eight Port Data Advantage

In the following SYSTEM.TXT two WNI boards are configured. This configuration supports eight ports. Note that under the heading [board 2] and [board 3] only the “type” command is specified. Data Advantage will default the application executable file to “01.02/loads/WNI.SX” and the ports 0 and 1 on each WNI to be input ports and the ports 2 and 3 on each board to be Output ports, since there are no “load” and “port_dir” command specified.

```
#####
# SYSTEM.TXT configuration file.
#####

[board 1]
type cap
load 01.02/loads/DACAP.SX

[board 2]
type wni

[board 3]
type wni

[ip]
cap_ext_address 1.0.15.14

[edcas_network]
ip_network_id 128.1.0.0

[device_config_table]
rdt 64 - 16382 128.1.0.64 FALSE
port 0          1.0.15.12
port 1          1.0.15.12
port 2          1.0.15.13
port 3          1.0.15.13
```

Sample SYSTEM.TXT File with commands under [system] heading

In the following SYSTEM.TXT there are several commands under the [system] heading. A command under this heading is used to set up global system parameters. In this example the msg_timeout command has a value 100. A message can be queued in Data Advantage for as long as 100 seconds before being sent out to the RDT. The edacs_err_retries command has two parameters. The first parameter specifies the number of retries in case of error when sending message to a RDT. The second parameter specifies the amount of time (in tenths of a second) that Data Advantage should wait after receiving an error indication from an RF control station before attempting a retry.

```
#####
# SYSTEM.TXT configuration file.
#####

[board 1]
type cap
load 01.02/loads/DACAP.SX

[board 2]
type wni

[ip]
cap_ext_address 1.0.15.14

[system]
msg_timeout 100
edacs_err_retries 220

[edcas_network]
ip_network_id 128.1.0.0

[device_config_table]
rdt 64 - 16382 128.1.0.64 FALSE
port 0          1.0.15.12
port 1          1.0.15.12
port 2          1.0.15.13
port 3          1.0.15.13
```

INSTALLATION

DATA ADVANTAGE CONTENTS

Data Advantage is shipped with the following items:

- VME chassis containing multiple microprocessor boards on a VME bus backplane
- Eight or four (depending on configuration) Orion Mobile Radios used as RF control stations
- Four or two (depending on configuration) RF control station shelves with internal cabling
- One or two RF control station power supplies (depending on configuration)
- One or two power distribution pannels (depending on configuration)
- 69" Data Advantage cabinet
- VT100 compatible terminal with power cord
- Terminal interface cable
- RF control station data interface cables
- RF control station power cables
- AC line cord
- Antennas for RF control stations
- AC outlet strip
- Data Advantage Technical Description manual
- Data Advantage Installation and Maintenance Manual
- Data Advantage Configuration Reference Manual
- Data Advantage User's Reference Manual
- Data Advantage Loader Diskette on one 3 1/2" floppy
- Data Advantage Application Diskettes on two 3 1/2" floppies
- Data Advantage Configuration Diskette on one 3 1/2" floppy

The following items are not provided as part of Data Advantage:

- IBM compatible printer and cable (optional)
- DB15 AUI Ethernet Transceiver and cable
- Network Device Driver Software [i.e. EDACS Network Driver (END)]

INSTALLATION ORDER

The *Data Advantage Software Release Notes Manual* (AE/LZT 123 1893) contains the installation procedure. This section provides the installation steps for the Data Advantage and the Host Computers as part of that procedure. The steps documented in this section are:

1. Set up MVME147 Board
2. Set up VCOM24 Board
3. Connect the Host Computer(s).
4. Modify the Host Computers Routing.
5. Tightening Data Advantage's Password Security (Optional).
6. Connect the Diagnostic Terminal to the Data Advantage equipment.
7. Connect the printer to the Data Advantage equipment (optional).
8. Connect the VCOM24 serial ports to the RF control stations.
9. Connect the RF control stations to the power supply.
10. Customize the Data Advantage configuration.
11. Connect the Data Advantage equipment to an AC source.
12. Turn on the Data Advantage equipment and Load the Software.
13. Program the RF control stations.

MVME147 BOARD SETUP

WARNING

The Data Advantage equipment must be powered off when removing or inserting processor boards.

There are two types of processor boards installed in the Data Advantage VME chassis: MVME147 and VCOM24. There will be only one MVME147 board, located in the bottom slot (slot 1). There will be one or two VCOM24 boards, beginning at slot 3. Each of these boards requires the installation of an EPROM set and the correct jumper settings for normal operation.

Shown below are the jumper settings for the MVME147 board. The two EPROMs for this board are to be installed in U22 and U30. U1 and U15 will not have any EPROMs installed.




Figure 5 - MVME147 Board Jumper Settings, Fuses, and Sockets

- * The Spare Fuse is on the 1992 revision of the board, but not the 1988 revision. The revision date is generally on the back near the VME connectors.

VCOM24 BOARD SETUP

Shown below are the jumper settings for the VCOM24 board. The two EPROMs for this board are to be installed in U49 and U50. U54 and U55 will not have any EPROMs installed.




Figure 6 - VCOM24 Board Jumper Settings, Fuses, and Sockets

* Jumpers J21 and J23 are for sockets U54 and U55. Any settings should work. Suggested settings are shown above.

Each VCOM24 board supports four serial data communication ports. Signals for all four ports are brought to P2 at TTL levels and require off-board translation to the proper signal levels as required by the selected communication standard. For Data Advantage, the Serial Communication Interface (SCI) module board allows each VCOM24 port to be configured for EIA-232-C communication standard. The SCI-232 module boards are not directly connected to the VCOM24 board, but through a small connector board for adapting SCI boards to the VCOM24.

When communicating with an RF control station, a serial port on the VCOM24 board functions as a DTE port. The DTE/DCE option is jumper-selectable. Set the jumpers on all four SCI-232 boards for each VCOM24 board as shown below to configure the VCOM24 board's serial ports as DTE ports.




Figure 7 - Jumping SCI-232 for DTE

CONNECTING IP HOST COMPUTERS

1. Connect your Ethernet Transceiver to the Data Advantage using the DB15 AUI Ethernet port on the rear of the Data AdvantageVME Chassis.
2. Connect your Ethernet Cable to your Ethernet Transceiver.

MODIFYING THE CONFIGURATION OF HOSTS

For most computers, a routing entry must be added to instruct the host computer to use Data Advantage as the next gateway for the IP Network ID assigned to the EDACS Network. Symbolic names can also be defined as desired for the Data Advantage CAP External Address, radios, and groups. These changes will normally be made by the System Administrator of the host computer(s). The following example commands will work on most UNIX (trademark of UNIX System Laboratories, Inc.) systems. Refer to the host computer's documentation for the actual commands.

Assuming that the CAP External Address had been assigned to 1.0.15.14, the following statement could be added to the /etc/hosts file to assign a symbolic name to Data Advantage Ethernet Network Interface.

```
1.0.15.14 da_gateway
```

Assuming that the EDACS IP Network ID had been assigned to 128.1.0.0, the following statement could be added to the /etc/rc.local file to route all messages destined to radios or groups through Data Advantage.

```
route add net 128.1.0.0 da_gateway 5
```

If the customer network contains routers between the Hosts and Data Advantage, the routers and the Hosts will need updated routing information. Normally, the administrators of the customer's network are involved in planning the network and making the routing changes.

TIGHTENING THE DATA ADVANTAGE'S PASSWORD SECURITY (OPTIONAL)

Data Advantage comes with three user id's installed; "root", "user", and "guest". The passwords for these user id's are the same as the user IDs. All of the user ids and passwords are in lower case. The passwords can be changed using the "passwd" command. See the Data Advantage User's Reference Manual for more information.

CONNECTING THE DIAGNOSTIC TERMINAL

A VT100 compatible terminal with a power cord and a terminal interface cable is included with the Data Advantage equipment. To connect the terminal to the Data Advantage VME Chassis, perform the following:

1. Attach the female connector of the terminal interface cable to the **Modem** connector on the terminal (refer to the terminal user's manual for location).
2. Attach the male connector of the terminal interface cable to the **SERIAL PORT 1/CONSOLE** connector on the rear of the Data Advantage VME Chassis.
3. Turn on the power to the terminal per the instructions in the terminal's manual.
4. Verify that the terminal is in VT100 emulation mode via the setup screen. Change and save the setup if it isn't.
5. Set the tabs to a tab every eight columns via the setup screen.

CONNECTING THE PRINTER (OPTIONAL)

NOTE

A printer and printer cable are NOT included with the Data Advantage equipment.

1. Connect the female end of the printer cable to your printer.
2. Connect the male end of the cable to the **PRINTER** connector on the rear of the Data Advantage VME Chassis.
3. Turn on the printer.

CONNECTING WNI SERIAL PORTS TO THE RF CONTROL STATIONS

Each of the four serial ports on the rear panel of a VCOM24 board connects into an 8-pin connector on the rear of the RF control station shelf. Within the shelf, this connector is wired to the radio. The following figure shows the interconnections between the RF Control Stations and the VCOM24 board's serial ports. Note the numbering of the RF Control Stations and the serial ports, and connect each RF Control Station to the serial port with the same number. It is important to follow this mapping between a RF Control Station and a serial port on a particular VCOM24 board to simplify the monitoring and trouble shooting of the system.

1. Connect the DB25 connector of a data interface cable to a serial port of the VCOM24 board.
2. Connect the 8-pin connector on the other end of the data interface cable to either connector J3 or J5 on the rear of the RF control station shelf.




Figure 8 - Interconnection between RF Control Stations and VCOM24 Serial Ports

CONNECTING RF CONTROL STATIONS TO THE POWER SUPPLY

A separate power system is provided for the RF control stations that consists of one or two power supplies depending on the configuration. Each power supply (PS) is connected to a DC power distribution panel (PDP). The power supply is a rack mountable assembly each supplying four RF control stations. The DC output of the power supply is connected to a power distribution panel that provides up to seven +13.6 VDC outputs to RF control stations (only four connectors are used). On the RF control station side, the rear of the shelf has two power connectors, one for each radio.

Use the following instructions to connect the RF control stations to the power supply. Note that a power connector on the shelf should be connected to a connector on the power distribution panel with the same number to minimize the cable length.

1. Connect the connector of the PS-PDP power cable marked "PS" to the output of the power supply. Connect the connector of the power cable marked "PDP" to a connector in the power distribution panel (preferably the fifth connector).
2. Locate the power connector of the first RF control station which is on the rear of the first shelf .
3. Locate the first DC output of the power distribution panel (preferably connector 2 on the power distribution panel).
4. Attach the PDP-RF Control Station power cable to the power connector of the first RF control station.
5. Attach the other end of the power cable to the DC output of the power distribution panel located in step 3.
6. Repeat the step 2 through 5 for other three RF control stations.
7. If it is a eight-port Data Advantage, repeat the steps 1 - 6 for the second group of RF control stations.




Figure 9 - Power Cabling of RF Control Stations

CUSTOMIZING THE DATA ADVANTAGE CONFIGURATION

NOTE

Diskettes must be Double Sided High Density (1.44MB).

1. Copy the files on the Configuration diskette to a working diskette using a MS-DOS PC.
2. Edit the SYSTEM.TXT configuration file to customize it using information gathered during network planning.

Security can be increased by setting the maximum number of Telnet and FTP sessions to 0. This disables Telnet and FTP sessions into the Data Advantage equipment.
3. Verify your configuration when done by entering "syscheck" at the DOS prompt, while on the working diskette.

Refer to the *Data Advantage Configuration Reference Manual* for more information.

CONNECTING TO AN AC SOURCE

The AC power strip is mounted in the bottom of the Data Advantage cabinet. The AC line cord goes out from the cabinet through a hole in the bottom rear of the cabinet . It must be connected to a 120 V, 60 Hz source.

1. Make sure that the power switches on the VME chassis and the RF Control Station power supplies are in the OFF position.
2. Plug the AC power cable for the cabinet fan into one outlet on the AC power strip.
3. Plug the AC power cable for each RF Control Station power supply into an outlet on the AC power strip.
4. Plug the AC power cable for the VME chassis into one outlet on the AC power strip.
5. Plug the AC line cord for the cabinet into the 120 V, 60 Hz source.

TURNING ON THE DATA ADVANTAGE EQUIPMENT AND LOADING THE SOFTWARE AND CONFIGURATION

To turn on the Data Advantage equipment and load the software and configuration perform the following steps:

1. If the software has not been loaded previously, insert the Loader diskette into the floppy drive. If the software has been previously loaded but the configuration hasn't, insert your configuration working diskette.
2. Turn on the power of the VME computer using the power switch on the rear of the VME chassis. If the power switch for the VME computer is already on, reset Data Advantage by pressing the RESET button on the front of the CAP board.
3. If Data Advantage is turned on (or reset) with a diskette inserted, it will prompt for a new diskette after it loads the current one. Each time Data Advantage prompts for a diskette, insert an Application diskette or Configuration Working diskette. When all disks have been loaded, press return with no diskette inserted.

PROGRAMMING

The Orion radios used in Data Advantage are enabled for Mobile Data in the factory. To verify that an Orion radio is Mobile Data enabled, turn on the radio by rotating the On-Off Volume knob clockwise. If "DATA ON" is displayed on the control head, the radio is Data enabled.

The parameters in the Orion radio personality need to be customized for the specific EDACS system where it is to be used. Before starting the programming of the radio, ensure that the equipment required for programming is available.

REQUIRED EQUIPMENT

The following radio programming equipment is required to modify the Personality of an RF Control Station:

- PC (IBM PC/XT/AT or any true compatible with MS-DOS version 3.0 or later with an available serial port and 640K Internal RAM) - Used to run the EDACS 3 Radio Programming Software.
- EDACS 3 Radio Programming Software (part # TQ3374, version 14 or later) - Used to program an RF Control Station.
- RS-232 Data Cable (part # 19B235027P1) - Connects the DB-25 male serial port of the PC to the Data Interface Module. If the PC uses a DB-9 male connector for the serial port, an adapter will be required.
- Data Interface Module (part # 19D438367G2) - Used to adjust logic levels between the Orion radio and the PC.
- 12 VDC Power Supply (part # 19B800850P2 for 120V, 60 Hz operation, or part # 19B800888P1 for 230V, 50 Hz operation) - Supplies power to the Data Interface Module.
- Programming Cable (part # 19B804722P1) - Connects the Data Interface Module to the Radio Shelf

PROGRAMMING STEPS

The procedure given here describes creating a new Personality, saving the Personality in a file on the PC, and writing the Personality into the Orion radio with the Radio Programming Software.

1. Load Programming Software:

- Turn on the PC and wait for it to complete its initialization.
- When the **C:>_** or **D:>_** command prompt is shown on the PC monitor, insert the EDACS 3 Radios Program Disk #1 (Version 14 or later) into the PC's A (or B) drive, type "A:" (or "B:"), press the **Enter** key, type "INSTALL", and press the **Enter** key again.
- The **Radio Programming Software Installation Procedure** screen will appear. In the highlighted **Target Drive** field, type in the letter of the PC's hard disk (usually C or D) and press the **F1** (Begin) function key.
- The PC will read the Program Disk, create a GE directory in the root directory of the hard disk, and load the programming files into this GE directory. The PC will prompt you to insert Program Disk #2 and #3 when needed. Remove the previous Program Disk, insert the next Program Disk, and press the **F1** (Begin) function key to continue the installation. The PC will prompt you when the installation is complete. Press the **Enter** key and remove the last Program Disk. If your PC's hard disk is the C drive, type "C:" and press the **Enter** key. The **C:\GE\EDACS\BIN>_** command prompt should now be shown on the PC monitor. Type in "CD\" and press the **Enter** key to return to the **C:>_** or **D:>_** command prompt.
- Copy the D192.SC file from Disk 4 of the Data Advantage Software Kit labeled "System Configuration Files" to the **C:\GE\EDACS3\MRK** directory . Without the D192.SC file in the right directory, you can not program the RF Control Stations correctly.

2. Connect Programming Equipment:

- Connect the radio programming equipment to J1/J2 on the Orion Radio Shelf as shown below.
- Move the switch for the Orion radio to be programmed to the up or “PROGRAM” position.

3. Run Programming Software:

- With the DOS command prompt C:\ or D:\ displayed on the PC monitor, type “CD \GE” and press the **Enter** key (to go to the directory named GE where the programming files are located).
- Enter “**MRK /sc D192**” to run the programming software for the RF Control Stations. You will know that the programming file is running when you see the introductory copyright screen briefly, followed by the **Current Personality** screen on the PC monitor. **Note:** The baud rate on the RDI data link between a RF Control Station and a system serial port is 19,200 bps. Without the “/sc D192” option you can not program this baud rate into the Orion radio.




Figure 10 - Programming Setup

4. Evoke Programming Mode:

- Turn the Orion radio off for one second and then back on again, using the upper left knob on the control head or by temporarily disconnecting the DC power cable on the back of the shelf. (Ignore any DSP ERR message that may briefly be displayed when the radio is turned on.)
- Make sure that **PC PROG** is displayed on the Orion radio. If not, check to make sure that the programming equipment is connected as shown in the above figure, and that the switch on the front of the radio shelf is in the up (programming) position. Then, start this step over.

5. Create new Radio Personality:

- Using the **Current Personality** screen as the starting point, press the **F4** (New) function key to bring up the **Radio Personality Screen**.
- In the **Sys Name** field, type in a name for the EDACS system. (PLANT1 is used in this manual).
- Press the **F8** (More) function key and then **F3** (Freq). Press **F3** (NewTrk) again to program the frequencies of the EDACS site used with Data Advantage. Enter all the TX frequencies used by the EDACS site (RX frequency will be automatically selected once TX frequency is entered).
- Press **F10** (Back) to exit the screen for frequency setting. Enter a filename to store the frequency set entered above (P1_FREQ is used in this manual). Press **F1** (Yes) to save the frequency set in the disk file and go back to the **Trunked Frequency Set** screen. Press **F10** (Back) to go back to the **Radio Personality** screen.
- Move the cursor under the **Freq Set** filed and type in the name of the frequency set entered in the previous step. This will link the current Radio Personality to the frequency set.
- Press **F8** (More) several times until you see the menu item Group. Press **F4** (Group), and then **F4** (New) to enter the Group Set defined for the EDACS system. At least one group set must be defined to satisfy the requirements to define the personality for the Orion radio. Enter the Group name and Group ID for all the groups (at least one) defined for the EDACS system. Press **F10** (Back), and **F1** (Yes) to save the Group set in the disk file. Press **F10** (Back) again to go back to the Radio Personality screen.
- Move the cursor under the **Group Set** filed and type in the name of the Group set entered in the previous step. This will link the current Radio Personality to the group set.
- In the **Radio Personality** screen, press **F7** (Option) to enter the **Radio Option** screen. Press **F1** (Agency) to enter the Agency definition. Enter the number of agencies and number of fleets per agency as defined in the current EDACS system. Press **F10** (Back) to go back to the **Radio Options** screen.
- In the **Radio Options** screen, press **F3** (Data) to enter the Data options. Set the data options as shown in Figure 14 Radio Data Option screen. Note that when you create the new personality the baud rate displayed in the **Radio Data Options** screen is 9600 bps. This is the default value for the baud rate. Ignore this field. Make sure that you have evoked the programming software with a special option parameter “/sc **D192**”. This option parameter will cause the programming software to overwrite whatever baud rate is in the Personality file with 19200 bps when it is writing the personality to the radio.
- Move the cursor to the **Site** field. Then type in the site ID of the EDACS system.
- Move the cursor to the **Unit** field. Then type a LID in the range from 1 to 63 that is not currently in use in the system. The LID is also called the Host ID of Data Advantage since an Orion radio in Data Advantage is a Host Radio versus a Terminal Radio which must have a LID larger than 63.
- In the **Radio Personality** screen, press **F2** (Switch) several times until you see the **Pwr Lev** Field in the **Radio Personality** screen. Move the cursor to the **Pwr Lev** field, and enter 8 to set the power level of the Transmitter to 8 Watts. This setting generates a 6-Watt power output at the N connector to the antenna on the rear of the radio shelf.

Write Personality to Radio

- Press the **F5** (Program) function key to program the Orion radio with the modified personality.
- When programming is complete, press the **F10** (Back) function key to go back to the DOS command prompt. Enter a filename to store the radio personality in a file. Make sure you see the DOS command prompt displayed on the PC monitor before proceeding.

Disconnect Programming Equipment

- Move the switch on the front of the Orion Radio Shelf to the down or “NORMAL” position.
- Disconnect the programming equipment from the Orion Radio Shelf.

Ericsson Inc.

Edit	EDACS RADIO PROGRAMMER - 3 (14.0)	TQ-3374
------	-----------------------------------	---------

Radio Personality

Sys	Name	Freq Set	Type	Site	Unit	Grp Set	Phn Set	Ind Set	FS Chan
1	PLANT1	P1_FREQ	T	4	55	TRUCK			
2									
3									
4									
5									
6									
7									
8									

Enter System Display Name

F1 Detail F2 Switch F3 Insert F4 Remove F5 Progrm F6 F7 Option F8 More F9 Help F10 Back

Press F9 for field help, Shift F9 for window help

Figure 11 - Radio Personality Screen

Ericsson Inc.

Frequency	EDACS RADIO PROGRAMMER - 3 (14.0)	TQ-3374
-----------	-----------------------------------	---------

Trunked Frequency Set
806 - 870

	Tx Freq	Rx Freq	OS		Tx Freq	Rx Freq	OS		Tx Freq	Rx Freq	OS
1	XXX.XXXX	YYY.YYYY	2	2			2	3			2
4				2	5		2	6			2
7				2	8		2	9			2
10				2	11		2	12			2
13				2	14		2	15			2
16				2	17		2	18			2
19				2	20		2	21			2
22				2	23		2	24			2
25				2							

Enter the transmit frequency for this channel

F1 F2 F3 F4 F5 Store F6 F7 Option F8 Band F9 Help F10 Back

Press F9 for field help, Shift F9 for window help

Figure 12 - Trunked Frequency Set screen

Ericsson Inc.

Groups	EDACS RADIO PROGRAMMER - 3 (14.0)	TQ-3374
--------	-----------------------------------	---------

Group Set Summary

Grp	Name	Grp ID	RX	TX	Scn	ALT	Calls	BCK	VG	Key
1			Y	Y	N	Y	Y	Y		DIS
2			Y	Y	N	Y	Y	Y		DIS
3			Y	Y	N	Y	Y	Y		DIS
4			Y	Y	N	Y	Y	Y		DIS
5			Y	Y	N	Y	Y	Y		DIS
6			Y	Y	N	Y	Y	Y		DIS
7			Y	Y	N	Y	Y	Y		DIS
8			Y	Y	N	Y	Y	Y		DIS

Enter the Group Name

F1 F2 F3 Insert F4 Remove F5 Store F6 F7 Option F8 F9 Help F10 Back

Press F9 for field help, Shift F9 for window help

Figure 13 - Group Set Screen

Ericsson Inc.

Radio Options	EDACS RADIO PROGRAMMER - 3 (14.0)	TQ-3374
---------------	-----------------------------------	---------

Radio Data Options

Data:	Enable	Port Configuration:	
Data Host Radio:	Yes	Stop bits:	1
Data Only Radio:	Yes	Bits per char:	8
PTT TX Data:	Disabled	Parity:	Even
PTT RX Data:	Disabled	Baud Rate:	
Enhanced RDI Support: Enabled			
BREN: On			

F1 F2 F3 F4 F5 F6 F7 F8 F9 Help F10 Back

Press F9 for field help, Shift F9 for window help

Figure 14 - Radio Data Option Screen

MAINTENANCE

MODIFYING PASSWORDS

Passwords can be changed by logging in and using the *passwd* command.

They can be added when logged in as root by entering the *passwd* command with the new User-id as the first parameter.

They can be deleted by coping the /etc/passwd file to diskette, using an editor on an MS-DOS PC to remove the line containing the user-id, copying the file back to the Data Advantage and rebooting the Data Advantage.

HARD DISK CLEANUP

The logs in the /activity directory should be deleted periodically to prevent the disk from filling up. The amount of data written to the log files can be reduced by limiting the types of messages logged. In most cases, information messages should be disabled unless maintenance work is being performed on the system. The command "log -m warn" will enable error and warning messages and disable informational messages. The "df" command displays the amount of free space on the hard disk.

LOADING NEW SOFTWARE RELEASES

1. Insert the Loader diskette into the floppy drive.
2. Enter "reboot -h" from the Diagnostic Terminal, press the reset button on the CAP Board, or turn on the Data Advantage VME chassis.
3. Each time Data Advantage prompts for a diskette, insert an Application diskette or Configuration Working diskette. When all disks have been loaded, press return with no diskette inserted.

NOTE

Do not press the reset button on the CAP Board while the hard disk is active. Doing so may lock up the drive, requiring power to be cycled on the Data Advantage VME Chassis.

DATA ADVANTAGE BOOT SEQUENCE

The following sequence occurs when the Data Advantage VME Chassis are booted (via power cycle, reset key, or reboot command):

Step	CAP Board	VCOM24 Board(s)
1.	Board Initializes Itself. The FAIL, STATUS, and SCON LEDs are lit for 1 second. FAIL is turned off, STATUS flickers, and RUN is lit for around 10 seconds. RUN flickers. If the hard disk has never been formatted, or has been replaced, a prompt will appear asking if a high level format should be performed. If the response is 'Y', a high level format will begin.	Board Initializes Itself. SYSFAIL and all of eight small LEDs flash on for 1 second. The RUN LED is lit and all others are turned off for around 10 seconds. The sixth LED is lit to indicate that the VCOM24 Board has posted an interrupt to the CAP Board.
2.	If present, LOADER.SX is copied from the floppy to the hard drive. The LOADER.SX from the hard drive is loaded into RAM and executed. If present, DACAP.SX and WNI.SX are copied from the floppy to the hard drive.	
3.	Board extends multiprocessor OS across all boards.	Board joins the multiprocessor OS. The small LEDs walk from 0 to 7 and back to indicate that the board will accept a download.
4.	The Loader parses the SYSTEM.TXT file for the board types and application load file pathnames. It then copies the applications to the CAP Board and VCOM24 Boards.	Board accepts download. When the download completes, the board number (2 through 3) is displayed on the small LEDs. If the board isn't configured, they sequence indefinitely.
5.	A banner is displayed on the Diagnostic Terminal. SYSTEM.TXT is parsed a second time. /cnfg/system.rpt is built with the results. Phase 1 verifies each command and its parameters. Phase 2 verifies that the commands are valid for the board type and that all required commands are present. Phase 3 supplies default values as necessary. Phase 4 does a complete check of the configuration. Phase 5 builds the internal routing tables.	Board waits for parser to complete. On configured boards, all small LEDs are lit.

Step	CAP Board	VCOM24 Board(s)
6.	Application is started on board. Board reports when it is ready.	<p>Application is started on board. If no errors, the board number is redisplayed, otherwise an error code is displayed.</p> <p>Note: The Data Advantage Parser reports three different levels of errors: (a) Warnings, (b) Errors and (c) Fatal Errors. A Warning message is generated, for example, when an obsolete command is found in the configuration file. If an Error is reported, the proper operation of the Data Advantage is not guaranteed, but the Network Interface will still be installed to provide remote access the Data Advantage. With a Fatal Error, the Network Interface can not be installed, and no remote access is possible. A fatal error occurs only in rare situation (for example, when an incorrect CAP external IP address is specified).</p> <p>Board reports when it is ready.</p>
7.	If all boards have reported that they are ready, all boards are told to start accepting data calls. If after 30 seconds, all boards haven't reported that they are ready, an error is displayed on the Diagnostic Terminal and written into the Activity Log.	Boards starts accepting data calls when told to.

VCOM24 BOOT ERROR CODES

If an error is detected while starting the application on the VCOM24 microprocessor board, one of the following LED patterns will be displayed on the eight small LEDs.

LEDs	Error	Severity
7 and 0	OS Clock could not be started.	Fatal
7 and 1	Memory Manager could not be initialized.	Fatal
7 and 3	Object could not be created.	Fatal
6 and 1	User Interface Gateway could not be started.	Non-fatal
6 and 3	Task could not be started.	Fatal

Fatal errors will prevent the proper operation of Data Advantage, and is usually indicative of a board hardware failure. Non-fatal errors will still allow the core Data Advantage features, such as call processing, to operate correctly. However, reduced functionality may result. For example, if the User Interface Gateway cannot be started on a VCOM24 microprocessor board, the User Interface 'network' command will not be able to obtain statistics from that board.

TROUBLESHOOTING GUIDE

WARNING

The Data Advantage VME Chassis power must be off when removing or inserting the MVME147 or VCOM24 boards.

Some of the actions below should only be performed by Ericsson Service Representatives. **If a problem can not be resolved or the corrective action involves checking Data Advantage hardware, contact your Ericsson Service Representative.**

Troubleshooting tools

When trying to correct problems, the following tools can be useful in locating problems:

- (1) System startup report in /cnfg/system.rpt file
- (2) Activity log in the /activity directory
- (3) Basic statistics in /activity statfile.txt file
- (4) Extended statistics in /activity statfile.txt file
- (5) ICMP messages

Tools	Using Tools	Useful Information
System startup report	Log into the Data Advantage command shell and view the system.rpt file in the /cnfg directory.	IP address <-> EDACS address mappings, Data Advantage Error Retry parameters, enabled features, port directions and more.
ICMP message	Use network utility “ ping ”, either as part of a TCP/IP protocol stack or stand-alone program.	Different types of ICMP error messages
Activity log	Log into the Data Advantage command shell and execute the commands: (1) “ log -m all ” for all Information, Warning and Error messages. (2) “ log -w all ” for all Warning and Error messages.	The message text, the timestamp, the name and the line number of the source programs that generate the messages.
Basic statistics	Log into the Data Advantage command shell and execute the command “ stats -b ”	The number, size, rate and direction of messages on each board of the Data Advantage.

Tools	Using Tools	Useful Information
Extended statistics	Log into the Data Advantage command shell and execute the command “ stats -e ”	<p>In addition to the information in the basic statistics:</p> <ul style="list-style-type: none"> (1) RDI port statistics for each VCOM24 serial port under the heading “Multiple Port Statistics”. (2) RDI error statistics on a per RF control station basis under the heading “WNI Extended RDI Statistics”. Note this section only displays information when at least one RF control station connected to a VCOM24 board has registered at least one RDI error code. (3) RF channel statistics for each working channel enabled for data.

RF Control Station Statistics

Two sections in the Extended Statistics with the heading “WNI Extended RDI Statistics” and “WNI Channel Statistics” are of special interest because they provide valuable information on each individual RF control station and each EDACS RF channel enabled for data. The statistics counts are maintained by each RF control station, and can be collected per user request through the Data Advantage user interface. Because the error text in these two sections originate from the RF control station software, they can be difficult for the normal user to understand. This section gives a explanation of the most frequently occurred error codes.

Error Text	Explanation
Retry Limit. No assignment.	TX Radio can not get the working channel assignment. The TX is aborted.
No initial sync on data channel.	<ul style="list-style-type: none"> • TX radio got working channel assignment. It also detected the barker, but it fails to receive a correct “Data Block” message to get synchronized on the working channel. • The RX radio that has not yet received any data burst times out while looking for a “Data Block” message on the assigned working channel.
No sync on data channel.	<ul style="list-style-type: none"> • TX radio first times out while waiting for ACKMAP and then fails to get re-synchronized on the working channel. • A RX radio has sent a final ACK, but times out while looking for a Data Burst Message.
No response from host.	<ul style="list-style-type: none"> • TX times out three times waiting for a ACKMAP from the receiving mobile, it drops the data call.
Group call failed.	<ul style="list-style-type: none"> • TX radio has transmitted all the data bursts of a group data call, but can not receive a “Special Drop” message from the site. The TX radio aborts the data call by sending the Data Advantage an abort (ACKA). • A RX radio fails to get a data burst for a group data call.
DOM call time out.	<ul style="list-style-type: none"> • TX radio times out, the 7 seconds timer on the working channel has expired.
Received Drop message in RX or TX mode.	<ul style="list-style-type: none"> • A TX / RX radio receives a “Drop” message from the site while transmitting or receiving.
Special Drop. Not all data transmitted.	<ul style="list-style-type: none"> • A RX radio receives channel assignment and tries to get synchronized on the working channel. But instead of a “Data Block” message, a “Special Drop” is received on the working channel. The RX radio aborts the call.
Bad Packets	<ul style="list-style-type: none"> • Each time a radio receives a data packet with incorrect CRC, it increments this count for the RF channel being used. If a channel has a excessive number of bad packets, the RF channel may not be set up properly (for example, the antenna is not connected properly).
Abort Count	<ul style="list-style-type: none"> • Number of data calls dropped on a particular working channel due to some abnormal condition.
No Fault Receive	<ul style="list-style-type: none"> • Number of packets correctly received on a particular RF channel.

System Startup

Problem	Corrective Actions
A board fails to power up	<ol style="list-style-type: none"> 1. Verify that power supply is plugged into a live source. 2. Verify that all of the boards are fully inserted. 3. Verify that the voltage levels at the back of the Data Advantage are correct. This should only be checked by qualified personnel. If they are not correct, replace the power supply. 4. Verify that boards contain the correct ROMs and that the ROMs are inserted correctly. If a ROM is upside down and power is applied, it should be replaced. 5. Replace the board. 6. Replace Data Advantage Chassis.
FAIL, SYSFAIL, or HALT LED(s) are on.	<ol style="list-style-type: none"> 1. Verify that the software on the hard drive is compatible with the ROMs. 2. Verify that boards contain the correct ROMs and that they are inserted correctly. If the ROMs are upside down and power is applied, they should be replaced. 3. Verify that the boards are jumpered correctly. 4. Verify that the boards are fully inserted. 5. Replace the board. 6. Replace Data Advantage Chassis.
CAP doesn't know sideboards exist.	<ol style="list-style-type: none"> 1. Check the slot 2 jumper on the back of the backplane. 2. Replace the boards. 3. Replace Data Advantage Chassis.
Software Load Fails	<ol style="list-style-type: none"> 1. Use the <i>df</i> command to determine if there is any space on the hard drive. Delete files if necessary. If activity files are the problem, set the reporting level to <i>Warning</i> using the <i>log</i> command (<i>log -m warn</i>). 2. Try a different floppy disk. 3. Replace the floppy drive. 4. Replace the hard drive.
Data Advantage Fails to successfully boot	<ol style="list-style-type: none"> 1. Check /cnfg/system.rpt for problem parsing SYSTEM.TXT. 2. Check Diagnostic Terminal for problem with LOADER.SX. Reload from floppy if necessary. 3. Check Diagnostic Terminal for problem accessing hard drive. Power cycle Data Advantage if access light stays on (RESET may have been pressed while the disk was active). 4. Check Diagnostic Terminal for other problems and attempt to correct.

(continued)

Problem	Corrective Actions
Data Advantage reboots itself	<ol style="list-style-type: none"> 1. Check /activity/fatal.log for sideboard that requested the reboot. Swap out the board and see if that corrects the problem. Note: The Data Advantage is not able to reboot itself for CAP problems and some types of sideboard problems. 2. Replace the boards. 3. Replace Data Advantage chassis. 4. Replace the power supply in the VME chassis.
Data Advantage Fails System Startup	<ol style="list-style-type: none"> 1. Verify that Data Advantage booted successfully (see above).
Diagnostic Terminal Fails to respond.	<ol style="list-style-type: none"> 1. Verify that the terminal isn't in block mode. If it is, press the block mode key again. 2. Check Terminal power and cable to Data Advantage. 3. Check Terminal fuse (if present). 4. Verify that Data Advantage is operational. 5. Restore factory setup, change emulation to VT100, and set tabs to every 8 columns. 6. Replace the Terminal.
Diagnostic Terminal display doesn't line up correctly.	<ol style="list-style-type: none"> 1. Set tabs to every 8 columns. 2. Restore factory setup, change emulation to VT100, and set tabs to every 8 columns. 3. Replace the Terminal.
Printer doesn't work.	<ol style="list-style-type: none"> 1. Verify that printer is on-line and has paper. 2. Check power and cable to Data Advantage. 3. Check for other alarms on printer and correct. 4. Verify that the Data Advantage is operational. 5. Replace the printer.
Telnet or FTP are not accepted	<ol style="list-style-type: none"> 1. Verify that host has the correct IP Address of the Data Advantage CAP External Address. 2. Verify that the Host and Data Advantage can reach each other by using "ping" or equivalent. 3. Verify both the Data Advantage's and host's network connections. 4. Verify that both the Data Advantage and host are operational. 5. Verify that the Max Telnet or FTP sessions is greater than 0 on the Data Advantage.
Login not accepted.	<ol style="list-style-type: none"> 1. Verify spelling and case of login name and password. 2. Verify that login name is still valid in /etc/passwd.

Network Connections

Problem	Corrective Actions
IP host can not reach Data Advantage	<ol style="list-style-type: none"> Verify that the Yellow Ethernet LED is lit on the 714 module. If it isn't check the fuse on the CAP Board. Verify that the Data Advantage is physically connected to the LAN network. Verify that the host and the Data Advantage CAP external network interface are on the same subnet. If the host and the Data Advantage are not on the same subnet, verify that the host has a route entry specifying a gateway to the Data Advantage.
IP host can reach the CAP board , but not the WNI board(s).	<ol style="list-style-type: none"> Verify that the host has a route entry which specifies the CAP external IP address as the next gateway to the Internal Network of the Data Advantage. Verify that the Backplane Network Interface of the Data Advantage is enabled.
IP host can reach both the CAP and the WNI board, but not the radios on the EDACS network.	<ol style="list-style-type: none"> Verify that the host has a route entry which specifies the CAP external IP address as the next gateway to the EDACS network. Verify that the mapping between the LID and the IP address of the destination radio is correct.
RDT can not reach the IP host.	<ol style="list-style-type: none"> Verify that the IP host and the Data Advantage are on the same subnet. If the IP host and the Data Advantage are not on the same subnet, verify that the Data Advantage has a route entry which specifies a next gateway to the IP host. If this is not the case, add the route entry to the Data Advantage (use "route add" command or add an entry to the External Routing Table in the SYSTEM.TXT). If the RDT does not have a Network Layer, verify that there is a mapping between a Data Advantage port and the IP address of the host in the SYSTEM.TXT.

RF Control Stations

Problem	Corrective Actions
RF control stations do not transmit (no “TX DATA” display).	<ol style="list-style-type: none"> 1. Verify that the RF control stations are feature encrypted (when turning on the power of the RF control station, the control head should display “DATA ON”). 2. Verify that the RF control stations are physically connected to a Data Advantage port. 3. Verify that the jumpers of the SCI-232 modules are set as DTE. 4. Verify that the baud rate of RF control stations is programmed correctly (19,200 bps). 5. Check fuse 3 on VCOM24 Board(s). 6. Verify that RF power supply is working. 7. Verify that the RF control station is not in programming mode. Ensure that the toggle switch on the front of the RF control station shelf is in “Normal” position.
RF control stations can not transmit data to radio, but the “TX DATA” on the RF control station is displayed. This problem occurs even if there is no other traffic on the EDACS site.	<ol style="list-style-type: none"> 1. Verify that the destination radio is locked onto the same site as the RF control stations. 2. Verify that the LID programmed into the RF control station is correct. A LID of RF control station is programmed correctly if (a) the radio is programmed as Data Host and (b) the LID is in the range (1 - 63). 3. Verify that the antenna system of both the radios and the site is set up properly. Check the RF channel statistics. If there is a channel with excessive number of “Bad Packets” then the RF system on that channel is not set up properly. 4. Verify that the destination radio is in the RF coverage area, and the signaling environment is acceptable.
Radio is transmitting, but no RF control station receives the call. There is no “RX DATA” display on the RF control station.	<ol style="list-style-type: none"> 1. Verify that radio is sending the data call to one of the LIDs assigned to RF control stations. 2. Verify that the LIDs programmed into the RF control stations are correct. A correct LID of RF control station must satisfy two conditions: (a) the radio is programmed as Data Host, and (b) the LID is in the range 1-63. 3. Verify that the radio and the RF control station are locked onto the same EDACS site. 4. Verify that the RF control stations are feature encrypted. When turning on the power of the RF control station, the control head should display “DATA ON”. 5. Verify that the RF control station is not in programming mode. 6. Verify that the transmitter power levels of the RF control stations are set correctly.
Radio is transmitting and the RF control station displays “RX DATA”, but the Data Advantage fails to receive data.	<ol style="list-style-type: none"> 1. Verify that the BREN Anti-Biasing in both the RDT and the RF control station is enabled. Check the personality of both the radio and the RF control station. 2. Verify that the baud rate of RF control station is programmed correctly (19,200 bps). 3. Verify that the RF signaling environment is acceptable.

Radios / RDTs

Problem	Corrective Actions
RDT does not receive data calls correctly.	<ol style="list-style-type: none"> 1. Verify that RDT is on and executing the correct application software. 2. Cycle power on the radio and RDT. 3. Verify that both the Data Advantage and the RDT are or aren't using the EDACS Network Layer. 4. Verify that the RF control stations and RDIs are using the same setting for BREN Anti-Biasing.
Radio fails to go to a working channel to receive a Group Data Call	<ol style="list-style-type: none"> 1. Verify that the data group has been programmed into the radio (using the RDI interface). 2. Verify that the group is either forced at the site or that at least one radio has logged in with the same voice group. 3. Check mic. Some radios display 'nd' or 'no data' when mic is connected or when it is off the hook, preventing data calls. 4. Verify that the radio supports Group Data Calls.

Excessive Error Rate

Problem	Corrective Actions
Excessive Error Rate	<ol style="list-style-type: none"> 1. Verify that both the radio and RF control stations are under RF coverage area and are not being interfered with. 2. Verify that the channels are tuned correctly and that the antenna system is connected properly. 3. Attempt to isolate the problem to a channel on the EDACS system. 4. If the excessive error rate is caused by “system busy” condition on the EDACS system, reduce the traffic of simultaneous data calls when possible, or to add more data-enabled RF channels. 5. Enable BREN, both in the radio and RF control station. 6. Verify that the SYSTEM.TXT Msg_Timeout value is long enough. 7. Verify that the SYSTEM.TXT Max_Msgs value is set high enough. 8. A major cause of excessive error rate is collision. In this case, reduce the amount of the simultaneous two-way data calls when possible, or to partition the Data Advantage ports into output and input ports. The radios send data calls only through the input ports, and Data Advantage forwards data calls only through the output ports. The direction of the Data Advantage ports is configurable in the SYSTEM.TXT file. 9. Increase the number of retries, either in the radio or the Data Advantage. On the RDT, change the number of ACKARetry command in the protocol.ini file. In Data Advantage, increase the number of EDACS_Err_Retry in the SYSTEM.TXT. 10. Change the delay of the retries, either in the radio or the Data Advantage . On the RDT, change the number of ticks for ACKA delay in the protocol.ini file. On the Data Advantage side, change the second parameter of the EDACS_Err_Retry command. 11. If Data Advantage has memory congestion, reduce the Max_Msgs and / or the Msg_Timeout in the SYSTEM.TXT. 12. Verify that the RF control stations are programmed as Data Only radios. This will prevent RF control stations from receiving voice calls.

ICMP MESSAGES RETURNED BY DATA ADVANTAGE

ICMP TYPE	ICMP Code	Reason
Echo Reply	N/A	Echo Request received
Destination Unreachable	Network Unreachable	1. No message can reach any radio on the EDACS network. See the activity log for more information.
Destination Unreachable	Host Unreachable	1. A message to a specific radio failed. See the activity log for more information.
Destination Unreachable	Protocol Unreachable	1. Attempt to send an ICMP message other than an Echo Request to an RDT.
Destination Unreachable	Fragmentation Needed and DF set	1. Message exceeds 512 bytes.
Source Quench	N/A	1. Maximum Number of messages exceeded on a WNI board. 2. All channels on a Site are busy (4 attempts/msg). 3. An Data Advantage board is out of memory. 4. Message rate too high for CAP.
Time Exceeded for a Datagram	Fragment reassembly time exceeded	1. Maximum message time-out exceeded for a message.
Timestamp Reply	N/A	1. Timestamp Request received.
Information Reply	N/A	1. Information Request received.
Address Mask Reply	N/A	1. Address Mask Request received.

FORCING A HARD DISK REFORMAT

The Data Advantage VME Chassis will only reformat the Hard Drive if it detects a problem. This procedure can be used to force Data Advantage to reformat its Hard Drive.

1. Verify that the Data Advantage Installation disks are available. If they aren't, copy the files /LOADER.SX, /loads/DACAP.SX and /loads/WNI.SX to three floppies. The Data Advantage User's Manual contains the commands used to copy files to the floppy.
2. Verify that the current SYSTEM.TXT file is available on floppy. If it isn't, copy the file /cfg/SYSTEM.TXT to a floppy.
3. Save other files such as /etc/passwd and activity logs to floppies as desired.
4. Login and remove the LOADER.SX file by entering "rm LOADER.SX".
5. Reboot the Data Advantage. The reboot will fail and ask if you want to attempt to reboot again. Enter "n" to bring up the diagnostic shell.
6. Enter "format". It will warn that the command will destroy all data on the hard drive twice. Enter "y" to continue each time. It will ask if a low level format should be performed. Enter "n".
7. When the prompt returns, insert the Loader Disk into the floppy drive and reboot the Data Advantage VME Chassis. Reload the SX files and the SYSTEM.TXT file as prompted.
8. After the Data Advantage VME Chassis have finished rebooting, restore other files as desired. The default root, user, and guest passwords must be used until the /etc/passwd file is restored.

FUSES

This section is for Ericsson Service Personnel only.

The Data Advantage VME Chassis contain several fuses. It is extremely rare for one of the fuses to need replacement under normal circumstances. The Trouble Shooting section indicates when to check the fuses. This section provides detailed information about the fuses.

CAP Board Fuse

Fuse Info: A 1 Amp fuse is located in the middle of the CAP Board, near the VME bus connectors. The 1992 boards contain a spare in the upper right corner. See the Board Hardware Section for picture of location.

Purpose: Protects +12V supply to Ethernet Interface.

Indications of Bad Fuse: IP Interface doesn't work. Yellow Ethernet LED on Transition Module isn't lit.

Possible Causes of Burn out. Lightning, power surges, bad CAP board, bad Data Advantage power supply, bad Transition Module, bad Adapter Board.

SCSI Fuse

Fuse Info: A 1 Amp fuse is located on the Adapter Board on the back of the VME backplane behind the CAP Board. The fuse is located near pin 1 of the J1 ribbon cable connector.

Purpose: Protects +5V supply to SCSI Terminator Logic.

Indications of Bad Fuse: Data Advantage can't access the hard disk on boot up, attempts to reformat the disk fail. Green SCSI Terminator LED on Transition Module isn't lit.

Possible Causes of Burn out. VMEAdapt boards not plugged in. Bad hard drive, floppy, Adapter Board, CAP, or Transition Module.

VCOM24 Fuses

Fuse Info:

Three 3 Amp fuses are located in the middle of the VCOM24 Board, near the VME bus connectors. See the Board Hardware Section for picture of locations. The fuses protect the voltages that the VCOM24 board supplies the VMEAdapt card via the P2 (bottom) VME bus connector. The pins are in 3 columns (A - C from the left) and 32 rows (row 1 is at the top).

Fuse 1 is on the +5V supply. It goes out on pin 1A. The VMEAdapt also gets unfused +5V from other pins on the connector. This fuse is available as a spare.

Fuse 2 is on the -12V supply. It goes out on pin 23C.

Fuse 3 is on the +12V supply. It goes out on pin 8C.

Purpose:

Protects the -12V and +12V supplies to the VMEAdapt and SCI-232 Modules.

Indications of Bad Fuse:

Fuse 2: Calls fail due to “Too Many Write Retries” and the 5th LED on each modem stays on.

Fuse 3: Calls fail due to “Port Open Failed”.

Possible Causes of Burn out.

Bad Data Advantage hardware. Perform the following steps to isolate the problem.

1. Verify that the pin in the P2 connector isn't grounded.
Turn the power off and remove the VCOM24 board. Insert a wire into the P2 connector pin on the backplane that corresponds to the blown fuse.
Verify that the connector pin in the backplane isn't grounded. Both pins 23C and 8C should read open. If the connector pin is grounded, go to step 2a. If it isn't go to step 2b.
- 2a. If the P2 pin location is grounded, check the check the SCI-232.
There are 4 SCI-232 modules on each SCI-232 card on the back of the chassis. Label and remove the ribbon cables from the 4 SCI-232 modules that connect to the corresponding VMEAdapt board. Check the P2 connector as in step 1. If the connector is now OK, replace the SCI-232 card.
- 3a. If the P2 pin is still grounded, check the chassis and the VMEAdapt Board.
Remove the VMEAdapt module from the back of the backplane. Check the P2 pin as in step 1. If the P2 pin is still grounded, replace the chassis. Otherwise replace the VMEAdapt Board.
- 2b. If the P2 pin isn't grounded, check the power to the chassis.
Turn the power back on and verify that the voltage levels at the back of the Data Advantage VME Chassis are correct. If they are not correct, check for loose wiring connections. If none are found, contact Technico for further instructions.

- 3b. If the voltage levels are correct at the chassis, check the fuse and VCOM24 board. Turn the power off while replacing components.

Replace the fuse (see the parts list), and reinsert the VCOM24 board . If the fuse still blows, replace the VCOM24 board. If the fuse still blows, contact Technico.

PIN OUT FOR THE DIAGNOSTIC TERMINAL CABLE

The following diagram shows the minimum number of pin connections required in the Diagnostic Terminal cable. If DTR handshaking is to be used, pin 20 must also be connected.

Description	Terminal	Data Advantage
Shield Ground	1	1
Terminal TX Data	2	2
Terminal RX Data	3	3
Signal Ground	7	7
DTR (optional)	20	20

PIN OUT FOR DATA INTERFACE CABLE

The following pin out should be used for the Serial Link Cable between a WNI port and a J3/J5 connector on the rear of the RF Control Station Shelf. Note that the pin function is from the perspective of the WNI serial port.

Description	WNI Serial Port	J3/J5 Connector of Radio Shelf
WNI TX Data	2	2
WNI RX Data	3	3
RTS	4	4
CTS	5	5
Signal Ground	7	7

PIN OUT FOR RADIO SHELF HARNESS / DATA INTERFACE

The following table shows the pin out of the radio shelf harness that connects the J3/J5 connector and the P1 connector of Orion radio. Note that the pin function is from the perspective of the Orion P1 connector.

Description	P1 Connector of Orion Radio	J3/J5 Connector of Radio Shelf
DATA IN	2	2
DATA OUT	3	3
RTS	6	4
CTS	20	5
Signal Ground	7	7

PIN OUT FOR THE PROGRAMMING CABLE

The following table shows the pin out of the Orion Host Radio Programming Cable between the DB25 connector of Data Interface Module (19D438367G2) and the J1/J2 connector on the front of an RF Control Station Shelf. Note that the pin function is from the perspective of the J1/J2 connector.

Description	J1/J2 Connector of Radio Shelf	DB25 Connector Data Interface Module Side
DATA OUT	3	12
DATA IN	2	11
RTS	5	10
CTS	4	9
FLASH PROG	6	5
GND	7	13
SW A+	8	6

PIN OUT FOR RADIO SHELF HARNESS / RADIO PROGRAMMING

The following table shows the pin out of the RF Control Station cable harness that connects the P1 connector of Orion radio and the J3/J5 connector on the radio shelf. Note that the pin function is from the perspective of the P1 connector of Orion radio.

Description	P1 Connector of Orion Radio	J1/J2 Connector of Radio Shelf
DATA OUT	3	3
DATA IN	2	2
RTS	6	5
CTS	20	4
FLASH PROG	8	6
GND	7	7
SW A+	25	8

Ericsson Inc.
Private Radio Systems
Mountain View Road
Lynchburg, Virginia 24502
1-800-592-7711 (Outside USA, 804-592-7711)

Printed in U.S.A.