

# NUCLEUS™ PAGING STATION QUICK REFERENCE MENU GUIDE

## STN - STATION

TX FREQ RANGE (read-only)  
CURRENT TX CHN \*

1 thru  
32

ALIGN 1 VCO \*\*

ALIGN 4 DELAY \*\*

SYS TIMER ALARM \*

DISABLE

2 MIN

15 MIN

30 MIN

60 MIN

90 MIN

120 MIN

180 MIN

FRONT PANEL PASSWORD \*

ENABLED

DISABLED

PASSWORD (DEFAULT = 6000)

SET STATION TIME

YEAR

MONTH

DAY

HOUR

MINUTE

SECONDS

## RX - RECEIVER

LINK/MONITOR RECEIVER

RX FREQ RANGE (read-only)

RX CHN FREQ

CHN SPACING \*

12.5 KHZ

20 KHZ

25 KHZ

RX DEEMPHASIS \*

ENABLED

DISABLED

RX OUTPUT \*

NOT INVERTED

INVERTED

MONITOR RX OUTPUT \*

ANALOG

TTL CNET

FM CUBED SATELLITE RECEIVER

RX UNIT ADDRESS (read-only)

NETOP ID (read-only)

GROUP ADDRESS

L-BAND FREQ

LNB POWER SUPPLY \*

DISABLED

ENABLED

INTERFACE PROTOCOL \*

RS232

RS485

RS232 AND RS485

INTERFACE SPEED (read-only)

FEC SETUP \*

DISABLED

ENABLED

ANT ALIGN TONE

DISABLED

ENABLED

## TX - TRANSMIT

TX CHN FRECS

CHN 1 FREQ

thru

CHN 32 FREQ

MEAN FREQ

TX CHN PWR (if CHN MAPPED PWR disabled)

OPERATING PWR

TX CHN PWR (if CHN MAPPED PWR enabled)

CHN 1 PWR

thru

CHN n PWR (if CHN n FREQ ≠ 0)

MEAN FREQ PWR

TX CHN OFFSETS

HIGH SPEED OFFSET

LOW SPEED OFFSET

88 US LOW PASS

140 US LOW PASS

250 US LOW PASS

NOMINAL BINARY DEVIATION

SPECIAL TX SETUP

TX DATA INVERT \*

ENABLED

DISABLED

TX = RX \*

ENABLED

DISABLED

TX = RX CHANNEL \*

1 thru

32

IDLE DEVIATION \*

NULL

SPACE

MARK

## ASET - ALARM SETUP

if CHN MAPPED PWR disabled:

NON - CHAN MAPPED PWR ALARMS

FWD PWR ALM PT

RFL PWR ALM PT

EXT WM FWD PWR ALM PT

EXT WM RFL PWR ALM PT

if CHN MAPPED PWR enabled:

INT FWD CHN MAPPED ALMS

CHN 1 FWD ALM PT

thru

CHN 32 FWD ALM PT

INT RFL CHN MAPPED ALMS

CHN 1 RFL ALM PT

thru

CHN 32 RFL ALM PT

EXT FWD CHN MAPPED ALMS (if EXT WATTMETER TYPE ≠ NONE)

CHN 1 EXT FWD ALM PT

thru

CHN 32 EXT FWD ALM PT

EXT RFL CHN MAPPED ALMS (if EXT WATTMETER TYPE ≠ NONE)

CHN 1 EXT RFL ALM PT

thru

CHN 32 EXT RFL ALM PT

## OPT 1 - STATION OPTIONS 1 STAT - STATION STATUS

ANTENNA RELAY \*

DISABLED

ENABLED

EXT CIRCULATOR \*

NOT PRESENT

PRESENT

CHN MAPPED PWR \*

DISABLED

ENABLED

FWD PWR

REL PWR

VSWR

EXT WM FWD PWR

EXT WM RFL PWR

EXT WM VSWR

SOFTWARE VERSIONS

APPLICATION

EXCITER

BOOT

INTERNAL FM CUBED\* RX (read-only)

ALIGNMENT ID

SCM (read-only)

EXCITER (read-only)

## CNFG - STATION CONFIGURATION

MAX PWR (read only)

NO PA

25 W

100 W

125 W

300 W

350 W

BATTERY REVERT SETUP

BATTERY TYPE \*

VENTED LEAD CALCIUM

SEALED LEAD CALCIUM

NICAD

GENERIC

BATTERY REVERT DISABLED

CHARGING \*

ENABLED

DISABLED

BACKUP \*

BACKUP STATION

BACKUP CONTROL

FIXED CUTBK RED %

EXT WATTMETER TYPE \*

NONE

CLASS 1 EXT

CLASS 2 EXT

CLASS 3 EXT

CLASS 4 EXT

CONTROL \*

INTERNAL CNET

EXT SYNCH LOCAL CTRL

RX TYPE \*

NO INTERNAL

INTERNAL LINK

INTERNAL MONITOR

INTERNAL SAT RX TYPE \*

NONE

FM CUBED\*

SPECIAL KEY SELECT \*

NONE

CD INT

CD EXT

SPCL KEY

FAST LOW

FAST HIGH

EXT LOW

EXT HIGH

## ALMS - STATION ALARMS

LOW FORWARD POWER

HIGH REFLECTED POWER

EXT LOW FORWARD POWER

EXT HIGH REFLECTED POWER

REDUNDANCY SWITCHOVER

PA FAN

SYNTH OUT OF LOCK

BATTERY REVERT

SYS TIMER EXPIRED

PA FAIL

STATION RESET

HIGH STABILITY REF FAIL

ALIGNMENT ID MISMATCHED

INT SAT RX FAIL

INT SAT RX NO CD

INT SAT RX NOT AUTH

INT SAT RX LNB FAIL

## SERV - SERVICE MODE

PA TEST MODE \*

ACTIVE

INACTIVE

SELECT SYMBOL \*

STAIRCASE

01-10

00-11

10

11

01

00

CARRIER

KEY ON SYMBOL

## DIS - ACCESS DISABLE

MAINT ACCESS

DISABLED

ENABLED

PAGING ACCESS

DISABLED

ENABLED

DISABLE STATUS (read-only)

DISABLE\_1

thru

DISABLE\_n

## ALGN - STATION ALIGNMENT

CAL STATION POWER

INITIALIZE CALIBRATION

INPUT MEASURED PWR

CALIBRATE \*\*\*

INPUT MEASURED PWR

CAL EXT WM

ALIGN UHSO

KEY START

START

KEY AND READ POWER

KEY AND READ EXT WM POWER

## RESET - RESET STATION

PRESS BUTTONS 1 & 3 SIMULTANEOUSLY

\* Select one of the following  
\*\* Alignment channels are displayed in the STN menu but are automatically selected during alignment procedures from the ALGN menu. Do not attempt to select them from the STN menu.  
\*\*\* For factory use only

### STN - STATION

TX FREQ RANGE (read-only)  
CURRENT TX CHN \*

1 thru  
32

ALIGN 1 VCO \*\*

ALIGN 6 VCO\*\*

ALIGN 1 DELAY\*\*

ALIGN 4 DELAY \*\*

SYS TIMER ALRM \*  
DISABLE

2 MIN  
15 MIN  
30 MIN  
60 MIN  
90 MIN  
120 MIN  
180 MIN

FRONT PANEL PASSWORD \*

ENABLED  
DISABLED

PASSWORD (DEFAULT = 6000)  
SET STATION TIME

YEAR  
MONTH  
DAY  
HOUR  
MINUTE  
SECONDS

### RX - RECEIVER

LINK/MONITOR RECEIVER  
RX FREQ RANGE (read-only)

RX CHN FREQ

CHN SPACING \*  
12.5 KHZ  
20 KHZ  
25 KHZ

RX DEEMPHASIS \*  
ENABLED  
DISABLED

RX OUTPUT \*  
INVERTED  
NOT INVERTED

MONITOR RX OUTPUT \*  
ANALOG  
TTL CNET

### TX - TRANSMIT

TX CHN FREQS  
CHN 1 FREQ

CHN 32 FREQ  
MEAN FREQ

TX CHN PWR (if CHN MAPPED PWR disabled)

OPERATING PWR  
TX CHN PWR (if CHN MAPPED PWR enabled)

CHN 1 PWR  
CHN n PWR (if CHN n FREQ ≠ 0)

MEAN FREQ PWR  
TX CHN OFFSETS

LOW SPEED OFFSET  
LOW SPEED SPLITTER FILTER \*

88 US LOW PASS  
140 US LOW PASS  
250 US LOW PASS  
180 US LOW PASS

HIGH SPEED SPLITTER FILTER \*

88 US LOW PASS  
180 US LOW PASS

NOMINAL BINARY DEVIATION  
SPECIAL TX SETUP

TX DATA INVERT \*  
ENABLED  
DISABLED

TX = RX \*  
ENABLED  
DISABLED

TX = RX CHANNEL \*  
1  
32

IDLE DEVIATION \*  
NULL  
SPACE  
MARK

### ASET - ALARM SETUP

if CHN MAPPED PWR disabled:  
NON-CHAN MAPPED PWR ALARMS

FWD PWR ALM PT  
REF PWR ALM PT

EXT WM FWD PWR ALM PT  
EXT WM REF PWR ALM PT

if CHN MAPPED PWR enabled:  
INT FWD CHN MAPPED ALMS

CHN 1 FWD ALM PT  
CHN 32 FWD ALM PT

INT RFL CHN MAPPED ALMS  
CHN 1 RFL ALM PT

CHN 32 RFL ALM PT  
EXT FWD CHN MAPPED ALMS (if EXT WATTMETER TYPE ≠ NONE)

CHN 1 EXT FWD ALM PT  
CHN 32 EXT FWD ALM PT

EXT RFL CHN MAPPED ALMS (if EXT WATTMETER TYPE ≠ NONE)

CHN 1 EXT RFL ALM PT  
CHN 32 EXT RFL ALM PT

\*\*\* For factory use only

### OPT 1 - STATION OPTIONS 1 STAT - STATION STATUS

FWD PWR  
REF PWR

VSMR  
EXT WM FWD PWR

EXT WM RFL PWR  
SOFTWARE VERSIONS (read-only)

APPLICATION (read-only)  
EXCITER (read-only)

BOOT (read-only)  
ALIGNMENT ID

SCM (read-only)  
EXCITER (read-only)

### ALMS - STATION ALARMS

LOW FORWARD POWER  
HIGH REFLECTED POWER

EXT LOW FORWARD POWER  
EXT HIGH REFLECTED POWER

PA FAN  
SYNTH OUT OF LOCK

BATTERY REVERT  
SYS TIMER EXPIRED

PA FAIL  
STATION RESET

HIGH STABILITY REF FAIL  
ALIGNMENT ID MISMATCHED

### SERV - SERVICE MODE

PA TEST MODE \*  
ACTIVE  
INACTIVE

SELECT SYMBOL \*  
STAIRCASE

01-10  
00-11  
10  
11

01  
00  
CARRIER

KEY ON SYMBOL

### CNFG - STATION CONFIGURATION

MAX PWR (read only)  
NO PA

20 W  
25 W  
100 W  
125 W  
300 W  
350 W

BATTERY REVERT SETUP  
BATTERY TYPE \*

SEALED LEAD CALCIUM  
BATTERY REVERT DISABLED

CHARGING \*  
ENABLED  
DISABLED

BACKUP \*  
BACKUP STATION  
BACKUP CONTROL

FIXED CUTBK RED %  
EXT WATTMETER TYPE \*

NONE  
CLASS 1 EXT  
CLASS 2 EXT  
CLASS 3 EXT  
CLASS 4 EXT

CONTROL \*  
INTERNAL CNET  
EXT SYNCH LOCAL CTRL

RX TYPE \*  
NO INTERNAL  
INTERNAL LINK  
INTERNAL MONITOR

SPECIAL KEY SELECT \*  
NONE  
CD INT  
CD EXT

SPCL KEY  
FAST LOW  
FAST HIGH  
EXT LOW  
EXT HIGH

### DIS - ACCESS DISABLE

MAINT ACCESS  
DISABLED  
ENABLED

PAGING ACCESS  
DISABLED  
ENABLED

DISABLE STATUS (read-only)  
DISABLE\_1  
thru  
DISABLE\_n

### ALGN - STATION ALIGNMENT

CAL STATION POWER  
MANUAL PA CALIBRATION

AUTO PA ALIGNMENT  
CAL EXT WM  
ALIGN UHSO

KEY START  
START  
KEY AND READ POWER

KEY AND READ EXT WM POWER

### RESET - RESET STATION

PRESS BUTTONS 1 & 3 SIMULTANEOUSLY

\* Select one of the following  
\*\* Alignment channels are displayed in the STN menu but are automatically selected during alignment procedures from the ALGN menu. Do not attempt to select them from the STN menu.  
\*\*\* For factory use only