

RA/RT CONFIGURATION (TRC CONTROL)

For Quantar and Quantro Stations

1 OVERVIEW

The RA/RT (TRC control) configuration allows a *Quantar/Quantro* station to be TRC controlled by a remote console using either a radio link or a microwave link in place of the usual wireline link. This configuration is typically used in cases where the station is located in a relatively inaccessible location (such as a mountain top) where running phone lines is either impractical or impossible.

As shown in Figure 1A, a pair of stations (called station 1 and station 2) is used to substitute for the normal wireline connections between the repeater station and the console. Figure 1B shows a microwave RA/RT link.




Figure 1A RA/RT WITH RF LINK




Figure 1B RA/RT WITH MICROWAVE LINK

Figure 1. Typical RA/RT Systems (TRC Control)

2 ELECTRICAL CONNECTIONS (RF LINK)

Install stations 1, 2, and 3 as described in the appropriate functional base station manual. Figure 2 shows the connections between the stations necessary to allow RA/RT (TRC control) operation. Perform the following procedures to make the wiring connections between the console and Station 1 and between Stations 2 and 3.





Figure 2. RA/RT (TRC Control) Wiring Connections (RF Link)

Console to Station 1 Wiring Connections

Note Phoneline connections may be made at either the 50-pin Telco connector or the 8-position terminal connector. Refer to the **Installation** section of the appropriate station functional manual for more details on phone line connections.

- Step 1.** Connect the landline-to-station audio (from the console) to the Line 1 connections on the backplane of Station 1 as shown below.
- Step 2.** Connect the station-to-landline audio (to the console) to the Line 2 connections on the backplane of Station 1, as shown below.




Station 2 to Station 3 Wiring Connections

Note Phone line connections may be made at either the 50-pin Telco connector or the 8-position terminal connector. Refer to the **Installation** section of the appropriate station functional manual for more details on phone line connections.


Wireline Connections

- Step 1.** Connect the Line 1 audio from Station 2 to the Line 2 connections on Station 3 as shown below.
- Step 2.** Connect the Line 2 audio from Station 2 to the Line 1 connections on Station 3 as shown below.




RDSTAT to EXT PTT Connection

- Step 1.** Connect the RD STAT + and - signals from Station 3 to the EXT PTT + and - signals on Station 2 as shown below. An equivalent schematic circuit for the RD STAT and EXT PTT signals is also shown.



Note RDSTAT INT signal goes high when Station 3 detects receive signal (according to RX Activation parameter setting via RSS). This energizes relay, turns on LED in opto-coupler, and pulls EXT PTT INT low. This causes Station 2 transmitter to key up and routes Line 1 audio to the transmitter.



3 ELECTRICAL CONNECTIONS (MICROWAVE LINK)

Install the station as described in the appropriate functional base station manual. Figure 2 shows the connections between the station, microwave equipment, and console necessary to allow RA/RT (TRC control) operation. Perform the following procedures to make the wiring connections between the console and the Microwave Station 1 and between Microwave Station 2 and Station 3.




Figure 3. RA/RT (TRC Control) Wiring Connections (Microwave Link)

Console to Microwave Station 1 Wiring Connections

Note Refer to the Microwave Station manual for details of making wireline connections.

- Step 1.** Connect the landline-to-station audio (from the console) to Microwave Station 1.
- Step 2.** Connect the station-to-landline audio (to the console) to the Microwave Station.


Microwave Station 2 to Station 3 Wiring Connections

Note Refer to the Microwave Station manual for details of making wireline connections.

Note Phone line connections may be made at either the 50-pin Telco connector or the 8-position terminal connector. Refer to the **Installation** section of the appropriate station functional manual for more details on phone line connections.


Wireline Connections

- Step 1.** Connect the station-to-landline audio from Microwave Station 2 to the Line 1 connections on Station 3 as shown below.
- Step 2.** Connect the landline-to-station audio to Microwave Station 2 to the Line 2 connections on Station 3 as shown below.




RDSTAT to E-Lead Connection

- Step 1.** Connect the RD STAT + and - signals from Station 3 to the E-Lead signal on Microwave Station 2 as shown below. An equivalent schematic circuit for the RD STAT and E LEAD signals is also shown.



Note **RDSTAT INT** signal goes high when Station 3 detects receive signal (according to RX Activation parameter setting via RSS). This energizes relay and provides ground signal to **E LEAD** input on Microwave Station 2.



4 RSS PROGRAMMING

Using the *Quantar/Quantro* Radio Service Software (RSS) program, make the following codeplug data changes to allow proper RA/RT operation. (Refer to the *RSS User's Guide 68P81085E35* for details on making codeplug programming changes.)

Table 1. Codeplug Data Changes for RA/RT Operation (RF Link Configuration)

Equipment	Codeplug Data Parameter	RSS User's Guide Location
Station 1	Change command for Guard Tone from (typically) MORE to KEY . Leave all other commands empty.	Programming the TRC Commands Data (p/o Chapter 4)
	Disable TX Notch Filter	Programming the Wireline Configuration Data (p/o Chapter 4)
Station 3	Enable TX Notch Filter	Programming the Wireline Configuration Data (p/o Chapter 4)

Note — Make sure console is programmed for 240 msec HLGT. On SECURENET systems, increase to 360 msec.

Table 2. Codeplug Data Changes for RA/RT Operation (Microwave Link Configuration)

Equipment	Codeplug Data Parameter	RSS User's Guide Location
Station 3	Enable TX Notch Filter	Programming the Wireline Configuration Data (p/o Chapter 4)

Note — Make sure console is programmed for 240 msec HLGT. On SECURENET systems, increase to 360 msec.

5 TX WIRELINE ALIGNMENT

You may align the TX Wireline levels as described in the *RSS User's Guide 68P81085E35* (which requires the use of an external signal generator), or you may use the station to generate the alignment tone. This method is described as follows.

Note — Make sure the *Automatic Line Control* parameter is disabled for Stations 1, 2, and 3.

Station 1 TX Wireline Alignment

Perform standard TX Wireline alignment procedure located in *RSS User's Guide 68P81085E35*.

Station 2 TX Wireline Alignment

- Step 1.** Connect the RSS to Station 3 and access the RX Wireline Alignment screen.
- Step 2.** Set the RX wireline level and **Save** it. (Note that the wireline level is typically set to -6 dBm.)
- Step 3.** Press **F2** to turn on the 1 kHz tone. **Do not** exit this screen.
- Step 4.** With the RSS program still running, disconnect the RSS cable from Station 3 and connect it to Station 2. Now exit the RX Alignment screen.
- Step 5.** Access the TX Wireline Alignment screen and press **F8** to save the alignment value. (Station 3 is providing the 1 kHz alignment tone.)
- Step 6.** Exit the TX Wireline Alignment screen.
- Step 7.** With the RSS program still running, disconnect the RSS cable from Station 2 and connect it to Station 3.
- Step 8.** Access the RX Wireline Alignment screen and turn off the 1 kHz tone.

Station 3 TX Wireline Alignment

- Step 1.** Connect the RSS to Station 2 and access the RX Wireline Alignment screen.
- Step 2.** Set the RX wireline level and **Save** it. (Note that the wireline level is typically set to -6 dBm.)
- Step 3.** Press **F2** to turn on the 1 kHz tone. **Do not** exit this screen.
- Step 4.** With the RSS program still running, disconnect the RSS cable from Station 2 and connect it to Station 3. Now exit the RX Alignment screen.
- Step 5.** Access the TX Wireline Alignment screen and press **F8** to save the alignment value. (Station 2 is providing the 1 kHz alignment tone.)
- Step 6.** Exit the TX Wireline Alignment screen.
- Step 7.** With the RSS program still running, disconnect the RSS cable from Station 3 and connect it to Station 2.
- Step 8.** Access the RX Wireline Alignment screen and turn off the 1 kHz tone.

RA/RT CONFIGURATION (E & M KEYING)

For Quantar and Quantro Stations

1 OVERVIEW

The RA/RT (E & M keying) configuration allows a *Quantar/Quantro* station to be controlled by a remote console using either a radio link or a microwave link in place of the usual wireline link. This configuration is typically used in cases where the station is located in a relatively inaccessible location (such as a mountain top) where running phone lines is either impractical or impossible.

As shown in Figure 1A, a pair of stations (called station 1 and station 2) is used to substitute for the normal wireline connections between the repeater station and the console. Figure 1B shows a microwave RA/RT link.




Figure 1A RA/RT WITH RF LINK




Figure 1B RA/RT WITH MICROWAVE LINK

Figure 1. Typical RA/RT Systems (E & M Keying)

2 ELECTRICAL CONNECTIONS (RF LINK)

Install stations 1, 2, and 3 as described in the appropriate functional base station manual. Figure 2 shows the connections between the stations necessary to allow RA/RT (E & M keying) operation. Perform the following procedures to make the wiring connections between the console and Station 1 and between Stations 2 and 3.





Figure 2. RA/RT (E & M Keying) Wiring Connections (RF Link)

Console to Station 1 Wiring Connections

Note Phoneline connections may be made at either the 50-pin Telco connector or the 8-position terminal connector. Refer to the **Installation** section of the appropriate station functional manual for more details on phone line connections.

- Step 1.** Connect the landline-to-station audio (from the console) to the Line 1 connections on the backplane of Station 1 as shown below.
- Step 2.** Connect the station-to-landline audio (to the console) to the Line 2 connections on the backplane of Station 1, as shown below.




Station 2 to Station 3 Wiring Connections

Note Phone line connections may be made at either the 50-pin Telco connector or the 8-position terminal connector. Refer to the **Installation** section of the appropriate station functional manual for more details on phone line connections.


Wireline Connections

- Step 1.** Connect the Line 1 audio from Station 2 to the Line 2 connections on Station 3 as shown below.
- Step 2.** Connect the Line 2 audio from Station 2 to the Line 1 connections on Station 3 as shown below.




RDSTAT to EXT PTT Connection (Station 3 to Station 2)

- Step 1.** Connect the RD STAT + and - signals from Station 3 to the EXT PTT + and - signals on Station 2 as shown below. An equivalent schematic circuit for the RD STAT and EXT PTT signals is also shown.




Note RDSTAT INT signal goes high when Station 3 detects receive signal (according to RX Activation parameter setting via RSS). This energizes relay, turns on LED in opto-coupler, and pulls EXT PTT INT low. This causes Station 2 transmitter to key up and routes Line 1 audio to the transmitter.




Station 2 to Station 3 Wiring Connections (Cont'd)

RDSTAT to EXT PTT Connection (Station 2 to Station 3)

Step 1. Connect the RD STAT + and – signals from Station 2 to the EXT PTT + and – signals on Station 3 as shown below. An equivalent schematic circuit for the RD STAT and EXT PTT signals is also shown.



Note *RDSTAT INT* signal goes high when Station 2 detects receive signal (according to RX Activation parameter setting via RSS). This energizes relay, turns on LED in opto-coupler, and pulls **EXT PTT INT** low. This causes Station 3 transmitter to key up and routes Line 1 audio to the transmitter.



3 ELECTRICAL CONNECTIONS (MICROWAVE LINK)

Install the station as described in the appropriate functional base station manual. Figure 2 shows the connections between the station, microwave equipment, and console necessary to allow RA/RT (E & M keying) operation. Perform the following procedures to make the wiring connections between the console and the Microwave Station 1 and between Microwave Station 2 and Station 3.




Figure 3. RA/RT (E & M Keying) Wiring Connections (Microwave Link)

Console to Microwave Station 1 Wiring Connections

Note Refer to the Microwave Station manual for details of making wireline connections.

- Step 1.** Connect the landline-to-station audio (from the console) to Microwave Station 1.
- Step 2.** Connect the station-to-landline audio (to the console) to the Microwave Station.


Microwave Station 2 to Station 3 Wiring Connections

Note Refer to the Microwave Station manual for details of making wireline connections.

Note Phone line connections may be made at either the 50-pin Telco connector or the 8-position terminal connector. Refer to the **Installation** section of the appropriate station functional manual for more details on phone line connections.


Wireline Connections

- Step 1.** Connect the station-to-landline audio from Microwave Station 2 to the Line 1 connections on Station 3 as shown below.
- Step 2.** Connect the landline-to-station audio to Microwave Station 2 to the Line 2 connections on Station 3 as shown below.




RDSTAT to E-Lead Connection (Station 3 to Station 2)

- Step 1.** Connect the RD STAT + and - signals from Station 3 to the E-Lead signal on Microwave Station 2 as shown below. An equivalent schematic circuit for the RD STAT and E LEAD signals is also shown.



Note **RDSTAT INT** signal goes high when Station 3 detects receive signal (according to RX Activation parameter setting via RSS). This energizes relay and provides ground signal to **E LEAD** input on Microwave Station 2.




Microwave Station 2 to Station 3 Wiring Connections (Cont'd)

M-Lead to EXT PTT Connection (Station 2 to Station 3)

Step 1. Connect the M-Lead on the Microwave Station 2 to the EXT PTT + signal on Station 3 as shown below. An equivalent schematic circuit for the EXT PTT and M LEAD signals is also shown.

Note MLEAD output from Microwave Station 2 goes low when transmitting signal on wireline. This causes **EXT PTT** to activate and key Station 3 transmitter.



4 RSS PROGRAMMING

Using the *Quantar/Quantro* Radio Service Software (RSS) program, make the following codeplug data changes to allow proper RA/RT operation. (Refer to the *RSS User's Guide 68P81085E35* for details on making codeplug programming changes.)

Table 1. Codeplug Data Changes for RA/RT Operation (RF Link Configuration)

Equipment	Codeplug Data Parameter	RSS User's Guide Location
Station 1	Disable TX Notch Filter	Programming the Wireline Configuration Data (p/o Chapter 4)
Station 3	Disable TX Notch Filter	Programming the Wireline Configuration Data (p/o Chapter 4)

Table 2. Codeplug Data Changes for RA/RT Operation (Microwave Link Configuration)

Equipment	Codeplug Data Parameter	RSS User's Guide Location
Station 3	Disable TX Notch Filter	Programming the Wireline Configuration Data (p/o Chapter 4)

5 TX WIRELINE ALIGNMENT

You may align the TX Wireline levels as described in the *RSS User's Guide 68P81085E35* (which requires the use of an external signal generator), or you may use the station to generate the alignment tone. This method is described as follows.

Note — Make sure the *Automatic Line Control* parameter is disabled for Stations 1, 2, and 3.

Station 1 TX Wireline Alignment

Perform standard TX Wireline alignment procedure located in *RSS User's Guide 68P81085E35*.

Station 2 TX Wireline Alignment

- Step 1.** Connect the RSS to Station 3 and access the RX Wireline Alignment screen.
- Step 2.** Set the RX wireline level and **Save** it. (Note that the wireline level is typically set to -6 dBm.)
- Step 3.** Press **F2** to turn on the 1 kHz tone. **Do not** exit this screen.
- Step 4.** With the RSS program still running, disconnect the RSS cable from Station 3 and connect it to Station 2. Now exit the RX Alignment screen.
- Step 5.** Access the TX Wireline Alignment screen and press **F8** to save the alignment value. (Station 3 is providing the 1 kHz alignment tone.)
- Step 6.** Exit the TX Wireline Alignment screen.
- Step 7.** With the RSS program still running, disconnect the RSS cable from Station 2 and connect it to Station 3.
- Step 8.** Access the RX Wireline Alignment screen and turn off the 1 kHz tone.

Station 3 TX Wireline Alignment

- Step 1.** Connect the RSS to Station 2 and access the RX Wireline Alignment screen.
- Step 2.** Set the RX wireline level and **Save** it. (Note that the wireline level is typically set to -6 dBm.)
- Step 3.** Press **F2** to turn on the 1 kHz tone. **Do not** exit this screen.
- Step 4.** With the RSS program still running, disconnect the RSS cable from Station 2 and connect it to Station 3. Now exit the RX Alignment screen.
- Step 5.** Access the TX Wireline Alignment screen and press **F8** to save the alignment value. (Station 2 is providing the 1 kHz alignment tone.)
- Step 6.** Exit the TX Wireline Alignment screen.
- Step 7.** With the RSS program still running, disconnect the RSS cable from Station 3 and connect it to Station 2.
- Step 8.** Access the RX Wireline Alignment screen and turn off the 1 kHz tone.

FALL BACK IN-CABINET REPEAT FEATURE

For *Quantar* and *Quantro* Stations

1 OVERVIEW

Feature Description

The Fall Back In-Cabinet Repeat (FBICR) feature provides limited backup communications capabilities in Simulcast (Option U764) and Non-Simulcast Voting (Option X269) systems in which the link to the Comparator has been lost (phone line disruption, cable disconnection, etc.). Figure 1 and Figure 2 illustrate typical scenarios in which the FBICR mode is activated. (Note that in these examples automatic FBICR mode is assumed; refer to *Automatic and External Modes* below for details.)

Note The FBICR feature is supported only for Station/RSS Release R10.03.00 and later.

Automatic and External Modes

The FBICR feature may be configured for either automatic or external modes (depending on system types, as explained later). Automatic mode is configured by programming certain station parameters using the Radio Service Software (RSS). External mode requires (in addition to RSS settings) that electrical connections be made to certain pins on the System Connector (Connector #17) located on the station backplane; external equipment (customer-provided) is used to ground one or more of these lines to force the station into FBICR mode.

The FBICR feature can be configured for the following system types in Automatic or External Modes:

Automatic Mode

- Conventional Analog (both Simulcast and Non-Simulcast Voting Systems)
- Conventional *ASTRO* (CAI) (both Simulcast and Non-Simulcast Voting Systems)
- Trunked *ASTRO* (SMARTZONE or SMARTNET) (CAI, VSELP) (Simulcast only)

External Mode

- Conventional Analog (both Simulcast and Non-Simulcast Voting Systems)
- Conventional *ASTRO* (CAI) (both Simulcast and Non-Simulcast Voting Systems)
- Trunked Analog (SMARTZONE or SMARTNET) (both Simulcast and Non-Simulcast Voting Systems)
- Trunked *ASTRO* (SMARTZONE or SMARTNET) (CAI, VSELP) (Simulcast only)

— continued on page 3 —




Figure 1. FBICR Feature in Simulcast Voting System (Automatic FBICR Mode Shown)




Figure 2. FBICR Feature in Non-Simulcast Voting System (Automatic FBICR Mode Shown)

Link Failure Detection Requirements

Before automatically enabling FBICR mode, a link failure detection must occur, defined as follows:

For Digital Systems

- Protocol Failure
- Carrier Detect Loss

Note In a V.24 Hybrid Configuration, the loss of the analog link **will not** cause the station to enter FBICR mode. Only the failure of the digital link will cause the station to enter FBICR mode.

For Analog Systems

- Loss of External PTT (Simulcast)
- No TRC Keyup (Voting)

Other Things to Know

- It is important to note that a station operating in FBICR mode is independent of other stations/receivers in the particular system. This is especially important in a Simulcast system, because simulcast transmission timing will be lost for the overlap coverage area between an active Simulcast station and a FBICR station. In a typical Simulcast scenario, the station responsible for the major coverage area is set for FBICR, and any adjacent stations are subsequently disabled.
- Automatic and External modes are mutually exclusive (i.e., a station may not be configured for both modes).

2 CONFIGURING THE FBICR FEATURE

Depending on the system type and whether you wish to configure for automatic or external operation, the FBICR feature must be configured by using the RSS only, or a combination of RSS programming and external wiring connections. Each configuration scenario is described on the following pages.

Automatic Mode

Conventional Analog or Conventional ASTRO (CAI) (Simulcast or Non-Simulcast Voting Systems)

- Step 1.** Access the *Wireline Configuration Screen*.
- Step 2.** Set the *Fall Back In-Cabinet Repeat* field to **ENABLED**.
- Step 3.** Enter the desired delay time (in msec) in the *Fall Back Timer* field.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 2 VER:XX.XX.XX :CHANGE/VIEW:WIRELINE CONFIGURATION		Use Up/Down Arrow Keys to Select Wireline Operation
Wireline Operation	4 WIRE FULL DUPLEX	
Console Priority	DISABLED	OPTION
Remote Control Type	ASTRO	
TRC Input	Line 1	
Outbound Analog Link Timer	120 sec	
Comparator	NONE	OPTION
Fall Back In-Cabinet Repeat	ENABLED	
Fall Back Timer	xxx msec	
Status Tone	ENABLED	
Status Tone Frequency	2175 kHz	
Wireline Squelch	DISABLED	
Rx Securenet/ASTRO To Wireline Equalization	ENABLED DISABLED	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------

◆ End of Procedure ◆

Automatic Mode (continued)

Note While in FBICR mode, the station will transmit Failsoft beeps and the subscriber will give the Failsoft indication.

**Trunked (SMARTZONE or SMARTNET) ASTRO (CAI, VSELP)
(Simulcast Systems Only)**

Step 1. Access the *Wireline Configuration Screen*.

Step 2. Set the *Fall Back In-Cabinet Repeat* field to **ENABLED**.
(No *Fall Back Timer* setting is required.)

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 2 VER:XX.XX.XX :CHANGE/VIEW:WIRELINE CONFIGURATION		Use Up/Down Arrow Keys to Select Wireline Operation
Wireline Operation	4 WIRE FULL DUPLEX	
Console Priority	DISABLED	OPTION
Remote Control Type	ASTRO	
TRC Input	Line 1	
Outbound Analog Link Timer	120 sec	
Comparator	NONE	OPTION
Fall Back In-Cabinet Repeat	ENABLED	
Status Tone	ENABLED	
Status Tone Frequency	2175 kHz	
Wireline Squelch	DISABLED	
Rx Securenet/ASTRO To Wireline Equalization	ENABLED DISABLED	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------

Step 3. Access the *6809 Trunking Interface Screen*.

Step 4. Make sure the *Failsoft* field is set to **ENABLED**, and set the *Modulation Type* to **ASTRO** or **ANALOG**.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS VER:XX.XX.XX :CHANGE/VIEW:6809 TRUNKING		Use Up/Dn Arrow Keys To Select RSTAT Mode
RSTAT Mode	Normal	
Failsoft	ENABLED	
Line TRC Encode	DISABLED	
Failsoft Carrier Squelch	DISABLED	
Dual CT Failsoft Only	DISABLED	
Modulation Type	ASTRO	
Trunking Tickle Source	TX DATA LINE	
Trunking Tickle Source TOT	1 sec	
CSC Logical Channel Number	1	
Rx Discriminator Type	QUANTAR/MICOR	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------

◆ End of Procedure ◆

External Mode

Conventional Analog or Conventional ASTRO (CAI) (Simulcast or Non-Simulcast Voting Systems)


Step 1. Access the *Wireline Configuration Screen*.

Step 2. Set the *Fall Back In-Cabinet Repeat* field to **DISABLED**.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 2 VER:XX.XX.XX :CHANGE/VIEW:WIRELINE CONFIGURATION		Use Up/Down Arrow Keys to Select Wireline Operation
Wireline Operation	4 WIRE FULL DUPLEX	
Console Priority	DISABLED	OPTION
Remote Control Type	ASTRO	
TRC Input	Line 1	
Outbound Analog Link Timer	120 sec	
Comparator	NONE	OPTION
Fall Back In - Cabinet Repeat	DISABLED	
Fall Back Timer	0 msec	
Status Tone	ENABLED	
Status Tone Frequency	2175 kHz	
Wireline Squelch	DISABLED	
Rx Securenet/ASTRO To Wireline	ENABLED	
Equalization	DISABLED	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------

Step 3. Connect a wire to pin 16 of System Connector #17 (located on the station backplane). To activate FBICR mode, an external circuit (customer-provided) must ground this pin.



◆ End of Procedure ◆

External Mode (continued)**Trunked (SMARTZONE or SMARTNET) Analog
(Simulcast or Non-Simulcast Voting Systems)****Step 1.** Access the *Wireline Configuration Screen*.**Step 2.** Set the *Fall Back In-Cabinet Repeat* field to **ENABLED**.
Set the *Fall Back In-Cabinet Repeat* field to **0 msec**.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 2 VER:XX.XX.XX :CHANGE/VIEW:WIRELINE CONFIGURATION		Use Up/Down Arrow Keys to Select Wireline Operation
Wireline Operation	4 WIRE FULL DUPLEX	
Console Priority	DISABLED	OPTION
Remote Control Type	ASTRO	
TRC Input	Line 1	
Outbound Analog Link Timer	120 sec	
Comparator	NONE	OPTION
Fall Back In-Cabinet Repeat	ENABLED	
Fall Back Timer	0 msec	
Status Tone	ENABLED	
Status Tone Frequency	2175 kHz	
Wireline Squelch	DISABLED	
Rx Securenet/ASTRO To Wireline Equalization	ENABLED DISABLED	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------

Step 3. Access the *6809 Trunking Interface Screen*.**Step 4.** Set the *Modulation Type* to **ANALOG**.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS VER:XX.XX.XX :CHANGE/VIEW:6809 TRUNKING		Use Up/Dn Arrow Keys To Select RSTAT Mode
RSTAT Mode	Normal	
Failsoft	DISABLED	
Line TRC Encode	DISABLED	
Failsoft Carrier Squelch	DISABLED	
Dual CT Failsoft Only	DISABLED	
Modulation Type	ANALOG	
Trunking Tickle Source	TX DATA LINE	
Trunking Tickle Source TOT	1 sec	
CSC Logical Channel Number	1	
Rx Discriminator Type	QUANTAR/MICOR	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------


— continued on next page —

External Mode (continued)

Trunked (SMARTZONE or SMARTNET) Analog (continued)

- Step 5.** Connect a wire to pin 11 and pin 16 of System Connector #17 (located on the station backplane). To activate FBICR mode, an external circuit (customer-provided) must ground these pins.

Note When pins 11 and 16 are grounded, the station will enter FBICR operation. The station will ignore any wireline transmit activity, ignore the EXT PTT line, and assert the TSTAT line. While in FBICR mode, the station will transmit Failsoft beeps and the subscriber will give the Failsoft indication.



◆ End of Procedure ◆

External Mode (continued)**Trunked (SMARTZONE or SMARTNET) ASTRO (CAI, VSELP)
(Simulcast Systems Only)****Step 1.** Access the *Wireline Configuration Screen*.**Step 2.** Set the *Fall Back In-Cabinet Repeat* field to **DISABLED**.
(No *Fall Back Timer* setting is required.)

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 2 VER:XX.XX.XX :CHANGE/VIEW:WIRELINE CONFIGURATION		Use Up/Down Arrow Keys to Select Wireline Operation
Wireline Operation	4 WIRE FULL DUPLEX	
Console Priority	DISABLED	OPTION
Remote Control Type	ASTRO	
TRC Input	Line 1	
Outbound Analog Link Timer	120 sec	
Comparator	NONE	OPTION
Fall Back In-Cabinet Repeat	DISABLED	
Status Tone	ENABLED	
Status Tone Frequency	2175 kHz	
Wireline Squelch	DISABLED	
Rx Securenet/ASTRO To Wireline Equalization	ENABLED DISABLED	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------

Step 3. Access the *6809 Trunking Interface Screen*.**Step 4.** Set the *Modulation Type* to **ASTRO** or **ANALOG**.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS VER:XX.XX.XX :CHANGE/VIEW:6809 TRUNKING		Use Up/Dn Arrow Keys To Select RSTAT Mode
RSTAT Mode	Normal	
Failsoft	DISABLED	
Line TRC Encode	DISABLED	
Failsoft Carrier Squelch	DISABLED	
Dual CT Failsoft Only	DISABLED	
Modulation Type	ASTRO	
Trunking Tickle Source	TX DATA LINE	
Trunking Tickle Source TOT	1 sec	
CSC Logical Channel Number	1	
Rx Discriminator Type	QUANTAR/MICOR	

F1 HELP	F2	F3	F4	F5	F6	F7	F8	F9	F10 EXIT
------------	----	----	----	----	----	----	----	----	-------------


— continued on next page —

External Mode (continued)

Trunked (SMARTZONE or SMARTNET) ASTRO (CAI, VSELP) (continued)

- Step 5.** Connect a wire to pin 11 and pin 16 of System Connector #17 (located on the station backplane). To activate FBICR mode, an external circuit (customer-provided) must ground these pins.

Note When pins 11 and 16 are grounded, the station will enter FBICR operation. The station will ignore any wireline transmit activity, ignore the EXT PTT line, and assert the TSTAT line. While in FBICR mode, the station will transmit Failsoft beeps and the subscriber will give the Failsoft indication.



◆ End of Procedure ◆



MAIN/STANDBY CONFIGURATION

For *Quantar* and *Quantro* Stations

1 OVERVIEW

The Main/Standby configuration allows two *Quantar/Quantro* stations to operate as a redundant pair. If the Main station should fail (due to hardware or software malfunction), the Standby station will immediately take over and provide service. Each station's operating mode (Main or Standby) is determined by a setting made using the Radio Service Software (RSS).

Please note the following requirements/restrictions that are applicable to the Main/Standby feature:

- Main/Standby feature is compatible with stations in **Conventional** systems only
- Main/Standby feature **is not** compatible with *ASTRO* signaling
- The station must be equipped with an 8 – wire Wireline Interface Module and the Enhanced Wildcard Option

2 ELECTRICAL CONNECTIONS

Install both stations (designating one as A and the other as B) as described in the appropriate functional base station manual. Make the wiring connections as shown in Figure 2 to allow Main/Standby operation.

Hint *Wiring connections between the two stations and with external equipment will be facilitated by using a standard telephone punch block. Figure 1 shows how to connect the stations and punch block.*




Figure 1. Using Punch Block to Facilitate Wiring Connections




Figure 2. Wiring Connections for Main/Standby Configuration

3 SETTING WIRELINE IMPEDANCE JUMPERS

Set the impedance jumpers on the Wireline Interface Modules in Stations A and B as described in Table 1. Figure 3 shows the location of the jumpers.

Table 1. Wireline Impedance Jumping for Main/Standby Operation

STATION A		STATION B	
2–Wire Connection to Console	4–Wire Connection to Console	2–Wire Connection to Console	4–Wire Connection to Console
Jumpers in position 1 on T1001	Jumpers in position 1 on T1000 and T1001	All jumpers removed (high impedance) on T1001	All jumpers removed (high impedance) on T1000 and T1001
Jumper JU1010 in 2-wire position	Jumper JU1010 in 4-wire position	Jumper JU1010 in 2-wire position	Jumper JU1010 in 4-wire position




Figure 3. Wiring Connections for Main/Standby Configuration

4 RSS PROGRAMMING

In order to enable the Main/Standby Feature, the following two tasks must be performed using the *Quantar/Quantro* Radio Service Software (RSS) program. (Refer to the *RSS User's Guide 68P81085E35* for details on performing the following tasks.)

- Step 1.** Connect a PC running the RSS program to one of the two stations and read the station codeplug.
- Step 2.** Access the *Hardware Configuration* screen and set the Main/Standby field for **MAIN** (for station designated as Main) or **STANDBY** (for station designated as standby) as shown in Figure 4.
- Step 3.** Perform all other RSS programming tasks to configure the station (as described in the *RSS User's Guide 68P81085E35*).

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS VER:XX.XX.XX MAIN:SERVICE:HARDWARE CONFIGURATION		Please Enter The Serial Number Type Alphanumeric/Punctuation Chars.											
Serial Number: Hardware Platform: QUANTAR		Station Name:											
System Type: CONVENTIONAL Rx Freq Band 1: UIHF_R2 438–470 MHz Rx Freq Band 2: NONE		Station Type: ANALOG ONLY Tx Freq Band: UIHF_R2 438–470 MHz IR Freq Band: NONE											
PA Power Rating: 25 Watts Power Supply: AC LOW		Output limited to xxx Watts Battery Type: NONE											
OPTIONS: Wireline: 8–WIRE Freq Ref: INTERNAL – STD Multi–Coded Squelch: DISABLED Scanning Receiver		WildCard: ENHANCED Simulcast Operation: DISABLED MRTI Interface: DISABLED Site Number: 1 Main/Standby: MAIN											
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px 10px;">F1 HELP</td> <td style="padding: 2px 10px;">F2</td> <td style="padding: 2px 10px;">F3</td> <td style="padding: 2px 10px;">F4</td> <td style="padding: 2px 10px;">F5</td> <td style="padding: 2px 10px;">F6</td> <td style="padding: 2px 10px;">F7</td> <td style="padding: 2px 10px;">F8 VALIDATE CONFIG</td> <td style="padding: 2px 10px;">F9</td> <td style="padding: 2px 10px;">F10 EXIT</td> </tr> </table>				F1 HELP	F2	F3	F4	F5	F6	F7	F8 VALIDATE CONFIG	F9	F10 EXIT
F1 HELP	F2	F3	F4	F5	F6	F7	F8 VALIDATE CONFIG	F9	F10 EXIT				

Set to MAIN (for Main Station)
 Set to STANDBY (for Standby Station)

Figure 4. Making Main/Standby RSS Setting

- Step 4.** Access the *Wildcard Configuration* menu screen and select *State/Action Configuration*. Press **F4** to set the WildCard Tables to their default values. This ensures that the tables for the Main/Standby Feature are programmed with the factory values. Note that any WildCard Tables that have been custom created by the customer will be deleted, and that any customization of the default tables will be returned to the factory default values. Re-enter these if the functions are still required for this installation.
- Step 5.** Save the codeplug to the station.
- Step 6.** Repeat Steps 1 thru 4 for the other station.

5 MAIN/STANDBY OPERATION

Three Modes of Main/Standby Operation

The Main/Standby Feature offers three modes of switching from MAIN to STANDBY and from STANDBY to MAIN:

- **Automatic (or “Hot”) Switchover** — Whenever one of the modules fails in the MAIN station, the MAIN station will automatically set itself to STANDBY and will signal its companion station to set itself to MAIN. The MAIN station will not automatically switch to STANDBY unless it is connected to its companion station and the companion station has not indicated a failure mode. (To disable automatic switchover mode, refer to page 8.)
- **Tone Remote Control Switchover** — Sending function tone 4 to the stations will force the MAIN station to STANDBY mode and the STANDBY station to MAIN mode. Sending function tone 5 to the stations will force the MAIN station back to MAIN mode and the STANDBY station back to STANDBY mode. If either station has detected a module failure, neither switchover will occur. (To change the particular function tones that trigger these events, refer to 9.)
- **External Control Switchover** — An external control device may be connected to Input 2 on Connector #17 (located on backplane of both stations) to initiate a Main-to-Standby or a Standby-to-Main switchover to occur. Grounding this signal causes the MAIN station to go to STANDBY mode and the STANDBY station to go to MAIN mode. Pulling this signal high causes the STANDBY station to go to MAIN mode and the MAIN station to go to STANDBY mode.

Additional Functions Provided by the Main/Standby Feature

- **Antenna Relay Control** — When the MAIN station is operating in MAIN mode, the relay driven output 8 is energized. The use of this closure is left up to the user. Typically a user will use this closure to drive an external relay which connects the antenna to whichever station is operating in MAIN mode.
- **Status Request** — Utilizing TRC function tone 14, the console operator can request which station is in MAIN mode. One beep will be returned if the MAIN station is in MAIN mode and two beeps if the STANDBY station is in MAIN mode.
- **Reset** — Utilizing TRC function tone 15, both stations will reset.

6 CUSTOMIZING MAIN/STANDBY OPERATION

Default Operation

The Main/Standby Feature is implemented using the Radio Service Software (RSS) WildCard Feature. As shipped from the factory, the RSS contains 21 WildCard Tables for the Main station and 20 WildCard Tables for the Standby station. These tables contain default settings that define the basic operation of the Main/Standby Feature (i.e., control of Main and Standby status of two interconnected stations via pre-defined Tone Remote Control function tones to provide backup redundancy in the event of a station failure).

Customizing Main/Standby Operation

Although all of the Main/Standby WildCard Tables are user configurable (via the RSS), it is recommended that only the following functions be customized by the user. Follow the instructions in Chapter 11 of the *RSS User's Guide 68P81085E35* for details on modifying the WildCard Tables.

- **Disable Automatic (Hot) Switchover** — Delete WildCard Table 8 in both stations

TABLE 8 OF 20					
STATE CONDITION			MAIN/STANDBY 8		
State	Description:	Cond	State	Cond	State
EVENT FLAG 6		AND	INPUT 8		
ACTION:			IN ACTION:		
-	STANDBY		-	NULL	
-	MRTI DISABLE		-		
-	RX WL MUTE		-		
-	WAIT	30	-		
-	CLR OUTPUT	3	-		
-	CLR OUTPUT	8	-		
-			-		
-			-		

- Select Alternate Function Tones to Activate Main/Standby Switchover (default is FT4 to switch, FT5 to switch back)** — To modify the Function Tone that initiates the initial switch from Main to Standby, modify the TRC TONE entry in WildCard Table 19 in the MAIN station and WildCard Table 17 in the STANDBY station.

To modify the Function Tone that initiates the switch back from Standby to Main, modify the TRC TONE entry in WildCard Table 18 in the MAIN station and WildCard Table 18 in the STANDBY station.

Main

Modify TRC Tone field to change Main-to-Standby Switchover

TABLE 19 OF 31

State	Description:	Cond	State	Cond	State
TRC TONE	4	AND NOT	EVENT FLAG 12		

ACTION:

-	STANDBY				
-	MRTI DISABLE				
-	RX WL MUTE				
-	WAIT	30			
-	CLR OUTPUT	3			
-	CLR OUTPUT	8			

INACTION:

-	NULL				
---	------	--	--	--	--

Standby

TABLE 17 OF 30

State	Description:	Cond	State	Cond	State
TRC TONE	4	AND NOT	EVENT FLAG 12		

ACTION:

-	SET OUTPUT	3			
-	SET OUTPUT	8			
-	WAIT	30			
-	RX WL ENABLE				
-	MRTI ENABLE				
-	MAIN				

INACTION:

-	NULL				
---	------	--	--	--	--

Main

Modify TRC Tone field to change Standby-to-Main Switchover

TABLE 18 OF 31

State	Description:	Cond	State	Cond	State
TRC TONE	5	AND NOT	EVENT FLAG 12		

ACTION:

-	SET OUTPUT	3			
-	SET OUTPUT	8			
-	WAIT	30			
-	RX WL ENABLE				
-	MRTI ENABLE				
-	MAIN				
-	SET EVENT FLAG	8			

INACTION:

-	NULL				
---	------	--	--	--	--

Standby

TABLE 18 OF 30

State	Description:	Cond	State	Cond	State
TRC TONE	5	AND NOT	EVENT FLAG 12		

ACTION:

-	STANDBY				
-	MRTI DISABLE				
-	RX WL MUTE				
-	WAIT	30			
-	CLR OUTPUT	3			
-	CLR OUTPUT	8			

INACTION:

-	NULL				
---	------	--	--	--	--

- 68P81095E89-O
2/15/99

The diagram illustrates the relationship between the Main and Standby states for the TRC Tone field modification. It features two tables, TABLE 12 OF 31 (Main) and TABLE 11 OF 30 (Standby), both showing STATE CONDITION and ACTION details. A large bracket on the left side of the diagram groups the two tables under the heading "Main". A horizontal line separates the two tables. A vertical line on the right side of the diagram separates the two tables. A diagonal line connects the "14" value in the "State" column of the Main table to the "14" value in the "State" column of the Standby table. A horizontal line connects the "14" value in the "State" column of the Main table to the "14" value in the "State" column of the Standby table. A vertical line on the right side of the diagram separates the two tables. A diagonal line connects the "14" value in the "State" column of the Main table to the "14" value in the "State" column of the Standby table. A horizontal line connects the "14" value in the "State" column of the Main table to the "14" value in the "State" column of the Standby table.

Main

Modify TRC Tone field to change which function tone initiates a Status Request

Standby

State	Description:	Cond	State	Cond	State
TRC TONE	14	AND NOT	STN KEYED		

State	Description:	Cond	State	Cond	State
TRC TONE	14	AND NOT	STN KEYED		



FAST KEYUP FEATURE

For *Quantar* and *Quantro* Stations

1 OVERVIEW

The Fast Keyup Feature allows *Quantar* and *Quantro* stations to be keyed up by an external device (such as a Data Controller) in approximately 12 milliseconds (*Quantar* VHF and *Quantro* UHF) or 10 milliseconds (all other stations). Note that normal keyup time using the station's PTT input is approximately 50 msec.

In order to implement this feature, three signals (TX Audio, RX Audio, and PTT) must be connected between the station and the external device. Also, an RSS parameter setting must be made to properly configure the feature's operation. This manual provides step-by-step instructions for performing these tasks.

Note — *The Fast Keyup Feature applies only to non-Simulcast, Analog Conventional stations.*

2 ELECTRICAL CONNECTIONS

As shown in Figure 1, the following signals must be connected properly between the station and the external device:

- PTT
- TX Audio
- RX Audio

Additionally, there are two possible connection configurations — **Direct Connection** and **Splatter Filter Connection**. The Direct Connection configuration is chosen when the external device provides the required splatter filtering of the TX Audio signal. The Splatter Filter Connection configuration is chosen when the station's internal splatter filter is to be utilized (no splatter filtering provided by the external device).

The following procedures describe how to make the signal connections for each type of connection configuration.





Figure 1. Fast Keyup Feature Wiring Diagram


Wiring Details for Direct Connection and Splatter Filter Configurations

- Step 1.** Connect the PTT signal from the external device to Connector #14 on the station backplane as shown below.
- Step 2.** Connect TX Audio (+) and (–) from the external device to Connector #17 on the station backplane as shown below.
- Step 3.** Connect Aux RX Audio and GND from the station backplane Connector #17 to the external device as shown below.

Direct Connection Configuration



Splatter Filter Connection Configuration



3

RSS PROGRAMMING

Using the *Quantar/Quantro* Radio Service Software (RSS) program (Version R09.05.00 or higher), make the following codeplug data changes to allow proper Fast Keyup operation. (Refer to the *RSS User's Guide 68P81085E35* for details on making codeplug programming changes.)

Table 1. Codeplug Data Changes for Fast Keyup Operation

Codeplug Data Parameter	RSS User's Guide Location
Set the Fast Key–Up parameter to <i>WIDEBAND</i> for Direct Connection configurations, or to <i>AUX TX</i> for Splatter Filter Connection configurations. Note <i>AUX TX</i> selection is not compatible with <i>MRTI</i> .	Programming the RF Configuration Data (p/o Chapter 4)

4 FAST KEYUP PERFORMANCE CHARACTERISTICS

Figure 2 shows the performance characteristics of the station after implementing the Fast Keyup Feature.




Figure 2. Fast Keyup Performance Characteristics



DUAL CONTROL OF GATED ACCESS VIA TRC AND SAM

For *Quantar* and *Quantro* Stations
Servicing MCS Users

1 OVERVIEW

This section describes how to program the station (*Quantar* or *Quantro*) and the Station Access Module (SAM) to allow two functions (repeater setup/knockdown and “gated access” to be controlled (toggled on and off) by both of the following methods:

- Console Operator using TRC tones
- Subscriber Unit using DTMF or MDC 1200 signaling transmitted over the air

By utilizing the MCS Feature and controlling the repeater setup/knockdown and “gated access” functions, an effective “Mutual Aid” talk group configuration can be created. In this configuration, subscribers within a specific coverage area (local subscribers) are assigned a “primary” PL and have their MCS User Access field set to ENABLED. These subscribers will repeat as normal (assuming station is toggled to “repeater setup” mode). Should emergency conditions require other subscribers outside of the local area to enter the communications area, these subscribers will be able to communicate with each other (as well as local users) via the same local repeater if they have been assigned with a “secondary” PL and have their MCS User Access set to GATED. Additionally, the repeat mode (setup or knocked down) and gated access mode (enabled or disabled) may be controlled by both a console operator or a subscriber unit. (Note that Gated User Access is disabled upon station reset. Gated Access must be enabled via over-the-air transmissions to the SAM module, or via TRC tones from the console.)

The following table shows how the repeater access and “gated access” functions may be controlled to provide access to local and visiting subscribers. Refer also to Figure 1 (showing a typical repeater access call flow chart **before** Gated Access is employed), and Figure 2 (showing a repeater access call flow chart **after** Gated Access is incorporated).

Gated Access	Repeater Up/Down	Subscriber Operation
Enabled	Up	<ul style="list-style-type: none">• Local subscribers (primary PL) will repeat.• Emergency subscribers (secondary PL and MCS User Access set to GATED) will repeat.
Enabled	Down	<ul style="list-style-type: none">• No subscribers will repeat.
Disabled	Up	<ul style="list-style-type: none">• Only local subscribers (primary PL) will repeat.
Disabled	Down	<ul style="list-style-type: none">• No subscribers will repeat.

In order to perform the procedures in this section, you must program certain parameters in the *Quantar* or *Quantro* station and the Station Access Module (SAM). In order to do this, you will need the following software programs:

- RVN5002 *Quantar/Quantro* Radio Service Software (RSS) Version R09.05.00 or higher)
- RVN4110 Station Access Module (SAM) Radio Service Software (RSS) Version R01.01 or higher)

Call Flow Prerequisites

- MCS User Access is Enabled (but not Gated)
- Analog Rptr Activation RSS Parameter set to SC
- Local Subscribers are using "Primary" PL




Figure 1. Typical Call Flow Chart Without Gated Access Incorporated

Call Flow Prerequisites

- MCS User Access is set to “Gated”
- Analog Rptr Activation RSS Parameter set to SC
- Emergency conditions exist, in which non-Local Subscribers are using “Secondary” PL




Figure 2. Typical Call Flow Chart With Gated Access Incorporated

2 STATION RSS PROGRAMMING


In order to support dual control of gated access by TRC and SAM, certain station parameters must be programmed using the *Quantar/Quantro* Radio Service Software (RSS) program (Version R09.05.00 or higher). (Refer to the *RSS User's Guide 68P81085E35* for details on making these settings.)

- Step 1.** Connect a PC running the Station RSS program to one of the two stations and read the station codeplug.
- Step 2.** Access the *Hardware Configuration* screen and set the *Multi-Coded Squelch* field to **MULTI-PL ONLY** to enable the Multi-Coded Squelch feature (as shown in Figure 3).

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS VER:XX.XX.XX MAIN:SERVICE:HARDWARE CONFIGURATION		Please Enter The Serial Number Type Alphanumeric/Punctuation Chars.							
Serial Number: Hardware Platform: QUANTAR		Station Name:							
System Type: CONVENTIONAL Rx Freq Band 1: UHF_R2 438-470 MHz Rx Freq Band 2: NONE		Station Type: ANALOG ONLY Tx Freq Band: UHF_R2 438-470 MHz IR Freq Band: NONE							
PA Power Rating: 25 Watts Power Supply: AC LOW		Output limited to xxx Watts Battery Type: NONE							
OPTIONS: Wireline: 8-WIRE Freq Ref: INTERNAL - STD Multi-Coded Squelch: MULTI-PL ONLY Scanning Receiver		WildCard: ENHANCED Simulcast Operation: DISABLED MRTI Interface: DISABLED Site Number: 1 Main/Standby: MAIN							
F1 HELP	F2	F3	F4	F5	F6	F7	F8 VALIDATE CONFIG	F9	F10 EXIT

Set to MULTI-PL ONLY

Figure 3. Making *Multi-Coded Squelch* RSS Setting

continued on next page 

Step 3. Access Page 1 of the *Channel Information* screen and set the *Analog Rptr Access* field to **MDC/TONE** (as shown in Figure 4) to enable the Station Access Module (SAM).

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 2 VER:XX.XX.XX MAIN:CHANGE/VIEW:CHANNEL INFORMATION		Please Enter A Channel Number. Valid Range Is 1 to 1	
Channel Number		1 CHANNEL# 1 OF 1	
Rx1 Frequency	0.000000 MHz	Tx Frequency	0.000000 MHz
Rx2 Frequency	0.000000 MHz	Tx Idle Frequency	0.000000 MHz
Modulation Type		ANALOG	
Tx Rated Deviation	5.00 kHz		
Receive Channel BW	WIDE	25–30 kHz Channel Spacing	
Call Sign			
Call Sign Over Wireline	DISABLED		
Access Code Table	1		
Analog Rx Activation	OFF		
Analog Rptr Activation	OFF		
Analog Rptr Hold-In	OFF		
Analog Rptr Access	MDC/TONE		
F1 HELP	F2	F3 ADD CHN	F4
F5 PREV CHN	F6 NEXT CHN	F7	F8 DELETE CHN
F9	F10 EXIT		

Set to MDC/TONE


Figure 4. Making *Analog Rptr Access* RSS Setting

Step 4. Access the *RF Configuration Data* screen and set the *Repeater Operation* field for **REPEATER** (as shown in Figure 5).

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS VER:XX.XX.XX :CHANGE/VIEW:RF CONFIGURATION		Use Up/Dn Arrow Keys To Select Repeater Operation	
Repeater Operation		REPEATER Fast Key–Up DISABLED	
Max Deviation		92 %	
Low Speed Deviation		17.0 %	
Antenna Relay		ENABLED	
Antenna Relay Delay		30 msec	
Call Sign Interval		15 min	
Startup On Last Active Channel		DISABLED	
Startup Channel		1	
ASTRO Fade Tolerance		3 FRAMES	
ASTRO RDLAP: Repeat		DISABLED	
Wireline Drop Out Delay		0 sec	
ASTRO TX Filter		WIDE PULSE	
ANALOG Simulcast Reverse Burst		INTERNAL	
Securenet: Rx Code Detect Fade Timer		80 msec	
Fade EOM Timer		80 msec	
F1 HELP	F2	F3	F4
F5	F6	F7	F8
F9	F10 EXIT		

Set to REPEATER

Figure 5. Making *Repeater Operation* RSS Setting

continued on next page 

Step 5. Access the *Multi-Coded Squelch* screen, enter the desired number of users, then set the “secondary” PL’s *User Access* field to **GATED** (as shown in Figure 6). Refer to the *RSS User’s Guide 68P81085E35* for details on setting up users in the *Multi-Coded Squelch* screen.




Figure 6. Entering Users and Setting to *Gated*

Step 6. Access the *TRC Commands* screen and program tones FT3–FT6 (as shown in Figure 7). Refer to the *RSS User's Guide 68P81085E35* for details on programming the tones.

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 1 of 3 VER:XX.XX.XX MAIN:CHANGE/VIEW:TRC COMMANDS	Enter Command or Use Tab/Shift Tab and Enter To Move Between Fields																				
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">Guard Tone 2175 Hz</td> <td style="width: 60%;">MORE</td> </tr> <tr> <td>FT1 — 2050 Hz</td> <td>MONITOR</td> </tr> <tr> <td>FT2 — 1950 Hz</td> <td>CIIN 001 KEY</td> </tr> <tr> <td>FT3 — 1850 Hz</td> <td>RPT ON</td> </tr> <tr> <td>FT4 — 1750 Hz</td> <td>RPT OFF</td> </tr> <tr> <td>FT5 — 1650 Hz</td> <td>GATEACC ON</td> </tr> </table>		Guard Tone 2175 Hz	MORE	FT1 — 2050 Hz	MONITOR	FT2 — 1950 Hz	CIIN 001 KEY	FT3 — 1850 Hz	RPT ON	FT4 — 1750 Hz	RPT OFF	FT5 — 1650 Hz	GATEACC ON								
Guard Tone 2175 Hz	MORE																				
FT1 — 2050 Hz	MONITOR																				
FT2 — 1950 Hz	CIIN 001 KEY																				
FT3 — 1850 Hz	RPT ON																				
FT4 — 1750 Hz	RPT OFF																				
FT5 — 1650 Hz	GATEACC ON																				
<table style="width: 100%; border-collapse: collapse;"> <tr> <td>F1</td><td>F2</td><td>F3</td><td>F4</td><td>F5</td><td>F6</td><td>F7</td><td>F8</td><td>F9</td><td>F10</td> </tr> <tr> <td>HELP</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>EXIT</td> </tr> </table>		F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	HELP									EXIT
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10												
HELP									EXIT												

MOTOROLA RADIO SERVICE SOFTWARE BASE STATION PRODUCTS Page 2 of 3 VER:XX.XX.XX MAIN:CHANGE/VIEW:TRC COMMANDS	Enter Command or Use Tab/Shift Tab and Enter To Move Between Fields																				
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">FT6 — 1550 Hz</td> <td style="width: 60%;">GATEACC OFF</td> </tr> <tr> <td>FT7 — 1450 Hz</td> <td></td> </tr> <tr> <td>FT8 — 1350 Hz</td> <td></td> </tr> <tr> <td>FT9 — 1250 Hz</td> <td></td> </tr> <tr> <td>FT10 — 1150 Hz</td> <td></td> </tr> </table>		FT6 — 1550 Hz	GATEACC OFF	FT7 — 1450 Hz		FT8 — 1350 Hz		FT9 — 1250 Hz		FT10 — 1150 Hz											
FT6 — 1550 Hz	GATEACC OFF																				
FT7 — 1450 Hz																					
FT8 — 1350 Hz																					
FT9 — 1250 Hz																					
FT10 — 1150 Hz																					
<table style="width: 100%; border-collapse: collapse;"> <tr> <td>F1</td><td>F2</td><td>F3</td><td>F4</td><td>F5</td><td>F6</td><td>F7</td><td>F8</td><td>F9</td><td>F10</td> </tr> <tr> <td>HELP</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>EXIT</td> </tr> </table>		F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	HELP									EXIT
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10												
HELP									EXIT												

Figure 7. Programming TRC Tones FT3–FT6

◆ End of This Procedure ◆

3 SAM RSS PROGRAMMING

In order to support dual control of repeater access by TRC and SAM, certain SAM parameters must be programmed using the Station Access Module (SAM) Radio Service Software (RSS) program. (Refer to the *SAM RSS User's Guide 68P80309E35* for details on performing the following tasks.)

- Step 1.** Connect a PC running the RSS program to the RSS port on the front panel of the SAM module and read the SAM codeplug.
- Step 2.** For **DTMF operation**, access *Page 03* of the *SAM Decoder Selection* screen and program the **TARGET** and **ACT TBL** settings as shown in Figure 1. These settings establish the keypad sequences and corresponding Action Tables for Repeater Setup, Repeater Knockdown, Gated Access Enable and Gated Access Disable. Note that if there is default data already entered when opening the screen, overwrite the data with the data shown below.

MOTOROLA RADIO SERVICE SOFTWARE
SAM with QUANTAR/QUANTRO
Page = 03 of 03
SAM DECODER SELECTION

Enter DTMF Target, Valid input is:
0-9, A-D, #, *, or X

Set to ENABLED..

DTMF DECODER
DTMF INPUT

ENABLED
RECEIVER 1

SAM MODE# 00 of 01

DTMF DECODER TARGET#	TARGET	ACT TBL
01	123*	03
02	456#	04
03	147*	06
04	369#	07
05		
06		
07		
08		
09		
10		
11		

Enter Action Table numbers to correspond to keypad sequences 01 thru 04. Use 03, 04, 06, and 07 as shown. (Note that if a table does not exist, the RSS will prompt you to create one.)

Enter desired keypad sequences for:
 Gated Access Enable – 123*
 Gated Access Disable – 456#
 Repeater Setup – 147*
 Repeater Knockdown – 369#
 (Keypad sequences are shown here as examples. You may choose other sequences as desired.)

F1
HELP

F2

F3

F4

F5
PRINT
PAGE

F6
ADD
MODE

F7
DELETE
MODE

F8
ACTION
EDIT

F9

F10
EXIT

Figure 1. Making DTMF SAM Decoder Selection RSS Settings

continued on next page

For MDC 1200 operation, access *Page 02* of the *SAM Decoder Selection* screen and program the *OPCODE*, *ID*, and *ACT TBL* settings as shown in Figure 2. These settings establish the IDs and corresponding Action Tables for Repeater Setup, Repeater Knockdown, Gated Access Enable and Gated Access Disable. Note that if there is default data already entered when opening the screen, overwrite the data with the data shown below.

MOTOROLA RADIO SERVICE SOFTWARE
 SAM with QUANTAR/QUANTRO
 Page = 02 of 03
 SAM DECODER SELECTION

Use UP/DOWN Arrows to Change Fields

BINARY DECODER
 BINARY INPUT

MDC1200
 RECEIVER 1

SAM MODE# 00 of 01

BINARY DECODER TARGET#	OPCODE	ID	ACT TBL
01	REPEAT ACC	0001	03
02	REPEAT ACC	0002	04
03	REPEAT ACC	0003	06
04	REPEAT ACC	0004	07
05			
06			
07			
08			
09			
10			
11			

F1	F2	F3	F4	F5	F6	F7	F8	F9	F10
HELP				PRINT	ADD	DELETE	ACTION		EXIT
				PAGE	MODE	MODE	EDIT		

Set to ENABLED..

Enter Action Table numbers to correspond to IDs 0001 thru 0004. Use 03, 04, 06, and 07 as shown.


The ID column reflects the MDC 1200 ID transmitted by the subscriber unit. IDs 0001 thru 0004 are shown here as examples. You may choose other IDs as desired.

Select REPEAT ACC for IDs 01 thru 04. (You MUST select REPEAT ACC. Do not use the Repeater Setup or Repeater Knockdown selections.)

Figure 2. Making MDC 1200 SAM Decoder Selection RSS Settings

continued on next page

- Step 3.** Access the *SAM Action Tables* screen and program Tables 03 and 04 as shown in Figure 3. These Action Tables control the Gated Access functions (enabled and disabled). Note that if there is default data already entered when opening the tables, overwrite the data with the data shown on the facing page.

continued on next page 

Setting Action Table 03 (Enable Gated Access)

MOTOROLA RADIO SERVICE SOFTWARE
SAM with QUANTAR/QUANTRO
Page = 01 of 04
ACTION TABLES

Use UP/DOWN Arrows to Change Fields

ACTION TABLE

03

ACTION TABLE# 03 of xx

#	ACTION	ADDRESS	TARG BIT	POLARITY
01	MANIBIT	004C	1	DISABLED
02	WAIT	WAIT TIME		
		100		
03	MANIBIT	004C	1	ENABLED
04	ACTION			
04	ACTION			

F1 HELP
F2
F3
F4
F5 PRINT PAGE
F6
F7 CLEAR TABLE
F8
F9
F10 EXIT

Use arrow keys to toggle to 03.

Program Actions 01 – 03 as shown.

Setting Action Table 04 (Disable Gated Access)

MOTOROLA RADIO SERVICE SOFTWARE
SAM with QUANTAR/QUANTRO
Page = 01 of 04
ACTION TABLES

Use UP/DOWN Arrows to Change Fields

ACTION TABLE

04

ACTION TABLE# 04 of xx

#	ACTION	ADDRESS	TARG BIT	POLARITY
01	MANIBIT	004C	1	ENABLED
02	MANIBIT	004C	0	DISABLED
03	WAIT	WAIT TIME		
		100		
04	MANIBIT	004C	1	DISABLED
05	ACTION			

F1 HELP
F2
F3
F4
F5 PRINT PAGE
F6
F7 CLEAR TABLE
F8
F9
F10 EXIT

Use arrow keys to toggle to 04.

Program Actions 01 – 04 as shown.

Figure 3. Programming the Action Tables for Gated Access Enable/Disable

- Step 4.** Access the *SAM Action Tables* screen and program Tables 06 and 07 as shown in Figure 4. These Action Tables control the Repeater Setup and Knockdown functions. Note that if there is default data already entered when opening the tables, overwrite the data with the data shown on the facing page.

◆ End of This Procedure ◆

Setting Action Table 06 (Repeater Setup)

MOTOROLA RADIO SERVICE SOFTWARE
SAM with QUANTAR/QUANTRO
Page = 01 of 04
ACTION TABLES

Use UP/DOWN Arrows to Change Fields

ACTION TABLE

06

ACTION TABLE# 06 of xx

#	ACTION	ADDRESS	TARG BIT	POLARITY
01	MANIBIT	004C	3	ENABLED
#	ACTION	WAIT TIME		
02	WAIT	100		
#	ACTION	ADDRESS	TARG BIT	POLARITY
03	MANIBIT	004C	3	DISABLED
#	ACTION			
04				
#	ACTION			
04				

F1 HELP
F2
F3
F4
F5 PRINT PAGE
F6
F7 CLEAR TABLE
F8
F9
F10 EXIT

Use arrow keys to toggle to 06.

Program Actions 01–03 as shown.

Setting Action Table 07 (Repeater Knockdown)

MOTOROLA RADIO SERVICE SOFTWARE
SAM with QUANTAR/QUANTRO
Page = 01 of 04
ACTION TABLES

Use UP/DOWN Arrows to Change Fields

ACTION TABLE

07

ACTION TABLE# 07 of xx

#	ACTION	ADDRESS	TARG BIT	POLARITY
01	MANIBIT	004C	3	DISABLED
#	ACTION	WAIT TIME		
02	WAIT	100		
#	ACTION	ADDRESS	TARG BIT	POLARITY
03	MANIBIT	004C	3	ENABLED
#	ACTION			
04				
#	ACTION			
04				

F1 HELP
F2
F3
F4
F5 PRINT PAGE
F6
F7 CLEAR TABLE
F8
F9
F10 EXIT

Use arrow keys to toggle to 07.

Program Actions 01–03 as shown.

Figure 4. Programming the Action Tables for Repeater Setup/Knockdown