


 **MOBILE RADIO**


MASTR[®] II

MAINTENANCE MANUAL LBI4681 F

DATAFILE FOLDER DF-9031




MOBILE RADIO



CONTROL UNIT

"E" SERIES
TWO-WAY FM
MOBILE
COMBINATIONS



SPEAKER

GENERAL  ELECTRIC

TABLE OF CONTENTS

EQUIPMENT INDEX	iii
SYSTEM SPECIFICATIONS	iv
COMBINATION NOMENCLATURE	v
TRANSMITTER TYPE NUMBERS	vi
DESCRIPTION	1
PRE-INSTALLATION CHECK	3
INITIAL ADJUSTMENT	4
OPERATION	4
MAINTENANCE	4
Removing ICs	4
Preventive Maintenance	4
Test and Troubleshooting	4
Mechanical Parts Breakdown	5
Re-Installation	5
Noise Suppression	5
MECHANICAL PARTS BREAKDOWN	
Standard Combinations	9
DFE Wide-Spaced Transmitter & DC Converter	10
SYSTEM INTERCONNECTION DIAGRAM (See Control Unit & System Board Maintenance Manuals)	

ILLUSTRATIONS

Figure 1 - Typical Bottom Section Module Layout	1
Figure 2 - Typical Top Section Module Layout	2
Figure 3 - Ignition Circuit with Noise Suppression Components	6
Figure 4 - Generator Circuit with Noise Suppression Components	7

WARNING

Although the highest DC voltage in the radio is supplied by the vehicle battery, high current may be drawn under short circuit conditions. These currents can possibly heat metal objects such as tools, rings, watchbands, etc. enough to cause burns. Be careful when working near energized circuits.

High-level RF energy in the transmitter Power Amplifier assembly can cause RF burns. KEEP AWAY FROM THESE CIRCUITS when the transmitter is energized.

EQUIPMENT INDEX

EQUIPMENT	MODEL OR PART NUMBER
Transmitter and Receiver	Refer to the applicable Maintenance Manual
Exciter/PA Cable	5491689P86
Receiver Antenna Cable Standard Noise Blanker or Pre-Amp	5491689P83 5491689P77
Control Unit	Refer to the applicable Maintenance Manual
Microphone	Refer to the Control Unit Maintenance Manual
Speaker	Refer to the Control Unit Maintenance Manual
Antennas	Refer to the Control Unit Maintenance Manual
Power/Control Cable 20 Foot, 18 Conductor 20 Foot, 30 Conductor 20 Foot, 38 Conductor	Refer to the Control Unit Maintenance Manual
12 Volt Fuse Assembly	Refer to the Control Unit Maintenance Manual
Ignition Switch Cable Assembly	Refer to the Control Unit Maintenance Manual
DC Converter	19D417134G1
Microphone Bracket	7141414G2
Channel Guard Microphone Hookswitch	19C320318G1
Extractor Kit	19B227456G1
Mounting Hardware	19A129474G1
Key (BF10A)	5491682P8
Alignment Tools	19B219676G1 19B219678P1

OPTION

EQUIPMENT	PART OR OPTION NUMBER
Power/Control Cables	
9 Foot, 18 Conductor	19D423424G1
9 Foot, 30 Conductor	19D423424G7
9 Foot, 38 Conductor	19D423424G13
27 Foot, 18 Conductor	19D423424G3
27 Foot, 30 Conductor	19D423424G9
27 Foot, 38 Conductor	19D423424G15
Handset	19C320478G1
Hookswitch	19B219846G1
12 Volt 3 wire Ignition Switch Cable Assembly	19B219537G1
Dual Front End	
Matching IF Frequencies	9201
Non-Matching IF Frequencies	9202
Wide Spaced Transmitter (Second Exciter)	
±0.0005% frequency stability	9203
±0.0002% frequency stability	9204

SYSTEM SPECIFICATIONS

FREQUENCY RANGE	25-50 MHz (Low Band) 138-174 MHz (High Band) 406-512 MHz (UHF)
BATTERY DRAIN (less options)	
Receiver Squelched	0.25 amperes at 13.8 VDC
Receiver Unsquelched	2.4 amperes at 13.8 VDC
Transmitter	
50 Watt Low Band	13 amperes at 13.6 VDC
100 Watt Low Band	26 amperes at 13.4 VDC
35 Watt High Band	10 amperes at 13.6 VDC
65 Watt High Band	15.9 amperes at 13.6 VDC
110 Watt High Band	29 amperes at 13.4 VDC
20 Watt UHF	6.0 amperes at 13.8 VDC
40 Watt UHF	12 amperes at 13.6 VDC
75 Watt UHF	17.0 amperes at 13.6 VDC
100 Watt UHF	27.5 amperes at 13.4 VDC
DIMENSIONS (HxWxD)	5" x 12-1/16" x 18-3/4"
WEIGHT (less mounting plate)	
Standard Radio	29 pounds
With Wide Spaced Transmitter	
Option	30 pounds
With Dual Front End Option	31-1/2 pounds
With DC Converter	36 pounds
TEMPERATURE RANGE	-40°C to +70°C (-40°F to +158°F)
DUTY CYCLE	
Intermittent	20% Transmit, 100% receive (EIA)
Continuous	100% transmit, (see applicable Specification Sheet)

* These specifications are intended primarily for the use of the serviceman. Refer to the appropriate Specification Sheet for the complete specifications.

COMBINATION NOMENCLATURE

1st Digit	2nd Digit	3rd Digit	4th Digit	5th Digit	6th Digit	7th Digit	8th & 9th Digits	10th Digit
Mechanical Package	System Voltage	Power Output	Channel Spacing	Frequency Capability	Number of Freq.	Options	Frequency Range	Oscillator Stability
E Model	C ±12 Volts DC	4 8-20 Watts	4 20 KHz	A 1-Freq.	A 1-Freq. Xmit 1-Freq. Rec.	S Standard	12 25-30 MHz	A ±5 PPM (0.0005%)
	J DC Converter ± Ground	5 21-40 Watts	5 25 KHz	C 2-Freq.	B 2-Freq. Xmit 1-Freq. Rec.	U Channel Guard	13 30-36 MHz	B ±2 PPM (0.0002%)
	X ±12 Volts DC Less Accessories	6 41-80 Watts	6 30 KHz	K 8-Freq.	C 2-Freq. Xmit 2-Freq. Rec.	N Noise Blanker	23 36-42 MHz	C ±5 PPM (Phase Lock Loop)
	Y ±24-48 Volts DC Less Accessories	7 81-128 Watts			D 1-Freq. Xmit 2-Freq. Rec.	W Channel Guard & Noise Blanker	33 42-50 MHz	D ±2 PPM (Phase Lock Loop)
					E 3-Freq. Xmit 3-Freq. Rec.	P UHS Receiver	44 66-78 MHz	
					F 4-Freq. Xmit 4-Freq. Rec.	G UHS Receiver & Channel Guard	45 77-88 MHz	
					G 5-Freq. Xmit 5-Freq. Rec.		56 138-155 MHz	
					H 5-Freq. Xmit 5-Freq. Rec.		66 150.8-174 MHz	
					J 7-Freq. Xmit 7-Freq. Rec.		77 406-420 MHz	
					K 8-Freq. Xmit 8-Freq. Rec.		78 420-450 MHz	
							88 450-470 MHz	
							89 470-494 MHz	
							91 194-512 MHz	

TRANSMITTER TYPE NUMBERS

STANDARD TRANSMITTER	FREQ. RANGE (MHz)	NUMBER OF FREQS.	FREQ. STABILITY	POWER OUTPUT (Watts)
KT-70-A	25-50	1 thru 8	±0.0005%	50
KT-70-C	25-50	1 thru 8	±0.0002%	50
KT-71-A	25-50	1 thru 8	±0.0005%	100
KT-71-C	25-50	1 thru 8	±0.0002%	100
KT-72-A	138-174	1 thru 8	±0.0005%	35/40
KT-72-B	138-174	1 thru 8	±0.0002%	35/40
KT-72-J	138-174	1 thru 8	±0.0002/0.0005%	40
KT-73-A	138-174	1 thru 8	±0.0005%	65
KT-73-C	138-174	1 thru 8	±0.0002%	65
KT-73-J	138-174	1 thru 8	±0.0002/0.0005%	65
KT-74-A	138-174	1 thru 8	±0.0005%	110
KT-74-C	138-174	1 thru 8	±0.0002%	110
KT-74-J	138-174	1 thru 8	±0.0002%	110
KT-75-B	406-512	1 thru 8	±0.0005%	20
KT-75-D	406-512	1 thru 8	±0.0002%	20
KT-76-B	406-512	1 thru 8	±0.0005%	40
KT-76-D	406-512	1 thru 8	±0.0002%	40
KT-126-A	406-512	1 thru 8	±0.0005%	75
KT-126-C	406-512	1 thru 8	±0.0002%	75
KT-77-A	406-512	1 thru 8	±0.0005%	100
KT-77-C	406-512	1 thru 8	±0.0002%	100

WIDE SPACED TRANSMITTER	FREQ. RANGE (MHz)	NUMBER OF FREQS.	FREQ. STABILITY	POWER OUTPUT (Watts)
KT-90-A	30-50	1 thru 8	±0.0005%	50
KT-90-C	30-50	1 thru 8	±0.0002%	50
KT-91-A	30-50	1 thru 8	±0.0005%	100
KT-91-C	30-50	1 thru 8	±0.0002%	100
KT-92-A*	138-174	1 thru 8	±0.0005%	35
KT-92-C*	138-174	1 thru 8	±0.0002%	35
KT-93-A*	138-174	1 thru 8	±0.0005%	65
KT-93-A*	138-174	1 thru 8	±0.0002%	65
KT-94-A*	138-174	1 thru 8	±0.0005%	110
KT-94-C*	138-174	1 thru 8	±0.0002%	110

TRANSMITTER WITH CONVERTER		FREQ. RANGE (MHz)	NUMBER OF FREQS.	FREQ. STABILITY	POWER OUTPUT (Watts)
STANDARD	WIDE-SPACED				
KT-70-E	KT-90-E	25-50	1 thru 8	±0.0005%	50
KT-70-G	KT-90-G	25-50	1 thru 8	±0.0002%	50
KT-72-E	KT-92-E*	138-174	1 thru 8	±0.0005%	35/40
KT-72-F	KT-92-G*	138-174	1 thru 8	±0.0002%	35/40
KT-72-K		138-174	1 thru 8	±0.0005/0.0002%	40
KT-73-E	KT-93-E*	138-174	1 thru 8	±0.0005%	65
KT-73-G	KT-93-G*	138-174	1 thru 8	±0.0002%	65
KT-73-K		138-174	1 thru 8	±0.0005/0.0002%	65
KT-75-F		406-470	1 thru 8	±0.0005%	20
KT-75-H		406-470	1 thru 8	±0.0002%	20
KT-76-F		406-512	1 thru 8	±0.0005%	40
KT-76-H		406-512	1 thru 8	±0.0002%	40

* Second exciter will be in the 150.8-174 MHz range.

DESCRIPTION

MASTR® II mobile radio combinations are compact, highly reliable and ruggedly-constructed units that are designed to meet the most stringent requirements in the two-way radio field.

The radios are fully transistorized-utilizing both discrete components and Integrated Circuits (IC'S) for highest reliability. Since no tubes are used, the radio is ready to use the instant it is turned on. The standard combination may be equipped with the following:

- One through eight frequencies
- Plug-in oscillators for $\pm 0.0002\%$ or $\pm 0.0005\%$ oscillator stability
- Channel Guard (tone squelch)
- Noise Blanker (25-50 and 138-174 MHz)
- Ultra High Sensitivity (UHS) pre-amplifier (138-174 and 406-512 MHz)
- DC Converter

The radio set is housed in a drip-proof case only five inches high. The radio mounts

to the vehicle by a bottom mounting plate, and is tamper-proof when locked into the mounting plate. When unlocked, the handle can be pulled down and the radio pulled out of the mounting plate or the top cover removed for servicing. When the handle is pulled down 90 degrees, the radio can be locked to hold the handle in the carrying position.

A hinged bottom section provides space for mounting a Dual Front End, a second exciter board for Wide-Spaced Transmitters, or other modules.

To gain access to the modules in the bottom section, remove the radio from its mounting frame and turn the radio over. Then loosen the two captive screws securing the bottom cover and remove the cover (see Figure 1).

The bottom section swings open so that all major modules and tuning adjustments in the radio are easily accessible for servicing. To swing the bottom section open, first remove the bottom cover. Next, loosen the screw in the retaining latch and slide the latch open. The bottom section will now swing open as shown in Figure 2.




Figure 1 - Typical Bottom Section Module Layout




Figure 2 - Typical Top Section Module Layout (Bottom Section Swing Open)

No power supply is required since the highest supply voltage used in the radio is derived from the vehicle battery.

Centralized metering jacks for the transmitter, receiver and system board are provided for simplified alignment and troubleshooting.

Both the transmitter, receiver and option modules are electrically isolated from the radio chassis to permit operating in positive or negative ground vehicles without the use of a polarity converter. The transmitter exciter and receiver modules are mounted in a Lexan® frame for isolation. In 12 Volt systems, simply changing four connections to the control unit and reversing the power leads at the fuse block allows the radio to be used in negative or positive ground vehicles. No changes are required in the radio.

TRANSMITTER

The transmitter consists of an exciter board located in the mounting frame, and a power amplifier assembly. The PA assembly consists of a PA board mounted on a PA casting at the rear of the radio. A hermetically sealed antenna switch is also mounted on the PA assembly.

RECEIVER

The receiver consists of an oscillator/multiplier assembly (Osc/Mult), RF assembly,

mixer/IF assembly (MIF), and IF-audio and squelch assembly (IFAS). In receivers with Noise Blankers, the noise blanker circuit replaces the standard MIF board. In UHS receivers, the pre-amplifier mounts in the area near the antenna input board.

DC CONVERTER

For systems that operate between a minimum of 16 Volts DC and a maximum of 60 Volts DC (i.e., nominal 24 Volt, 36 Volt or 48 Volt systems), a DC converter mounts at the rear of the radio under the transmitter PA assembly. The converter supplies all power to the radio, and no changes are required in the power leads on the radio for positive or negative ground operation.

CONTROL UNIT

The control unit contains the power on-off rocker switch, volume and squelch controls, channel selector switch in multi-frequency models, a red transmit indicator light and a power on/frequency indicator light. Space is provided for an optional rocker switch, and two optional indicator lights.

The control unit is enclosed in a two piece molded Lexan® housing, and is supplied with a Lexan® mounting bracket and Safety Release assembly. The Safety Release assembly breaks away under the impact for passenger safety. This mounting assembly also permits the control unit to be swiveled as desired for the convenience of the operator.

Two or three connectors are located on the rear of the control unit, depending on the type of control unit used. Two of the connectors are for the control cable(s), and one (Vehicle Systems Jack J701) is for power, accessories and external options.

MICROPHONE AND HANDSET

MASTR II mobile combinations use a dynamic microphone with a built-in transistorized microphone pre-amplifier. The microphone is housed in a sturdy Lexan® case, and the extendable coiled cord plugs into the microphone jack on the bottom of the control unit. The plug is secured to the jack by a retaining screw.

An optional Telephone-type headset is available for use with the radio. The handset uses a dynamic microphone with a built-in microphone pre-amplifier. The extendable coiled cord plugs into the microphone jack on the bottom of the control unit, and is secured to the jack by a retaining screw.

HOOKSWITCHES

In Channel Guard applications, a microphone or handset hookswitch is supplied with the radio. The hookswitches are equipped with a Channel Guard disable switch.

Placing the switch in the "up" position (towards the small speaker symbol) disables the receive Channel Guard. With the switch in the "down" position, the Channel Guard is disabled only when the microphone or handset is removed from the hookswitch.

SPEAKER

A five-inch speaker contained in a Lexan® housing provides an audio output of 12 watts. The speaker impedance is eight ohms. The speaker leads are terminated in Vehicle Systems Plug P701 which connects to J701 on the rear of the control unit.

The speaker is supplied with a Lexan® mounting bracket and Safety Release assembly. The Safety Release assembly breaks away under impact for passenger safety and permits the speaker to be swiveled as desired to direct sound to the operator.

OPTIONS

Dual Front End (DFE)

The DFE option consists of an RF assembly, an oscillator-multiplier assembly located in the module mounting frame in the bottom section. An RF steering switch mounted on the panel on the front of the PA assembly connects the antenna to the selected RF assembly input.

A total of eight frequencies can be divided between the DFE and the receiver.

Wide-Spaced Transmitter

The Wide-spaced Transmitter option consists of a second exciter board in the bottom module mounting frame, and a second system board to provide power for the exciter. The two exciter outputs are connected to the PA through a combiner circuit mounted on the panel on the front of the PA assembly.

A total of eight frequencies can be divided between the two exciters.

PRE-INSTALLATION CHECK

MASTR II radios are shipped from the factory completely connected to permit the serviceman to perform system checks on the transmitter and receiver without removing the radio from its shipping container. Simply removing the lid on the internal packing case provides access to the battery cables, ignition switch cables, microphone, control unit and radio antenna jack. The radio is shipped connected for 12 Volt, negative ground operation except when equipped with DC converter.

CAUTION

Before bench testing the MASTR II Mobile Radio, be sure of the output voltage characteristic of your bench power supply.

To protect the transmitter power output transistors from possible instant destruction, the following input voltages must not be exceeded:

Transmitter unkeyed: 20 Volts
 Transmitter keyed: 18 Volts
 (50 ohm resistive load)
 Transmitter keyed: 15.5 V (25-50 MHz)
 14.5 V (138-174 MHz)
 15.5 V (406-512 MHz)
 (no load or non-resistive load)

These voltages are specified at the normal vehicle battery terminals of the radio and take the voltage drop of standard cables into account. The voltage limit shown for a non-optimum load is for "worst case" conditions. For antenna mismatches likely to be encountered in practice, the actual limit will approach the 18 Volt figure.

Routine transmitter tests should be performed at EIA Standard Test Voltages (13.6 VDC for loads of 6 to 16 amperes; 13.4 VDC for loads of 16 to 36 amperes). Input voltages must not exceed the limits shown, even for transient peaks of short duration.

Many commonly used bench power supplies cannot meet these requirements for load regulation and transient voltage suppression. Bench supplies which employ "brute force" regulation and filtering (such as Lapp Model 73) may be usable when operated in parallel with a 12 Volt automotive storage battery.

INITIAL ADJUSTMENT

After the MASTR II Radio has been installed (as described in the Installation Manual), the following adjustments should be made by an electronics technician who holds a 1st or 2nd Class FCC Radio-telephone license.

Make sure that a RADIO TRANSMITTER IDENTIFICATION form (FCC Form 452-C or General Electric Form NP270303) has been filled out and attached to the transmitter.

TRANSMITTER ADJUSTMENT

The adjustment for the transmitter includes measuring the Forward and Reflected Power and adjusting the antenna length for optimum ratio, then setting the transmitter to rated power output (or to the specific output or input which may be required by the FCC station authorization). Next, measuring the frequency and modulation and entering these measurements on the FCC-required Station records. For the complete transmitter adjustment, refer to the ALIGNMENT PROCEDURE in the MAINTENANCE MANUAL for the transmitter.

RECEIVER ADJUSTMENT

The initial adjustment for the receiver includes tuning the input circuit to match the antenna. For the Receiver Initial Adjustment Procedure, refer to the FRONT END ALIGNMENT PROCEDURES in the MAINTENANCE MANUAL for the receiver.

OPERATION

Complete operating instructions for the Two-Way Radio are provided in the separate OPERATOR'S MANUAL. The basic procedures for receiving and transmitting messages follows:

TO RECEIVE A MESSAGE

1. Turn the radio on by pressing the POWER-ON rocker switch to the ON position.
2. Turn the SQUELCH control clockwise (to the right) as far as possible.

3. Adjust the VOLUME control until the noise is easily heard but is not annoyingly loud.
4. Now, slowly turn the SQUELCH control counterclockwise (to the left) until the noise just fades out.

The radio is now ready to receive messages from other radios in the system.

TO TRANSMIT A MESSAGE

1. Turn the radio on as directed in the "To Receive a Message" section.
2. Press the push-to-talk button on the microphone and speak across the face of the microphone in a normal voice. Release the button as soon as the message has been given. The red indicator light on the control unit will glow each time the microphone button is pressed, indicating that the transmitter is on the air. The receiver is muted whenever the transmitter is keyed.

MAINTENANCE

REMOVING IC's

Removing IC's (and all other soldered-in components) can be easily accomplished by using a De-soldering tool such as a SOLDA-PULLT® or equivalent. To remove an IC, heat each lead separately on the solder side and remove the old solder with the de-soldering tool.

An alternate method is to use a special soldering tip that heats all of the pins simultaneously.

PREVENTIVE MAINTENANCE

To insure high operating efficiency and to prevent mechanical and electrical failures from interrupting system operations, routine checks should be made of all mechanical and electrical parts at regular intervals. This preventive maintenance should include the checks as listed in the table of Maintenance Checks.

TEST AND TROUBLESHOOTING PROCEDURES

The individual Maintenance Manual for the transmitter and receiver describe standard test procedures which the serviceman can use to compare the actual performance of the transmitter or receiver against the specifications of the unit when shipped from the factory. In addition, specific troubleshooting procedures are available to assist the serviceman in troubleshooting the transmitter and receiver.

MAINTENANCE CHECKS	INTERVAL	
	6 Months	As Required
CONNECTIONS - Ground connections and connections to the voltage source should be periodically checked for tightness. Loose or poor connections to the power source will cause excessive voltage drops and faulty operation.	X	
ELECTRICAL SYSTEM - Check the voltage regulator and alternator or generator periodically to keep the electrical system within safe and economical operating limits. Over-voltage is indicated when the battery loses water rapidly. Usage of 1 or 2 ounces of water per cell per week is acceptable for batteries in continuous operation.		X
MECHANICAL INSPECTION - Since mobile units are subject to constant shock and vibration, check for loose plugs, nuts, screws and parts to make sure that nothing is working loose.	X	
ANTENNA - The antenna, antenna base and all contacts should be kept clean and free from dirt or corrosion. If the antenna or its base should become coated or poorly grounded, loss of radiation and a weak signal will result.	X	
ALIGNMENT - The transmitter and receiver meter readings should be checked periodically, and the alignment "touched up" when necessary. Refer to the applicable ALIGNMENT PROCEDURE and troubleshooting sheet for typical voltage readings.		X
FREQUENCY CHECK - Check transmitter frequency and deviation as required by FCC. Normally, these checks are made when the unit is first put into operation, after the first six months, and once a year thereafter.		X

NOTE

In positive ground operation only, A- is "hot" with respect to vehicle ground. Shorting the receiver front end casting or any printed wiring board ground patterns to the radio case may cause one of the in-line fuses to blow.

NOISE SUPPRESSION

After completing the initial adjustment of the transmitter and receiver, the serviceman should determine whether additional noise suppression is required. The following information should assist the serviceman in identifying and eliminating undesirable noise interference.

Ignition Noise

Ignition noise sounds like a "popping" sound in the speaker, whose frequency varies with engine speed while a weak signal is being received. This type of interference is generated by the spark plugs, distributor and any poor connections in the high-voltage system which might cause arcing. Ignition noise may be identified by noting that the noise disappears as soon as the ignition switch is turned off.

1. If the vehicle does not have a resistance lead from the coil to the center of the distributor cap, disconnect the lead at the distributor and cut the lead

MECHANICAL PARTS BREAKDOWN

Mechanical parts breakdown diagrams of the two-way radio are provided in this manual. The diagrams show the placement and GE Part Number of mechanical items on the Two-Way radio set (see Table of Contents).

RE-INSTALLATION

If the radio is ever moved to a different vehicle, always check the battery polarity and voltage of the new system before using the radio.




Figure 3 - Ignition Circuit with Noise Suppression Components

so that a Cable-Type Suppressor may be inserted in it close to the distributor. Screw the cut ends of the lead into the suppressor.

NOTE

A resistance lead operates as a very effective noise suppressor as long as there are no breaks anywhere along its length. Never cut a resistance lead to insert a suppressor. A loose knot is often tied in the lead to prevent excess flexing, which might break the conductor.

2. Check to see that:

- the distributor points and condenser are in good condition.
- the high-voltage leads from the distributor are not broken and are making good contact at each end.
- the spark plugs have clean, dry insulators and their electrodes are clean and properly adjusted.
- the timing has been properly adjusted.

3. Use a 0.5-mFd by-pass capacitor to by-pass the battery lead to the ignition coil. Mount the capacitor under a screw which will provide a good ground and connect the capacitor lead to the terminal of the coil which is connected to the ignition.

4. Remove the ignition coil and its mounting bracket. Clean paint from coil (where the bracket mounts), from the bracket and from the engine block. Re-mount the coil so as to obtain a good ground for the coil case.
5. If the vehicle has been driven 30,000 or 40,000 miles or more, the cap and rotor of the distributor will probably need replacing. This will not only reduce ignition noise, but also improve the overall performance of the engine.
6. High-voltage ignition wires can become capacitively coupled to the low-voltage systems, causing ignition noise to appear in the low-voltage system. This coupling can be minimized by separating the high- and low-voltage leads, or if necessary, separately shielding the leads.
7. If one of the ignition leads happens to have the critical length for radiating at the receiver's frequency, the noise can be reduced by changing the length of the lead. A noise source of this type is not common and can only be found by using a noise meter or by trial and error.
8. If the preceding steps fail to reduce ignition noise to a satisfactory level, it may be necessary to install resistance-type spark plugs, individual suppressors on each spark plug, or a shielded ignition wire harness.




Figure 4 - Generator Circuit with Noise Suppression Components

Alternator Noise

Alternator noise shows up as a high-pitched "whine", whose pitch varies with engine speed. To check for this type of noise, run the engine at a moderate speed and then shut off the engine, while listening to the noise on the receiver. Alternator noise will continue as long as the engine turns, lowering in pitch as the engine slows down.

It may be necessary to install a coaxial type, 0.5-mFd filter capacitor from the ungrounded alternator terminal to ground.

CAUTION

Do not install this capacitor on alternators that are equipped with a factory-supplied capacitor for protecting the rectifiers and suppressing noise.

Generator Noise

Generator noise shows up as a high-pitched "whine", whose pitch varies with engine speed. To check for this type of noise, run the engine at a moderate speed and then shut off the engine, while listening to the noise on the receiver. Generator noise will continue as long as the engine turns, lowering in pitch as the engine slows down.

By-pass the armature terminal on the generator to ground with a 0.5-mFd, 40 or 50-amp coaxial capacitor. Be sure to scrape the area where the capacitor is to be mounted, so that its case will be well grounded.

CAUTION

Do not by-pass the field terminal (F), as this will damage the voltage regulator contacts.

Generator Regulator Noise

Generator regulator noise shows up as a "raspy" sound which is generated by the contacts in the regulator and radiated by the leads coming out to the regulator. If suppression of regulator noise is necessary, connect a 5 ohm resistor in series with a .002-mFd capacitor from the field, terminal (F) of the regulator to ground. If possible, these components should be mounted inside regulator case. The battery terminal (BAT) and armature terminal (ARM) can be by-passed to ground with 0.5-mFd capacitors.

CAUTION

If the regulator is opened to install the capacitor or resistor, remember that one wrong connection or shorted wire can damage the regulator or generator.

Gauge noise produces a "hissing" or "crackling" sound. Tapping the face of each gauge while the engine is running usually shows up which gauge is at fault. By-pass the gauge lead to ground with a 0.5-mFd capacitor, connected close to the sensing element.

Static and Arcing Noise


The following suggestions may help to cure other unusual types of interference:

1. Use bonding braid to electrically bond the hood and each corner of the engine block to the vehicle's frame. Scrape paint and dirt from bonding points to obtain a good ground.
2. Treat noisy tires with anti-static powder.
3. Use front-wheel static collectors for irregular "popping" noise which disappears when the brakes are applied.
4. Use heavily graphited penetrating oil on the exhaust pipe and muffler supports if they are producing noise.

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION
WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.

GENERAL  **ELECTRIC***
U.S.A.

* Trademark of General Electric Company, Inc.
Printed in U.S.A.



MECHANICAL PARTS BREAKDOWN

MASTR II "E" SERIES STANDARD COMBINATIONS

