

User's Manual

EDACS®
Duplex Portables
IPE-200

NOTICE!

This manual covers Ericsson and General Electric products manufactured and sold by Ericsson Inc.

NOTE!

Repairs to this equipment should be made only by an authorized service technician or facility designated by the supplier. Any repairs, alterations or substitution of recommended parts made by the user to this equipment not approved by the manufacturer could void the user's authority to operate the equipment in addition to the manufacturer's warranty.

NOTE

The software contained in this device is copyrighted by Ericsson Inc. Unpublished rights are reserved under the copyright laws of the United States.

This manual is published by **Ericsson Inc.**, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by **Ericsson Inc.**, at any time and without notice. Such changes will be incorporated into new editions of this manual. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of **Ericsson Inc.**

Copyright© May 1996, Ericsson Inc.

TABLE OF CONTENTS

INTRODUCTION	5
BASIC OPERATION	7
TURNING THE RADIO ON	7
PLACING AN INTERCONNECT CALL	8
Nobody Answers or You Hear a Busy or	
Fast Busy Tone	9
Last Number Re-Dial	9
A Call is Unsuccessful or a Call in Progress	
is Interrupted	10
ANSWERING AN INTERCONNECT CALL	10
Unanswered call Counter	10
PLACING AN INDIVIDUAL CALL	11
PLACING A GROUP CALL	11
PLACING AN EMERGENCY CALL	12
ANSWERING AN INDIVIDUAL CALL	12
VOLUME CONTROL	13
MUTE KEY	14
AIR TIME METER	14
TURNING THE UNIT OFF	15
DISPLAY, KEYPAD, AND AUDIBLE SIGNALS	15
DISPLAY	15
Alphanumeric Field	15
Numeric Field	15
Status Indicators	16
BUTTON	16
KEYPAD	17
MENU	18
Illumination	20
ALERT TONES	21
AUDIBLE SIGNALS	23
Ringing Signal	23
Error Signal	23
Malfunction Alarm Signal	23
ELECTRONIC LOCK AND CALL RESTRICTIONS	24
SETUP LOCK CODE	25
STORING NUMBERS	26
STORING A NUMBER (AND NAME)	26
MEMORY PROTECTION	28
MEMORY FULL	29
RECALLING NUMBERS	30

TABLE OF CONTENTS

Displaying Extended Digits	30
Alpha Recall	30
Recalling a Number by Entering the Memory Location	31
Appending Digits to a Recalled Number	32
Changing a Recalled Number	32
SPEED CALLING	32
ERASING A STORED NUMBER	33
RECALLING A NUMBER DURING A CALL	33
DTMF SIGNALING	34
DTMF SIGNALING USING THE KEYPAD	34
Pause Before Sending DTMF Signals	35
SYSTEM SELECTION	36
GROUP SELECTION	36
GROUP SCAN	37
ACCESSING USER MENU FUNCTIONS	37
MENU FUNCTION DEFINITIONS	38
BATTERIES AND RECHARGING	43
BATTERIES	43
Battery Level Indicator	43
Low Battery Alert	44
Care and Maintenance	44
Rechargeable Battery Pack Disposal	45
Inserting and Removing a Battery	46
RECHARGING	47
Using a Desk-Top Charger	48
Restoring Battery Capacity	49
APPENDIX 1	50
FAULT TRACING	50
No Power to the Radio	50
SERV Indicator Does Not Come On	50
Received Signal is Weak	50
A Call Cannot be Placed	51
"LOCKED" Is Displayed	51
WARRANTY	53

INTRODUCTION

This manual describes how to use the IPE-200 Portable Radios. The IPE (Infinity) is a synthesized, micro-processor-based, duplex portable FM radio providing reliable two-way communications in Enhanced Digital Access Communications System (EDACS) trunking environments.

Duplex is provided in EDACS systems while operating in the Telephone Interconnect Mode. At other times, the radio provides simplex communications, i.e. when placing group calls in the EDACS environment. In an EDACS trunked environment the user selects a communications system. In this mode, channel selection is transparent to the user and is controlled via digital communication with the system controller. This provides advanced programmable features and fast access to communication channels.


The exact operation of the radio depends on the radio mode, the operating mode, the radio's programming, and the particular radio system. Most features described in this manual may be enabled or disabled through programming. Consult the system administrator for the required features to be programmed into the radio.



BASIC OPERATION

TURNING THE RADIO ON




Turn the radio on by holding down the  key until you hear a beep.

The display illumination comes on. All the status indicators and all the segments in the alphanumeric and numeric fields in the display will flash 3 times.

The radio's LID number is displayed briefly.

Own Logical ID System Indicator Battery Level Indicator



A **battery level indicator** is shown in the upper right corner of the display. This can be a value from B0 to B5 in proportion to the battery's voltage level. You can read more about this in the chapter ***Batteries and Recharging***.

Once service is available from an EDACS system, the **SERV** (Service) indicator comes on and the **CC SCAN** goes off in the display.

Note the following points:

- If the **SERV** indicator does not come on, you have lost contact with the EDACS system and cannot, therefore, place or receive any calls. Refer to **Appendix 1** for further information.

PLACING AN INTERCONNECT CALL



1. Enter the desired number on the numeric keys. The digits are shown in the display.

If you enter a wrong digit or a wrong number:


Erase a wrong digit by pressing the **CLR** key momentarily. You may delete all wrong digits individually like this, or eliminate all entered digits by holding the **CLR** key for approximately 1 second. If you are not in a call, pressing the **END** key will also delete all entered digits.

2. When you have entered the number, press **SEND**.

The text "**DIALING**" shows in the display and the TX and BSY symbols come on.




The number dialed will remain in the display until any key is pressed, or the call is ended, at which time the minutes and seconds of the call will be displayed.



The left two digits show minutes, and the right two digits show the seconds (separated by two dashes).





3. When the conversation is finished, press .

Nobody Answers or You Hear a Busy or Fast Busy Tone

Press . The telephone number will be retained in the memory and you can easily repeat the call.

Last Number Re-Dial



Press , then  to scroll to the **RECALL** function. Then press , the word **LAST DIAL** will appear and the last dialed number will be displayed. Press  to place the call.


The last number called will remain in the memory even though the radio is turned off.


A Call is Unsuccessful or a Call in Progress is Interrupted


An error signal (a short beep) is heard. Refer to **Appendix 1** for further information.


ANSWERING AN INTERCONNECT CALL

When you are being called, the radio rings according to the setting in the Menu Mode. The backlight flashes Green while the word "**CALL**" also flashes in the display.



Press  to answer. The TX and BSY symbols will light up and **CALL** will be removed.



When the conversation is finished, press .

Unanswered call Counter

If one or more calls have not been answered, the number of unanswered calls will be displayed. For example, **02 CALLS**. The unanswered call counter will reset as soon as you press any key.


PLACING AN INDIVIDUAL CALL

1. Press the **# IND** key followed by the LID of the unit you wish to call. These digits are shown in the second line of the display.

If you enter a wrong digit or a wrong LID:

Erase a wrong digit by pressing the **CLR** key momentarily. You may delete all wrong digits individually like this, or eliminate all entered digits by holding the **CLR** key for approximately 1 second. If you are not in a call, pressing the **END** key will also delete all entered digits.

2. After you have entered the LID, press the [PTT] key. The text **"*INDV*"** will appear on the first line of the display.



3. When the conversation is finished, press the **END** key.

PLACING A GROUP CALL

To place an EDACS Group Call on the desired Group (refer to GROUP SELECTION for further information) simply press the [PTT] key and speak into the microphone.

PLACING AN EMERGENCY CALL

Press and hold the Emergency button for approximately 2 seconds. The Red LED will begin to flash and the work ***EMERG*** will appear in the display.

NOTE


This feature can be disabled in the radio's personality.


To clear an EMERGENCY (supervisory function only):



Select the Group where the Emergency is active. Press the Emergency button and then the **CLR** key. The radio will send the Clear Emergency message.

ANSWERING AN INDIVIDUAL CALL

When you are being called, the radio will beep every 5 seconds to alert you of the incoming call and will continue until any key is pressed. The backlight flashes while the word **"ICALL"** and the calling unit's LID flash in the display.



Press the [PTT] key to return the call, the flashing will stop. The TX and BSY symbols will turn on while transmitting. When the conversation is finished, press the  key.

Unanswered ICALLS will cause the WHC symbol to flash. The LID of the calling radio can be recalled by pressing  + .

VOLUME CONTROL




During a conversation you can adjust the volume of the earpiece with these keys. Press and hold to increase or decrease the volume. The volume of the keypad tones may be adjusted in the same manner when not in a conversation.

NOTE

There are separate volume levels for handheld & handsfree modes for both earpiece/speaker and the keypad tones.

NOTE

The volume level can also be adjusted by the VOLUME control knob.




The display will show a line of zeroes representing the volume level. This will remain as set, after the radio is turned off.

MUTE KEY

- Ⓜ During a conversation, the microphone can be deactivated by holding down the Ⓜ key. Release the Ⓜ key to resume the conversation.

AIR TIME METER

At end of a call, the elapsed air time, in minutes and seconds, is displayed for two seconds.






The air time of the outgoing call includes the time taken to connect the call.

NOTE

The air time meter is only a guide; actual billing time from your service provider may differ.


TURNING THE UNIT OFF



Press and hold down the  key until you hear a beep. If a call is in progress, end the call by pressing and releasing the  key, wait a few seconds, and then press and hold down the  key until you hear a beep.

DISPLAY, KEYPAD, AND AUDIBLE SIGNALS

DISPLAY



Alphanumeric Field

- Displays names and memory locations, etc.
- Displays messages, queries, and warnings.
- Displays "air time" at end of a call.
- Displays battery level indicator.

Numeric Field

Displays the telephone number entered on the keypad, or recalled from memory.

Status Indicators

EMG **Emergency.** Indicates that an emergency is declared on the current group.

SERV **Service.** Indicates control channel.

TX **Transmit.** Indicates unit is transmitting.

SCN **Scan.** Indicates Group has been added to Group Scan List. Flashing indicates scan function is turned on.

BSY **Busy.** Unit is active in some type of call. Shown during a call and also while an outgoing call is being connected.


WHC **Who Has Called.** Flashes to indicate that you received an Individual Call.




Battery. Flashes when battery reaches level B0.

BUTTON

PUSH-TO-TALK (PTT button) Located on side. Enables radio's transmitter. PTT must be held down to transmit during simplex operation.

MONITOR Located on side. Same function as  key on keypad except it will not turn scan on/off.

KEYPAD



END ON/OFF

If a call is in progress, pressing terminates the call. Otherwise you can turn the radio ON or OFF by holding down the key until you hear a beep. This key is also used to exit from any sub-mode and return to the standby mode. May also be used to delete all entered digits while outside of a call.



SEND

Places a call after a number has been entered, or recalled from the memory, and answers an incoming call.



MENU

This key has two different functions: 1) **MENU** and 2) **Mute Key**.


MENU



Press to select the Special Functions of the radio. Refer to chapter, ***User Menu Functions***.

Mute Key (Microphone Mute)



Hold down  to mute the microphone during a conversation. If the radio is used with hands free equipment, the separate microphone will be muted.

Volume Control



To change the volume simply press and hold up or down arrows until the desired level is reached. If the radio is in handsfree operation, the loudspeaker volume will be adjusted.



CLEAR

Press the key for either of the following functions.

1. If is pressed momentarily, it erases the last digit or letter entered. Clear can be executed repeatedly to erase several characters.
2. If is held down for at least one second, it erases all digits displayed, for example, a telephone number from the display.
3. Pressing will turn on/off Group Scan function.

Numeric Keys



...



Used to enter telephone numbers to be called, or stored in the memory.

Used to enter memory locations when recalling telephone numbers.



Used to scroll to an option within the menu function.

When in **Alpha** mode, letters and digits can be entered. Press the appropriate nu-

meric key once, twice, 3 or 4 times according to the position of the desired letter on the key. (Digit is fourth position).





Star

Used when entering an automatic **pause** before a sequence of digits that is to be sent in a cluster as DTMF signals. Press  and then, within two seconds, . Refer to the chapter, **DTMF Signaling**.

Used in **Alpha** mode to enter a space or a star.



Pound

Used when entering a manual **pause** before a sequence of digits that is to be sent in a cluster as DTMF signals. Press  and then, within two seconds . Refer to the chapter, **DTMF Signaling**.

Used when placing an Individual Call. Refer to PLACING AN INDIVIDUAL CALL.

Illumination


The display and keys are illuminated.

The light will be on if the phone is being dialed, or if a key has been pressed. After 10 seconds of inactivity the light will automatically turn off. See the chapter on **User Menu Functions** for further information on this option.


ALERT TONES

The IPE-200 radios generate a set of unique alert tones to indicate operating status. The following section identifies and describes the alert tones used in the Duplex radio for EDACS applications.



CALL ORIGINATE ALERT

If programmed, a short tone is sounded whenever the  key or PTT button is pressed and the radio has acquired a channel. This tone indicates the user may begin communications.


CALL QUEUED

If no tone is heard after the transmitter is keyed and the display flashes, this indicates that the system has placed the request in a queue. If the  key or PTT button is pressed while in queue, the radio autokeys (automatically keys) when a channel becomes available (see AUTOKEY).


AUTOKEY

When the  key or PTT button is pressed to place a call on the system, but is released before the channel is assigned (e.g. a queued call), the radio automatically keys on the channel when it gets the assignment. The radio generates a long beep and holds the transmitter keyed for two seconds. Pressing the  key or PTT button keeps the channel and sends the message before this two second time-out has expired.


SYSTEM BUSY

If after pressing  key or PTT button a short tone is heard and the words **SYS BUSY** appear on the display, this indicates that your calling party is either already on the system or the system queue is full. You must rekey later to access the system.

CALL DENIED

If after pressing  key or PTT button a short tone is heard and the word **DENIED** appears on the display, this indicates that the system has denied your request. This happens when either the caller or callee unit LIDs are not valid on the system.

OUT OF RANGE SYSTEM INOPERATIVE

A single tone sounds immediately after the  key or PTT button is pressed indicating the radio is out of range of the repeater. The radio tries to place the call for a short period (3 seconds) after the initial attempt. The radio generates a second low pitched tone when it gives up trying to place the call. The system is off the air or the radio needs servicing when the radio is within calling range, and these tones are heard. Observe the SERV icon and the CCSCAN display to determine when the system is in range and/or operational again.

AUDIBLE SIGNALS

Ringing Signal

The ringing signal sounds when a call is received. It will be repeated until the call is answered or is terminated by the system.

There is a special function to allow you to set the volume of the ringing signal. The ringing volume can be set to one of several different signals. See the chapter ***User Menu Functions***.

Error Signal

A short beep tells you have done something incorrectly. For example, if you try to store a telephone number in a memory location that is already in use, or if you try to place a call when the **SERV** indicator is not present in the display.

Malfunction Alarm Signal

A long beep will be heard if:

- The attached battery is becoming exhausted. The warning **LOW BATT** will also flash in the display. Refer to the chapter ***Batteries and Recharging***.

ELECTRONIC LOCK AND CALL RESTRICTIONS

In this function the radio may be locked completely, except for emergency calls. One of a number of call restrictions for the user may also be selected. The 4-digit personal Code may also be changed from this function.

IMPORTANT

The radio is factory programmed with a lock code of **0000**. To improve security, enter a personalized four digit code by using the **ALTER CODE** option.






An option is set by entering the menu, toggling to the right alternative and pressing **M**. The telephone then prompts for the personal code. If the right code is entered, the option is set. (To change the personal code, the code must be entered, then the new code must be entered and verified).

When the radio is completely locked, the option **LOCK AUTO** is set and the text **LOCKED** is shown in the display. If the right 4-digit code is entered the text **UNLOCKED** will be displayed for 5 seconds and the lock is temporarily removed. When the phone is powered off, the lock becomes active again.

The only way to permanently remove the lock is to enter this menu and select another option. If the option **LOCK OFF** is set, no restriction is active.

If an incorrect personal code is entered, **WRONG CODE** appears in the display and the display returns to manual standby mode.

SETUP LOCK CODE


1. Press  twice.
2. Press  key to scroll to **LOCK**.
3. Press any digit key (1-9) to scroll to **ALTER CODE**.
4. Press .
5. Enter OLD code.
6. Enter NEW code.
7. Enter NEW code (to verify new code).
8. Press  to store new code.
9. Press  to exit from menu function.


STORING NUMBERS




You can store often used telephone numbers in the radio's memory, both when the radio is in standby mode and during a conversation. Numbers can be stored with, or without, an accompanying name.


A number to be stored may contain up to 32 digits, and a name up to 8 letters, including spaces. Up to 25 numbers may be stored depending on the number of systems and groups already configured.

STORING A NUMBER (AND NAME)

1. Enter the telephone number you wish to store. If you make a mistake, you can erase a wrong digit by pressing the  key.




2. Press . Then press  to scroll to STORE --. Press  and the word **STORE** is displayed, followed by the first free memory location, for example 22.




3. To store the number in this memory location, go to step 5.
4. To store the number in a different memory location, enter the number of the memory location, for example 11.

1oz

1oz



5. Press **M** again. The question **NAME?** appears. This indicates that you can now enter an accompanying name if you wish to do so.



6. Enter the first letter of the name. Pressing a different key or waiting for one second will move the cursor to the next position. You can enter up to **eight** letters.
 - To enter a letter, press the appropriate numeric key once, twice, or three times, depending on the position of the letter on the key.
 - To enter a number, press the appropriate numeric key four times.

- Star (★ PHN) toggles between "*" and "space" in the alpha mode.
 - Pound (# IND) toggles between "#" and "-" in the alpha mode.
 - If you make a mistake, correct it by pressing the (CLR) key.
7. When you have entered the entire name, press (M). The number and name are stored.


NOTE

If you do not wish to enter a name, press (M) when the question **NAME ?** appears. The number will then be stored without a name.

If you do not press (M), the number (and name) will be stored automatically after about 20 seconds.

MEMORY PROTECTION

If you try to store a number in a memory location which already contains a number, a short beep is heard and the word **USED** flashes in the display for five seconds.




You can choose either to:

- a. Store the number in a different memory location. Enter the number of the memory location and press **(M)**.
- b. Store the number under the selected memory location, thus **erasing** the old number (and name). Just press **(M)**.

MEMORY FULL

If, when you attempt to store a new number, all memory locations are in use, **STORE ? - -** is displayed.





If you do not wish to store the number, press the **(END)** key or the **(CLR)** key.

If, on the other hand, you do wish to store the number, you can do the following:

Store the number in an already occupied memory location, thus erasing the old number (and name). Enter the required memory position and press **(M)**.

RECALLING NUMBERS




There are two ways of calling a stored number. You can either recall the number so that it appears in the display and then call it by pressing , or if you are certain of the memory location, enter the memory location and press just  (speed calling).


Displaying Extended Digits

If you recall a telephone number which has thirty-two (32) digits, the number will be displayed in blocks of numbers starting with the first two (2) digits, followed by the next ten (10) digits, the next ten (10) digits, and then the last ten (10) digits.

Alpha Recall

Only applies to telephone numbers stored with an accompanying name.


1. Press . Press  to scroll to **RECALL --**. Press  twice and the work **LETTER -** appears.






2. Enter the first letter of the name by pressing the relevant numeric key once, twice or three times, depending on the position of the desired letter.




3. The first name match will be displayed.




4. If the desired name is not displayed, scroll through the names by holding down the  key until you find it. The names will be sorted alphabetically. If you scroll past the name you can go backward by repeatedly pressing the  key.




5. To place a call, press .



Recalling a Number by Entering the Memory Location


1. Press . Press  to scroll to **RECALL--**



2. Enter the memory location (one or two digits).
The number (and name) appears in the display.




If you are **uncertain** of the memory location, enter a **lower** memory location and then scroll forward by holding down the  key until you find the number. If you scroll too far, you can go backward by repeatedly pressing the  key.

3. To place the call, press .


Appending Digits to a Recalled Number


If you have stored a partial number you can recall it from the memory and then append the remaining digits.


Changing a Recalled Number

A telephone number recalled from the memory can be altered by erasing the last digits using the  key, and then entering new digits.

SPEED CALLING






A stored number can be called by just entering the memory location (one or two digits) and pressing . The number appears in the display.



If you called a wrong number, you can press  before the call has been connected.

ERASING A STORED NUMBER

A stored number (and name) will be erased automatically if you store a new number in the same location. However, you can erase a number without replacing with a new number, by proceeding as follows:

1. Press  key and hold for approximately 1 second to erase any entered digits.
2. Press . Press  to scroll to **RECALL--**.
3. Enter the desired location, for example **22**. Press . The warning message "**USED**" flashes for 5 seconds.
4. Press  again. The message "**CLEARED 22**" is displayed for 5 seconds, and the number (and name) stored in location 22 are now erased.

RECALLING A NUMBER DURING A CALL

You may recall a memory location during a call. The number in that location may then be sent using **DTMF** (Dual Tone Multi-Frequency) tones. See the chapter on **DTMF Signaling** for further information.

DTMF SIGNALING

You can use your telephone to send DTMF (Dual Tone Multi Frequency) signals to perform banking by phone, controlling answering machines , and other functions.

DTMF SIGNALING USING THE KEYPAD

If click sounds, or nothing, are heard when you press the keys, use the menu function to select **KEY BURST** or **KEY CONT** to turn the key tones on. Refer to the chapter *User Menu Functions*.

If you select the **Burst** option, a tone of fixed length will sound when you press a numeric key.

With the **Continuous** option, a tone will sound as long as a numeric key is pressed.



If you select the "Clicks" option, you will hear keyclicks in the speaker, but DTMF tones will be transmitted.

To send DTMF signals:

1. Call the desired number.
2. When the call has been connected, pressing keys **0 - 9**, *****, and **#** will cause the corresponding DTMF signals to be sent.

Pause Before Sending DTMF Signals



You can also pause during transmission of a DTMF string to acknowledge handshaking with the called device, or system. Some automatic voice response systems may require pauses to facilitate entering digits in response to system commands.

An automatic two (2) second pause is entered by pressing  (Function) followed within two seconds by . A pause appears in the display as a "P".

Several pauses can be entered to separate different codes, for example:

<Tel. No.> **P** <Code 1> **P** <Code 2> **P** <Code 3>.

You can enter a maximum of 32 characters, including the pauses.

Pressing  and , during a call, will send the characters up to the first pause. After approximately two (2) seconds transmission will begin again until another pause is encountered. This will continue until the entire sequence has been sent.

SYSTEM SELECTION




To select the EDACS system for operation from the available systems stored by PC programming, the menu function is used.

1. Press **M**. Then use the **↻** key to scroll to **SYS-TEM**. The current system will be displayed.
2. Press any digit key (1-9) to scroll through the list of pre-programmed systems. Press **M** to store desired selection. The word **STORED** will appear in the display to indicate that a new system has been selected.
3. Press **END RUN** to exit from the menu function.


GROUP SELECTION

EDACS group selections are also made through the user menu.

1. Press **M**. Then use the **↻** key to scroll to the GROUP menu. The current Group will be displayed.
2. Press any digit key (1-9) to scroll through the Group Set for the currently selected System. Another press of the **M** key will store the new selected group.








3. While scrolling, the  key is used to add the Group to the Group Scan List, the SCN symbol will indicate the Group has successfully been added. The  key is used to delete the Group from the Group Scan List.
4. Press the  key to exit from the user menu.

GROUP SCAN

To enable Group Scan press  key. The flashing SCN symbol will indicate that the scan function is turned on. All groups previously entered into the Group Scan List will be monitored.

ACCESSING USER MENU FUNCTIONS

To access the user menu functions:

1. Press .
2. Press  to scroll forward or  to scroll backward to select desired function.
3. Press any digit key (1-9) to select an option within a function.
4. Press  to store desired option.
5. Press  or  to continue to scroll through menu function or press  to exit menu.

MENU FUNCTION DEFINITIONS

Menu Position	Function
1	Store telephone number (name)
2	Recall telephone number (name)
3	Select system
4	Group Selection
5	Electronic Lock
6	Battery Saver
7	Ring Volume
8	Ring Tone
9	LCD contrast
10	Key Burst, Tones, Clicks
11	Backlight Selector
12	Bat. Voltage
13	Pers Program
14	Resettable Accumulated Call Time
15	Last Call Time

(1) STORING NUMBERS (and names): Lets you store telephone numbers (names) in memory.

Default: STORE --

STORE --: Store number in memory by entering memory location and then pressing **(M)**.

NAME: Stores name associated with stored number.

(2) RECALL NUMBERS (and names): Lets you recall telephone numbers (names) from memory.

Default: RECALL --

RECALL --: Recall number from memory by entering memory location and then pressing **Ⓜ**.

LAST DIAL: Recall last number dialed by scrolling forward with **↻** key and then pressing **Ⓜ**.

LETTER-: Recall number from memory by entering names.

(3) SYSTEM SELECTION: Lets you select the system operation.

Default: Current System

Use any digit key (1-9) to scroll through the list of programmed systems. Press **Ⓜ** to select new systems.

(4) GROUP SELECTION: Allows selection of different EDACS Groups.

Default: Current Group

Use any digit key (1-9) to scroll through the current Group Set. Press **Ⓜ** to store the selected group.

(5) ELECTRONIC LOCK: Lets you lock the radio to restrict unauthorized use and enter personal lock code.

Default: LOCK OFF

LOCK OFF: No restrictions, the radio can send and receive calls.

LOCK AUTO: The radio can receive calls only. The Keypad is "locked" automatically at power on.

ALTER CODE: Allows you to change your personal lock code.

(6) BATTERY SAVER: Lets you select the amount of battery savings.

Default: NORMAL

NORMAL: Radio achieves 33 hours of standby on a single charge.

EXTENDED: Radio achieves 40 hours of standby on a single charge.

OFF: Radio achieves 16 hours of standby on a single charge.

(7) RING VOLUME: Lets you select the ring volume signal.

Default: RING HIGH

Note: One ring signal is sounded for each corresponding Ring Volume displayed.

RINGSILENT: Ring signal is silent. the low battery warning only clicks once.

RING LOW: Ring signal is continuous and low.

RING MED: Ring signal is continuous and medium.

RING HIGH: Ring signal is continuous and high.

RING STEP: Ring signal is stepped and low.

(8) RING TONE: Lets you select the ring tone frequency.

Default: TONE HIGH

Note: One ring signal is sounded for each corresponding Ring Tone displayed.

TONE LOW: Frequency tone is low.

TONE MED: Frequency tone is medium.

TONE HIGH: Frequency tone is high.

TONE MIXED: Frequency tone cycles through the high, medium, and low tones.

(9) LCD CONTRAST: Lets you set the LCD display contrast.

Default: LCD LOW

LCD LOW: Display contrast is low.

LCD MEDIUM: Display contrast is medium.

LCD HIGH: Display contrast is high.

(10) KEY BURST, TONES, OR CLICKS: Lets you select whether keypad numeric keys (0-9, #, *) produce DTMF tones or key clicks.

Default: KEY CONT.

KEY BURST: Burst mode avoids double-digitting error. The radio signal may drop out very briefly when you make a call in motion. This drop out can cause equipment to interpret two or more digits when you only press one. Select this mode if you experience a double digit error often.

KEY CONT: Some answering machines require continuous mode. Select this mode if you are having difficulty controlling answering machines.

KEY CLICK: Click mode sends the digits as a DTMF click as opposed to a DTMF tone.

(11) BACKLIGHT SELECTOR: Keypad or display illumination to be automatic or switched off.

Default: LIGHT AUTO.

LIGHT AUTO: The illumination comes on for ten seconds after any key is pressed. The illumination stays on continuously if the radio is mounted in a car kit and turned on.

LIGHT OFF: The illumination is off at all times.

(12) BATTERY VOLTAGE: Shows the input battery voltage to the radio (for example, 6-3 = 6.3 volts).

(13) PERS PROG: PC personality programming mode.

(14) RESETTABLE ACCUMULATED CALL TIME: Displays accumulated call time, in hours and minutes, since last reset.

ACCUM TIME: Displays the accumulated time.

RESET?--RCL: Resets to zero by pressing key.

(15) LAST CALL TIME: Displays "air time" of last call in minutes and seconds.


BATTERIES AND RECHARGING

BATTERIES


The Ericsson IPE-200 is designed for use with high quality Ericsson batteries provided in the package. Use of other batteries should be avoided as it may be hazardous and may result in voiding your radio's warranty.

Battery Level Indicator


A number from B0 to B5, based on the battery level is shown on the right of the display. A fully charged battery will show B5. A battery which is almost discharged will indicate B1 or B0.



Low Battery Alert



Your radio should typically provide ninety (90) minutes of continuous talk-time before needing to be recharged.

An alert tone sounds for a short time and the message **LOW BATT** flashes in the display. The  symbol will also flash.

If the radio is left on, the low battery alert will sound and, eventually, the radio will turn itself off.

If the low battery alarm sounds while a call is in progress, you should end the call as quickly as possible. If the call continues, the radio will turn itself off after a short period.


Care and Maintenance

The batteries are of Nickel Metal Hydride type. They have a long maintenance-free service life if properly treated.

- Discharge battery completely before recharging.
- **Never** let a battery get into contact with metal objects that may short-circuit the battery poles, for example a bunch of keys in a pocket.

- **Do Not** disassemble a battery.
- A battery may explode if disposed of in a fire.
- Use only Ericsson specified batteries and chargers.

Rechargeable Battery Pack Disposal




The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal. Call Toll Free 1-800-8-BATTERY for information and/or procedures for returning rechargeable batteries in your state.


Inserting and Removing a Battery

Standard Battery

Removal:



Insertion:



RECHARGING


Your charger is intended for indoor use only. Keep charger and AC adaptor dry. **Do not** use in or near water.

Avoid recharging a battery before the low battery alert is displayed.

Never recharge a battery when the ambient temperature is below 5°C or 40°F, or above 40°C or 105°F.

The LED on the charger will indicate that charging is in progress. Remove the battery when the LED turns green. Do not leave the battery in the charger for more than 48 hours. Over-charging may reduce battery life.

Using a Desk-Top Charger



1. Connect the AC Adapter to the desk-top charger.
2. Plug the AC adapter into a wall outlet.
3. Remove the battery from the radio and lay it on the desk-top charger, radio side down. For longest battery life, remove the battery after charging.

Restoring Battery Capacity

If you often recharge a battery before the low battery alarm has been issued, the battery's ability to accept charge may be impaired. This will result in less and less time between recharges. To restore the battery, perform the following:

1. Use the radio as you normally would, until the low battery alarm has been issued.
2. Allow the radio to remain on until it turns itself off.
3. Charge the battery using the desk-top charger.


After discharging and recharging the battery this way, it can be used for a longer period before the next recharge is required. To get the longest period between charges, repeat this procedure 3 or 4 times.

Also if a battery has not been used for several months, it may require 3 or 4 charge-discharge cycles to return to full capacity.

APPENDIX 1

FAULT TRACING

No Power to the Radio

- If the radio does not come on when you hold down the  key, recharge or replace the battery. Refer to the chapter ***Batteries and Recharging***.

SERV Indicator Does Not Come On

You have lost contact with the EDACS system and you cannot place any calls. The reason for this is either:

- The received signal is too weak. See the next section, ***Received Signal is Weak***
- You are in an area which is not covered by the EDACS system selected.

Received Signal is Weak

If the radio displays **CC SCAN** often, move the radio to obtain a stronger signal.

- Large obstacles such as buildings, hills and mountains can drastically affect the signal strength and you may have to move to obtain a sufficiently strong signal.
- Indoors, it is usually best to use the radio near a window.

A Call Cannot be Placed


The reason for this is either:

- The phone number displayed may be incorrect.
- The radio may not be in service or the signal is weak. See the prior sections.
- The EDACS system you are using requires or does not allow the phone number to be preceded by a "1" or the area code. Try various combinations or contact the operator for more information.
- You are roaming and the EDACS system you are using doesn't have a roaming agreement with your home system.

"LOCKED" Is Displayed

The radio is locked to prevent unauthorized use.

To unlock:

1. If anything is shown on the numeric field of the display, erase it with the  key.
2. Enter the 4-digit code **lock code**. **UNLOCKED** will be displayed briefly.

PERSONAL MEMORY DIRECTORY

Mem. Loc.	Name	LID or Tel. No.
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		

WARRANTY

- A. Ericsson Inc. (hereinafter "Seller") warrants to the original purchaser for use (hereinafter "Buyer") that Equipment manufactured by Seller shall be free from defects in material, workmanship and title, and shall conform to its published specifications. With respect to any Equipment not manufactured by Seller (except for integral parts of Seller's Equipment to which the warranties set forth above shall apply). Seller gives no warranty, and only the warranty, if any, given by the manufacturer shall apply. Batteries are excluded from this warranty.
- B. Seller's obligations set forth in Paragraph C below shall apply only to failures to meet the above warranties (except as to title) occurring within the following periods of time from date of sale to the Buyer and are conditioned on Buyer's giving written notice to Seller within thirty (30) days of such occurrence:
1. for fuses, incandescent lamps, vacuum tubes and non-rechargeable batteries, operable on arrival only.
 2. for parts and accessories (except as noted in B.1) sold by Seller's Service Parts Operation, ninety (90) days.
 3. for all other Equipment of Seller's manufacture, one (1) year.
- C. If any Equipment fails to meet the foregoing warranties, Seller shall correct the failure at its option (i) by repairing any defective or damaged part or parts thereof, or (ii) by making available at Seller's factory any necessary repaired or replacement parts. Any repaired or replacement part furnished thereunder shall be warranted for the remainder of the warranty period of the Equipment in which it is installed. Where such failure cannot be corrected by Seller's reasonable efforts, the parties will negotiate an equitable adjustment in price. Labor to perform warranty service will be provided at no charge only for the Equipment covered under Paragraph B.3, and only during the first three (3) months following the date of sale to the Buyer. Thereafter, labor will be charged at prevailing rates. To be eligible for no-charge labor, service must be performed by an Authorized Service Center or other Services approved for these purposes either at its place of business during normal business hours, for mobile or personal equipment, or at the Buyer's location, for fixed location equipment. Service on fixed location equipment more than thirty (30) miles from the Service Center or other approved Service's place of business will include a charge for transportation. Equipment located off-shore is not eligible for no-charge labor.
- D. Seller's obligations under Paragraph C shall not apply to any Equipment, or part thereof, which (i) has been modified or otherwise altered other than pursuant to Seller's written instructions or written approval or, (ii) is normally consumed in operation or, (iii) has a normal life inherently shorter than the warranty periods specified in Paragraph B, or (iv) is not properly stored, installed, used, maintained or repaired, or, (v) has been subjected to any other kind of misuse or detrimental exposure, or has been involved in an accident.
- E. The preceding paragraphs set forth the exclusive remedies for claims (except as to title) based upon defects in or nonconformity of the Equipment, whether the claim is in contract, warranty, tort (including negligence), strict liability or otherwise, and however instituted. Upon the expiration of the warranty period, all such liability shall terminate. The foregoing warranties are exclusive and in lieu of all other warranties, whether oral, written, expressed, implied or statutory. **NO IMPLIED OR STATUTORY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE SHALL APPLY. IN NO EVENT SHALL THE SELLER BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, INDIRECT OR EXEMPLARY DAMAGES.**

This warranty applies only within the United States.
1-800-528-7711 (outside U.S.A., 804-528-7711)

NOTES

NOTES

Emergency Numbers

Police

State Police

Fire

Poison Control

Ambulance

Life Saving & Rescue Squad

Ericsson Inc.

Private Radio Systems

Mountain View Road

Lynchburg, Virginia 24502

1-800-528-7711 (Outside USA, 804-528-7711)

AE/LZT 123 1907 R1A

Printed in U.S.A.