

Maintenance Manual

GPS Simulcast Transmit Site

Volume 1

COMMON EQUIPMENT

Table Of Contents

<u>Tab</u>	<u>Description</u>	<u>Publication</u>
1	Site Grounding	LBI-39067
2	Electrostatic Discharge Protection	LBI-38737
3	GPS Simulcast System Drawings	LBI-39208
	GPS Simulcast Tx Site Cable	
	Drawings	LBI-39216
	Simulcast Cable Drawings	LBI-38878
4	Simulcast Equipment Rack	LBI-39217

NOTE

Repairs to this equipment should be made only by an authorized service technician or facility designated by the supplier. Any repairs, alterations or substitution of recommended parts made by the user to this equipment not approved by the manufacturer could void the user's authority to operate the equipment in addition to the manufacturer's warranty.

NOTICE!

The software contained in this device is copyrighted by Ericsson Inc. Unpublished rights are reserved under the copyright laws of the United States.

This manual is published by **Ericsson Inc.**, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by **Ericsson Inc.**, at any time and without notice. Such changes will be incorporated into new editions of this manual. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of **Ericsson Inc.**

Copyright© November 1996, Ericsson Inc.

Ericsson Inc.
Private Radio Systems
Mountain View Road
Lynchburg, Virginia 24502
1-800-592-7711 (Outside USA, 804-592-7711)

Printed in U.S.A.