

QT1 TONE FREQUENCY PROGRAMMING

TONE FREQ	Jumpers - "X" jumper in place, "0"= no jumper					
(Hz)	P5	P4	P3	P2	P1	P0
67.0	0	0	0	0	0	0
69.3	0	0	0	X	X	0
71.9	X	0	0	0	0	0
74.4	0	0	0	0	0	X
77.0	X	X	0	0	0	0
79.7	0	0	0	0	X	0
82.5	X	0	0	0	0	X
85.4	0	0	0	0	X	X
88.5	X	X	0	0	0	X
91.5	0	0	0	X	0	0
94.8	X	0	0	0	X	0
97.4	0	0	0	X	0	X
100.0	X	X	0	0	X	0
103.5	X	0	0	0	X	X
107.2	X	X	0	0	X	X
110.9	X	0	0	X	0	0
114.8	X	X	0	X	0	0
118.8	X	0	0	X	0	X
123.0	X	X	0	X	0	X
127.3	X	0	0	X	X	0
131.8	X	X	0	X	X	0
136.5	X	0	0	X	X	X
141.3	X	X	0	X	X	X
146.2	X	0	X	0	0	0
151.4	X	X	X	0	0	0
156.7	X	0	X	0	0	X
159.8	0	0	X	X	X	0
162.2	X	X	X	0	0	X
167.9	X	0	X	0	X	0
173.8	X	X	X	0	X	0
179.9	X	0	X	0	X	X
183.5	0	0	X	X	0	X
186.2	X	X	X	0	X	X
189.9	0	0	X	X	0	0
192.8	X	0	X	X	0	0
196.6	0	0	X	0	X	X
203.5	X	X	X	X	0	0
210.7	X	0	X	X	0	X
218.1	X	X	X	X	0	X
225.7	X	0	X	X	X	0
233.6	X	X	X	X	X	0
241.8	X	0	X	X	X	X
250.3	X	X	X	X	X	X