

PARTS LIST

LBI-4481D

LBI4481D

TRANSISTORIZED DYNAMIC MICROPHONE
19C320270G1, G2
(SEE RC2454)

(Also see LBI-4840)

SYMBOL	GE PART NO.	DESCRIPTION
1	RP127	Front Case Assembly. (INCLUDES ITEMS 14, 15).
2		Retaining spring. (Part of item 18).
3		Tap screw, phillips. (Part of item 16).
4		Retaining bar. (Part of item 16).
5	19D416766P1	Connector base.
6	19A129435P1	Contact.
7	19A701289P1	Retaining ring.
8	19D416767P1	Connector cover.
9	19B219723G1	Thumb screw: Lexan.
10	N136AP905Y6	Tap screw, phillips: No. 4 x 5/16.
11	19A116937P1	Cable clip.
12	19B219749P1	Strain relief.
13	RP126	Switch button kit.
14		Rear Case Assembly. (Part of item 1).
15		Tap screw, phillips. (Part of item 1).
16	19C321016G1	Cable assembly: Includes items 3-12 and cable RP129.
17	RP128	Switch Assembly.
18	RP130	Grille Assembly. (includes items 2, 19, 21).
19		"O" Ring. (Part of item 18).
20	RP117	Transistorized Cartridge.
21		Washer. (Located under cartridge- part of item 18).
22	19C321016G3	Connector assembly: Includes items 5-12.

*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.



