

# INSTALLATION

**PROGRESS LINE** 

Professional Series

General Electric MASTR Progress Line features ruggedly constructed Two-Way Mobile Radios with unusually flexible mounting possibilities. The Two-Way Radio locks into a steel mounting frame to provide an exceptionally stable mobile installation.

## MTS MOBILE COMBINATIONS

LB1-8632A DF-9017



**CONTROL UNIT** 

## TRUNK MOUNT





#### TRUNK-MOUNTING HARDWARE



#### **ACCESSORIES**

FUSE ASSEMBLY



ANTENNAS 132-470 MHz 25-88 MHz



POWER CABLE

18-FOOT (TRUNK MOUNT) 23-FOOT (OPTIONAL)





## UNPACKING AND CHECKING EQUIPMENT

Carefully unpack the Two-Way Radio. It is recommended that you identify the items in the packing case and check them off in the appropriate column below before discarding the packing material. If any damage has occurred to the equipment during shipment, file a claim with the carrier immediately.

| EQUIPMENT   | TRUNK | EQUIPMENT   | TRUNK         |
|---|-------|---|---------------|
| MASTR Progress Line Two-Way Radio   |       | Front Panel<br>Trunk Mount 19B204417P1_                                       | П             |
| Control Unit Type EC-75A or B   |       |   | _             |
| Handset 4038824P1   | П     | Key 5491682P8   |               |
| Antenna, Cable and RF Connector (25-88 MHz antenna whip shipped in separate carton) |       | Alignment Tools (2)   |               |
|   |       | OPTIONAL EQUIPMENT  | OPTION NUMBER |
| Fuse Assembly   |       | 23-Foot Control Cable Multi-Frequency 19D4027060 23-Foot, 12-Volt Power Cable | G25807        |
| Mounting Frame 19C303430G1  | П     | 19C303601G2   | 7083          |
| Trunk Mounting Hardware 19A121626G2   |       | Ledge-Mounting Hardware Kit   | 7002          |
| 12-Volt   |       | 5-Watt Speaker Model 4EZ20A1  | 15809         |
| Battery Cables (2)  |       | Trunk Mount Spacer Kit<br>19A121884G1   | 7082          |
| Trunk Mount Power Cable   |       | Channel Jewels 19A122416G1_   | 5818          |
| 18-Foot Control Cable 19D402706G1   |       |   |               |

### PLANNING THE INSTALLATION

The accompanying photograph of a typical MASTR installation should help you in planning your installation. Suggestions for locating and installing the units are given with the following installation instructions.

Before starting, plan your installation carefully
—so that it will be:

- Convenient for the operator to use
- Neat
- Protected from damage from water
- Easy for the serviceman to service

- Out of the way of auto mechanics
- Out of the way of passengers

It is suggested that you take advantage of the experience of one of the many authorized General Electric Service Stations located throughout the United States by having them install your Two-Way Radio and make the final adjustments.

#### TRUNK-MOUNT INSTALLATION

Trunk-Mount Combinations are designed so that the Two-Way Radio can be mounted up to 18 feet from the operator (23 feet with option cables), such as in the trunk compartment or under the seat of a vehicle. The Control Unit mounts on the instrument panel of the vehicle.








Fig. 2—Two-Way Radio Mounting




Fig. 3-Mounting Dimensions

#### **EQUIPMENT REQUIRED**

The equipment required for installing the MASTR Two-Way Radio are

- Electric drill for drilling mounting holes
- Drills and circle cutters (see sizes in box below)
- Soldering iron for systems connector and antenna
- Phillips and flat-blade screwdrivers, and %-inch hex head driver for mounting screws.

#### **DRILL SIZES**

#36 (7/64-inch) Drill for #6 Self-Tapping Screws.

#32 (1/8-inch) Drill for #8 Self-Tapping Screws.

#29 (9/64-inch) Drill for #10 Self-Tapping Screws.

#9 (3/16-inch) Drill for #14 Self-Tapping Screws.

9/32-Inch Drill for Lo-Band Antenna and ¼-inch bolt.

3/8-Inch Drill for Hi-Band Antenna.

1%-Inch Circle Cutter, Holesaw or Socket Punch for Lo-Band Antenna.

78-Inch Circle Cutter, Holesaw or Socket Punch for Rubber Grommet.

#### **RUNNING CABLES**


To assure the feasibility of the cable routings you plan to use, it is suggested that you run the cables before mounting the Two-Way Radio. Be sure to leave some slack in each cable going to the Control Unit and Trunk Mount Unit so that they may be pulled out for servicing with the power applied.

Try to route the cables away from locations where they will be exposed to heat, battery acid, sharp edges, or mechanical damage or where they will be a nuisance to automobile mechanics, the driver, or passengers. Keep wiring away from ignition circuits to help prevent noise pickup in the radio epuipment.

In addition, try to utilize existing holes in the firewall and trunk wall and the channels above or beneath the doors. You may also use the channels through door and window columns, where they are convenient for running cables, unless you plan to install rigid or flexible conduit in which to run the cables.

If an existing hole is not conveniently located for the passage of the Power Cable through the firewall, drill a %-inch hole and insert the rubber grommet provided. Refer to Figure 4 and to the CABLING DIAGRAMS (Figures 5 and 15) for additional information.

If an existing hole is not conveniently located for the passage of the Battery Cable In-Line Fuse holder through the firewall, drill a 1½-inch hole and insert the rubber grommet provided. Refer to Figure 4 and to the CABLING DIAGRAM (Figure 15) for additional information.



TRUNK MOUNT

#### POWER AND CONTROL CABLES (TRUNK MOUNT ONLY)

It is preferable to run the Power and Control Cables on opposite sides of the vehicle to minimize noise coupling. Leave at least 18 inches of slack in the female-plug ends of the cables at the location for the Two-Way Radio.

- Run the ring-terminal end of the Power Cable to the vicinity of the battery.
- 2. Run the Control Cable to the vicinity of the Control Unit.
- Use the 3-inch cable straps and #6 self-tapping screws provided in the Basic Mounting hardware to secure the cables neatly in place. See Figure 5.




Figure 5—Installing Cable Straps

#### **FUSE ASSEMBLY**

Remove the Fuse from the block and mount the Fuse Assembly in the engine compartment of the vehicle, within reach of the 3-foot Battery Cables.

Replace the Fuse after connecting the Battery and Power Cables as shown in Figure 6.






Fig. 6-Installation, Battery and Power Cable Connections to Fuse Assembly

Figure 7—Connections for 12-Volt Ignition Switch Cables

Power to the radio can be controlled by one of the two methods described below. Select the type of control desired, and connect the Ignition Switch cables as directed.



Transmitter and receiver will operate only with ignition switch in ACCESSORY or ON position.
Turning ignition switch OFF removes all power to the radio.




7

#### TRUNK-MOUNT TWO-WAY RADIO

The Two-Way Radio may be mounted horizontally, vertically or on its side. Select a mounting location with sufficient room for the radio to be pulled out of the mounting frame for servicing. Mount the Two-Way Radio as shown in Figure 8

Figure 8—Installing the Trunk-Mount Radio










(5) PLUG IN POWER AND CONTROL CABLES. LEAVE FRONT PANEL OFF UNTIL ANTENNA IS INSTALLED AND ALL CONNECTIONS ARE MADE TO THE VEHICLE SYSTEMS PLUG. THEN CONNECT ANTENNA AND SYSTEMS PLUG AND ATTACH FRONT PANEL WITH TWO KNURLED SCREWS.



ANT JACK CAN BE TILTED

TOWARD POWER

JACK FOR EASIER

CONTROL

POWER ANT JACK

#### **CONTROL UNIT**

In Trunk-Mount installations, the Control Unit should be mounted within convenient reach of the operator, and located so that it will not interfere with safe operation of the vehicle. Normally, the Control Unit is mounted on the underside and in the middle of the instrument panel. Use the bracket as a template for locating three mounting holes. Leave room for access to controls on rear of unit. Mount the Control Unit as shown in Figure 9. After mounting the unit, plug in the Control Cable and secure by means of the cover plate.




Fig. 9




Fig. 10

#### **ANTENNA**

Installation instructions for the High-Band and Low-Band Antennas are packaged with the antenna. The antenna must be installed in accordance with good engineering practice for optimum results.

- For the 132-470 MHz antenna, the most effective mounting position is usually in the center of the roof of the vehicle. The antenna cable will normally run from the front of the Two-Way Radio, behind sections of the interior trim to a door or window post, and then up between the roof and header in the passenger compartment to the antenna base.
- For the 25-88 MHz antenna, the most effective mounting position is usually on the driver's side of the vehicle near the top of the left rear fender or body of the vehicle.

Try to route the cable away from locations where it will be exposed to heat, sharp edges or mechanical damage, and where it will be out of the way of the driver, passengers or vehicle mechanics. Wherever possible, existing holes in the trunk wall, and the channels above or beneath doors and window columns should be utilized.

#### NOISE SUPPRESSION

The Noise Suppression instructions are shown for information purposes only. Components shown are available in ignition noise suppression Kit PL-4035219-G1.





Fig. 11
IGNITION CIRCUIT WITH NOISESUPPRESSION COMPONENTS



If the vehicle does not have a resistance lead from the coil to the center of the distributor cap, disconnect the lead at the distributor and insert a cable-type suppressor close to the distributor. Never cut the lead to insert a suppressor.

Fig. 12
IGNITION COIL SUPPRESSION






Fig. 13 GENERATOR CIRCUIT WITH NOISE-SUPPRESSION COMPONENTS



tor.

**REGULATOR** LATOR.


FOR MORE EFFECTIVE NOISE SUPPRESSION THE CAPACITOR AND RESISTOR CONNECTED TO THE FIELD TERMINAL MAY BE MOUNTED INSIDE THE REGU-



- CAUTION -

IF REGULATOR IS OPENED TO INSTALL THE CAPACITOR AND RESISTOR, REMEMBER THAT ONE WRONG CONNECTION OR SHORTED WIRE CAN DAMAGE THE REGULATOR AND GENERATOR.

Fig. 14 GENERATOR CIRCUIT INSTALLATION DETAILS



## -9017

### PLACING THE TWO-WAY RADIO IN OPERATION

After completing the installation of the Two-Way Radio, the following final operations should be performed:

#### These include:

- Have an electronics technician who holds a 1st or 2nd Class FCC Radiotelephone license make the final adjustments.
  - 1. Transmitter (final tuning and loading; frequency and modulation check)
  - 2. Receiver (matching to antenna)
  - 3. Checking to see if any additional noise suppression is needed.
  - 4. Setting the Call Number, Home Channels and Installing the Call Number Card.

Instructions are included in the Maintenance Manual for the Two-Way Radio. Alignment Tools packed with the radio, should be given to the technician, along with the key set.

- Be sure that a RADIO TRANSMITTER IDENTI-FICATION form (FCC Form 452-C or General Electric Form ECP-82) is filled out and attached to the transmitter.
- Fill out and mail the WARRANTY REGISTRA-TION Card (General Electric Form CPD-271).

MOBILE RADIO DEPARTMENT
GENERAL ELECTRIC COMPANY ● LYNCHBURG, VIRGINIA 24502

