

## COMBINATION NOMENCLATURE

| Digits 1 & 2                | Digit 3                    | Digit 4                        | Digit 5                                               | Digit 6                                  | Digit 7                   | Digits 8 & 9             |
|-----------------------------|----------------------------|--------------------------------|-------------------------------------------------------|------------------------------------------|---------------------------|--------------------------|
| Product Line                | RF Power                   | Channel Spacing                | Mode of Operation                                     | Alert Tones                              | Options                   | Frequency Range          |
| <b>AH</b><br>Personal Pager | <b>O</b><br>(Receive only) | <b>5</b><br>25 kHz Chan. (UHF) | <b>A</b><br>Automatic Reset (Tone & Voice)            | <b>W</b><br>Fixed Alert Tone Volume      | <b>L</b><br>Type 99 Tone  | <b>66</b><br>150-174 MHz |
|                             |                            | <b>6</b><br>30 kHz Chan. (HB)  | <b>B</b><br>Push-to-Reset (Tone & Voice)              | <b>V</b><br>Adjustable Alert Tone Volume | <b>S</b><br>Noise Squelch | <b>77</b><br>406-420MHz  |
|                             |                            |                                | <b>C</b><br>Push-to-Listen (Tone & Voice)             | <b>U</b><br>Noise Squelch                |                           | <b>88</b><br>450-470 MHz |
|                             |                            |                                | <b>D</b><br>Push-to-Silence (Tone)                    |                                          |                           |                          |
|                             |                            |                                | <b>E</b><br>Voice Only                                |                                          |                           |                          |
|                             |                            |                                | <b>F</b><br>Group Call (Tone & Voice) Push-to-Reset   |                                          |                           |                          |
|                             |                            |                                | <b>G</b><br>Group Call (Tone & Voice) Push-to-Listen  |                                          |                           |                          |
|                             |                            |                                | <b>H</b><br>Group Call (Tone Only) Push-to-Silence    |                                          |                           |                          |
|                             |                            |                                | <b>J</b><br>Group Call (Tone & Voice) Automatic Reset |                                          |                           |                          |

Issue 2

January 1980

**11000-6 (PC10)**

**PUBLICATION INDEX  
EXECUTIVE PAGER**

Product Code 10  
EXECUTIVE PAGER

OPERATOR'S MANUAL

LBI30353

MAINTENANCE MANUAL  
DIGIT 4      DIGIT 7

|   |   |
|---|---|
| 5 | L |
| 5 | S |
| 6 | L |
| 6 | S |

LBI30253/DF1114  
LBI30390/DF1114  
LBI30252/DF1114  
LBI30392/DF1114

# EXECUTIVE PAGER OPTIONS (PC10)

| OPTION | PUBLICATION                                                                  | DESCRIPTION                 |
|--------|------------------------------------------------------------------------------|-----------------------------|
| 1401   | LBI30253*/DF1114<br>LBI30390*/DF1114<br>LBI30252*/DF1114<br>LBI30392*/DF1114 | Lapel Speaker               |
| 1402   | LBI30253*/DF1114<br>LBI30390*/DF1114<br>LBI30252*/DF1114<br>LBI30392*/DF1114 | Earpiece                    |
| 1403   | LBI30253*/DF1114<br>LBI30390*/DF1114<br>LBI30252*/DF1114<br>LBI30392*/DF1114 | Leather Case                |
| 1407   | LBI30253*/DF1114<br>LBI30390*/DF1114<br>LBI30252*/DF1114<br>LBI30392*/DF1114 | White Case                  |
| 5401   | None                                                                         | Delete Rechargeable Battery |
| 5402   | LBI30253*/DF1114<br>LBI30390*/DF1114<br>LBI30252*/DF1114<br>LBI30392*/DF1114 | Mercury Battery Pack (12)   |
| 5403   | LBI30253*/DF1114<br>LBI30390*/DF1114<br>LBI30252*/DF1114<br>LBI30392*/DF1114 | Rechargeable Battery        |

## LEGEND:

NONE= NO INSTRUCTION  
 \*= INSTRUCTIONS  
 PROVIDED AS PART  
 OF ASSOCIATED  
 EQUIPMENT MANUAL

## PC10 PUBLICATION INDEX CHANGE

Reason for Change: To incorporate new format

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION  
 WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.



\* Trademark of General Electric Company U.S.A.  
 Printed in U.S.A.