



11000-6
ISSUE 9

[PC17]
OCTOBER 1988

PUBLICATION INDEX

MASTR II 800 MHz STATION

COMBINATION NOMENCLATURE

Digit 1	Digit 2	Digit 3	Digit 4	Digit 5	Digit 6	Digit 7	Digits 8 & 9	Digit 10	Digit 11
Mechanical Package	Duty Cycle	RF Power Output Range	Channel Spacing	Control	Number of Freq.	Options	Frequency Range MHz	Oscillator Stability	PA Type
D 30 Inch Desk Mate Cabinet	C 120/240 VAC Continuous Duty	5 21-40 Watts	5 25 KHz/ 12.5 KHz	E Local	A 1 Tx 1 Rx	D Duplex	96 851-870 Tx 806-825 Rx	E ± 1 PPM	S Solid State
P Pole Mount		6 41-60 Watts		J Local/Tone Remote		L CG/Duplex			V MCM PA
S 44 Inch Desk Mate Cabinet		7 81-92 Watts		K Local/DC Remote		M GE-MARC V 3051.9 Hz Busy Tone			
V Floor Mount		8 93-128 Watts		N Local/Repeat		N GE-MARC V 2918.7 Hz Busy Tone			
				R DC Remote		S Standard			
				T Tone Remote		U CG			
				U DC Remote/Repeat					
				V Tone Remote/Repeat					
				Y Repeat					

INSTALLATION MANUAL/MAINTENANCE MANUAL

BINDER

ECP-200

COMBINATION MANUAL (BLACK)

<u>Digit 3</u>	<u>Digit 7</u>	<u>Digit 11</u>
5	D,L,S,U	S
5	M,N	S
7	D,L,S,U	S
7	M,N	S
7	D,L,S,U	V
7	M,N	V
6	D,L,S,U	S
8	D,L,S,U	S

LBI-30951/DF9033
 LBI-30967/DF9033
 LBI-30965/DF9033
 LBI-30966/DF9033
 LBI-30490/DF9033
 LBI-30849/DF9033
 LBI-31783
 LBI-31782

INSTALLATION MANUAL (BLACK)

<u>Digit 3</u>	<u>Digit 7</u>	<u>Digit 11</u>
5,7,6	D,L,S,U	S
5,7	M,N	S
7	D,L,S,U	V
7	M,N	V

LBI-30963/DF9033
 LBI-30964/DF9033
 LBI-30414/DF9033
 LBI-30852/DF9033

TRANSMITTER MANUAL (ORANGE)

<u>Digit 3</u>	<u>Digit 11</u>	<u>Digit 7</u>	<u>Digit 5</u>
6	S	D,L,S,U	R,T,U,V,Y
5	S		
7	S	S,U	E,K,J,R,T
7	V		
7	S	D,L	E,K,J,R,T
7	S	S,U,M,N	Y,N,U,V
8	S	D,L,S,U	R,T,U,V,Y

LBI-31773
 LBI-30855/DF3158
 LBI-30943/DF3158
 LBI-30489/DF3158
 LBI-31501
 LBI-31501
 LBI-31772

RECEIVER MANUAL (BROWN)

ALL

LBI-30464/DF1104

POWER SUPPLY MANUAL (LIGHT BLUE)

<u>Digit 3</u>	<u>Digit 7</u>	<u>Digit 11</u>
5,7	D,L,S,U	S
6,8	D,L,S,U	S

LBI-30867/DF0072
 LBI-31758

CONTROL MANUAL (DARK BLUE)

<u>Digit 5</u>	<u>Digit 7</u>
R,K	S,U,D,L
T,J	S,U,D,L
U	S,U
V	S,U
N,Y	S,U
U,V,N,Y	M,N

LBI-30717/DF4098
 LBI-30718/DF4098
 LBI-30720/DF4098
 LBI-30721/DF4098
 LBI-30719/DF4098
 LBI-31036/DF4098

TONE MANUAL (LIGHT GREEN)

<u>Digit 3</u>	<u>Digit 7</u>
E,K,J,R,T	U
E,R,T	L
N,U,V	U
Y	U

LBI-31056 (LBI-4743 PRIOR TO 12/82)
 LBI-31056/LBI-31123
 LBI-31056/LBI-31123
 LBI-31123 (LBI-4877 PRIOR TO 12/82)
 & LBI-31056

MASTR® II 800 MHz STATION OPTIONS (PC17)

PC17

<u>OPTIONS</u>	<u>PUBLICATION</u>	<u>DESCRIPTION</u>
9603	LBI-4845/DF8414	BUILT-IN METERING
9604	LBI-4845/DF8414	BUILT-IN METERING
9605	LBI-4848/DF8414	BUILT-IN METERING
9606	LBI-30490*/DF9033	DUPLEXER
9607	LBI-4845/DF8414	BUILT-IN METERING
9608	NONE	DELETE RECEIVER
9609	LBI-30490*/DF9033	HEATSINK BLOWER KIT
9610	LBI-30490*/DF9033	HEATSINK BLOWER KIT
9611	LBI-30490*/DF9033	HEATSINK BLOWER KIT
9632	LBI-30490*/DF9033	DUPLEXER CABLE KIT
9678	LBI-4845/DF8414	BUILT-IN METERING
9679	LBI-4848/DF8414	BUILT-IN METERING
9680	LBI-30490*/DF9033	DUPLEXER
9681	LBI-30490*/DF9033	DUPLEXER ISOLATOR
9682	LBI-30490*/DF9033	DUPLEXER ISOLATOR
9683	LBI-4845/DF8414	BUILT-IN METERING
9684		
9685	LBI-30953	MULTI-RACK STATIONS
9686		
9687	LBI-30954	MULTI-RACK STATIONS
9744		
9745	LBI-30955	MULTI-RACK STATIONS

THE FOLLOWING MASTR II MASE STATION OPTIONS APPEARING ON PC67 ARE COMPATIBLE WITH THE 800 MHz MASTR II STATIONS.

3457	9519	9542
7646	9520	9543
7777	9521	9544
7778	9522	9549
7779	9523	9550
9505	9524	9551
9506	9525	9555
9507	9527	9561
9508	9528	9568
9509	9529	9659
9511	9530	9570
9512	9531	9578
9513	9532	9580
9514	9533	9582
9515	9534	9583
9516	9538	9584
9517	9539	9595
9518	9541	9601
		9669

NOTE: FOR OPTIONS 9538, 9539, 9541, GO TO PC70. DO NOT PICK UP BINDER (ECP200).

LEGEND:

NONE = NO INSTRUCTIONS

* = INSTRUCTIONS PROVIDED AS PART OF ASSOCIATED EQUIPMENT MANUAL



GE Mobile Communications

General Electric Company
Lynchburg, Virginia 24502

Printed in U.S.A.