

## COMBINATION NOMENCLATURE

| Digit 1                        | Digit 2             | Digit 3                 | Digit 4            | Digit 5                            | Digit 6                              | Digit 7                                     | Digits 8 & 9               |
|--------------------------------|---------------------|-------------------------|--------------------|------------------------------------|--------------------------------------|---------------------------------------------|----------------------------|
| Mechanical Package             | Operating Voltage   | RF Power Output Range   | Channel Spacing    | Mounting                           | No. of Freq.                         | Options                                     | Frequency Range            |
| <b>R</b><br>Mobile             | <b>G</b><br>12-VDC  | <b>4</b><br>8-16 watts  | <b>4</b><br>20 MHz | <b>T</b><br>Trunk Mount Mobile     | <b>A</b><br>1 Freq. Tx<br>1 Freq. Rx | <b>S</b><br>Standard                        | <b>11</b><br>25-33 MHz     |
| <b>F</b><br>Desk Top Station   | <b>M</b><br>117 VAC | <b>5</b><br>16-38 watts | <b>5</b><br>25 MHz | <b>F</b><br>Front Mount Mobile     | <b>B</b><br>2 Freq. Tx<br>1 Freq. Rx | <b>N</b><br>Noise Blanker                   | <b>22</b><br>33-42 MHz     |
| <b>W</b><br>Wall Mount Station |                     | <b>6</b><br>38-64 watts | <b>6</b><br>30 MHz | <b>L</b><br>Local Control Station  | <b>C</b><br>2 Freq. Tx<br>2 Freq. Rx | <b>U</b><br>Channel Guard                   | <b>33</b><br>42-50 MHz     |
|                                |                     |                         | <b>7</b><br>40 MHz | <b>K</b><br>Local/Remote Station   | <b>D</b><br>1 Freq. Tx<br>2 Freq. Rx | <b>W</b><br>Channel Guard and Noise Blanker | <b>44</b><br>66-77 MHz     |
|                                |                     |                         | <b>8</b><br>50 MHz | <b>R</b><br>Remote Control Station | <b>E</b><br>3 Freq. Tx<br>3 Freq. Rx |                                             | <b>45</b><br>77-88 MHz     |
|                                |                     |                         | <b>9</b><br>60 MHz |                                    | <b>F</b><br>4 Freq. Tx<br>4 Freq. Rx |                                             | <b>55</b><br>132-150.8 MHz |
|                                |                     |                         |                    |                                    | <b>G</b><br>5 Freq. Tx<br>5 Freq. Rx |                                             | <b>66</b><br>150.8-174 MHz |
|                                |                     |                         |                    |                                    | <b>H</b><br>6 Freq. Tx<br>6 Freq. Rx |                                             | <b>77</b><br>406-420 MHz   |
|                                |                     |                         |                    |                                    | <b>J</b><br>7 Freq. Tx<br>7 Freq. Rx |                                             | <b>88</b><br>450-470 MHz   |
|                                |                     |                         |                    |                                    | <b>K</b><br>8 Freq. Tx<br>8 Freq. Rx |                                             |                            |

Issue 2

March 1980

**11000-6 (PC34)**

**PUBLICATION INDEX  
EXECUTIVE MOBILE AND STATION**

PRODUCT CODE 34  
EXECUTIVE MOBILE & STATION

OPERATOR'S MANUAL

DIGIT 1

R

F,W

INSTALLATION MANUAL

DIGIT 1

R

F

W

MAINTENANCE MANUAL (BLUE)

DIGIT 2

DIGIT 6

DIGITS 8 & 9

G

A-F

11,22,33

G

A-F

44,45

G

A-F

55,56

G

G-K

66

G

A-K

77,88

M

11,22,33

M

44,45

M

55,66

M

77,88

TONE MANUAL (LIGHT GREEN)

DIGIT 7

U,W

LBI3731

LBI3516

LBI3711/DF9016

LBI3738/DF9016

LBI3740/DF9016

LBI3748

LBI3772

LBI4325

LBI4183

LBI4212

LBI3752

LBI3774

LBI4331

LBI4226

LBI4143/DF5039

## EXECUTIVE MOBILES AND STATIONS OPTIONS (PC34)

| OPTION | PUBLICATION     | DESCRIPTION                                          |
|--------|-----------------|------------------------------------------------------|
| 3211   | None            | Delete LB Antenna                                    |
| 3213   | None            | Delete HB Antenna                                    |
| 3453   | LBI3184/DF5031  | Noise Suppression Kit                                |
| 3457   | None            | Lease Decal                                          |
| 7008   | LBI3732         | Int./Ext. Speaker Kit                                |
| 7012   | None            | Low Loss Coax Antenna                                |
| 7094   | LBI3748*        | Low Band Antenna                                     |
|        | LBI4325*        |                                                      |
|        | LBI4212*        |                                                      |
| 7096   | LBI3748*        | High Band Antenna                                    |
|        | LBI4325*        |                                                      |
|        | LBI4212*        |                                                      |
| 7349   | LBI4138/DF8405  | Carrier Control Timer                                |
| 7610   | LBI4093/DF4072  | COR, Station                                         |
| 8003   | LBI3612/DF8389  | 10-Watt Speaker Amp                                  |
| 8009   | None            | 2-Watt Speaker & Window Mount                        |
| 8011   | LBI3612*/DF8389 | Window Mount for 10-Watt Speaker                     |
| 8013   | LBI3773/DF9016  | Weatherproof Box                                     |
| 8015   | LBI3711/DF9016  | Mounting Accessories, Mobile Front Mount             |
| 8016   | LBI3711/DF9016  | Mounting Accessories, Mobile Trunk Mount             |
| 8017   | LBI4325*        | Control Unit, Single Frequency                       |
|        | LBI3748*        | Control Unit                                         |
|        | LBI4345*        | Control Unit                                         |
| 8018   | LBI4325*        | Control Unit, Two Frequency                          |
|        | LBI4345*        | Control Unit                                         |
|        | LBI3748*        | Control Unit                                         |
| 8019   | LBI4325*        | Control Unit, Four Frequency                         |
|        | LBI4345*        | Control Unit                                         |
|        | LBI3748*        | Control Unit                                         |
| 8020   | LBI3711/DF9016  | Microphone and Hanger                                |
| 8021   | LBI3775/DF0062  | Positive Ground Adapter, Front Mount                 |
| 8022   | LBI3775/DF0062  | Positive Ground Adapter, Trunk Mount 1 & 2 Frequency |
| 8023   | LBI3775/DF0062  | Positive Ground Adapter, Trunk Mount 3 & 4 Frequency |
| 8024   | LBI4362*/DF8385 | Handset/Hookswitch                                   |
| 8026   | LBI4143/DF5039  | Channel Guard, Decode Only                           |
| 8027   | LBI4362/DF8385  | Channel Guard Hookswitch for Military Mike           |
| 8032   | LBI3660*/DF5027 | Ext. CG Encoder Front Mount, 2-Tone                  |
|        | LBI3664*        |                                                      |
| 8033   | LBI3660*/DF5027 | Ext. CG Encoder Front Mount, 3-Tone                  |
|        | LBI3664*        |                                                      |
| 8034   | LBI3660*/DF5027 | Ext. CG Encoder Front Mount, 4-Tone                  |
|        | LBI3664*        |                                                      |
| 8035   | LBI3660*/DF5027 | Ext. CG Encoder Front Mount, 5-Tone                  |
|        | LBI3664*        |                                                      |
| 8036   | LBI3660*/DF5027 | Ext. CG Encoder Front Mount, 6-Tone                  |
|        | LBI3664*        |                                                      |
| 8037   | LBI3660*/DF5027 | Ext. CG Encoder Trunk Mount, 2-Tone                  |
|        | LBI3664*        |                                                      |
| 8038   | LBI3660*/DF5027 | Ext. CG Encoder Trunk Mount, 3-Tone                  |
|        | LBI3664*        |                                                      |
| 8039   | LBI3660*/DF5027 | Ext. CG Encoder Trunk Mount, 4-Tone                  |
|        | LBI3664*        |                                                      |
| 8040   | LBI3660*/DF5027 | Ext. CG Encoder Trunk Mount, 5-Tone                  |
|        | LBI3664*        |                                                      |
| 8041   | LBI3660*/DF5027 | Ext. CG Encoder Trunk Mount, 6-Tone                  |
|        | LBI3664*        |                                                      |

| OPTION | PUBLICATION     | DESCRIPTION                                   |
|--------|-----------------|-----------------------------------------------|
| 8044   | LBI3684/DF5031  | Tone Decoder Adapter, Mobile                  |
| 8046   | LBI3775/DF0062  | Positive Ground Adapter, Front Mount          |
| 8047   | LBI3775/DF0062  | Positive Ground Adapter, Trunk Mount          |
|        |                 | 1 & 2 Freq.                                   |
| 8048   | LBI3775/DF0062  | Positive Ground Adapter, Trunk Mount,         |
|        |                 | 3 & 4 Freq.                                   |
| 8092   | None            | Noise Cancelling Microphone                   |
| 8093   | LBI3748*        | Handset/Hookswitch                            |
|        | LBI4325*        |                                               |
|        | LBI4212*        |                                               |
| 8094   | LBI3748*        | Handset                                       |
|        | LBI4212*        |                                               |
|        | LBI4325*        |                                               |
| 8301   | None            | OCDM Decal                                    |
| 8302   | RC2400*/DF1091  | Improved Intermod Option, High Band           |
|        | RC2401/DF1091   | Improved Intermod Option, UHF                 |
| 8304   |                 | Marine Hi-Low Power, Pt. 81, FLL              |
| 8306   | LBI4138*/DF8405 | Carrier Control Timer, Mobile Executive       |
| 8308   | LBI4138*/DF8405 | Carrier Control Timer, Desk Top Station       |
| 8311   | None            | 30-Watt Input/5-12 Watt RF Output Mod.        |
| 8312   | None            | 3-Watt Input, Station Mod.                    |
| 8313   | None            | 3-Watt Input, Mobile Mod.                     |
| 8315   | See Applicable  | Military Microphone CG Station                |
|        | Maint. Manual   |                                               |
| 8316   | See Applicable  | Handset w/o Hookswitch CG Desk Station        |
|        | Maint. Manual   |                                               |
| 8401   | LBI3752*        | 12 Hr. Clock, 117 VAC Desk Top Station        |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8402   | LBI3752*        | 12/24 Hr. Clock & Meter, 117 VAC, 60 Hz       |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8403   | LBI3752*        | Test Meter, Station                           |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8404   | LBI3752*        | 12 Hr. Clock & Meter, 117 VAC, 60 Hz          |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8405   | LBI3752*        | 12/24 Hr. Clock & Meter, 117 VAC, 60 Hz       |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8406   | None            | 220 VAC Desk Station Mod.                     |
| 8407   | None            | 220 VAC Wall Mount Station Mod.               |
| 8411   | LBI3684*/DF5031 | Type 90, Type 99 Tone Decoder Adapter,        |
|        |                 | Desk Top Station                              |
| 8412   | LBI3752*        | 12 Hr. Clock, 220 VAC, 60 Hz, Desk Station    |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8413   | LBI3752*        | 12/24 Hr. Clock, 220 VAC, 60 Hz, Desk Station |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8414   | LBI3752*        | 12 Hr. Clock, 220 VAC, 50 Hz, Desk Station    |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |
| 8415   | LBI3752*        | 12/24 Hr. Clock, 220 VAC, 50 Hz, Desk Station |
|        | LBI4331*        |                                               |
|        | LBI4226*        |                                               |

| OPTION | PUBLICATION                                | DESCRIPTION                                             |
|--------|--------------------------------------------|---------------------------------------------------------|
| 8416   | LBI3752*<br>LBI4331*<br>LBI4226*           | 12 Hr. Clock, 117 VAC, 50 Hz, Desk Station              |
| 8417   | LBI3752*<br>LBI4331*<br>LBI4226*           | 12/24 Hr. Clock, 117 VAC, 50 Hz, Desk Station           |
| 8418   | None                                       | Cabinet Heater, 220 VAC                                 |
| 8419   | LBI3815/DF8397                             | Compressor, Station                                     |
| 8421   | LBI3752*<br>LBI4331*<br>LBI4226*           | Speaker & Microphone (4EZ20A11)                         |
| 8422   | LBI3752*<br>LBI4331*<br>LBI4226*           | Fan, 117 VAC, 60 Hz, Desk Top Station                   |
| 8423   | LBI3752*<br>LBI4331*<br>LBI4226*           | Fan, 117 VAC, Wall Mount Station                        |
| 8424   | LBI3752*<br>LBI4331*<br>LBI4226*           | Cabinet Heater, 117 VAC                                 |
| 8444   | See Applicable<br>Mobile, Maint.<br>Manual | Tone Option Jack                                        |
| 8450   | LBI4331                                    | 10-Watt Output, Rec. Dispatch Station                   |
| 8451   | LBI4912/DF8411                             | Digital Clock 12 Hr., 121 VAC, 60 Hz                    |
| 8452   | LBI4912/DF8411                             | Digital Clock 24 Hr., 121 VAC, 60 Hz                    |
| 8453   | LBI4912/DF8411                             | Digital Clock 12 Hr., 121 VAC, 50 Hz                    |
| 8454   | LBI4912/DF8411                             | Digital Clock 24 Hr., 121 VAC, 50 Hz                    |
| 8455   | LBI4912/DF8411                             | Digital Clock 12 Hr. 242 VAC, 60 Hz                     |
| 8456   | LBI4912/DF8411                             | Digital Clock 24 Hr. 242 VAC, 60 Hz                     |
| 8457   | LBI4912/DF8411                             | Digital Clock 12 Hr. 242 VAC, 50 Hz                     |
| 8458   | LBI4912/DF8411                             | Digital Clock 24 Hr. 242 VAC, 50 Hz                     |
| 8461   | LBI3752*<br>LBI4331*<br>LBI4226*           | 12 Hr. Clock, 220 VAC, 60 Hz                            |
| 8462   | LBI3752*<br>LBI4331*<br>LBI4226*           | 12/24 Hr. Clock, 220 VAC, 60 Hz                         |
| 8463   | LBI3752*<br>LBI4331*<br>LBI4226*           | 12 Hr. Clock, 220 VAC, 50 Hz                            |
| 8464   | LBI3752*<br>LBI4331*<br>LBI4226*           | 12/24 Hr. Clock, 220 VAC, 50 Hz                         |
| 8465   | LBI3752*<br><br>LBI4331*<br>LBI4226*       | 12 Hr. Clock & Meter 117 VAC, 50 Hz, Desk<br>Station    |
| 8466   | LBI3752*<br><br>LBI4331*<br>LBI4226*       | 12/24 Hr. Clock & Meter 117 VAC, 50 Hz, Desk<br>Station |

| OPTION | PUBLICATION                      | DESCRIPTION                              |
|--------|----------------------------------|------------------------------------------|
| 8467   | None                             | Fan, 220 VAC, 60 Hz, Wall Mount          |
| 8468   | None                             | Fan & Heater, 220 VAC, 60 Hz, Wall Mount |
| 8472   | LBI3660/DF5027<br>LBI3664        | Ext. CG Encoder, Desk Station, 2-Tone    |
| 8473   | LBI3660/DF5027<br>LBI3664        | Ext. CG Encoder, Desk Station, 3-Tone    |
| 8474   | LBI3660/DF5027<br>LBI3664        | Ext. CG Encoder, Desk Station, 4-Tone    |
| 8475   | LBI3660/DF5027<br>LBI3664        | Ext. CG Encoder, Desk Station, 5-Tone    |
| 8476   | LBI3660/DF5027<br>LBI3664        | Ext. CG Encoder, Desk Station, 6-Tone    |
| 8493   | LBI3752*<br>LBI4331*<br>LBI4226* | Handset/Hookswitch, Desk Top Station     |
| 8494   | LBI3752*<br>LBI4331*<br>LBI4226* | Handset, Desk Top Station                |
| 8495   | LBI3752*<br>LBI4331*<br>LBI4226* | Military/Mike, Desk Top Station          |
| 8496   | LBI3752*<br>LBI4331*<br>LBI4226* | Handset/Hookswitch, Desk Top Station, CG |

LEGEND:

NONE= NO INSTRUCTION.

\*= INSTRUCTIONS  
PROVIDED AS PART  
OF ASSOCIATED  
EQUIPMENT MANUAL

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION  
WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.

GENERAL  ELECTRIC\*  
U.S.A.