

COMBINATION NOMENCLATURE

Digits 1 & 2	Digit 3	Digit 4	Digit 5	Digit 6	Digit 7	Digit 8	Digit 9	Digit 10	Digit 11	Digit 12
Product	Version	1st Rack Position	2nd Rack Position	3rd Rack Position	4th Rack Position	5th Rack Position	6th Rack Position	7th Rack Position	8th Rack Position	Rack Size
T6	A US Cellular	O None	O None	O None	O None	O None	O None	O None	O None	L 96-Inch Rack
		B Blank Panel	B Blank Panel	B Blank Panel	B Blank Panel	B Blank Panel	B Blank Panel	B Blank Panel	B Blank Panel	M 96-Inch Rack
		C Channel Unit	C Channel Unit	C Channel Unit	C Channel Unit	C Channel Unit	C Channel Unit	C Channel Unit	C Channel Unit	S 76-Inch Rack
		T TEST & ALARM UNIT	T TEST & ALARM UNIT	T TEST & ALARM UNIT	T TEST & ALARM UNIT	T TEST & ALARM UNIT	T TEST & ALARM UNIT	T TEST & ALARM UNIT	T TEST & ALARM UNIT	C Channel Unit Only
										T TEST & ALARM UNIT

11000-6(PCT6)
Issue 2
November 1985

MAINTENANCE MANUAL

ECP200

BINDER

COMBINATION MANUAL (BLACK)

DIGIT 3

DIGIT 12

DIGITS 4-12

A

S,M,L

LBI-31320

A

C

LBI-31322

A

T

T

LBI-31510

LBI-31335

NON STRUCTURED OPTIONS

OPTIONS

PUBLICATION

DESCRIPTION

IB01

LBI-31382

SYSTEM INSTALLATION

SU01

LBI-31391

COAXIAL TRANSFER RELAY

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION
WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.