







- 12 SA2
- 11 SA1
- 10 SA0
- 9 SD1
- 8 SD2
- 7 RECEIVE LOCK
- 6 SD3
- 5 SD0
- 4 RECEIVE LOOP
- 3 RECEIVE AUDIO
- 2 LOGIC GND
- 1 A+



- 14 SA1
- 13 MODULATION ENBL
- 12 XMIT LOCK
- 11 SD2
- 10 SD1
- 9 AUDIO GND
- 8 +9.6V
- 7 XMIT AUDIO
- 6 SD0
- 5 SD3
- 4 XMIT LOOP
- 3 SA0
- 2 SA2
- 1 XMIT STROBE
- 14 PA ON
- 13 FORWARD VOLTAGE

UNIBOARD MODEL TRN9880A COMPONENT SIDE DETAIL



SOLDER SIDE ● BD-EEPS-45397-0
COMPONENT SIDE ● BD-EEPS-45398-0
OL-EEPS-45399-0

6-8 GND
5 XMTR SYNTH
4 STEERING LINE
3 CONTROL
2 VOLTAGE
1 VOLTAGE
1 FORWARD
VOLTAGE

TX
METERING

EXT REF INPUT
EXT REF MOD

MOD
COMP
ADJ



PIN 1 DRAIN
PIN 2 GATE 2
PIN 3 GATE 1
PIN 4 SOURCE, SUBSTRATE,
AND CASE

Q202, Q263-Q265,
Q322-Q325, Q401,
Q402, Q404, Q405



Q261, Q321,
Q327



Q326

