

21-1834

® RadioShack®

Handheld Clip-on Speaker Microphone

FEATURES AND SPECIFICATIONS

- Fits RadioShack and many other handheld transceivers
- Electret condenser microphone with 2-meter coiled cord
- Nickel-plated mono 2/32-Inch (2.5 mm) jack microphone
- Nickel-plated mono 1/8-Inch (3.5 mm) speaker plug
- 8 ohms, 36 mm Mylar type speaker
- Lapel clip
- Weight: 3.52 oz (100 g)

CONNECTION

1. To avoid accidental transmission, turn off your transceiver before connecting the handheld speaker microphone.
2. Insert the speaker microphone's plug into the transceiver's microphone/earphone or speaker jacks.

Note: For private listening, you can connect an earphone (not supplied) to the jack on the bottom of the speaker microphone. Connecting an earphone disconnects the speaker.

OPERATION

To switch between transmitting and receiving:

1. Set the transceiver's volume control to the minimum position.
2. Turn on your transceiver and adjust the volume control to a comfortable listening level.
3. Press the microphone's push-to-talk button to transmit. Release it to receive.

Note: For added convenience, you can use the lapel clip on the back of the microphone to attach the microphone to your clothing.

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

07A00

