All-Hazards Weather Alert Clock Radio with Skywarn

Programming Skywarn Channels into Memory

Before using the Skywarn function, you must store Skywarn channels into the memory. Visit RadioReference.com to find

ADVISORY   WATCH   WARNING

144.520

RadioShack

the Skywarn frequencies used in your area. You can store up to 20 Skywarn frequencies into memory.

Press **Skywarn** to enter the Skywarn mode, the radio will select the last channel used.

1. Press **Program** and use ▲ or ▼ to scroll to the desired channel number (1-20).

2. Use the number keys to enter a 6-digit frequency.

3. Press **Enter** to confirm.

Using Skywarn

To **listen to a stored channel:**

Press **Manual** and use ▲ or ▼ to find desired channel. Press **Enter** to confirm.

Or, press Scan to auto scan the stored Skywarn channels.