

# RC-850 Repeater Controller

## Programming Reference Manual

Firmware Version 3

COPYRIGHT © 1987  
ADVANCED COMPUTER CONTROLS, INC.



**Got a question? Be sure and check the manual supplement,  
"Most Often Asked Questions, and Answers".**

Touch-Tone is a registered trademark of American Telephone and Telegraph Company.

Copyright (c) 1987 Advanced Computer Controls, Inc.  
All rights reserved  
Printed in U.S.A.

Specifications subject to change without notice

RC-850 Controller Software Copyright (c) 1983, 1984, 1985 ACC  
RC-850 Controller Command Codes Copyright (c) 1983, 1984, 1985, 1987 ACC

**8/87 Rev 3**



## **About This Manual . . .**

This manual provides reference information for those responsible for programming repeaters controlled by the RC-850 Repeater Controller.

## **Table of Contents**

- 1 Introduction**
  - Remote Programming ... 1-1
  - Security ... 1-1
  - Command Channels ... 1-1
  - Response Messages ... 1-2
  - Command Entry From the Telephone ... 1-2
  - Command Entry From the Serial Ports ... 1-2
- 2 Unlocking and Locking the Controller**
  - Unlocking the Controller ... 2-1
  - Locking the Controller ... 2-1
  - Programming the Unlock Code ... 2-1
- 3 The Message Editor**
  - Selecting the Message ... 3-1
  - Vocabulary ... 3-2
  - Commands ... 3-2
  - Message Size ... 3-3
  - Morse Code Character Codes ... 3-4
  - Speech Synthesizer Vocabulary Codes ... 3-5
  - Message Groups ... 3-8
- 4 Advanced Message Editing**
  - Run-Time Variable Speech Strings ... 4-2
  - Message Macros ... 4-4
  - Changing Message Type ... 4-5
  - Change to Morse Code ... 4-5
  - Change to Synthesized Speech ... 4-6
  - Touch-Tone Signalling ... 4-6
  - Pager Memory Signalling ... 4-6
  - Digital Voice Recorder Tracks ... 4-7
  - External Devices ... 4-7

- 5 **Morse Code Parameters**
  - Morse Code Speed ... 5-1
  - Morse Code Pitch ... 5-2
  - Morse Code Level ... 5-2
- 6 **Courtesy Tone Parameters**
  - Delay To/Between Segments ... 6-2
  - Segment Pitch ... 6-2
  - Segment Level ... 6-2
  - Segment Duration ... 6-2
  - Hang Time ... 6-3
  - Preview Courtesy Tone ... 6-3
  - Copy Courtesy Tone Set ... 6-3
  - Programming Example ... 6-4
- 7 **Timers**
  - Alarm Timer ... 7-1
  - Command Decoder Timers ... 7-2
  - External Device Timer ... 7-2
  - ID Timers ... 7-3
  - Patch Timers ... 7-3
  - Phone Answer Delay Timer ... 7-4
  - Repeater Timeout Timers ... 7-5
  - Spare Audio 1 Timer ... 7-5
  - Tail Message Timer ... 7-5
  - Touch-Tone Access Mode Timer ... 7-5
  - Transmitter Turn-on Delay ... 7-6
- 8 **Setting the Clock/Calendar**
  - Time of Day Set ... 8-1
  - Date Set ... 8-1
  - Day of Week Set ... 8-1
  - Select 12/24 Hour Format ... 8-2
- 9 **Command Codes and Channels**
  - Control Operator Command Prefix and Root Set ... 9-1
  - User Command Prefixes ... 9-2
  - User Command Attributes ... 9-3
  - Individual User Access Codes ... 9-5
  - User Mapped Control Operator Commands ... 9-6
  - Primary / Secondary Unlock Code Select ... 9-6
  - Command Channel Enable / Disable ... 9-6
- 10 **Logic I/O Senses**
- 11 **Emergency Autodial Numbers**
- 12 **Macro Sets and the Scheduler**
  - Macro Sets ... 12-1
  - Events ... 12-1
  - Setpoints ... 12-1
  - Example ... 12-4
- 13 **Telemetry Meter Faces**
  - Meter Faces ... 13-1
  - Temperature Calibrate ... 13-2

- 14 **Patch Restrictions and Mapping**
  - Toll Restrict ... 14-1
  - Antidialer ... 14-2
  - Dialing Format ... 14-3
  - Phone Line Dedicated / Shared ... 14-3
  - Logical Phone Line Assignment ... 14-3
  - Remote Phone Line Up / Down Channels ... 14-4
- 15 **Remote Base Frequency Memories**
  - Remote Base Frequency Memories ... 15-1
  - Remote Base / Link Channel Assignment ... 15-2
- 16 **Pager Memories**
  - Programming Summary**
  - Programming Sheets**

**Look for these symbols:**



Provides miscellaneous trivia and notes of interest associated with the use of a command.



**WARNING**

Alerts you to potential pitfalls or dangers associated with the use of a command.





## Chapter 1

# Introduction

This chapter provides an overview of the Programming level commands.

### Remote Programming

The RC-850 Repeater Controller is remotely programmable – many of its characteristics can be customized by the repeater owner, without the need to visit the site.

The controller has a set of simple, high level commands, which instruct it to modify information in its non-volatile memory. The information in its memory is referred to frequently during the course of normal operation. For example, ID messages, timer values, and much more are retrieved by the controller's operating system firmware from the non-volatile memory.

Since the memory can be reprogrammed thousands of times, and remembers its information even when power is removed from the controller, the repeater owner has a great deal of flexibility in customizing and changing the operation of the repeater system from anywhere.

### Security

Since the repeater can be reprogrammed remotely, it's obviously necessary to provide a high degree of security against accidental or unauthorized reprogramming. The controller normally doesn't recognize programming commands – it must be "unlocked" with a secret custom code to accept these commands. The repeater owner can change the "unlock" code to any of more than 10 billion possible codes.

The controller may be instructed to ignore unlock and programming commands from certain command channels. For example, you may wish to allow programming commands only from the control receiver or from the control receiver and the phone.

### Command Channels

Touch-Tone Programming commands may be entered from any of the repeater's command channels, including the main repeater receiver, the link / remote base receivers, the telephone line, the control receiver, and the local microphone. With the Computer Interface option, Touch-Tone commands may also be entered through the auxiliary Touch-Tone decoder, and serial ASCII commands may be entered through serial I/O ports 1 and 2.

Command entry through the repeater receiver, the link receivers, the phone line, the auxiliary decoder, and the serial ports may be inhibited by the repeater owner to enhance security. Command entry through the repeater receiver may also require sub-audible tone (PL) to guard command access.

## Response Messages

The controller may respond to each Programming command with a unique response message, verifying that you've entered the command you intended. (The controller will respond with the unique messages, a "generic" message, or no response based on the Control Operator level selected "Command Acknowledgement Mode".) The response is provided to one of several channels depending on the command input channel.

<b>Command Channel</b> ---->	<b>Response Channel</b>
Repeater receiver	Repeater transmitter
Link / Remote receivers	Repeater / link / remote transmitters
Control receiver	Repeater transmitter
Telephone	Telephone
Local microphone	Repeater transmitter
Auxiliary decoder	Repeater transmitter
ASCII serial port 1 or 2	ASCII serial port 1 or 2

## Command Entry From the Telephone

When entering commands over the air, the controller knows you're done entering tones when it sees your carrier drop. It then evaluates the Touch-Tone command you've sent. When controlling over the phone, there's no "carrier" to drop. It therefore is necessary to terminate a Touch-Tone command with the # key, which serves as an "Enter" key. When the controller sees the #, it evaluates and acts on the command you've entered.

For example, if the Programming command is \*1101, it should be entered over the telephone as "\*1101#".

## Command Entry From the Serial Ports

Programming commands may be sent in serial ASCII format to Serial Port 1 or 2 on the Computer Interface option. ASCII command strings may be sent, similar to Touch-Tone commands, but terminated with <CR><LF> (carriage-return, line-feed).

## Chapter 2

# Unlocking and Locking the Controller

The controller normally operates in the “locked” mode, where Programming commands are *not* accepted. In order to access the Programming commands to make changes to the messages, timers, command codes, etc., the controller must be “unlocked”.

### Unlocking the Controller

The “unlock code” is programmed by the repeater owner, and can contain any keys except # or D. Two unlock codes may be stored in the controller’s memory. The repeater owner may change between the two unlock codes remotely if it should become necessary for security reasons. If it becomes further necessary to actually change the unlock codes, they may be changed at the site as described below.

The controller is unlocked by entering the ten-digit unlock code, as a Touch-Tone sequence through any of the available Touch-Tone command channels - it responds with “UL” if the command was entered successfully. The controller may also be unlocked through serial port 1 or 2, by sending the unlock code as a serial ASCII sequence.

While the controller is unlocked, the “UL” prompt indicates that it is waiting for valid Programming commands. Each entry of a valid command extends the unlock timer for 60 seconds. If the timer times out, the controller locks itself back up.

While the controller is unlocked, it is expecting Programming commands. However, *it will accept ordinary Control Op and User level commands* while unlocked, by preceding them with “\*\*\*”.

### Locking the Controller

The controller is normally locked back up after a series of Programming commands with the # key (## over the phone).

### Programming the Unlock Code

The repeater owner may program two of his favorite ten-digit sequences as the controller’s unlock codes. Simply flip DIP switch 8 “ON”, and DIP switch 7 “OFF”, and enter the desired *primary* ten-digit unlock code as Touch-Tone over any of the command channels. The controller writes the code into its non-volatile memory and responds by saying “UL PGM”. DIP switch 7 may be turned “ON”, and the procedure repeated for the *secondary* unlock code. DIP switch 8 should then be turned “OFF”, and the controller may then be unlocked

by entering the primary ten-digit unlock code (followed by # over the phone). If it should become necessary, the secondary unlock code may be selected remotely, with the "Secondary Unlock Code" programming command (see "Command Codes").



**WARNING**

The ten-digit code should not contain # or D. Nor should it begin with the Pad Test or Autopatch user command prefixes, to avoid conflicts with them.

Be sure to turn off DIP switch 8 after entering the desired unlock codes. The position of DIP switch 7 doesn't matter.



**The controller should be unlocked only to enter Programming commands. Control Operator and User level commands do not require unlocking the controller. However, while unlocked, Control Operator and User level commands may be activated by proceeding them with \*\*.**

## Chapter 3

# The Message Editor

Messages are information and signalling provided by the controller to the users, Control Ops, and repeater owner. They may be generated in synthesized speech, Morse code, and a variety of other formats. Many of the messages are remotely programmable, including ID's, tail messages, Emergency Autodial responses, telephone answer and hangup messages, alarm messages, and many more. The ability to remotely program these messages, and the intelligence of the controller to construct "run time variable" message strings, are some of the keys to the power of the controller. They contribute to the evolution of the repeater into an *information center*.

The message editor is an interactive utility which allows the repeater owner to select a message, and then string together the speech vocabulary, Morse code, or other format signalling that will comprise the message.

The types of signalling which may be mixed within any programmable messages include:

- Synthesized speech (approximately 300 word internal vocabulary)
- Morse code (all letters, numbers, and punctuation)
- Digital Voice Recorder tracks (for remotely recordable audio, with ACC's DVR)
- DTMF (Touch-Tone) sequences
- Paging tones (two-tone sequential, 5/6 tone sequential, CTCSS, HSC display, GSC digital)
- External strobed devices (such as cartridge tape playback units)

The controller can automatically construct, as run-time variable synthesized speech strings, the following:

- Time of day, am/pm, and date
- "Morning/afternoon/evening"
- Analog telemetry and weather instrumentation readings, plus stored min/max readings
- Repeater system telemetry, such as number of messages in the mailbox, period repeater has been active, number of autopatches, period repeater has been timed out, etc.

### Selecting the Message

The controller must be *unlocked* to use the message editor. The message to be edited is selected with one of the commands shown on the following pages. Once you've selected the message, you're "in the editor".

Messages may start out either as Morse code or synthesized speech. [The following chapter describes how to change type within a message.] Using the command \*10... starts the message out as Morse code, while \*11... starts it out as synthesized speech. The controller responds to the command with a unique response to confirm that you've chosen the message you intended (if the Control Op level "Unique Response Message" command acknowledgement mode is selected).

Once the message has been selected and you're in the editor, a new set of commands, along with vocabulary codes, are used to actually build the message. Commands provide the ability to review what you've entered, backspace, start over, store the message in the controller's non-volatile memory, or get out of the editor.

While you're editing the message, it's stored in the controller's temporary memory. The previously stored message isn't affected, until you *write* the newly edited message from the temporary to the non-volatile memory.

### Vocabulary

Codes for Morse code and speech letters and numbers are based on their position on a telephone keypad. The first digit of the code indicates what button the letter appears on, and the second digit indicates whether it's the first, second, or third letter on the key. The letters Q and Z are represented by 70 and 90. Numbers are represented by 00 through 09. This logical layout makes it easy to enter letters and numbers without having to look up codes.

The additional synthesized speech vocabulary and Morse code punctuation characters are assigned two- and four-digit codes as shown in the tables below.

After each transmission, or after the # terminator is entered from the phone, the controller reads back the portion of the message entered during that transmission. Message construction can then continue. Generally it's best to *enter a few characters at a time*, so you can catch errors as you make them.

### Commands

Several commands control the Message Editor's operation.

**Read Back Message** - At any time while editing a message, you can read back what's been entered so far with \*2 (\*2# over the phone). With long messages, it's always a good idea to enter a few characters at a time and occasionally read back the entire message to verify that you've entered what you intended.

**Delete Last Character** - If you make a mistake in entering a word or character, the last character entered can be deleted (i.e., backspace or rubout) with \*1 (\*1# over the phone). The deleted character is read back for confirmation. One character at a time can be deleted.

**Delete Message** - If you've made several errors, or have changed your mind about what you want the message to say, you can delete everything you have loaded into the editor for the selected message, with \*3 (\*3# over the phone). The delete message command lets you start over for the selected message.

**Change Message Type** - While editing a message, these commands specify the characters that follow are to be another one of the signalling types supported by the controller. The commands are described in the next chapter, "Advanced Message Editing".

**Store Message in Memory** - When you've completed editing the message and it's correct, it may then be transferred from the temporary memory (buffer) to the controller's non-volatile memory by entering a \*0 (\*0# over the phone). There will be a brief delay as the E<sup>2</sup>PROM is programmed, then the controller will announce "Write, UL", indicating a successful write operation, and that it is ready for either the next Programming level command or the Lock command.

**Abort Message Editor** - At any time while editing a message, you can abort the operation *without storing the message* with \*4 (\*4# over the phone), and return to a "UL" prompt, ready to enter either the next Programming level command or the Lock command.

### NOTE

These commands apply *only to the message editor* - not to any other Programming commands. For example, \*0 is *not used* with other Programming commands - only to write edited *messages* into the controller's non-volatile memory.

If the controller responds to the Store Message in Memory command with "E R", a hardware error has occurred. Refer to the Hardware Reference Manual, "Troubleshooting", for suggestions.

An *empty message* can be written by selecting the message (\*11.), then storing message in memory (\*0), without entering any characters.

### Message Size

Each programmable message may consist of a maximum number of characters shown below with its message select command. Exceeding the allowable message size causes the controller to respond with "Overflow". The overflowed characters are thrown away, and you may backspace (delete last character) or start over (delete message) to try again.

Synthesized speech words beginning with \*9 *take up 2 character slots each*.

Message types other than speech are permitted a maximum size of *one less than shown*. For example, the Initial IDs allow 22 characters as speech messages. If they are selected as Morse code, only 21 characters are available.


Change Message Type commands also take up character spaces as well, as defined in the next chapter. For example, changing from speech to Morse code in the middle of a message uses up one character slot for the change.

## Message Editor Commands

Read Back Message	*2	(to read back what you've entered so far)
Delete Last Character	*1	(to delete a mistaken character)
Delete Message	*3	(to delete the entire message to start over)
Store Message in Memory	*0	(after completed editing a message)
Abort Message Editor	*4	(to return to "UL" level without storing the message in memory)

## Morse Code Character Codes

A	21	0	00
B	22	1	01
C	23	2	02
D	31	3	03
E	32	4	04
F	33	5	05
G	41	6	06
H	42	7	07
I	43	8	08
J	51	9	09
K	52		
L	53	word	
M	61	space	11
N	62		
O	63	-	10
P	71	/	12
Q	70	:	14
R	72	?	20
S	73	:	24
T	81	,	30
U	82	(	50
V	83		
W	91	AR	13
X	92	AS	80
Y	93	SK	60
Z	90		
		macro 1	15
		macro 2	25
		macro 3	35
		macro 4	45





# Speech Synthesizer Vocabulary Codes

(pause)	34	D	31	G	41	M	61
A	21	danger	*712	gage	*961	machine	84
a	21	days	*952	gallons	*991	manual	*965
abort	*992	dayton	*928	gate	*845	me	*920
about	*855	dee	31	gee	41	measure	*970
adjust	*944	degrees	*722	get	*962	meeting	35
advanced	*916	delta	*631	go	*895	mega	*680
afternoont	*842	device	*953	golf	*641	messages	*625
alert	40	dial	*936	good†	*834	meter	*620
all	*685	direction	*752	green	*762	micro	*931
alpha	*621	display	*954	H	42	mike	*661
am	61	door	*955	ham	*938	mill	*971
amateur	*917	down	*654	hamfest	*946	milli	*825
amps	*831	E	32	hamvention	*947	minus	*612
an	62	east	*754	henry	*642	minutes	*645
and	74	echo	*632	hertz	*684	mobile	*958
are	72	eight	08	hi	*763	morning†	*841
area	*713	eight†	*808	high	*763	motor	*972
at	*742	eighteen†	*884	hold	*963	move	*973
ate	08	electrician	*943	home	*615	N	62
auto	*918	eleven	11	hours	*655	net	25
automatic	*741	elevent†	*811	hundred	*640	nine	09
B	22	emergency	*937	I	43	nine†	*809
be	22	enter	*995	inch	*964	nineteen†	*894
base	*911	equal	*893	india	*643	north	*772
between	*660	evening†	*843	information	*996	not	*695
bravo	*622	exit	*761	-ing	*948	november	*662
break	*743	F	33	inspector	*785	number	*734
button	*993	fail	*755	intruder	*764	O	63
C	23	farad	*930	is	*733	o'clock†	*824
calibrate	*735	feet	15	is†	*823	of	*694
call	*751	fif-	50	J	51	off	*614
cancel	*664	fifteen†	*854	jay	51	oh	63
caution	*711	fifty†	*850	juliet	*651	oh†	*800
change	*875	fire	*634	K	52	ohms	*933
charlie	*623	five	05	kaye	52	on	*613
check	*865	five†	*805	kilo	*652	one	01
circuit	*720	flow	*960	knot	*695	one†	*801
clock	*945	for	04	L	53	open	94
club	*926	forty†	*840	light	*934	operator	*630
code	75	four	04	lima	*653	oscar	*663
complete	*721	four†	*804	line	*942	out	*740
computer	*927	fourteen†	*814	link	*998	over	*773
connect	*940	foxtrot	*633	left	*770		
control	*624	frequency	*610	look	*957		
crane	*950	from	64	low	*771		
cycle	*951						

P	71
patch	*966
papa	*671
pass	*774
passed	*974
percent	*675
phone	*914
pico	*932
please	*967
plus	*611
point	*674
position	*780
police	*968
power	*714
practice	85
press	*781
pressure	*935
probe	*975
pull	*980
push	*977
(pause)	34
Q	70
quebec	*670
R	72
radio	*976
range	*981
ready	*783
red	*744
remote	*910
repair	*745
repeat	*982
repeater	80
right	*665
romeo	*672
S	73
safe	*784
sea	23
seconds	*635
see	23
service	*723
set	*885
seven	07
sevent	*807
seventeen†	*874
shut	*765
sierra	*673
six	06
six†	*806
sixteen†	*864
slow	*983

smoke	*795
south	*790
speed	*984
s (suffix)	*915
start	*730
stop	*731
switch	*725
system	*997

T	81
(see -ty for suffix)	
tango	*681
tea	81
-teen	14
temperature	*724
ten	10
ten†	*810
test	*792
thank you	*978
the	24
the†	*821
thir-	13,30
thirteen†	*813
thirty†	*830
this is	65
thousand	*644
three	03
three†	*803
time	44
time†	*822
timer	*732
to	02
tomorrow	55
tonight	45
too	02
tool	*985
turn	*990
twelve	12
twelve†	*812
twenty	20
twenty†	*820
two	02
two†	*802
-ty	60

U	82
under	*775
uniform	*682
unit	*715
up	*650

V	83
valley	*986
valve	*941
victor	*683
volts	*750

W	91
wait	54
watts	*815
weather	95
whether	95
welcome	*913
west	*793
what's	*815
whiskey	*691
will	*912
won	01
write	*665
why	93

X	92
x-ray	*692

Y	93
yankee	*693
yellow	*794
you	82
your	*987

Z	90
zed	*988
zero	00
zulu	*690

† = female speaker

\*9xx take 2 character slots

Numbers - male

zero	00
oh	63
one	01
two	02
three	03
four	04
five	05
six	06
seven	07
eight	08
nine	09
ten	10
eleven	11
twelve	12
thir-	13
-teen	14
twenty	20
fif-	50
hundred	*640
thousand	*644
-ty	60

Numbers - female

oh†	*800
one†	*801
two†	*802
three†	*803
four†	*804
five†	*805
six†	*806
sevent†	*807
eight†	*808
nine†	*809
ten†	*810
elevent†	*811
twelve†	*812
thirteent†	*813
fourteent†	*814
fifteent†	*854
sixteent†	*864
seventeent†	*874
eighteent†	*884
nineteent†	*894
twenty†	*820
thirty†	*830
forty†	*840
fifty†	*850

Sound effects

crowd	*892
explosion	*891
laser	*873
phaser	*882
tic	*860
toc	*870
train	*883
whistle	*881

Colors

green	*762
red	*744
yellow	*794

Directions

east	*754
north	*772
south	*790
west	*793

Names

charlie	*623
dee	31
henry	*642
jay	51
juliet	*651
kaye	52
mike	*661
oscar	*663
papa	*671
romeo	*672
victor	*683

Macros

macro 1	*861
macro 2	*862
macro 3	*863
macro 4	*852

Run-Time Variables

m/a/e	*844
time	*872
am/pm	*832
date	*833
mail present	*994
t.o.period	*5731
# mail	*5732
VRT	*57xx

Change Type

Morse	*50
speech	*51
dtmf	*52(digits)
pager	*53xx
ASCII	*54x
DVR	*55xyz
ext dev	*56x
tts	*58x

## Message Groups

Message selection commands are grouped in the following pages as:

- Alarm
- Courtesy Tone
- Control Op Command Response
- Demo / Bulletin Board / Pad Test
- Emergency Autodialer Responses
- ID
- Macros
- Mailbox
- Pager Prompt
- Patch
- Remote Base / Link
- Scheduler
- Special Patch Utilities
- Tail Messages
- Timeout Messages
- Touch-Tone Cover Tone
- User Call Signs
- User Function Responses

<b>Alarm Messages</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Alarm #1	*1078	*1178	"AL1"	10
Alarm #2	*1079	*1179	"AL2"	10
Alarm #3	*10106	*11106	"AL3"	5
Alarm #4	*10107	*11107	"AL4"	5

**Purpose**

The Alarm messages are generated periodically when the alarms are triggered.

**Remarks**

The alarms may activate the transmitter and announce the alarm messages defined above.

**Examples**

"Power amp's over temperature"  
 "Intruder, (laser), intruder"

**See Also**

Operation Manual - "Alarms"

**Courtesy Tone Messages**

Courtesy Tone #1	*1041	*1141	"CT1"	4
Courtesy Tone #2	*1042	*1142	"CT2"	4
Courtesy Tone #3	*1043	*1143	"CT3"	4
Courtesy Tone #4	*1044	*1144	"CT4"	4
Courtesy Tone #5	*1045	*1145	"CT5"	4
Courtesy Tone #6	*1046	*1146	"CT6"	4
Courtesy Tone #7	*1047	*1147	"CT7"	4
Courtesy Tone #8	*1048	*1148	"CT8"	4
Courtesy Tone #9	*10109	*11109	"CT9"	4
Courtesy Tone #10	*10110	*11110	"CT ten"	4
Courtesy Tone #11	*10111	*11111	"CT eleven"	4
Courtesy Tone #12	*10112	*11112	"CT twelve"	4
Courtesy Tone #13	*10113	*11113	"CT thirteen"	4

**Purpose**

The Courtesy Tone Messages may be Morse code characters, synthesized speech vocabulary such as sound effects, DVR tracks, etc.

**Remarks**

Courtesy Tones are generated at the end of each user transmission. The tone indicates that the timeout timer has been reset and that the next user may transmit. The one of twelve tone sets selected by the controller may also convey information, or telemetry, to users. Courtesy Tone 13, generated in addition to one of twelve, indicates a link or remote base in the transmit enabled mode. Courtesy Tones may be sine wave tone sets defined using the Courtesy Tone Parameter Programming commands, or may be *messages* defined above.

**HINT**

Courtesy Tones defined as *messages* override any sine wave tone sets defined for that particular courtesy tone. To restore sine wave tone sets, load an empty message into that set using the commands above (select the message, enter “\*0” without entering any characters). Delay to the courtesy tone, and hang time, are always defined using the sine wave tone set commands (see Chapter 6 - “Courtesy Tone Parameters”).

**Examples**

- “N” (for use during net)
- “DC” (for use during battery backup operation)
- “tic-toc” (for general use)

**See Also**

Programming Reference Manual - “Courtesy Tone Parameters”  
 Operation Manual - “Courtesy Tones”

**Control Operator Command Response Message**

Generic Command Response \*1060 \*1160 “COPR” 6

**Purpose**

When the Control Op Command Acknowledgement Mode is selected as Generic Response, the Control Operator Generic Response message is generated by the controller when it acknowledges Control Op level commands.

**Examples**

“dit-dit (Morse code “I”)” “R” “C”

**See Also**

Control Operator’s Reference Manual - “Control Operator Utilities”

**Demo / Bulletin Board Messages**

Demo Tag	*1067	*1167	“DEMO”	18
Bulletin Board #1	*10101	*11101	“B1”	24
Bulletin Board #2	*10102	*11102	“B2”	24
Bulletin Board #3	*10103	*11103	“B3”	24
Bulletin Board #4	*10104	*11104	“B4”	24
Bulletin Board #5	*10105	*11105	“B5”	24
Pad Test Responses	*10120	*11120	“PAD”	16

**Purpose**

The Demo Tag message follows the selected stored call sign using the Demo User command. The Bulletin Board messages are available to users as a means of posting information. The pad test responses determine the pad test readback for each of the 16 keys.

## Operation Manual V3.8 Errata

(p. 7-8 8/87/V3)

*Add...*

### Previewing the User Loadable Autodialer Numbers

Autodial numbers can be read back from the phone and from over the air without dialing them in order to determine or verify their contents.

User Command

[User Loadable Autodial Bank 0/1/2 Load/Erase Prefix] \* [two digit location]

(p.11-3 8/87 V3)

*Add...*

### Telemetry Channels

Channel # Description

30 Number of Emergency Autodials

## Programming Reference Manual V3.8 Errata

(p. 3-13 8/87 V3)

*Change...*

<b>Macros</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Macro 1	*10141	*11141	"M1"	10 22
Macro 2	*10142	*11142	"M2"	10 22
Macro 3	*10143	*11143	"M3"	6 22
Macro 4	*10144	*11144	"M4"	6 22





Pending ID - "From eight-teen hundred feet, this is WA6AXX Repeater."  
 Touch-Tone Access Down ID - "Seventy three, from WA6AXX Repeater."  
 QST ID - "This is WA6AXX Repeater, open system, PL 100 Hz."



**WARNING**

The Periodic QST ID should be used only when a Control Operator is on duty at a local or remote control point. Automatic control of bulletin transmissions is not authorized on repeater output frequencies by Part 97. Use of the Periodic QST ID to "make your presence known" on a frequency, when you have reason to believe that it may cause interference to co-channel users, is an invitation for a citation from the FCC.

<b>Macros</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Macro 1	*10141	*11141	"M1"	22
Macro 2	*10142	*11142	"M2"	22
Macro 3	*10143	*11143	"M3"	22
Macro 4	*10144	*11144	"M4"	22

**Purpose**

The macro messages may be included in other programmable messages to make the most efficient use of the storage space available.

**Remarks**

Macros are useful for storing the repeater's call sign, so that it only need be stored once in the controller's memory. Various ID's can include the "ID" macro, which is expanded out to the full call sign. Macros are also useful whenever there isn't sufficient space to store a particular message.

**Example**

Macro 1 can be loaded with the repeater call sign in synthesized speech, "WA6AXX, repeater". The various speech ID messages can be edited using the Macro 1 in place of the complete call sign.

**See Also**

Programming Reference Manual - "Advanced Message Editing (Message Macros)"

<b>Mailbox Messages</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Mailbox Message #0	*1090	*1190	"MBM0"	6
Mailbox Message #1	*1091	*1191	"MBM1"	10
Mailbox Message #2	*1092	*1192	"MBM2"	10
Mailbox Message #3	*1093	*1193	"MBM3"	10
Mailbox Message #4	*1094	*1194	"MBM4"	18
Mailbox Message #5	*1095	*1195	"MBM5"	18
Mailbox Message #6	*1096	*1196	"MBM6"	18
Mailbox Message #7	*1097	*1197	"MBM7"	18
Mailbox Message #8	*1098	*1198	"MBM8"	18
Mailbox Message #9	*1099	*1199	"MBM9"	50
Mail Present Message	*1073	*1173	"MAIL"	5

**Purpose**

The Mailbox messages are the canned "notes" which may be left by one user for another. The Mail Present message may be included in any of the programmable messages as a run-time variable as an indication to users of mail present.

**Remarks**

The Mail Present message is an indication to users that mail is in the mailbox and that they might want to check to see if there is any for them.

The Mail Present run-time variable string might typically be included in Initial ID's, Pending ID's, and Tail Messages. [Run time variables are discussed in detail in the next chapter.] If there is mail present, the Mail Present Message is announced. If there is no mail, nothing is announced as a result of the Mail Present run-time variable included in the message.

**Examples**

Mailbox messages - "Phone home" "Call me on PIY repeater" "Call me at..."  
 "The repeater will be down for service tomorrow from 2 p.m. to 5 p.m. Call AXX for information."

Mail present message - "(pause) (pause) Check for messages"

It could be included in a Tail Message as "Good (morning/afternoon/evening) (Mail Present run time variable)". If mail were present (in the morning), the Tail Message would say "Good morning, check for messages". If there were no mail, it would simply say "Good morning".

**See Also**

Operation Manual - "Demo Messages, Bulletin Board, and the Mailbox"

<b>Pager Prompt</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
	*10152	*11152	"PPRO"	10

**Purpose**

The Pager Prompt message is generated by the controller during a tone and voice page to allow time for the pager squelch to open and to cue the person when to begin speaking.

**Remarks**

The duration of the message should be long enough to allow the user's pager to stop beeping and open squelch.

**Example**

"Ready, set, ... go!"

<b>Patch Messages</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Autopatch Activate	*1020	*1120	"AP up"	6
User Autodial Activate	*1029	*1129	"ADU up"	6
Antidial	*1072	*1172	"A N T I"	10
Patch Cover Tone	*1018	*1118	"PCT"	6
Patch Timeout Warning	*1017	*1117	"P time out alert"	6
Phone Answer	*1065	*1165	"P H A N"	18
Phone Hangup	*1066	*1166	"H A N G"	10
Reverse Patch Call-For	*10151	*11151	"RPC"	4

**Purpose**

These messages are generated at various times related to patch operation.

**Remarks**

The Autopatch and User Loadable Autodialer Activate messages are announced when a user brings up the patch in one of these modes.

The Antidial message is generated when a user brings up the Autopatch with a phone number trapped out by the antidialer.

The Patch Cover Tone is generated in place of the mobile's audio when the cover tone is active during a patch.

The Patch Timeout Warning message tells the user that the patch is about to time out. The user can complete the call or extend the timer.

The Phone Answer message is generated by the controller when answering an incoming phone call; that is, when someone calls the repeater on the phone.

The Phone Hangup message is generated when the the controller hangs up the phone.

The Reverse Patch "call-for" message is generated before the call-sign during directed reverse patches.

**Examples**

Autopatch Activate - "Auto patch"

User Loadable Autodialer Activate - "Auto dial"

Antidial - "Contact control operator"

Patch Cover Tone - "Beep-beep" [Morse code I]

Phone Answer - "Good (morning/afternoon/evening), this is WA6AXX Repeater, control."

Phone Hangup - "Call complete at (time) (am/pm) on (date)"  
 Reverse Patch "Call-For" - "Call for"

**See Also**

Operation Manual - "Telephone Interconnect"

**Remote Base / Link Messages**

Remote Base #1 Name	*1063	*1163	"L1"	6
Remote Base #2 Name	*1064	*1164	"L2"	6
Remote Base #3 Name	*10115	*11115	"L3"	4
Remote Base #4 Name	*10114	*11114	"L4"	4
Remote Base #1 Freq. Prefix	*1061	*1161	"Remote 1 P"	6
Remote Base #2 Freq. Prefix	*1062	*1162	"Remote 2 P"	6
Remote Base #1 Mem. 1 Name	*10121	*11121	"L1N1"	6
Remote Base #1 Mem. 2 Name	*10122	*11122	"L1N2"	6
Remote Base #1 Mem. 3 Name	*10123	*11123	"L1N3"	6
Remote Base #1 Mem. 4 Name	*10124	*11124	"L1N4"	6
Remote Base #1 Mem. 5 Name	*10125	*11125	"L1N5"	6
Remote Base #1 Mem. 6 Name	*10126	*11126	"L1N6"	6
Remote Base #1 Mem. 7 Name	*10127	*11127	"L1N7"	6
Remote Base #2 Mem. 1 Name	*10131	*11131	"L2N1"	6
Remote Base #2 Mem. 2 Name	*10132	*11132	"L2N2"	6
Remote Base #2 Mem. 3 Name	*10133	*11133	"L2N3"	6
Remote Base #2 Mem. 4 Name	*10134	*11134	"L2N4"	6
Remote Base #2 Mem. 5 Name	*10135	*11135	"L2N5"	6
Remote Base #2 Mem. 6 Name	*10136	*11136	"L2N6"	6
Remote Base #2 Mem. 7 Name	*10137	*11137	"L2N7"	6

**Purpose**

These messages relate to operation of the Remote Bases and Links.

**Remarks**

The remote base names allow the user to verify he's entered the intended commands, and lets listeners understand what they're listening to.

The frequency prefixes allow frequency readback to announce the complete frequency, by preceding the MHz digit to the hundreds and tens MHz information.

The memory names replace frequency readback for a more meaningful response when selecting frequency memories. These require 8K E<sup>2</sup>PROM for storage.

**NOTE**

When all BCD frequency digits are set to zero, the controller always responds with the name in place of frequency readback. If a remote is a single channel transceiver, set the frequency to its actual frequency for meaningful readback, or to all zeros so the controller reads back its name in place of frequency.

**Examples**

Remote Base Names - "Two meter" "UHF" "23 centi meter"  
 Frequency Prefix - "One four -ty" "Four four -ty" "Twelve nine -ty"

**See Also**

Operation Manual - "Remote Bases"

**Scheduler**

Changeover Announcement	*10140	*11140	"Change over"	5
Event 1 Message	*10146	*11146	"E1"	12
Event 2 Message	*10147	*11147	"E2"	12
Event 3 Message	*10148	*11148	"E3"	12
Event 4 Message	*10149	*11149	"E4"	12
Event 5 Message	*10150	*11150	"E5"	12

**Purpose**

These messages are generated at scheduler changeovers and events.

**Remarks**

The Changeover Announcement is generated at a changeover when a new Macro Set is loaded by the scheduler. If the repeater transmitter is on the air, the announcement is made; if the transmitter is off the air, it isn't. Event messages are generated by the controller at scheduled event times.

**Examples**

Changeover Announcement - "Automatic control operator change over"  
 Event Message - "Net in two minutes"

**See Also**

Operation Manual - "The Scheduler"

**Special Patch Utilities**

	<u>(Speech)</u>	<u>Response</u>	<u># Chars</u>
Phone Number Leading "1" Override	*1168	"LD over"	6
Phone Number Macro "A"	*11128	"MA"	6
Phone Number Macro "B"	*11129	"MB"	6
Phone Number Macro "C"	*11130	"MC"	6
Local Area Code	*1169	"Area code L"	3
Adjacent Area Code	*1170	"Area code J"	3
Permitted Area Code #1	*11117	"Area code P1"	3
Permitted Area Code #2	*11118	"Area code P2"	3
Permitted Area Code #3	*11119	"Area code P3"	3
Primary Patch Dialing Prefix	*1171	"PPRE"	8
Secondary Patch Dialing Prefix	*11138	"SPRE"	6
Tertiary Patch Dialing Prefix	*11139	"TPRE"	6

**Purpose**

The above information relates to patch operation. The information is stored using the message editor.

**Remarks**

The "override" and macro digit strings replace the first digit of any Autopatch or autodial phone number when its first digit is 1, A, B, or C. They allow macro-like expansion of area codes or other special sequences without requiring the full amount of storage in each autodial location.

The local and adjacent area codes cross reference to the stored exchange tables, which allow design of a custom calling area.

The permitted area codes are additional area codes in which all exchanges are considered to be local, or permitted.

The Patch Dialing Prefixes precede Autopatch and autodialer calls placed by the controller, based on the Autopatch access code, or prefix stored with the autodial number.

**See Also**

Operation Manual - "Telephone Interconnect"

**Examples**

An unusual phone company requires long distance calls to be placed with a leading "1121" instead of the normal leading 1. The Phone Number Leading 1 Override Message may be loaded with "1121". Long distance calls can then be placed through the controller with the standard leading 1 - the controller expands it out to the required 1121.

Many of our autodial numbers are 11 digit numbers, beginning with 1-415 and 1-602. We can load the Phone Number Macro A and B Messages with "1415" and "1602" respectively. We can now use eight digit autodial slots for these phone numbers by replacing the stored 1 and area code with A or B.

Our local area code is 408, and our adjacent area code is 415. We can load these into the Local and Adjacent Area Code messages, so that when Autopatch calls are placed, the controller checks the appropriate exchange tables to determine if the call is long distance.

From the repeater's location, all calls to area code 714 are toll-free, even though they require a leading 1. We can load "714" into Permitted Area Code #1, #2, or #3.

Our controller is connected to a PBX extension. All local calls should be preceded by "9 (pause)", while "7 (pause)" accesses a tie line to a nearby city. We can load the Primary Patch Dialing Prefix message with "9 (pause)", the Secondary with "7 (pause)", and the Tertiary Prefix as empty. The three Autopatch prefixes then automatically access the local line, the tie line, or the PBX directly.

<b>Tail Messages</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Tail Message #1	*1011	*1111	"TM1"	6
Tail Message #2	*1012	*1112	"TM2"	6
Tail Message #3	*1013	*1113	"TM3"	6
Tail Message #4(0)	*1014	*1114	"TM40"	6
Tail Message #4(1)	*1081	*1181	"TM41"	8
Tail Message #4(2)	*1082	*1182	"TM42"	8
Tail Message #4(3)	*1083	*1183	"TM43"	8
Tail Message #4(4)	*1084	*1184	"TM44"	8
Tail Message #4(5)	*1085	*1185	"TM45"	8
Tail Message #4(6)	*1086	*1186	"TM46"	8
Tail Message #4(7)	*1087	*1187	"TM47"	8
Tail Message #4(8)	*1088	*1188	"TM48"	8
Tail Message #4(9)	*1089	*1189	"TM49"	8

**Purpose**

These are messages which may be selected to be announced periodically at the end of the repeater's hang time.

**Remarks**

When Tail Message #4 is selected, the controller generates TM4(0) through TM4(9) based on the Macro Set currently selected manually or by the scheduler.

**See Also**

Operation Manual - "Tail Messages"  
 Control Operator's Reference Manual - "Tail Messages"

**Examples**

"Net tonight at 8" "Weather alert!" "(time), (mail present)"

<b>Timeout Messages</b>	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Repeater Timeout	*1015	*1115	"Repeater timeout"	6
Repeater Timeout Clear	*1016	*1116	"Repeater timeout cancel"	10
Patch Timeout Warning	*1017	*1117	"Patch timeout alert"	6

**Purpose**

These messages announce timed out conditions of the repeater and the patch.

**Remarks**

The Repeater Timeout announcement warns listeners that the user has timed out the machine. The Timeout Clear message announces that it is again available. The Patch Timeout Warning message indicates to the patch user that he has 30 seconds before the patch times out. He may extend the patch timer if desired.

**Examples**

Repeater Timeout - "Repeater time out - please wait"  
 Timeout Clear - "Time out cancel, (gun) (gun)"  
 Patch Timeout Warning - "Thir -ty seconds left"

**Touch-Tone Cover Tone**

<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
*1019	*1119	TTCT	4

**Purpose**

This message is generated over the user's muted Touch-Tone commands.

**Examples**

"dit" [Morse code E], "tic-toc"

**User Call Signs**

	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
Call Sign	*12xx (xx = 00-99)	"Call"	6

**Purpose**

These messages are the call signs of the repeater's users.

**Remarks**

Call sign messages are used for the Directed Reverse Patch, the Mailbox, and for individual user access code cross-reference. The call sign messages should be synthesized speech.

Slots 78 and 79 are special. The unanswered reverse patch mailbox message is left *for* the user, *from* slot 79. Uncleared alarm messages are left *for* slot 78, *from* slot 79. Slot 79 should therefore be loaded with a message such as "The Repeater", or "The system", while 78 should be loaded with a message such as "Control Operators".

**HINT**

Call sign slots 80-99 are available only with the 8K byte E<sup>2</sup>PROM.

**Examples**

"WA6AXX", "N6HWL", "WB6 kilo hotel papa", "The repeater system"

**User Function Response Messages**

	<u>Morse</u>	<u>Speech</u>	<u>Response</u>	<u># Chars</u>
User Function 1 High	*1021	*1121	"UF 1 high"	6
User Function 1 Low	*1031	*1131	"UF 1 low"	6
User Function 2 High	*1022	*1122	"UF 2 high"	6
User Function 2 Low	*1032	*1132	"UF 2 low"	6
User Function 3 High	*1023	*1123	"UF 3 high"	6
User Function 3 Low	*1033	*1133	"UF 3 low"	6
User Function 4 High	*1024	*1124	"UF 4 high"	6
User Function 4 Low	*1034	*1134	"UF 4 low"	6
User Function 5 High	*1025	*1125	"UF 5 high"	6
User Function 5 Low	*1035	*1135	"UF 5 low"	6



User Function 6 High	*1026	*1126	"UF 6 high"	6
User Function 6 Low	*1036	*1136	"UF 6 low"	6
User Function 7 High	*1027	*1127	"UF 7 high"	6
User Function 7 Low	*1037	*1137	"UF 7 low"	6
User Function 8 High	*1028	*1128	"UF 8 high"	6
User Function 8 Low	*1038	*1138	"UF 8 low"	6
User Function Byte 1 Name	*1030	*1130	"UFB1"	6
User Function Byte 2 Name	*1039	*1139	"UFB2"	6

**Purpose**

The User Function response messages indicate the state of the UF remote control logic outputs, with information about what the output states mean in your system.

**Remarks**

The UF outputs can be commanded high or low, and they may be interrogated. The response is a high or low beep, plus the message defined above.

The response to User Functions 9-32 is a high or low beep, followed by the output number. UF 9-32 don't have response messages as do UF 1-8. When controlled as groups, UF Byte 1 (outputs 17-24) and Byte 2 (outputs 25-32) respond with the programmable name and the value 0-255.

**Examples**

"Two meter high power", "North west down", "B E A M"

**See Also**

Operation Manual - "General Purpose Remote Control"



## Chapter 4

# Advanced Message Editing

This chapter describes advanced message editor capabilities. You may want to skip this chapter until you become familiar with the controller's operation in general.

Programmable messages may consist of a mixture of stored vocabulary synthesized speech, run-time variable speech strings, Morse code, Digital Voice Recorder tracks, paging tones, etc. This chapter describes editing messages which consist of other than simply synthesized speech vocabulary or Morse code characters.

The topics covered include:

- Run Time Variable Speech Strings
- Message Macros
- Changing Message Type
- Touch-Tone Signalling
- Pager Memory Signalling
- Digital Voice Recorder Tracks
- External Devices

### Run-Time Variable Speech Strings

The RC-850 Repeater Controller is very smart – it can do and say much more than simply what you tell it to. For example, since the controller always knows what time it is, the time can be included in any programmable message. It also knows whether it's morning, afternoon, or evening, and can say the proper word based on the time of day; i.e., "Good Morning" in the morning, "Good Afternoon" in the afternoon, "Good Evening" in the evening.

The controller has analog measurement capabilities – it can measure voltages and convert them to temperature, signal strength, and numerous other conditions. These measurements can also be included in any programmable messages; e.g., "At *eighteen watts* on 440 MHz, this is WA6AXX, Repeater".

In addition to the real time measurements, the controller stores the max and min values for each measurement channel, and these may be included in messages as well; e.g., "The low temperature this morning, *fourteen degrees*, at WA6AXX, Repeater".

Several system related pieces of information are available, such as the period of time the repeater was last timed out. The Timeout Clear message can say "Repeater time out for *32 seconds*".

These are examples of controller generated synthesized speech strings determined by the controller at run-time – the actual time when they're said.

The run-time variable speech strings available in the message editor are defined below, and include:

- Time and Date
- Mailbox
- Telemetry
- Stored High Value Telemetry
- Stored Low Value Telemetry

**Remember that run-time variables are used just like other synthesized speech vocabulary after unlocking the controller and selecting a message to edit.**

### Time and Date Run-Time Variables

Morning/Afternoon/Evening	*844
Time (in 12 or 24 hour format)	*872
A.M. or P.M. (if 12 hour format)	*832
Date (month and day)	*833

These are announcements which are determined by the time of day and date. Time announcements are based on 12 or 24 hour clock mode selected by the repeater owner.

**Examples**

Morning/Afternoon/Evening in Tail Message: "Good (morning/afternoon/evening)"

Time (12 hour), am/pm, Date in Phone Hangup Message: "Call complete at (time) (am/pm) on (date)"

**Mailbox Run-Time Variables**

Mail Present	*994	(requires 2 character slots)
Number of Messages in Mailbox	*5732	(requires 2 character slots)

The Mail Present variable expands out to the "Mail Present" message if there is mail in the mailbox. If there is no mail in the mailbox, nothing is generated.

The Number of Messages variable indicates the quantity of mail currently in the mailbox. This run-time variable requires two character slots.

**Example**

Assume the Mail Present Message = (number of messages run-time variable) + (pause) + ("check it out") and that a Tail Message = (mail present run-time variable). If there are three mailbox messages, the tail message would expand out to "Three messages, check it out". If there were no mail, the tail message would be silent.

**See Also**

Operation Manual - "Demo Messages, Bulltetin Board, and the Mailbox"

**Telemetry Run-Time Variables**

VRT channel 1-32 measurement \*571 - \*5732 (require 2 character slots)

Channels 1-16 are hardware analog inputs 1-16. Each input has assigned to it a "meter face" which determines scaling and measurement unit readback.

Channels 17-32 are additional types of weather related telemetry measured digitally by the controller, and also system datalogging information.

**Examples**

The Temperature meter face is assigned to channel 15. Including "\*5715" in a programmable message results in "Fifty five degrees" (the actual measured temperature) to be spoken as part of the message.

Channel 25 is defined in the firmware as the "Number of repeater keyups" since last cleared. Including "\*5725" in a message results in "Seventeen" (or whatever the actual number of keyups was).

**See Also**

Operation Manual - "Telemetry"

**Stored High Value Telemetry Run-Time Variables**

VRT Channel 1-32 max value \*5733 - \*5764 (channel+32)

Channels 33-64 store the highest measured value of channels 1-32. They are available for inclusion in messages and require two character slots.

High value channels are cleared manually with Control Op commands, or as Scheduler events. You could clear the outside temp max value channel each morning so that it contains valid daytime high temp data through the evening.

**Example**

Channel 47 stores the max measured value of channel 15 in the example above. Inclusion in a message results in the highest temperature, i.e., "seventy two degrees" to be spoken. An ID message could say, "To-days high temperature, *seventy two degrees*, at WA6AXX, Repeater".

**Stored Low Value Telemetry Run-Time Variables**

VRT Channel 1-16 min value \*5765 - \*5780 (channel+64)

Channels 65-80 store the lowest measured value of channels 1-16. They are available for inclusion in messages and require two character slots.

Min value channels are cleared manually with Control Op commands, or as Scheduler events. You might want to clear the outside temperature min value channel each evening so it contains valid overnight low temperature data throughout the next day.

**Example**

Channel 79 stores the lowest measured value of channel 15 in the example above. Inclusion in a message results in the lowest temperature; e.g., "forty five degrees", to be spoken. An ID message could say "Good morning - the low temperature, *forty five degrees*, at WA6AXX, Repeater".

**Message Macros**

	(from Morse)	(from speech)
Macro 1	15	*861
Macro 2	25	*862
Macro 3	35	*863
Macro 4	45	*852

Each programmable message is limited to a maximum size. Normally, there's plenty of room to fit everything you want a message to say in the space provided. Occasionally, there may not be room. The "message macros" are programmable messages which may be inserted inside other messages.

For example, your repeater call sign is used in all the repeater ID messages. By programming the speech call sign into one macro, and the Morse call sign into another, and inserting the macros inside the ID messages, you have more room in each ID for other information.

**Examples**

Macro #1 = "WA6AXX, Repeater" [speech]

Pending ID #2 = "Good afternoon, this is (macro #1), at eight teen hundred feet overlooking repeater valley"

**Changing Message Type**

Each programmable message may contain a mixture of Morse code and synthesized speech characters, Digital Voice Recorder tracks, paging tones, voice response telemetry measurements, etc.

After the controller is unlocked, the message to be edited is selected by a programming command, which specifies whether it *starts out* as a Morse code or speech message. At any point inside the message, a different "type" may be selected. For example, an ID message may say in synthesized speech "From fifteen hundred feet, this is WA6AXX, Repeater...", then switch to Morse code to say "SAN JOSE".

Messages which start as a type other than Morse or speech should be selected as a speech message with the appropriate programming command, and then the first "character" entered into the message should be a type change.

The commands to change message type within a message are summarized below and described individually. (^ means unkey over the air, or enter # from phone.)

	<u>code</u>	<u>response</u>
Change to Morse (until another "change")	*50^	"check"
Change to speech (until another "change")	*51^	"check"
DTMF digits	*52(digits)^	(dtmf)
Pager memory xy and optional data	*53xy(data)^	(paging tones)
Digital Voice Recorder Track #0-127	*55xyz^	(dvr track)
External device #1-4 activate	*56x^	(ext dev)

**Change to Morse Code**

While editing a message, "\*50" may be imbedded anywhere within the character sequence. All characters following the \*50 (until a new "change" command) are generated as Morse code.

**Example** Pending ID #1 = [speech] This is WA6AXX, Repeater [Morse] SAN JOSE  
 Unlock and select PID1 as speech message (\*1104)  
 Enter 65 91 21 06 21 92 92 34 80 34 ^ \*50 ^ 73 21 62 11 51 63  
 73 32

As usual, you may unkey (or enter # from phone) at various points along the way while entering the message. The controller will read back what you entered during that transmission, so that you can be sure that you're entering what you intend. Be sure to unkey before and after the change command.

### Change to Synthesized Speech

While editing a message, “\*51” may be imbedded anywhere within the character sequence. All characters following the \*51 (until a new “change” command) are generated as synthesized speech.

**Example** Pending ID #1 = above example plus [speech] seven -ty three  
 Unlock and select PID1 as speech message (\*1104)  
 Enter 65 91 21 06 21 92 92 34 80 34 ^ \*50 ^ 73 21 62 11 51 63 73  
 32 ^ \*51 ^ 34 07 60 03

### Touch-Tone Signalling

While editing a message, “\*52” may be imbedded anywhere within the character sequence. All characters following the \*52 until the end of the transmission (or until the # over the phone) are generated directly as Touch-Tone, with one tone generated per digit entered. The \*52 and tone digits *must be entered as a single transmission*. Touch-Tone # and D may not be generated with this method.

\*52[Touch-Tone digits] entered as a single transmission

**Example** Alarm #1 message = Touch-Tone sequence “ABC1472580369” followed by [speech] “intruder alert”  
 Unlock and select Alarm #1 message as speech message (\*1178)  
 Enter \*52ABC1472580369 ^ \*51 ^ \*764 40

### Pager Memory Signalling

Paging tones stored in the controller’s 50 user memories may be generated from any of the programmable messages. Paging formats which include optional data transmission may include data to be sent along with the activation tones. Tone and voice formats may be specified so that a synthesized speech message or DVR track may follow.

\*53xx[\*][data] ^  
 xx = 00-49  
 \* is optional – indicates voice page for HSC and GSC only  
 data is optional – numeric encoded data

**Example** Pager memory 25 addresses a five-tone sequential pager. We want to follow the paging tones with a synthesized speech message saying “Net in two minutes”. Event #1 is scheduled to occur at 7:58 pm on Tuesdays.  
 Unlock and select Event #1 message as speech message (\*11146)  
 Enter \*5325 ^ \*51 ^ 25 62 02 \*645

When the message is activated, the controller generates the paging tones followed by a brief pause to allow the pager’s speaker to open, and then says, “Net in two minutes”.



### Digital Voice Recorder Tracks

Any programmable message may include prerecorded audio from ACC's DVR. The tracks may be recorded remotely and are always available for use by the message editor. DVR tracks are referenced in messages as

\*55xyz^ where xyz is the track number 0-127

**Example** Build Pending ID1 from DVR tracks 3 and 19 and speech words.

Unlock and select PID1 as a speech message (\*1104)

Enter \*553 ^ \*5519 ^ \*51 ^ 65 91 21 06 21 92 92 34 80

When the message is activated, the controller replays DVR tracks 3 and 19, followed by synthesized speech, "This is WA6AXX, Repeater."

### External Devices

External tape playback units and other devices may be activated from any programmable message. Up to four devices may be addressed independently. External devices are referenced in messages as

\*56x^ where x is external device #1-4

**Example** Specify Pending ID1 as external device #2.

Unlock and select PID1 as a speech message (\*1104)

Enter \*562 ^

When the message is activated, the controller strobes device #2 and waits for its busy signal to return inactive.



## Chapter 5

# Morse Code Parameters

The characteristics of messages generated by the controller in Morse code are fully programmable. The speed, pitch, and level of various classes of Morse code messages may be programmed independently. Control Operator responses could be high speed; informative ID messages can be sent more slowly; the Forced CW ID can be lower in level and high in pitch so it can be heard yet not compete with the user talking.

The following sections describe programming the speed, pitch, and level of the Morse code messages. There are seven classes of messages:

- Initial ID Messages
- Forced CW ID Message
- Anxious ID Message
- Pending ID, Periodic QST ID, Pager and Phone Line ID Messages
- Special ID Message
- User Command Response Messages, including
  - All User level command responses
  - Tail Messages
  - Courtesy Tone Messages
  - Repeater and Patch Timeout Messages
- Control Operator Response Messages, including
  - Control Operator level command responses
  - Programming level command responses

### Morse Code Speed

The speed of response messages can be selected to be between 5 and 35 words per minute. The commands include the speed directly in WPM.

Initial ID	*2000(speed)	speed = 5-35 WPM
Forced CW ID	*2001(speed)	
Anxious ID	*2002(speed)	
Pending/QST ID	*2003(speed)	
Special ID	*2004(speed)	
User Command	*2005(speed)	
Control Op Command	*2006(speed)	

### Examples

Set the Forced CW ID speed to 20 WPM - \*200120

Set the Control Op Command response speed to 35 WPM - \*200635

**WARNING**

Part 97 requires Morse code repeater ID's to be 20 WPM or less.

**Morse Code Pitch**

The pitch of Morse code messages can be programmed to be between 0 and several thousand Hertz. The practical high frequency limit for clean sine waves is approximately 3000 Hz. The commands include the pitch directly in Hertz.

Initial ID	*2010(pitch)	pitch = 0-3000 Hz
Forced CW ID	*2011(pitch)	
Anxious ID	*2012(pitch)	
Pending/QST ID	*2013(pitch)	
Special ID	*2014(pitch)	
User Command	*2015(pitch)	
Control Op Command	*2016(pitch)	

**Examples**

Set the Forced CW ID pitch to 880 Hz - \*2011880

Set the Control Op Command response pitch to 1200 Hz - \*20161200

**Morse Code Level**

The level of Morse code messages may be programmed to 0 db, -3 db, -6 db, or -9 db. 0 db is the maximum level of the controller's tone generator. For example, if the tone generator is adjusted with its pot to 3.5 kHz deviation, -3 db results in 2.5 kHz, -6 db in 1.75 kHz, and -9 db in 1.25 kHz deviation.

Initial ID	*2020(level)	level = 0 (0 db)
Forced CW ID	*2021(level)	1 (-3 db)
Anxious ID	*2022(level)	2 (-6 db)
Pending/QST ID	*2023(level)	3 (-9 db)
Special ID	*2024(level)	
User Command	*2025(level)	
Control Op Command	*2026(level)	

**Examples**

Set the Forced CW ID level to -6 db - \*20212

Set the Control Op Command response level to 0 db - \*20260

## Chapter 6

**Courtesy Tone Parameters**

The Courtesy Tone is generated by the controller at the end of each user transmission. The tone indicates that the repeater timeout timer has been reset, and that the next user may transmit. In addition to these functions, the actual tone selected (out of the twelve available) may convey telemetry, or information to users, such as status of the repeater.

The tones may be sine wave tone sets defined with Programming commands described below; or they may be messages, defined with the Courtesy Tone Message commands. Tone "messages" override tone "sets" described in this chapter. To restore a sine wave tone set if a message has been defined, an empty message must be written into the Courtesy Tone message.

Each tone set may consist of up to three segments of tones. The pitch, duration, and delay between tones may be programmed independently. The delay to the Courtesy Tone after the user unkeys, and the repeater hang time, are also programmed with these commands.

Courtesy Tones 1-8 are selected for signals through the main repeater receiver, based on a prioritized system of telemetry described in the Operation Manual (Courtesy Tones). Tones 9, 10, 11 and 12 indicate signals coming through the remote base or link receivers. Tone set 13 is generated *in addition to* the otherwise selected tone when a remote base or link is in the transmit enabled mode.

In the commands below, T is the tone set 1 through 13:

<u>Tone Set</u>	<u>T</u>
1-8	1-8
9 (RB/Link1)	9
10 (RB/Link2)	0
11 (RB/Link3)	*1
12 (RB/Link4)	*2
13 (RB/Link TX)	*3

### Delay To/Between Segments

The delay to the first segment, and the delay between tone segments, may be programmed in milliseconds.

	<u>Command</u>	<u>Response</u>	
Delay To Segment 1	*3T10(delay)	BPD	delay = 85 - 3500 ms
Delay From Segment 1 to 2	*3T20(delay)	BPD	T = tone set 1-9,0(10)
Delay From Segment 2 to 3	*3T30(delay)	BPD	*1(11), *2(12), *3(13)

### Segment Pitch

The pitch of each segment may be programmed in Hertz. Each segment is actually a dual tone, and each of the two frequencies may be programmed independently. Setting pitch A and B the same allows 0 db and -3 db levels as defined in the Segment Level commands. Setting one of the pitches to zero allows -6 db and -9 db levels. The pitches may be set differently for dual tones (similar to Touch-Tone).

Segment 1A Pitch	*3T11(pitch)	BPP	pitch = 0 - 3000 Hz
Segment 1B Pitch	*3T12(pitch)	BPP	
Segment 2A Pitch	*3T21(pitch)	BPP	
Segment 2B Pitch	*3T22(pitch)	BPP	
Segment 3A Pitch	*3T31(pitch)	BPP	
Segment 3B Pitch	*3T32(pitch)	BPP	

### Segment Level

The level of each segment can be programmed. If the two pitches for the segment are both non-zero, the level can be set to 0 db or -3 db. If one pitch is set to zero Hz, the level can be set to -6 db or -9 db.

Segment 1 Level	*3T13(level)	BPL	level = 0 (0/-6 db) 1 (-3/-9 db)
Segment 2 Level	*3T23(level)	BPL	
Segment 3 Level	*3T33(level)	BPL	

### Segment Duration

The duration of each segment can be programmed. A segment can be blanked out by setting its duration to zero.

Segment 1 Duration	*3T14(dur)	BPD	dur = 0 - 3500 ms
Segment 2 Duration	*3T24(dur)	BPD	
Segment 3 Duration	*3T34(dur)	BPD	



**Programming Example**

Design Courtesy Tone Set #4 to be a single 440 Hz, 150 ms tone, with a 250 ms delay to the tone, and a 4 second hang time.

* <u>3410</u> <u>250</u>	250 ms delay to segment 1
* <u>3411</u> <u>440</u>	pitch a = 440 Hz
* <u>3412</u> <u>440</u>	pitch b = 440 Hz (single freq. tone, 0 db)
* <u>3413</u> <u>0</u>	level = 0 db
* <u>3414</u> <u>150</u>	duration = 150 ms
* <u>3420</u> <u>0</u>	zero out delay and duration for unused
* <u>3424</u> <u>0</u>	segments 2 and 3
* <u>3430</u> <u>0</u>	
* <u>3434</u> <u>0</u>	
* <u>3440</u> <u>4000</u>	hang time = 4 second (4000 ms)

Only those parameters to be changed need be entered. For example, to increase the duration to 200 ms, enter \*3414200.



## Chapter 7 Timers

The various timers in the repeater system are programmable by the repeater owner. The timer values are entered directly in seconds as part of each command.

Certain of the timers may be disabled by setting their value to zero. For example, it may be desirable to disable the Emergency Autodialer Timer, relying on only the activity timer for emergency calls. However, disabling certain timers may have unexpected results. Disabling the Tail Message Timer, for example, will cause tail messages to be generated at every tail. Disabling the Phone Answer Delay timer will cause the phone never to be answered.

The maximum timer duration is 1799 seconds (30 minutes). Values above 1799 "wrap around" and will result in unpredictable durations.

The timers which may be programmed include:

- Alarm Timer
- Command Decoder Timers
- External Device Timer
- ID Timers
- Patch Timers
- Phone Answer Delay Timer
- Repeater Timeout Timers
- Spare Audio 1 Timer
- Tail Message Timer
- Touch-Tone Access Mode Timer
- Transmitter Turn-on Delay Timer

### HINT

Hang time and delay to the courtesy tone are programmed with Courtesy Tone Programming commands.

<b>Alarm Timer</b>	<u>Command</u>	<u>Response</u>
Alarm	*4019(period)	"AL timer"

#### **Purpose**

The alarm timer determines the length of time the alarm will sound over the air.

#### **Remarks**

If the alarm is not cleared before the timer expires, the system leaves a message in the mailbox alerting the Control Op of the alarm condition.

**Command Decoder Timers**

Sequence Interdigit Timer	*4004(period)	"SEQ"
Beginning of Transmission to Sequence	*4018(period)	"SQB"
Sequence to End of Transmission	*4005(period)	"SQE"
Individual User Access Code Timer	*4020(period)	"IUA"
Repeater Activity Timer	*4021(period)	"rptr A timer"

**Purpose**

These commands relate to command decoding.

**Remarks**

The Sequence Interdigit timer disqualifies Touch-Tone commands entered over the air when the digits are separated by more than several seconds. Its purpose is to eliminate the effects of decoder falsing.

The Beginning of Transmission to Sequence timer requires the user to key down for several seconds before starting to enter a Touch-Tone command. This can encourage users to ID before entering their commands and reject jammers.

The Sequence to End of Transmission timer disqualifies Touch-Tone commands entered long before the end of the user's transmission. It eliminates the effects of decoder falsing.

The Individual User Access Code timer determines how quickly a user must enter a command function after entering his user access code. This timer applies only to the classes of user commands which have the Individual User Access attribute set.

The Repeater Activity timer causes the controller to reload the currently selected link / remote base and user function output macro set information after a period of repeater inactivity (on the repeater receiver channel). It automatically "cleans up" these functions unintentionally left on by a user. To function, both the scheduler must be turned on, and the Repeater Activity Timer must be enabled by the Control Op.

**Examples**

- Sequence Interdigit Timer = 5 seconds (≈3-15 seconds)
- Beginning of Transmission to Sequence Timer = 0 seconds (≈0-15 seconds)
- Sequence to End of Transmission Timer = 8 seconds (≈5-15 seconds)
- Individual User Access Code Timer = 15 seconds (≈0-1799 seconds)
- Repeater Activity Timer = 600 seconds (≈60-1799 seconds)

**External Device Timer**

External Device Timer	<u>Command</u> *4028(period)	<u>Response</u> "EXT"
-----------------------	---------------------------------	--------------------------

**Purpose**

The External Device timer functions as a failsafe timer in case an external message device source fails to provide a valid busy signal to the controller.

**Example**

An external cartridge tape machine is used for a tape ID message. The tape runs about 25 seconds. The External Device timer may be set for approximately 35 seconds.

**ID Timers**

	<u>Command</u>	<u>Response</u>
Initial ID Timer	*4000(period)	"Timer IID"
Forced CW ID Timer	*4001(period)	"Timer FID"
Anxious ID Timer	*4002(period)	"Timer AID"
Pending ID Timer	*4003(period)	"Timer ID"
Periodic QST ID Timer	*4017(period)	"Timer QST"

**Purpose**

These timers define the timing related to the ID sequencing.

**Remarks**

The ID timing is described in detail in the Operation Manual, "Identification".

**Examples**

- Initial ID Timer = 10 seconds (≈1-15 seconds)
- Forced CW ID Timer = 60 seconds (≈1-? seconds)
- Anxious ID Timer = 180 seconds (≈1-? seconds)
- Pending ID Timer = 360 seconds (≈30-? seconds)



**WARNING**

The sum of the periods of the Pending ID Timer plus Anxious ID Timer plus Forced CW ID Timer must be less than 10 minutes in order to comply with Part 97.

**Patch Timers**

Autopatch Timeout	*4008(period)	"AP timeout"
User Loadable Autodialer Timeout	*4009(period)	"AU timeout"
Emergency Autodialer Timeout	*4010(period)	"AE timeout"
Patch Timer Extend Timer	*4016(period)	"Timer X"
Patch Activity Timer	*4013(period)	"APAT"
Reverse Patch Ring Timeout	*4027(period)	"RP timeout"

**Purpose**

These timers relate to patch operation.



**Repeater Timeout Timers**

Long Timeout Timer	*4006(period)	"Repeater timer L"
Short Timeout Timer	*4007(period)	"Repeater timer S"

**Purpose**

These are the repeater timeout timers which limit the maximum transmission duration through the repeater main receiver.

**Remarks**

Two values may be programmed and a Control Op or the scheduler can select one to be active.

**Examples**

Long Timeout Timer = 180 seconds (≈30-1799 seconds)  
 Short Timeout Timer = 45 seconds (≈15-1799 seconds)

**Spare Audio 1 Timer**

Spare Audio 1 Timer	*4014(period)	"SP1 timer"
---------------------	---------------	-------------

**Purpose**

This timer limits how long a user may activate the Spare Audio 1 function.

**Example**

Spare Audio 1 Timer = 90 seconds (0, ≈30-1799)

**Tail Message Timer**

Tail Message Timer	*4015(period)	"TM timer"
--------------------	---------------	------------

**Purpose**

When the Control Op "Tail Message Timer" mode is selected for tail message frequency, this timer determines how frequently the tail message is generated.

**Example**

Tail Message Timer = 600 seconds (≈60-1799 seconds)

**Touch-Tone Access Mode Timer**

Touch-Tone Access Mode Timer	*4011(period)	"TTAM"
------------------------------	---------------	--------

**Purpose**

This timer determines how long the Touch-Tone Access Mode remains "up" after the end of repeater activity.

**HIKT**

The Touch-Tone Access Mode timer may be disabled by setting the value to zero. When disabled, Touch-Tone Access may be brought up and down manually, and will not time out.

**Example**

Touch-Tone Access Mode Timer = 60 seconds (0, ≈15-1799 seconds)

**Transmitter Turn-on Delay**

Turn-on Delay \*4026(period in ms) "TX on"

**Purpose**

This timer delays turn-on of the repeater transmitter when a new signal appears at the repeater receiver. It can help reject against interference.

**Example**

Turn-on delay = 700 ms (0, ≈100-3500)

**HIKT**

This function would normally be disabled by setting the timer value to zero.

## Chapter 8

# Setting the Clock/Calendar

The RC-850 Controller includes a crystal controlled time-of-day clock and calendar. It allows users to request the time of day; the time and date may be included in any programmable message; and the clock/calendar drives the Scheduler. The clock/calendar may be set at any time after powerup with these Programming commands.

### Time of Day Set

\*4100 (am/pm) (hours 10s) (hours 1s) (minutes 10s) (minutes 1s)  
 am -> am/pm=0  
 pm -> am/pm=1

Note: The time command should be entered so that it's evaluated by the controller "straight up", or right on the new minute.

### Examples

It's 7:56 am. Enter \*410000756  
 It's 11:45 pm. Enter \*410011145

### Date Set

\*4101 (month 10s) (month 1s) (day 10s) (day 1s) (year 10s) (year 1s)

### Examples

It's March 15, 1985. Enter \*4101031585  
 It's October 25, 1999. Enter \*4101102599

### Day of Week Set

\*4102 (dow)  
 dow / 0 = Sunday  
 1 = Monday  
 2 = Tuesday  
 3 = Wednesday  
 4 = Thursday  
 5 = Friday  
 6 = Saturday

### Example

It's Monday. Enter \*41021

**Select 12/24 Hour Format**

*41031	12 hour format	(female voice readback)
*41032	24 hour format	(male voice readback)

**HINT**

The clock should always be *set* using 12 hour format. This command determines the format for time of day *announcements* requested by users or included in programmable messages.



## Chapter 9

**Command Codes / Channels**

Command code prefixes may be defined for each class of user command and for Control Operator commands. In addition, each class of user command may be assigned a set of attributes (characteristics).

**Control Operator Command Prefix and Root Set**

Control operator commands consist of a programmable prefix followed by a three-digit root code. The prefix may be between one and seven digits long. Two separate prefixes are available - one for use from over the telephone command channel, and another for use over the other command channels.

The root codes specify the actual control operator function to be performed, and are drawn from one of four different sets. The repeater owner can specify which set of root codes are to be used.

The repeater owner has the option at any time to change the command prefix, and/or the root code set, so he can partially or completely change the codes.

Control Op commands may be between four and ten digits long, for ease of use, or for optimum security. Since different prefixes may be used over the air vs. over the phone, phone commands could be short, while over the air commands could be long with A/B/C digits included to maximize security. Control operator level commands may also selectively require PL over the air, or may be disabled completely over the air and/or over the phone.

*5000(1-4)	Control Operator Command Root Set 1-4
*5001(prefix)	Control Operator Command Prefix (Over the air)
*5014(prefix)	Control Operator Command Prefix (Over the phone)

**Example**

Select control operator root set #3, and define the over the air prefix as A3C9, and the over the phone prefix as 789. With the controller unlocked, enter

```
*50003
*5001A3C9
*5014789
```

**See Also**

Control Operator's Reference Manual

## User Command Prefixes

The various classes of user commands consist of minimal length roots defined by the controller's firmware, preceded by one- to seven-digit prefixes defined with programming commands. As with Control Op commands, the tradeoff may be made between short, easy commands, or long secure ones, and they may be modified at any time remotely. The user commands are classified by function to allow independent modifications to be made for the various features. The repeater owner may want to make available only some of the user commands to users.

Care should be taken in selection of command code prefixes to avoid conflicts among the various user and Control Operator commands. Each valid command must be unique to be interpreted correctly by the controller. For example, if a Control Operator command prefix is \*2538 and the autopatch command prefix is \*, then \*2538085 could be interpreted as a control operator command with root code 085, or as an Autopatch to 253-8085.

The prefixes should also not begin with the same sequence as the Touch-Tone Pad Test to prevent a conflict.

*Any user command may be disabled* by loading an empty prefix; i.e., no digits following the \*50xx. For example, if you don't intend to use the Secondary Autopatch, you may enter \*5016 to disable access to that function. If you don't intend to use Spare Audio 1 function, enter \*5012. Disabling unused command prefixes helps minimize potential code conflicts.

## Patch Commands

*5005(prefix)	Primary Autopatch Prefix
*5016(prefix)	Secondary Autopatch Prefix
*5017(prefix)	Tertiary Autopatch Prefix
*5003(prefix)	Primary Emergency Autodialer Prefix
*5018(prefix)	Secondary Emergency Autodialer Prefix
*5004(prefix)	User Loadable Autodialer Bank 0 Prefix
*5019(prefix)	User Loadable Autodialer Bank 1 Prefix
*5029(prefix)	User Loadable Autodialer Bank 2 Prefix
*5007(prefix)	User Loadable Autodialer Bank 0 Load/Erase Prefix
*5020(prefix)	User Loadable Autodialer Bank 1 Load/Erase Prefix
*5030(prefix)	User Loadable Autodialer Bank 2 Load/Erase Prefix
*5013(prefix)	Patch Utility Group P Prefix (reverse patch answer, custom hangup, duplex, cover, timer extend)
*5021(prefix)	Patch Utility Group Q Prefix (redial, hookflash)
*5011(command)	Reverse Patch Activate Command
*5022(command)	Patch / Spare Audio 1 Hangup Command (loading an empty command makes the hangup command #)

**HINT**

The Autopatch, Emergency Autodialer, and User Loadable Autodialers may all have the same prefix. For example, if they're all "\*", with the User Loadable Autodialer Bank 1 prefix as "\*1" and Bank 2 prefix as "\*2", then \*(phone number) activates the Autopatch, \*\_0 activates an Emergency Autodialer slot, \*\_99 activates a Bank 0 User Loadable Autodialer slot, \*\_199 activates a Bank 1 Autodialer slot.

The Patch Hangup command may be set to # by loading an empty command; i.e., \*5022.

**Remote Control Commands**

- \*5023(prefix)            BSR Remote Control Prefix
- \*5002(prefix)            User Function Remote Control Prefix

**Link / Remote Base Commands**

- \*5006(prefix)            Link / Remote Base Prefix

**Others**

- \*5015(prefix)            Paging Prefix
- \*5012(command)          Spare Audio 1 On Command
- \*5010(prefix)            Demo Message / Bulletin Board Prefix
- \*5025(prefix)            Mailbox Prefix
- \*5009(prefix)            Voice Response Telemetry Prefix
- \*5008(prefix)            Touch-Tone Access Up/Down Prefix
- \*5026(prefix)            Touch-Tone Pad Test Prefix
- \*5027(prefix)            User Mapped Control Operator Command Prefix
- \*5028(prefix)            Individual User Access Code Prefix

**User Command Attributes**

Each class of user command may have associated with it an optional set of attributes. The attributes include:

- X    PL *required* for this command in Access/Command Mode B, F, and J
- Y    PL *not required* for this command in Access/Command Mode C, G, and I
- Z    User command belongs to User Command Group A or Group B
- ZZ   Requires individual user access command

Programming a new command prefix for a user command *clears all its attributes*. The attributes may be selectively set *after* the *prefix* is defined.

- (attributes) = (X Y Z ZZ)            0 = clear the attribute, 1 = set the attribute
- X    1 = PL required ...
  - Y    1 = PL not required ...
  - Z    1 = Group B (0 = Group A)
  - ZZ   1 = Requires individual user access ...

**Patch Attributes**

*5055(attributes)	Primary Autopatch Attributes
*5066(attributes)	Secondary Autopatch Attributes
*5067(attributes)	Tertiary Autopatch Attributes
*5053(attributes)	Primary Emergency Autodialer Attributes
*5068(attributes)	Secondary Emergency Autodialer Attributes
*5054(attributes)	User Loadable Autodialer Bank 0 Attributes
*5069(attributes)	User Loadable Autodialer Bank 1 Attributes
*5079(attributes)	User Loadable Autodialer Bank 2 Attributes
*5057(attributes)	User Loadable Autodialer Bank 0 Load/Erase Attributes
*5070(attributes)	User Loadable Autodialer Bank 1 Load/Erase Attributes
*5080(attributes)	User Loadable Autodialer Bank 2 Load/Erase Attributes
*5063(attributes)	Patch Utility Group P Attributes
*5071(attributes)	Patch Utility Group Q Attributes

**HINT**

The Patch Hangup attributes X and Y are the same as the attributes associated with the command to activate the patch. Attributes Z and ZZ don't apply.

**Remote Control Attributes**

*5073(attributes)	BSR Remote Control Attributes
*5052(attributes)	User Function Remote Control Attributes

**Link/Remote Base Attributes**

*5056(attributes)	Link Attributes
-------------------	-----------------

**Others**

*5065(attributes)	Paging Attributes
*5062(attributes)	Spare Audio 1 On Attributes
*5060(attributes)	Demo Message / Bulletin Board Attributes
*5075(attributes)	Mailbox Attributes
*5059(attributes)	Voice Response Telemetry Attributes
*5058(attributes)	Touch-Tone Access Up/Down Attributes
*5076(attributes)	Touch-Tone Pad Test Attributes
*5077(attributes)	User Mapped Control Operator Command Attributes
*5078(attributes)	Individual User Access / Identify Attributes

**Example**

Set the Tertiary Autopatch attributes to require PL in Access/Command Mode B, F, and J; require individual user access code before accessing.

```
*5067 1 0 0 1
      |   |
      X   ZZ
```

Remember that if the Tertiary Autopatch Prefix is reprogrammed, the attributes are cleared and must be reprogrammed.

## Individual User Access Codes

Users may be assigned individual access codes for selective access to certain functions, defined as "requires individual user access" by its attributes. The access codes are three digit numbers, ranging from 000 to 799, and follow the Individual User Access command prefix to form the user level command. In response to the user command to "open up" these functions, the controller says "control up". At that time, a programmable timer begins to run, which automatically takes control back down at its timeout. The user may also manually take control down by entering the Individual User Access prefix plus (\*). The user may interrogate the status with (IUAC).

Interrogate = (IUAC)  
Control down = (IUAC)\*

Each three digit code may be enabled or disabled individually, and for convenience, all codes may be enabled or disabled with a single command.

*4610	Disable all 800 individual user access codes
*4611	Enable all 800 individual user access codes
*4610xyz	Disable user access code xyz
*4611xyz	Enable user access code xyz (xyz = 000 - 799)

Users whose call signs are stored in the controller may be acknowledged when activating the individual user access command. A user's three digit access code should consist of *one programmable digit*, followed by their *two digit call sign slot*.

User access code = (programmable digit 0-7)(two digit callsign slot number)

The programmable first digit may be crossed to a call sign slot with the command

*45DCC	Specify first digit "D" for call sign slot "CC" (D = 0-7, CC = 00-99)
--------	--------------------------------------------------------------------------

In this way, the one hundred access codes crossed to call signs may be randomly "scattered" throughout the eight hundred possible access codes.

### Example

WA6AXX is stored in call sign slot 57. We want his individual user ID code to be 657, so that when he activates his individual user access command, the controller will acknowledge by announcing his call sign. Enter \*45657 to cross access code 657 to call sign slot 57. Access code 657 may be enabled by entering \*4611657.

The user would like to activate the Tertiary Autopatch (see example above). The Individual User Access Prefix is 1\*.

The user first enables individual user access by entering 1\*657. The controller responds by saying "WA6AXX, control up". The user may then proceed with activating the autopatch. When he's done, he may disable individual user access by entering 1\*\*, or allow it to time itself down.

## User Mapped Control Operator Commands

Up to ten Control Op level commands may be mapped to user level commands, consisting of a user level prefix followed by one digit (0-9). This capability allows the repeater owner to provide a small subset of Control Op commands to certain users, without needing to disclose the Control Op prefix and root codes.

*5000 0 xxx	User Mapped Control Op Command 0
*5000 1 xxx	User Mapped Control Op Command 1
*5000 2 xxx	User Mapped Control Op Command 2
*5000 3 xxx	User Mapped Control Op Command 3
*5000 4 xxx	User Mapped Control Op Command 4
*5000 5 xxx	User Mapped Control Op Command 5
*5000 6 xxx	User Mapped Control Op Command 6
*5000 7 xxx	User Mapped Control Op Command 7
*5000 8 xxx	User Mapped Control Op Command 8
*5000 9 xxx	User Mapped Control Op Command 9

(xxx = Control Op root 1 code)

### NOTE

Positions may be cleared by entering the Dummy root code - 231.

### Example

The repeater owner would like to make the Repeater Enable and Repeater Disable commands available to several repeater users, without disclosing Control Op level command codes. The two commands can be mapped to User Mapped Control Op Commands 0 and 1, by entering \*5000 0 031 and \*5000 1 032. Assuming the User Mapped Control Op Prefix is 654, then the commands 6540 and 6541 function as Control Op level commands for Repeater Enable and Disable.

## Primary / Secondary Unlock Code Select

Two unlock codes may be stored in the controller (see Chapter 2 - "Unlocking and Locking the Controller"). One of the two may be selected remotely.

*58080	Primary Unlock Code Select
*58081	Secondary Unlock Code Select

## Command Channel Enable / Disable

*Programming and Control Op level commands* may be blocked from several command channels to enhance system security.

*58010	Disable command from repeater receiver
*58011	Enable command from repeater receiver
*58020	Disable command from telephone
*58021	Enable command from telephone

## Chapter 10

# Logic I/O Senses

Certain of the logic inputs and outputs of the controller may be selected to be high true (high when active) or low true (low when active). These include link and remote base COS and PTT signals, the telephone offhook signal, and PL logic inputs.

### **NOTE**

Repeater transmitter PTT signal, and repeater receiver and control receiver COS signal logic senses are set with DIP switches on the main controller board. See the Hardware Reference Manual.

s = 0 => low true / active low  
s = 1 => high true / active high

- \*5100s Link / Remote Base 1 COS Logic Input
- \*5101s Link / Remote Base 2 COS Logic Input
- \*5102s Link / Remote Base 1 PTT Logic Output
- \*5103s Link / Remote Base 2 PTT Logic Output
  
- \*5108s Link / Remote Base 3 COS Logic Input
- \*5109s Link / Remote Base 4 COS Logic Input
  
- \*5104s User / Control Op PL Logic Input
- \*5112s User Only PL Logic Input

### Special Function

- \*5105p Phone Offhook p = 0/FCC registered board, 1/non-registered board
- \*5106q User Function Logic Outputs q = 0/latched, 1/expanded

### Example

Set remote base 1 PTT output to be active low.

\*51020





## Chapter 11

**Emergency Autodialer Numbers**

The Emergency Autodialer telephone numbers may be programmed with the following commands. Each phone number may be up to eleven digits long and may begin with Macro Digit A, B, or C to form longer telephone numbers if necessary. [Leading 1 may be replaced by the Phone Number Leading 1 Override, if necessary, for unusual telephone systems which require other than a leading one for long distance.]

*5200(telephone number)	Emergency Autodial #0
*5201(telephone number)	Emergency Autodial #1
*5202(telephone number)	Emergency Autodial #2
*5203(telephone number)	Emergency Autodial #3
*5204(telephone number)	Emergency Autodial #4
*5205(telephone number)	Emergency Autodial #5
*5206(telephone number)	Emergency Autodial #6
*5207(telephone number)	Emergency Autodial #7
*5208(telephone number)	Emergency Autodial #8
*5209(telephone number)	Emergency Autodial #9

**Example:** Load telephone number 1-408-555-1212 into location 9.

\*5209 14085551212

**Emergency Autodialer response messages are programmed using the Message Editor, described in Chapter 3.**

**Logical Phone Line**

If multiple or remote phone lines are configured, leading Macro Digits A, B, or C, or no leading macro digit, direct the call to the various logical phone lines. The macro digits are expanded out as well. Normally in this application the macros would be loaded with empty messages, and the leading macro digits would be used only to direct the call to the proper logical phone line.

<b>Leading Macro Digit</b>	<b>Logical Phone Line Selection</b>
none or A	Logical Phone Line #1
B	Logical Phone Line #2
C	Logical Phone Line #3

**See Also:** Operation Manual - "Telephone Interconnect"



## Chapter 12

# Macro Sets and the Scheduler

Macro Sets can be stored for manual selection by Control Ops and automatic selection by the Scheduler. They contain information describing the complete Control Operator defined setup of the repeater, plus link, remote base, and remote control user function information. Events are one-shot happenings which may include message generation and clearing telemetry memories. Scheduler setpoints define when changeovers occur to different Macro Sets, and when events are to occur.

### Macro Sets

Macro Sets are stored as Control Operator setup, remote base and link setup, and UF output setup. Setpoints define what setup information is loaded at each changeover – Control Operator setup only, remote/link setup only, UF setup only, or all setup.

### Store Control Op, Remote, Link, and UF Setup into Macro Set

\*591x     Store current setup into Macro Set x (x = 0-9)

Macro Set 0 is special in that it is automatically loaded by the controller on powerup. Macro Set 0 should contain the desired powerup condition of the controller. All ten sets are available for manual selection by the Control Operator, and for automatic selection by the scheduler.

### Events

Events are scheduled generation of programmable messages and scheduled clearing of telemetry min/max memories.

Five event messages may be programmed using the message editor. Message events specify the message number and an attribute, which defines under what circumstances the message is to be generated. For example, an event message may be generated only if the repeater is not in use, or it may be generated on top of any user talking through the repeater at the event time. Messages may also be directed to the auxiliary (remote base) transceivers.

### Setpoints

Setpoints define when changeovers to different Macro Sets occur or when events are to occur. Up to thirty setpoints may be scheduled. Setpoints are defined by a time of day and day of week. The day of week may be any one day, every day, weekdays, or weekends.

Setpoints may be removed by loading an invalid time, such as 00 o'clock, or 99 o'clock.

Setpoints are always programmed using 12 hour am/pm format, even if the time of day clock is selected for 24 hour military time *announcements*.

### Changeover Setpoint

\*42(ss)(dow)(am/pm)(10's hours)(1's hours)(10's minutes)  
(1's minutes)(Macro Set)(changeover attribute)

### Event Message Setpoint

\*43(ss)(dow)(am/pm)(10's hours)(1's hours)(10's minutes)  
(1's minutes)(event message)(event attribute)

### Event Telemetry Memory Clear Setpoint

\*44(ss)(dow)(am/pm)(10's hours)(1's hours)(10's minutes)  
(1's minutes)(telemetry memory channel)

### HINT

Only one setpoint will be activated at a particular day / hour / minute. If more than one setpoint qualify at a particular time, the *lowest numbered setpoint* is the one which will be activated. If several actions should occur at approximately the same time, specify a different time for each setpoint.

In some cases, this characteristic can conserve setpoints. For example, if something should happen everyday at 10 pm, except Thursday, when something else should happen, then place the Thursday setpoint in a lower numbered position than the everyday setpoint. The Thursday setpoint will be guaranteed to occur on Thursday, while the "everyday" setpoint will occur on days other than Thursday.

Also be aware that some scheduler actions wait for the channel to be clear. Changeovers wait for any user to unkey. Event messages, depending on their attribute, may also wait for a clear channel. *Only one scheduler action is held pending at a time.* This means that if a changover is pending, waiting for the user to unkey, and a minute later a telemetry clear event occurs, the changeover will be lost. Leave several minutes after changeovers and waiting event messages until the next scheduler action.

ss = setpoint 00-29 (both changeovers and events share the same 30 setpoints)

dow = day of week

0 = Sunday	5 = Friday
1 = Monday	6 = Saturday
2 = Tuesday	7 = everyday
3 = Wednesday	8 = weekdays
4 = Thursday	9 = weekends

am/pm

0 = am  
1 = pm

(10's hours)(1's hours)(10's minutes)(1's minutes)  
Time of day of the setpoint (i.e. 10:58)

[Hours digits may be set to a "wildcard" value with Touch-Tone "D". Setting 10's and 1's hours to D causes a match every hour at "minutes" after.]

Macro Set

0-9 = Macro Set 0-9

Changeover Attribute

0 = Control Operator setup only  
1 = Link and Remote Base setup only  
2 = User Function output setup only  
3 = Control Op, Link/Remote, and UF setup

Event Message = 1-5

Event Message Attribute

0 = Repeater transmitter, if repeater not in use  
1 = Repeater transmitter, wait for user to unkey  
2 = Repeater transmitter even if in use  
3 = Remote base #1 transmitter, memory 9  
4 = Remote base #2 transmitter, memory 9  
5 = Remote base #3 transmitter

Event Telemetry Channel = 33 - 80

**Example - Let's Schedule Our Repeater**

Now let's actually schedule the operation of our repeater. The three most important steps are PLAN, PLAN, and PLAN. We need to figure out in advance exactly what we want the repeater to do, then what the repeater's schedule should be. The Scheduler will do what you ask, but it can't read your mind (even now)!

Let's decide what we want our Scheduler to do for starters. Perhaps you'd like to turn off certain features at night, leaving them on until later on weekends for the party goers. Maybe you have a net Tuesdays, and you'd like to remind users for several hours before net time. Just before the net we can fire off the users' pagers with an event message. During the net it might be nice to have a distinctive courtesy tone. It might be a good idea to have frequent time reminders as people are going to work in the morning. And wish everyone TGIF on Friday afternoons. And OGIM (Oh goodness it's Monday) on Monday mornings. We can wake up the repeater owner weekday mornings with a "signon" event message. And ask "Why are you up?" as a tail message in the middle of the night. Finally, we can maintain daily valid min/max temperature information for the built-in temperature sensor by clearing the memories daily. This will be a good start - we can always add more capability later on.

From our example above, we can decide what Macro Sets and events we need. Since the controller always powers up to Macro Set 0, it's best to make that our normal daytime operation set. We can define our sets:

Macro Set 0:	Normal daytime
Macro Set 1:	Weekday mornings frequent "Time" tail message
Macro Set 2:	Friday afternoon "TGIF" tail message
Macro Set 3:	Monday morning "OGIM" tail message
Macro Set 4:	Tuesday net reminder "Net tonight ..." tail msg and PID3
Macro Set 5:	Net in progress "N" courtesy tone
Macro Set 6:	Normal nighttime
Macro Set 7:	Middle of night "Why are you up?"
Macro Set 8:	not used - available for future use
Macro Set 9:	not used - available for future use

And our events:

Event msg 1:	Tuesday 7:58 pm pager message
Event msg 2:	Weekdays 6:45 am "signon" message
Event:	Everyday 10 am clear VRT channel 15 max memory (47)
Event:	Everyday 7 pm clear VRT channel 15 min memory (79)

Let's start defining our macro sets with set 0. Make sure all the Control Operator selections are what we want (enter the proper Control Operator commands if you're not sure what they're set at), along with the remote base and UF setups, although in this example they're not important. Unlock the controller, and enter the \*5910 programming command (responds with "INIT"). You've taken a snapshot of the current setup of the controller, and it's been stored as Macro Set 0. From now on, on powerup, or when Macro Set 0 is selected automatically by the Scheduler or manually by the Control Op, the controller will be in the same state that it's in now.

Let's load the various tail messages, ID's and so on for the various special macro sets and events. We can load

TM4(1) (\*1181): (time) (am/pm) (msgs present)  
 TM4(2) (\*1182): "TGIF"  
 TM4(3) (\*1183): "OGIM"  
 TM4(4) (\*1184): "Net tonight at 8:30"  
 TM4(7) (\*1187): "Why are you up?"

PID3(C) (\*1175): "BARC Net tonight at 8:30, on WA6AXX, repeater"

Courtesy Tone 8 (\*1048): Morse code "N"

Event 1 Message: "(pager memory 35 - group call) Net in two minutes"  
 Event 2 Message: "Time for all Control Operator 's to get up and get go -ing (explosion). This is WA6AXX, repeater" (use message macros to fit it all in)

Now back to the Macro Sets. For set 1, let's select TM4 (114) and TMS1 (116) with the right Control Operator commands, then unlock the controller and enter "\*5911" to store state 1. For set 2, let's select TM4 again, but less frequently with TM Timer (\*\*/prefix/118), and store the state with \*5912. Set 3 for Monday morning is pretty much the same except for the automatic selection of TM4(3), so we can store the existing state again into set 3 (\*5913).

Set 4 for Tuesday net reminder again uses TM4(4), and PID3(C). Let's make sure that the pending ID at least rotates through PID3 by selecting RPID command (105), then storing the state using \*5914.

Set 5 selects a special courtesy tone for during the net, CT8 as loaded above. We also want the tail message off, so we command TM OFF (\*\*/prefix/115), and CT8 (\*\*/prefix/148). Now we can store the current state into Macro Set 5, by entering \*5915.

Normally during the night, we may want to disable the Autopatch and User Loadable Autodial, require PL for Control Operator commands, disable Spare Audio 1 and the Pad Test, lock the User Autodialer, disable the reverse patch, and so on. We can enter the appropriate Control Operator commands. We may want the tail message off (\*\*/prefix/115). Now we can enter "\*5916" to store the state.

Say in the middle of the night we'd like the controller to ask "Why are you up?" as a tail message. We can modify the set we last defined by selecting TM4(7) (\*\*/prefix/114), generated every 4 tails TMS4 (\*\*/prefix/117). Store the modified nighttime state in 7 by entering \*5917.

Now we've defined and stored all the Macro Sets for our example. We can get back to the daytime set by manually selecting Macro Set 0 (\*\*/prefix/130). Now we define the changeover and event times, or setpoints.

Friday afternoons at 1 o'clock let's select set 2 for the TGIF tail message, until 7:30. Monday mornings we want the "OGIM" message from 6:30 until 9. Tuesdays from 4:30 til net time we want the net reminder state, and at net time we switch over to the "N" courtesy tone. We can switch to the nighttime state at midnight on weeknights and at 1:30 am on weekends. From 3 to 6 am, let's ask "Why are you up?". From this we can define our setpoints with programming commands:

Setpoint	Time	Day	Macro Set/Event	Prog Command
0	1:00 pm	Fridays	MS2	*42 00 5 10100 2 0
1	7:30 pm	Fridays	MS0	*42 01 5 10730 0 0
2	6:30 am	Mondays	MS3	*42 02 1 00630 3 0
3	9:00 am	Mondays	MS0	*42 03 1 00900 0 0
4	4:30 pm	Tuesdays	MS4	*42 04 2 10430 4 0
5	8:00 pm	Tuesdays	MS5	*42 05 2 10800 5 0
6	8:30 pm	Tuesdays	MS0	*42 06 2 10830 0 0
7	12:00 am	weekdays	MS6	*42 07 8 01200 6 0
8	1:30 am	weekends	MS6	*42 08 9 00130 6 0
9	3:00 am	everyday	MS7	*42 09 7 00300 7 0
10	6:00 am	everyday	MS0	*42 10 7 00600 0 0
11	7:00 am	weekdays	MS1	*42 11 8 00700 1 0
12	9:00 am	weekdays	MS0	*42 12 8 00900 0 0
13	7:58 pm	Tuesdays	EV1	*43 13 2 10758 1 1
14	6:45 am	weekdays	EV2	*43 14 8 00645 2 1
15	10:00 am	everyday	clr 15 max	*44 15 7 01000 47
16	7:00 pm	everyday	clr 15 min	*44 16 7 10700 79
17-29	not used - available for later use			

If we ever want to erase a setpoint, we can do it by loading a time that will never happen, e.g. 00 o'clock, or \*42 xx 0 00000 0 0.

Now we're done! You can think about jazzing it up some more by providing additional PID3's as different states are selected for ID message variety, adding more events, and so on.



## Chapter 13

# Telemetry Meter Faces

The Meter Face Assignment commands define a particular meter type to be assigned to each of the sixteen analog input channels. Note that many analog channels may be assigned the same meter type, making it possible to have several temperature sensors, several voltage and power readings, etc.

\*55 CC FF      CC is hardware analog input channel 01-16  
                   FF is meter face number 00-33

Meter face FF is assigned to hardware analog input channel CC.

Analog input channel 15 should be assigned meter face 05, and channel 16 should be assigned meter face 00 for readback of internal temperature and voltage.

<b>Meter Faces</b>	<b>(FF)</b>
<b>Voltage</b>	
0-16 volts	00
0-32 volts	25
0-256 volts	24
<b>Current</b>	
0-64 ua	23
0-4 amps	22
0-8 amps	21
0-16 amps	01
0-32 amps	20
<b>Power</b>	
0-2 watts (fractional)	17
0-4 watts	18
0-8 watts	19
0-8 watts (units)	11
0-16 watts	12
0-32 watts	13
0-64 watts	14
0-128 watts	15
0-256 watts	16
<b>Temperature/Weather</b>	
LM335 sensor	05
Hi accuracy	06
Direction (cardinal)	08
Direction (deg)	26
Wind speed	09

**Receiver Measurements  
(sampled 1 sec. into repeater  
user's transmission)**

S-meter	02
Freq. error	03
Freq. error inverted	27
Quieting	04
Deviation	10

**Receiver Measurements  
(measured on request)**

S-meter	30
Freq. error	31
Quieting	32
Deviation	33

**Miscellaneous**

General 0-100	07
Empty assignment	99

**Example**

Assign the S-meter "meter face" to analog input channel 1, so that it's automatically measured 1 second into the user's transmission and read back when interrogated. This will allow users to read their signal strength into the repeater by entering the user command (VRT prefix) 1. The programming command to make this assignment is "\*55 01 02".

**Example**

Assign the S-meter "meter face" to analog input 4 so that we can read the S-meter on a remote base transceiver. The measurement will be made when our command is evaluated by the controller. The programming command to make this assignment is "\*55 04 30".

**Example**

Assign the LM335 temperature sensor meter face to channel 15, with "\*55 15 05".

**Temperature Calibrate**

The Temperature Calibrate command adjusts the on-board temperature sensor and others using the LM335 sensor meter face (05). It is used to set the readback to agree with a reference thermometer, and is normally done at the factory.

\*5500 xxxx    xxxx = 0-9999 calibration constant  
 (typically 3000-5000, approximately 100 units per degree error)

If the adjustment needs to be made in the field, select a constant such as 4000 and read temperature. If the readback is, for example, five degrees high, subtract 500 from the constant and try again. Continue until you're within a couple of degrees of the thermometer.

## Chapter 14

**Patch Restrictions and Mapping**

Telephone calls placed through the Autopatch may be toll restricted. The Control Operator selects long distance enable or disable independently for each of the three Autopatch access commands. These selections may also be automatically implemented by the Scheduler.

An "antidialer" may trap specific telephone numbers, or blocks of numbers, from being placed through the Autopatch.

**Toll Restrict**

When long distance is disabled by the Control Operator or Scheduler, the controller examines the number to be dialed to determine if it's considered to be a toll call. Two toll restrict modes are available to choose from depending on the characteristics of the repeater system and the local telephone company.

Toll Restrict Mode A simply restricts calls to telephone numbers beginning with a 0 or 1, or longer than seven digits. This mode is sufficient for many repeater systems, providing the necessary protection against unauthorized toll calls.

Mode B permits the repeater owner to define the calling area available to users. He may specify which exchanges are permitted and which are restricted in two different area codes. All eight hundred exchanges in each area code may be individually defined as permitted or restricted (exchanges 200-999). In addition, he can define permitted area codes in which *all* exchanges are allowed (such as toll-free 800 numbers).

See the Operation Manual - "Telephone Interconnect" - for additional discussion on toll restriction.

**Toll Restrict Mode Selection**

- \*5691 Toll Restrict Mode A
- \*5692 Toll Restrict Mode B

**Toll Restrict Mode B Exchange Tables**

- \*5610 Define *entire* Local Exchange Table to be "long distance"
- \*5611 Define *entire* Local Exchange Table to be "local"
- \*5610xxx Define exchange xxx in Local Exchange Table to be "long distance"
- \*5611xxx Define exchange xxx in Local Exchange Table to be "local"
- \*5620 Define *entire* Adjacent Exchange Table to be "long distance"
- \*5621 Define *entire* Adjacent Exchange Table to be "local"
- \*5620xxx Define exchange xxx in Adjacent Exchange Table as "long distance"
- \*5621xxx Define exchange xxx in Adjacent Exchange Table as "local"

(Note: xxx is the three-digit telephone exchange, from 200 through 999.)

Area codes are defined using the *Message Editor*. Those which are used should be loaded as three-digit speech or Morse code messages. Unused area codes should be loaded as empty messages. (To enter an empty message, unlock the controller, select the message, and enter \*0 - store message.)

- \*1169 Local Area Code
- \*1170 Adjacent Area Code
- \*11117 Permitted Area Code #1
- \*11118 Permitted Area Code #2
- \*11119 Permitted Area Code #3

**Example**

The local area code is 408. Unlock the controller and select the Local Area Code message with \*1169. After the controller responds, then enter 04 00 08. The message editor reads back "408". Write the message into non-volatile memory with \*0.

**Antidialer**

Ten telephone numbers or blocks of numbers may be loaded into the antidialer which are trapped by the Autopatch.

The telephone numbers stored in the antidialer may be up to eleven digits long. In addition to individual phone numbers, blocks of numbers may be stored using "wildcards" and "globals".

A wildcard in a digit position automatically "matches" any digit dialed by a user. For example, if a number stored in the antidialer is "253808W", then ten telephone numbers, from 253-8080 through 253-8089, will be blocked.

A global in a digit position causes a match to any telephone number which matches the digits preceding the global. For example, a number stored in the antidialer as "1301G" matches any telephone number beginning with a 1-301.

Wildcard = Touch-Tone D

Global = Touch-Tone \*

- |                         |                   |
|-------------------------|-------------------|
| *5300(telephone number) | Antidialer slot 0 |
| *5301(telephone number) | Antidialer slot 1 |
| *5302(telephone number) | Antidialer slot 2 |
| *5303(telephone number) | Antidialer slot 3 |
| *5304(telephone number) | Antidialer slot 4 |
| *5305(telephone number) | Antidialer slot 5 |
| *5306(telephone number) | Antidialer slot 6 |
| *5307(telephone number) | Antidialer slot 7 |
| *5308(telephone number) | Antidialer slot 8 |
| *5309(telephone number) | Antidialer slot 9 |

### Dialing Format

Telephone numbers are regenerated by the controller into the phone line. The dialing format may be selected with these commands. Dialing to *remote phone lines* is always normal DTMF.

- \*5400 Normal DTMF
- \*5403 Slow DTMF
- \*5401 Dial pulse 10 pps
- \*5402 Dial pulse 20 pps

### Phone Line Dedicated / Shared

The controller may share a phone line with several other controllers at the same site. In the shared mode, the Phone Line Busy input is examined by the controller before placing a call. If it's in use by another controller, the user is given a "Busy" message. Otherwise, the controller grabs the phone line and sets the Phone Line Busy output.

In the normal Dedicated mode, the Phone Line Busy input is not tested prior to placing outgoing calls.

- \*5404 Dedicated phone line (normal)
- \*5405 Shared phone line

### Logical Phone Line Assignment

There are three "logical phone lines" accessible from the Autopatch and autodialers. Each logical phone line is assigned to be Local Phone Line #1 or #2, or Remote Phone Line #1, #2, or #3. See the Operation Manual - "Telephone Interconnect - Multiple and Remote Phone Lines" - for more details.

The logical phone lines are assigned using the following programming commands.

- \*54061(L) Logical Phone Line #1 Assignment
- \*54062(L) Logical Phone Line #2 Assignment
- \*54063(L) Logical Phone Line #3 Assignment

- L = 1 / Local Phone Line #1
- 2 / Local Phone Line #2
- 3 / Remote Phone Line #1
- 4 / Remote Phone Line #2
- 5 / Remote Phone Line #3

#### Example

Assign Logical Phone Line #1 to be Local Phone Line #1 and Logical Phone Line #2 to be Remote Phone Line #1.

\*540611, \*540623

**Remote Phone Line Up / Down Channels**

Remote telephone lines may be accessed automatically through the repeater system. The up and down channels to the remote phone line location may be through the auxiliary transceivers, the control receiver, and/or the repeater transmitter. The up and down channels are assigned with these commands.

\*5407(u) Up Channel Assignment  
\*5408(d) Down Channel Assignment

u = 0 / control receiver  
1 / auxiliary transceiver 1  
2 / auxiliary transceiver 2  
3 / auxiliary transceiver 3  
4 / auxiliary transceiver 4

d = 0 / repeater transmitter  
1 / auxiliary transceiver 1  
2 / auxiliary transceiver 2  
3 / auxiliary transceiver 3  
4 / auxiliary transceiver 4

**Example**

Assign the up channel for remote phone line calls to be auxiliary transceiver 2 (memory frequency 8) and the down channel to be the repeater transmitter.

\*54072, \*54080

## Chapter 15

# Remote Bases / Links

### Remote Base Frequency Memories

Frequently used remote base frequencies may be stored in memories and may be accessed by users with abbreviated commands. In addition to frequency, the PL, antenna direction, and band select bits which are supplied in the serial data stream are also stored in the memories.

When users activate a remote base memory, the response, instead of the normal frequency readback, may be a programmable "name" which may be the call of the repeater or other identifier, such as "five-two" (short for 146.52 MHz).

Two memories for each remote base serve special functions and are not available to users. They are automatically activated when patch calls are directed to remote phone lines accessed through the auxiliary (remote base) transceivers and when the system sends paging tones or event messages directed to them.

To store a frequency memory, bring up the remote base on the desired frequency, with PL, direction, and band select properly selected if these are used. Then, unlock the controller and enter the "Store" command to write the information for the remote into memory. (The remote base may be commanded when the controller is unlocked by preceding the remote base user command with \*\*.)

- \*5711 Store Remote Base #1 Frequency Memory 1
- \*5712 Store Remote Base #1 Frequency Memory 2
- \*5713 Store Remote Base #1 Frequency Memory 3
- \*5714 Store Remote Base #1 Frequency Memory 4
- \*5715 Store Remote Base #1 Frequency Memory 5
- \*5716 Store Remote Base #1 Frequency Memory 6
- \*5717 Store Remote Base #1 Frequency Memory 7
- \*5718 Store Remote Base #1 Frequency Memory 8 (remote phone line)
- \*5719 Store Remote Base #1 Frequency Memory 9 (paging, events, modem messages)
  
- \*5741 Store Remote Base #2 Frequency Memory 1
- \*5742 Store Remote Base #2 Frequency Memory 2
- \*5743 Store Remote Base #2 Frequency Memory 3
- \*5744 Store Remote Base #2 Frequency Memory 4
- \*5745 Store Remote Base #2 Frequency Memory 5
- \*5746 Store Remote Base #2 Frequency Memory 6
- \*5747 Store Remote Base #2 Frequency Memory 7
- \*5748 Store Remote Base #2 Frequency Memory 8 (remote phone line)
- \*5749 Store Remote Base #2 Frequency Memory 9 (paging, events, modem messages)

See Chapter 3, "The Message Editor", for information on defining memory names.

### Remote Base / Link Channel Assignment

Four hardware channels are available for assignment as remote bases, full duplex links, a control receiver, and the user selectable "Spare Audio 1" function.

Remote bases and links are handled similarly by the controller.

Each channel assigned as a remote base or link may permit certain levels of command entry from the remote / link.

*5761(c)(t)	Remote Base / Link 1 Channel
*5762(c)(t)	Remote Base / Link 2 Channel
*5763(c)(t)	Remote Base / Link 3 / Spare Audio 1 Channel
*5764(c)(t)	Remote Base / Link 4 / Control Receiver Channel

c = 1 / Link; 2 / Remote Base; 3 / Spare Audio 1; 4 / Control Receiver  
t (applies to remote base / link selection only) = 0 / no command;  
2 / user commands only; 3 / all commands ok

#### Example

Assign channel 1 as Remote Base 1, no command capability from the remote; channel 2 as Link 2, all commands ok; channel 3 as Remote Base 3, user commands only from the remote; channel 4 as Control Receiver.

\*576120, \*576213, \*576322, \*576443



## Chapter 16

# Pager Memories

Information identifying each pager in the system may be stored in one of fifty-four memories. Fifty memories are intended to address user's pagers while four memories specify optional signalling format to remote phone line locations.

Each pager is identified by its format, address, and frequency. Memories are loaded using programming commands of the format

**\*29xx f aaaa f**

**xx** = pager memory 00-53

**f** = format

0 = two-tone 1 - 3 second	7 = CTCSS
1 = two-tone 2.7 - .8 second	8 = HSC pager activate
2 = two-tone .4 - .8 second	9 = HSC board mute
3 = two-tone group call 8 second	* = HSC board activate
4 = DTMF	D = HSC pager mute
5 = five-tone	
6 = six-tone (extended address)	

**aaaa** = address

two-tone = A/G# A/T# B/G# B/T# (A=B for group call)  
 DTMF = T1 T2 T3 T4 (1-4 digits)  
 5/6 tone = T2 T3 T4 T5 (T1 fixed as 0, preamble fixed as 1)  
 CTCSS = xx (2 digits, 01-32, see CTCSS frequency table)  
 HSC = T2 T3 T4 T5 (T1 fixed as group call,  
 T2-5 may be group call - key "\*\*")

**f** = frequency

0 = repeater transmitter  
 1 = Remote Base #1 memory 9  
 2 = Remote Base #2 memory 9  
 3 = Remote Base #3 (fixed frequency)

### Examples

Memory 14 - Two-tone .4-.8 second, A = group #2 tone #3,  
 B = group #1 tone #5, repeater transmitter \*2914 2 2315 0

Memory 3 - Six-tone, address 01234, Remote Base #1 transmitter  
 \*2903 6 1234 1

Memory 38 - CTCSS 110.9 Hz, repeater transmitter \*2938 7 15 0



Morse	Speech	Message	Response	#Char					
*1078	*1178	Alarm #1	AL1	10	*1090	*1190	Mailbox Message #0	MBM0	6
*1079	*1179	Alarm #2	AL2	10	*1091	*1191	Mailbox Message #1	MBM1	10
*10106	*11106	Alarm #3	AL3	5	*1092	*1192	Mailbox Message #2	MBM2	10
*10107	*11107	Alarm #4	AL4	5	*1093	*1193	Mailbox Message #3	MBM3	10
*1041	*1141	Courtesy Tone #1	CT1	4	*1094	*1194	Mailbox Message #4	MBM4	18
*1042	*1142	Courtesy Tone #2	CT2	4	*1095	*1195	Mailbox Message #5	MBM5	18
*1043	*1143	Courtesy Tone #3	CT3	4	*1096	*1196	Mailbox Message #6	MBM6	18
*1044	*1144	Courtesy Tone #4	CT4	4	*1097	*1197	Mailbox Message #7	MBM7	18
*1045	*1145	Courtesy Tone #5	CT5	4	*1098	*1198	Mailbox Message #8	MBM8	18
*1046	*1146	Courtesy Tone #6	CT6	4	*1099	*1199	Mailbox Message #9	MBM9	50
*1047	*1147	Courtesy Tone #7	CT7	4	*1073	*1173	Mail Present Message	MAIL	5
*1048	*1148	Courtesy Tone #8	CT8	4	*10152	*11152	Pager Prompt	PPRO	10
*10109	*11109	Courtesy Tone #9	CT9	4	*1020	*1120	Autopatch Activate	AP up	6
*10110	*11110	Courtesy Tone #10	CT ten	4	*1029	*1129	User Autodial Activate	ADU up	6
*10111	*11111	Courtesy Tone #11	CT eleven	4	*1072	*1172	Antidial	ANTI	10
*10112	*11112	Courtesy Tone #12	CT twelve	4	*1018	*1118	Patch Cover Tone	PCT	6
*10113	*11113	Courtesy Tone #13	CT thirteen	4	*1017	*1117	Patch Timeout Warning	P time out alert	6
*1060	*1160	Generic Command Response	COPR	6	*1065	*1165	Phone Answer	PHAN	18
*1067	*1167	Demo Tag	DEMO	18	*1066	*1166	Phone Hangup	HANG	10
*10101	*11101	Bulletin Board #1	B1	12	*10151	*11151	Reverse Patch Call-For	RPC	4
*10102	*11102	Bulletin Board #2	B2	12	*1063	*1163	Remote Base #1 Name	L1	6
*10103	*11103	Bulletin Board #3	B3	12	*1064	*1164	Remote Base #2 Name	L2	6
*10104	*11104	Bulletin Board #4	B4	12	*10115	*11115	Remote Base #3 Name	L3	6
*10105	*11105	Bulletin Board #5	B5	12	*10114	*11114	Remote Base #4 Name	L4	6
*10120	*11120	Pad Test Responses	PAD	16	*1061	*1161	Remote Base #1 Freq. Prefix	Remote 1 P	6
*1050	*1150	Emergency Autodial #0	ADE0	6	*1062	*1162	Remote Base #2 Freq. Prefix	Remote 2 P	6
*1051	*1151	Emergency Autodial #1	ADE1	6	*10121	*11121	Remote Base #1 Mem. 1 Name	L1N1	6
*1052	*1152	Emergency Autodial #2	ADE2	6	*10122	*11122	Remote Base #1 Mem. 2 Name	L1N2	6
*1053	*1153	Emergency Autodial #3	ADE3	6	*10123	*11123	Remote Base #1 Mem. 3 Name	L1N3	6
*1054	*1154	Emergency Autodial #4	ADE4	6	*10124	*11124	Remote Base #1 Mem. 4 Name	L1N4	6
*1055	*1155	Emergency Autodial #5	ADE5	6	*10125	*11125	Remote Base #1 Mem. 5 Name	L1N5	6
*1056	*1156	Emergency Autodial #6	ADE6	6	*10126	*11126	Remote Base #1 Mem. 6 Name	L1N6	6
*1057	*1157	Emergency Autodial #7	ADE7	6	*10127	*11127	Remote Base #1 Mem. 7 Name	L1N7	6
*1058	*1158	Emergency Autodial #8	ADE8	6	*10131	*11131	Remote Base #2 Mem. 1 Name	L2N1	6
*1059	*1159	Emergency Autodial #9	ADE9	6	*10132	*11132	Remote Base #2 Mem. 2 Name	L2N2	6
*1001	*1101	Initial ID #1	IID1	22	*10133	*11133	Remote Base #2 Mem. 3 Name	L2N3	6
*1008	*1108	Initial ID #2	IID2	22	*10134	*11134	Remote Base #2 Mem. 4 Name	L2N4	6
*1009	*1109	Initial ID #3	IID3	22	*10135	*11135	Remote Base #2 Mem. 5 Name	L2N5	6
*1002	-----	Forced CW ID	FID	14	*10136	*11136	Remote Base #2 Mem. 6 Name	L2N6	6
*1003	*1103	Anxious ID	AID	14	*10137	*11137	Remote Base #2 Mem. 7 Name	L2N7	6
*1004	*1104	Pending ID #1	PID1	26	*10140	*11140	Changeover Announcement	Change over	5
*1005	*1105	Pending ID #2	PID2	26	*10146	*11146	Event 1 Message	E1	12
*1006	*1106	Pending ID #3 (0,1)	PID3A	26	*10147	*11147	Event 2 Message	E2	12
*1074	*1174	Pending ID #3 (2,3)	PID3B	26	*10148	*11148	Event 3 Message	E3	12
*1075	*1175	Pending ID #3 (4,5)	PID3C	26	*10149	*11149	Event 4 Message	E4	12
*1076	*1176	Pending ID #3 (6,7)	PID3D	26	*10150	*11150	Event 5 Message	E5	12
*1077	*1177	Pending ID #3 (8,9)	PID3E	26	-----	*1168	Phone Number Leading "1"		
*1007	*1107	Special ID	SPID	50	-----		Override	LD over	6
*1000	*1100	Periodic QST ID	QST	14	-----	*11128	Phone Number Macro "A"	MA	6
*1010	*1110	Touch-Tone Access Down ID	TTID	6	-----	*11129	Phone Number Macro "B"	MB	6
*10100	*11100	Aux. Transmitter Pager ID	PGID	4	-----	*11130	Phone Number Macro "C"	MC	6
*10108	*11108	Aux. Transmitter Phone ID	PHID	4	-----	*1169	Local Area Code	Area code L	3
*10141	*11141	Macro 1	M1	10	-----	*1170	Adjacent Area Code	Area code J	3
*10142	*11142	Macro 2	M2	10	-----	*11117	Permitted Area Code #1	Area code P1	3
*10143	*11143	Macro 3	M3	6	-----	*11118	Permitted Area Code #2	Area code P2	3
*10144	*11144	Macro 4	M4	6	-----	*11119	Permitted Area Code #3	Area code P3	3

# Programming Summary

-----	*1171	Primary Patch Dialing Prefix	PPRE	8
-----	*11138	Secondary Patch Dialing Prefix	SPRE	6
-----	*11139	Tertiary Patch Dialing Prefix	TPRE	6
	*1011	Tail Message #1	TM1	6
	*1012	Tail Message #2	TM2	6
	*1013	Tail Message #3	TM3	6
	*1014	Tail Message #4 (0)	TM40	6
	*1081	Tail Message #4 (1)	TM41	8
	*1082	Tail Message #4 (2)	TM42	8
	*1083	Tail Message #4 (3)	TM43	8
	*1084	Tail Message #4 (4)	TM44	8
	*1085	Tail Message #4 (5)	TM45	8
	*1086	Tail Message #4 (6)	TM46	8
	*1087	Tail Message #4 (7)	TM47	8
	*1088	Tail Message #4 (8)	TM48	8
	*1089	Tail Message #4 (9)	TM49	8
	*1015	Repeater Timeout	Repeater timeout	6
	*1016	Repeater Timeout Clear	Repeater timeout cancel	10
	*1017	Patch Timeout Warning	Patch timeout alert	6
	*1019	Touch-Tone Cover Tone	TTCT	4
-----	*12xx	Call Sign	Call	6
	*1021	User Function 1 High	UF 1 high	6
	*1031	User Function 1 Low	UF 1 low	6
	*1022	User Function 2 High	UF 2 high	6
	*1032	User Function 2 Low	UF 2 low	6
	*1023	User Function 3 High	UF 3 high	6
	*1033	User Function 3 Low	UF 3 low	6
	*1024	User Function 4 High	UF 4 high	6
	*1034	User Function 4 Low	UF 4 low	6
	*1025	User Function 5 High	UF 5 high	6
	*1035	User Function 5 Low	UF 5 low	6
	*1026	User Function 6 High	UF 6 high	6
	*1036	User Function 6 Low	UF 6 low	6
	*1027	User Function 7 High	UF 7 high	6
	*1037	User Function 7 Low	UF 7 low	6
	*1028	User Function 8 High	UF 8 high	6
	*1038	User Function 8 Low	UF 8 low	6
	*1030	User Function Byte 1 Name	UFB1	6
	*1039	User Function Byte 2 Name	UFB2	6

**Morse Code Parameters**

Speed	Pitch	Level		
*2000	*2010	*2020	Initial ID	speed = 5-35 WPM
*2001	*2011	*2021	Forced CW ID	pitch = 0 -3000 Hz
*2002	*2012	*2022	Anxious ID	level = 0 (0 dB)
*2003	*2013	*2023	Pending/QST ID	1 (-3 dB)
*2004	*2014	*2024	Special ID	2 (-6 dB)
*2005	*2015	*2025	User Command	3 (-9 dB)
*2006	*2016	*2026	Control Op Command	

**Courtesy Tone Selection**

Command			
*3T10 (delay)	Delay to Segment 1	BPD	delay = 0 - 3500 ms
*3T20 (delay)	Delay from Segment 1 to 2	BPD	T = tone set 1-9, 0 (10)
*3T30 (delay)	Delay from Segment 2 to 3	BPD	*1 (11), *2 (12), *3 (13)
*3T11 (pitch)	Segment 1A Pitch	BPP	pitch = 0-3000 Hz
*3T12 (pitch)	Segment 1B Pitch	BPP	
*3T21 (pitch)	Segment 2A Pitch	BPP	
*3T22 (pitch)	Segment 2B Pitch	BPP	
*3T31 (pitch)	Segment 3A Pitch	BPP	
*3T32 (pitch)	Segment 3B Pitch	BPP	
*3T13 (level)	Segment 1 Level	BPL	level = 0 (0/-6 dB)
*3T23 (level)	Segment 2 Level	BPL	1 (-3/-9 dB)
*3T33 (level)	Segment 3 Level	BPL	
*3T14 (dur)	Segment 1 Duration	BPD	dur = 0-3500 ms
*3T24 (dur)	Segment 2 Duration	BPD	
*3T34 (dur)	Segment 3 Duration	BPD	
*3T40 (hang time)	Hang Time	BPHT	hang time = 0-10,000 ms
*3T50	Preview Courtesy Tone	BPPRV	
*3(dest)0(source)	Copy Source to Destination	BPCPY	

**Timers**

*4019 (period)	Alarm	AL timer
*4004 (period)	Sequence Interdigit Timer	SEQ
*4018 (period)	Beginning of Transmission to Sequence	SQB
*4005 (period)	Sequence to End of Transmission	SQE
*4020 (period)	Individual User Access Code Timer	IUA
*4021 (period)	Repeater Activity Timer	repeater A timer
*4028 (period)	External Device Timer	EXT
*4000 (period)	Initial ID Timer	Timer IID
*4001 (period)	Forced CW ID Timer	Timer FID
*4002 (period)	Anxious ID Timer	Timer AID
*4003 (period)	Pending ID Timer	Timer ID
*4017 (period)	Periodic QST ID Timer	Timer QST
*4008 (period)	Autopatch Timeout	AP timeout
*4009 (period)	User Loadable Autodialer Timeout	AU timeout
*4010 (period)	Emergency Autodialer Timeout	AE timeout
*4016 (period)	Patch Timer Extend Timer	Timer X
*4013 (period)	Patch Activity Timer	APAT
*4027 (period)	Reverse Patch Ring Timeout	RP timeout
*4012 (period)	Phone Answer Delay Timer	PHAN
*4006 (period)	Long Timeout Timer	Repeater timer L
*4007 (period)	Short Timeout Timer	Repeater timer S
*4014 (period)	Spare Audio 1 Timer	SP1 timer
*4015 (period)	Tail Message Timer	TM timer
*4011 (period)	Touch-Tone Access Mode Timer	TTAM
*4026 (period in ms)	Turn-on Delay	TX on

**Setting the Clock and Calendar**

*4100 (am/pm) (hours 10s) (hours 1s) (minutes 10s) (minutes 1s)	
am → am/pm = 0	
pm → am/pm = 1	
*4101 (month 10s) (month 1s) (day 10s) (day 1s) (year 10s) (year 1s)	
*4102 (dow)	dow / 0 = Sunday ... 6 = Saturday
*41031	12 Hour Format
*41032	24 Hour Format

**Command Codes / Channels**

\*5000 (1-4) Control Operator Command Root Set 1 - 4  
 \*5001 (prefix) Control Operator Command Prefix (Over the air)  
 \*5014 (prefix) Control Operator Command Prefix (Over the phone)  
 \*5005 (prefix) Primary Autopatch Prefix  
 \*5016 (prefix) Secondary Autopatch Prefix  
 \*5017 (prefix) Tertiary Autopatch Prefix  
 \*5003 (prefix) Primary Emergency Autodialer Prefix  
 \*5018 (prefix) Secondary Emergency Autodialer Prefix  
 \*5004 (prefix) User Loadable Autodialer Bank 0 Prefix  
 \*5019 (prefix) User Loadable Autodialer Bank 1 Prefix  
 \*5029 (prefix) User Loadable Autodialer Bank 2 Prefix  
 \*5007 (prefix) User Loadable Autodialer Bank 0 Load/Erase Prefix  
 \*5020 (prefix) User Loadable Autodialer Bank 1 Load/Erase Prefix  
 \*5030 (prefix) User Loadable Autodialer Bank 2 Load/Erase Prefix  
 \*5013 (prefix) Patch Utility Group P Prefix (reverse patch answer, custom hangup, duplex, cover, timer extend)  
 \*5021 (prefix) Patch Utility Group Q Prefix (redial, hookflash)  
 \*5011 (command) Reverse Patch Activate Command  
 \*5022 (command) Patch / Spare Audio 1 Hangup Command (loading an empty command makes the hangup command #)  
 \*5002 (prefix) User Function Remote Control Prefix  
 \*5006 (prefix) Link / Remote Base Prefix  
 \*5015 (prefix) Paging Prefix  
 \*5012 (command) Spare Audio 1 On Command  
 \*5010 (prefix) Demo Message / Bulletin Board Prefix  
 \*5025 (prefix) Mailbox Prefix  
 \*5009 (prefix) Voice Response Telemetry Prefix  
 \*5008 (prefix) Touch-Tone Access Up/Down Prefix  
 \*5026 (prefix) Touch-Tone Pad Test Prefix  
 \*5027 (prefix) User Mapped Control Operator Command Prefix  
 \*5028 (prefix) Individual User Access Code Prefix  
 \*5055 (attributes) Primary Autopatch Attributes  
 \*5066 (attributes) Secondary Autopatch Attributes  
 \*5067 (attributes) Tertiary Autopatch Attributes  
 \*5053 (attributes) Primary Emergency Autodialer Attributes  
 \*5068 (attributes) Secondary Emergency Autodialer Attributes  
 \*5054 (attributes) User Loadable Autodialer Bank 0 Attributes  
 \*5069 (attributes) User Loadable Autodialer Bank 1 Attributes  
 \*5079 (attributes) User Loadable Autodialer Bank 2 Attributes  
 \*5057 (attributes) User Loadable Autodialer Bank 0 Load/Erase Attributes  
 \*5070 (attributes) User Loadable Autodialer Bank 1 Load/Erase Attributes  
 \*5080 (attributes) User Loadable Autodialer Bank 2 Load/Erase Attributes  
 \*5063 (attributes) Patch Utility Group P Attributes  
 \*5071 (attributes) Patch Utility Group Q Attributes  
 \*5052 (attributes) User Function Remote Control Attributes  
 \*5056 (attributes) Link Attributes  
 \*5065 (attributes) Paging Attributes  
 \*5062 (attributes) Spare Audio 1 On Attributes  
 \*5060 (attributes) Demo Message / Bulletin Board Attributes  
 \*5075 (attributes) Mailbox Attributes  
 \*5059 (attributes) Voice Response Telemetry Attributes  
 \*5058 (attributes) Touch-Tone Access Up/Down Attributes  
 \*5076 (attributes) Touch-Tone Pad Test Attributes  
 \*5077 (attributes) User Mapped Control Operator Command Attributes  
 \*5078 (attributes) Individual User Access / Identify Attributes

\*4610 Disable all individual user access codes  
 \*4611 Enable all individual user access codes  
 \*4610xyz Disable user access code xyz (xyz = 000 - 799)  
 \*4611xyz Enable user access code xyz (xyz = 000 - 799)  
 \*45DCC Specify first digit ("D" for call sign slot "CC")  
 \*5000 0 xxx User Mapped Control Op Command 0  
 \*5000 1 xxx User Mapped Control Op Command 1  
 \*5000 2 xxx User Mapped Control Op Command 2  
 \*5000 3 xxx User Mapped Control Op Command 3  
 \*5000 4 xxx User Mapped Control Op Command 4  
 \*5000 5 xxx User Mapped Control Op Command 5  
 \*5000 6 xxx User Mapped Control Op Command 6  
 \*5000 7 xxx User Mapped Control Op Command 7  
 \*5000 8 xxx User Mapped Control Op Command 8  
 \*5000 9 xxx User Mapped Control Op Command 9 (xxx = Control Op root 1 code)  
 \*58080 Primary Unlock Code Select  
 \*58081 Secondary Unlock Code Select  
 \*58010 Disable command from repeater receiver  
 \*58011 Enable command from repeater receiver  
 \*58020 Disable command from telephone  
 \*58021 Enable command from telephone

**Logic I / O Senses**

\*5100s Link / Remote Base 1 COS Logic Input s = 0 / low true, 1 / high true  
 \*5101s Link / Remote Base 2 COS Logic Input  
 \*5102s Link / Remote Base 1 PTT Logic Output  
 \*5103s Link / Remote Base 2 PTT Logic Output  
 \*5108s Link / Remote Base 3 COS Logic Input  
 \*5109s Link / Remote Base 4 COS Logic Input  
 \*5104s User / Control Op PL Logic Input  
 \*5112s User Only PL Logic Input  
 \*5105p Phone Offhook p = 0 / TP-1, 1 / TP-3  
 \*5106q User Function Logic Outputs q = 0/atched, 1/expanded

**Emergency Autodialer Numbers**

\*5200 (telephone number) Emergency Autodial #0  
 \*5201 (telephone number) Emergency Autodial #1  
 \*5202 (telephone number) Emergency Autodial #2  
 \*5203 (telephone number) Emergency Autodial #3  
 \*5204 (telephone number) Emergency Autodial #4  
 \*5205 (telephone number) Emergency Autodial #5  
 \*5206 (telephone number) Emergency Autodial #6  
 \*5207 (telephone number) Emergency Autodial #7  
 \*5208 (telephone number) Emergency Autodial #8  
 \*5209 (telephone number) Emergency Autodial #9

**Macro Sets and the Scheduler**

\*591x Store current setup into Macro Set x (x = 0-9)  
 \*42 (ss) (dow) (am/pm) (10s hours) (1s hours) (10s minutes) (1s minutes) (Macro Set) (changeover attributes)  
 \*43 (ss) (dow) (am/pm) (10s hours) (1s hours) (10s minutes) (1s minutes) (Event Message) (event attributes)  
 \*44 (ss) (dow) (am/pm) (10s hours) (1s hours) (10s minutes) (1s minutes) (Telemetry memory channel)

**Meter Faces**

\*55 CC FF      CC = hardware analog input channel 01 - 16  
                   FF = meter face number 00 - 33  
 \*5500 xxxx    xxxx = 0 - 9999 calibration constant

**Patch Restrictions and Mapping**

\*5691      Toll Restrict Mode A  
 \*5692      Toll Restrict Mode B  
 \*5610      Define entire Local Exchange Table to be long distance  
 \*5611      Define entire Local Exchange Table to be local  
 \*5610xxx    Define exchange xxx in Local Exchange Table to be long distance  
 \*5611xxx    Define exchange xxx in Local Exchange Table to be local  
 \*5620      Define entire Adjacent Exchange Table to be long distance  
 \*5621      Define entire Adjacent Exchange Table to be local  
 \*5620xxx    Define exchange xxx in Adjacent Exchange Table as long distance  
 \*5621xxx    Define exchange xxx in Adjacent Exchange Table as local  
                   (xxx is the three-digit telephone exchange, from 200 through 999)  
 \*1169      Local Area Code  
 \*1170      Adjacent Area Code  
 \*11117      Permitted Area Code #1  
 \*11118      Permitted Area Code #2  
 \*11119      Permitted Area Code #3  
 \*5300 (telephone number)    Antidialer slot 0  
 \*5301 (telephone number)    Antidialer slot 1  
 \*5302 (telephone number)    Antidialer slot 2  
 \*5303 (telephone number)    Antidialer slot 3  
 \*5304 (telephone number)    Antidialer slot 4  
 \*5305 (telephone number)    Antidialer slot 5  
 \*5306 (telephone number)    Antidialer slot 6  
 \*5307 (telephone number)    Antidialer slot 7  
 \*5308 (telephone number)    Antidialer slot 8  
 \*5309 (telephone number)    Antidialer slot 9  
 \*5400      Normal DTMF  
 \*5403      Slow DTMF  
 \*5401      Dial pulse 10 pps  
 \*5402      Dial pulse 20 pps  
 \*5404      Dedicated phone line (normal)  
 \*5405      Shared phone line  
 \*54061 (L)    Logical Phone Line #1 Assignment  
 \*54062 (L)    Logical Phone Line #2 Assignment  
 \*54063 (L)    Logical Phone Line #3 Assignment  
                   L = 1 / Local Phone Line #1  
                   2 / Local Phone Line #2  
                   3 / Remote Phone Line #1  
                   4 / Remote Phone Line #2  
                   5 / Remote Phone Line #3  
 \*5407 (u)    Up Channel Assignment  
 \*5408 (d)    Down Channel Assignment  
                   u = 0 / control receiver  
                   1 / auxiliary transceiver 1  
                   2 / auxiliary transceiver 2  
                   3 / auxiliary transceiver 3  
                   4 / auxiliary transceiver 4  
                   d = 0 / repeater transmitter  
                   1 / auxiliary transceiver 1  
                   2 / auxiliary transceiver 2  
                   3 / auxiliary transceiver 3  
                   4 / auxiliary transceiver 4

**Remote Bases / Links**

\*5711      Store Remote Base #1 Frequency Memory 1  
 \*5712      Store Remote Base #1 Frequency Memory 2  
 \*5713      Store Remote Base #1 Frequency Memory 3  
 \*5714      Store Remote Base #1 Frequency Memory 4  
 \*5715      Store Remote Base #1 Frequency Memory 5  
 \*5716      Store Remote Base #1 Frequency Memory 6  
 \*5717      Store Remote Base #1 Frequency Memory 7  
 \*5718      Store Remote Base #1 Frequency Memory 8 (remote phone line)  
 \*5719      Store Remote Base #1 Frequency Memory 9 (paging, events)  
 \*5741      Store Remote Base #2 Frequency Memory 1  
 \*5742      Store Remote Base #2 Frequency Memory 2  
 \*5743      Store Remote Base #2 Frequency Memory 3  
 \*5744      Store Remote Base #2 Frequency Memory 4  
 \*5745      Store Remote Base #2 Frequency Memory 5  
 \*5746      Store Remote Base #2 Frequency Memory 6  
 \*5747      Store Remote Base #2 Frequency Memory 7  
 \*5748      Store Remote Base #2 Frequency Memory 8 (remote phone line)  
 \*5749      Store Remote Base #2 Frequency Memory 9 (paging, events)  
 \*5761 (c)(t)    Remote Base/Link 1 Channel  
 \*5762 (c)(t)    Remote Base/Link 2 Channel  
 \*5763 (c)(t)    Remote Base/Link 3/Spare Audio 1 Channel  
 \*5764 (c)(t)    Remote Base/Link 4/Control Receiver Channel  
 c = 1 / Link  
       2 / Remote Base  
       3 / Spare Audio 1  
       4 / Control Receiver  
 1 (applies to remote base/link selection only) =  
       0 / no command  
       2 / user commands only  
       3 / all commands ok

DATE \_\_\_\_\_

RC-850 VERSION 3.4 PROGRAMMING SHEETS

MORSE AND SPEECH MESSAGES

INITIAL ID1 (22) \_\_\_\_\_  
INITIAL ID2 (22) \_\_\_\_\_  
INITIAL ID3 (22) \_\_\_\_\_  
FORCED CW ID (14) \_\_\_\_\_  
ANXIOUS ID (14) \_\_\_\_\_  
PENDING ID1 (26) \_\_\_\_\_  
  
PENDING ID2 (26) \_\_\_\_\_  
  
PENDING ID3A (26) \_\_\_\_\_  
  
PENDING ID3B (26) \_\_\_\_\_  
  
PENDING ID3C (26) \_\_\_\_\_  
  
PENDING ID3D (26) \_\_\_\_\_  
  
PENDING ID3E (26) \_\_\_\_\_  
  
SPECIAL ID (50) \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
  
PERIODIC QST ID (14) \_\_\_\_\_  
TTAM DOWN ID (6) \_\_\_\_\_  
AUX TX PAGE ID (4) \_\_\_\_\_  
AUX TX PHONE ID (4) \_\_\_\_\_

\*\*\*\*\*

ALARM #1 (10) \_\_\_\_\_  
ALARM #2 (10) \_\_\_\_\_  
PAGER PROMPT (10) \_\_\_\_\_  
COP GENERIC (6) \_\_\_\_\_  
TT PAD TEST (16) \_\_\_\_\_  
MAIL PRESENT (6) \_\_\_\_\_  
RPTR TIMEOUT (6) \_\_\_\_\_  
RPTR TIMEOUT C (10) \_\_\_\_\_

\*\*\*\*\*

TAIL MSG #1 (6) \_\_\_\_\_  
TAIL MSG #2 (6) \_\_\_\_\_  
TAIL MSG #3 (6) \_\_\_\_\_  
TAIL MSG #4<0> (6) \_\_\_\_\_  
TAIL MSG #4<1> (8) \_\_\_\_\_  
TAIL MSG #4<2> (8) \_\_\_\_\_  
TAIL MSG #4<3> (8) \_\_\_\_\_  
TAIL MSG #4<4> (8) \_\_\_\_\_  
TAIL MSG #4<5> (8) \_\_\_\_\_  
TAIL MSG #4<6> (8) \_\_\_\_\_

TAIL MSG #4<7> (8) \_\_\_\_\_  
TAIL MSG #4<8> (8) \_\_\_\_\_  
TAIL MSG #4<9> (8) \_\_\_\_\_

\*\*\*\*\*

USER FUNC 1 HI (6) \_\_\_\_\_  
USER FUNC 1 LO (6) \_\_\_\_\_  
USER FUNC 2 HI (6) \_\_\_\_\_  
USER FUNC 2 LO (6) \_\_\_\_\_  
USER FUNC 3 HI (6) \_\_\_\_\_  
USER FUNC 3 LO (6) \_\_\_\_\_  
USER FUNC 4 HI (6) \_\_\_\_\_  
USER FUNC 4 LO (6) \_\_\_\_\_  
USER FUNC 5 HI (6) \_\_\_\_\_  
USER FUNC 5 LO (6) \_\_\_\_\_  
USER FUNC 6 HI (6) \_\_\_\_\_  
USER FUNC 6 LO (6) \_\_\_\_\_  
USER FUNC 7 HI (6) \_\_\_\_\_  
USER FUNC 7 LO (6) \_\_\_\_\_  
USER FUNC 8 HI (6) \_\_\_\_\_  
USER FUNC 8 LO (6) \_\_\_\_\_  
UF BYTE1 NAME (6) \_\_\_\_\_  
UF BYTE2 NAME (6) \_\_\_\_\_

\*\*\*\*\*

REM #1 NAME (6) \_\_\_\_\_  
REM #2 NAME (6) \_\_\_\_\_  
REM #3 NAME (6) \_\_\_\_\_  
REM #4 NAME (6) \_\_\_\_\_  
REM1 FREQ PRE (6) \_\_\_\_\_  
REM2 FREQ PRE (6) \_\_\_\_\_  
\* REM1 MEM 1 NAME (6) \_\_\_\_\_  
\* REM1 MEM 2 NAME (6) \_\_\_\_\_  
\* REM1 MEM 3 NAME (6) \_\_\_\_\_  
\* REM1 MEM 4 NAME (6) \_\_\_\_\_  
\* REM1 MEM 5 NAME (6) \_\_\_\_\_  
\* REM1 MEM 6 NAME (6) \_\_\_\_\_  
\* REM1 MEM 7 NAME (6) \_\_\_\_\_  
\* REM2 MEM 1 NAME (6) \_\_\_\_\_  
\* REM2 MEM 2 NAME (6) \_\_\_\_\_  
\* REM2 MEM 3 NAME (6) \_\_\_\_\_  
\* REM2 MEM 4 NAME (6) \_\_\_\_\_  
\* REM2 MEM 5 NAME (6) \_\_\_\_\_  
\* REM2 MEM 6 NAME (6) \_\_\_\_\_  
\* REM2 MEM 7 NAME (6) \_\_\_\_\_

\*\*\*\*\*

MAILBOX #0 (6) \_\_\_\_\_  
MAILBOX #1 (10) \_\_\_\_\_  
MAILBOX #2 (10) \_\_\_\_\_  
MAILBOX #3 (10) \_\_\_\_\_  
MAILBOX #4 (18) \_\_\_\_\_  
MAILBOX #5 (18) \_\_\_\_\_  
MAILBOX #6 (18) \_\_\_\_\_

\*: IN EXPANDED EEPROM



MAILBOX #7 (18) \_\_\_\_\_  
 MAILBOX #8 (18) \_\_\_\_\_  
 MAILBOX #9 (50) \_\_\_\_\_

DEMO TAG (18) \_\_\_\_\_  
 \*\*BULLETIN #1 (12) \_\_\_\_\_  
 \*\*BULLETIN #2 (12) \_\_\_\_\_  
 \*\*BULLETIN #3 (12) \_\_\_\_\_  
 \*\*BULLETIN #4 (12) \_\_\_\_\_  
 \*\*BULLETIN #5 (12) \_\_\_\_\_

\*\*\*\*\*

MORSE CODE PARAMETERS

	SPEED	PITCH	LEVEL
INITIAL ID	_____	_____	_____
FORCED ID	_____	_____	_____
ANXIOUS ID	_____	_____	_____
PENDING ID	_____	_____	_____
SPECIAL ID	_____	_____	_____
USER CMD	_____	_____	_____
COP CMD	_____	_____	_____

\*\*\*\*\*

CALL SIGNS (6)

00	_____	25	_____	50	_____	75	_____
01	_____	26	_____	51	_____	76	_____
02	_____	27	_____	52	_____	77	_____
03	_____	28	_____	53	_____	78	_____
04	_____	29	_____	54	_____	79	_____
05	_____	30	_____	55	_____	*80	_____
06	_____	31	_____	56	_____	*81	_____
07	_____	32	_____	57	_____	*82	_____
08	_____	33	_____	58	_____	*83	_____
09	_____	34	_____	59	_____	*84	_____
10	_____	35	_____	60	_____	*85	_____
11	_____	36	_____	61	_____	*86	_____
12	_____	37	_____	62	_____	*87	_____
13	_____	38	_____	63	_____	*88	_____
14	_____	39	_____	64	_____	*89	_____
15	_____	40	_____	65	_____	*90	_____
16	_____	41	_____	66	_____	*91	_____
17	_____	42	_____	67	_____	*92	_____
18	_____	43	_____	68	_____	*93	_____
19	_____	44	_____	69	_____	*94	_____
20	_____	45	_____	70	_____	*95	_____
21	_____	46	_____	71	_____	*96	_____
22	_____	47	_____	72	_____	*97	_____
23	_____	48	_____	73	_____	*98	_____
24	_____	49	_____	74	_____	*99	_____

\*: IN EXPANDED EEPROM  
 \*\*: IN RAM

METER FACE ASSIGNMENTS

1	_____	2	_____	3	_____	4	_____
5	_____	6	_____	7	_____	8	_____
9	_____	10	_____	11	_____	12	_____
13	_____	14	_____	15	INT. TEMP.	16	INT. VOLTS

\*\*\*\*\*

EMERGENCY AUTODIAL

NUMBER (11) MESSAGE (6)		NUMBER (11) MESSAGE (6)	
0	_____	5	_____
1	_____	6	_____
2	_____	7	_____
3	_____	8	_____
4	_____	9	_____

\*\*\*\*\*

TIMERS

ALARM	_____	SEC
SEQ INTERDIGIT	_____	SEC
BEGIN TO SEQ	_____	SEC
SEQ TO EOT	_____	SEC
INDIV USER ACCESS	_____	SEC
REPEATER ACTIVITY	_____	SEC
INITIAL ID	_____	SEC
FORCED CW ID	_____	SEC
ANXIOUS ID	_____	SEC
PENDING ID	_____	SEC
PERIODIC QST ID	_____	SEC
AUTOPATCH TIMEOUT	_____	SEC
USER AD TIMEOUT	_____	SEC
EMER AD TIMEOUT	_____	SEC
EXT DEVICE WCHDG	_____	SEC
PATCH TIME XTEND	_____	SEC
PATCH ACTIVITY	_____	SEC
REV PATCH RING	_____	SEC
PHONE ANS DELAY	_____	SEC
REPT TIMEOUT LONG	_____	SEC
REPT TIMEOUT SHORT	_____	SEC
SPARE AUDIO 1	_____	SEC
TAIL MESSAGE	_____	SEC
TTAM TIMEOUT	_____	SEC
TX TURNON DELAY	_____	MS.

\*\*\*\*\*

MESSAGE MACROS

MSG MACRO #1	(10)	_____
MSG MACRO #2	(10)	_____
MSG MACRO #3	(6)	_____
MSG MACRO #4	(6)	_____

COURTESY TONE MESSAGE

COURTESY TONE #1	(4)	_____
COURTESY TONE #2	(4)	_____
COURTESY TONE #3	(4)	_____
COURTESY TONE #4	(4)	_____
COURTESY TONE #5	(4)	_____
COURTESY TONE #6	(4)	_____
COURTESY TONE #7	(4)	_____
COURTESY TONE #8	(4)	_____
COURTESY TONE #9	(4)	_____
COURTESY TONE #10	(4)	_____
COURTESY TONE #11	(4)	_____
COURTESY TONE #12	(4)	_____
COURTESY TONE #13	(4)	_____

\*\*\*\*\*

PATCH MESSAGES

AUTOPATCH ACTIVATE	(6)	_____
USER AD ACTIVATE	(6)	_____
ANTIDIAL	(10)	_____
PATCH COVER TONE	(6)	_____
PATCH TIMEOUT WARN	(6)	_____
PHONE ANSWER	(18)	_____
PHONE HANGUP	(10)	_____
REV PATCH CALL FOR	(4)	_____

\*\*\*\*\*

SCHEDULER

CHANGEOVER MSG	(5)	_____
EVENT #1	(12)	_____
EVENT #2	(12)	_____
EVENT #3	(12)	_____
EVENT #4	(12)	_____
EVENT #5	(12)	_____

\*\*\*\*\*

NON-MESSAGE PATCH UTILITIES

PHONE LEADING 1 OVRDE	(6)	_____
PHONE NUM MACRO A	(6)	_____
PHONE NUM MACRO B	(6)	_____
PHONE NUM MACRO C	(6)	_____
LOCAL AREA CODE	(3)	_____
ADJACENT AREA CODE	(3)	_____
PERMITTED A/C #1	(3)	_____
PERMITTED A/C #2	(3)	_____
PERMITTED A/C #3	(3)	_____
PRI PATCH DIAL PREFIX	(8)	_____
SEC PATCH DIAL PREFIX	(6)	_____
TER PATCH DIAL PREFIX	(6)	_____

AUTODIAL BANK 0 NUMBERS (11 DIGITS)

10		25	
11		26	
12		27	
13		28	
14		29	
15		30	
16		31	
17		32	
18		33	
19		34	
20		35	
21		36	
22		37	
23		38	
24		39	

AUTODIAL BANK 0 NUMBERS (8 DIGITS)

40	60	80
41	61	81
42	62	82
43	63	83
44	64	84
45	65	85
46	66	86
47	67	87
48	68	88
49	69	89
50	70	90
51	71	91
52	72	92
53	73	93
54	74	94
55	75	95
56	76	96
57	77	97
58	78	98
59	79	99

\*AUTODIAL BANK 1 NUMBERS (11 DIGITS)

00	34	68
01	35	69
02	36	70
03	37	71
04	38	72
05	39	73
06	40	74
07	41	75
08	42	76
09	43	77
10	44	78

\*: BANK 1 IN EXPANDED EEPROM - OTHERWISE IN RAM

11		45		79	
12		46		80	
13		47		81	
14		48		82	
15		49		83	
16		50		84	
17		51		85	
18		52		86	
19		53		87	
20		54		88	
21		55		89	
22		56		90	
23		57		91	
24		58		92	
25		59		93	
26		60		94	
27		61		95	
28		62		96	
29		63		97	
30		64		98	
31		65		99	
32		66			
33		67			

\*\*\*\*\*

\*AUTODIAL BANK 2 NUMBERS (35 DIGITS)

00	
01	
02	
03	
04	
05	
06	
07	
08	
09	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	
20	
21	

\*: IN EXPANDED EEPROM

22 \_\_\_\_\_  
 23 \_\_\_\_\_  
 24 \_\_\_\_\_  
 25 \_\_\_\_\_  
 26 \_\_\_\_\_  
 27 \_\_\_\_\_  
 28 \_\_\_\_\_  
 29 \_\_\_\_\_  
 30 \_\_\_\_\_  
 31 \_\_\_\_\_  
 32 \_\_\_\_\_  
 33 \_\_\_\_\_  
 34 \_\_\_\_\_  
 35 \_\_\_\_\_  
 36 \_\_\_\_\_  
 37 \_\_\_\_\_  
 38 \_\_\_\_\_  
 39 \_\_\_\_\_  
 40 \_\_\_\_\_  
 41 \_\_\_\_\_  
 42 \_\_\_\_\_  
 43 \_\_\_\_\_  
 44 \_\_\_\_\_  
 45 \_\_\_\_\_  
 46 \_\_\_\_\_  
 47 \_\_\_\_\_  
 48 \_\_\_\_\_  
 49 \_\_\_\_\_

\*\*\*\*\*

COURTESY TONE PARAMETERS

	SEG 1					SEG 2					SEG 3					HANG
	DEL	PA	PB	L	DUR	DEL	PA	PB	L	DUR	DEL	PA	PB	L	DUR	
1	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
2	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
3	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
4	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
5	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
6	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
7	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
8	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
9	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
10	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
11	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
12	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
13	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

\*\*\*\*\*

USER AND COP PREFIXES

NON-PHONE PREFIX \_\_\_\_\_ PHONE PREFIX \_\_\_\_\_  
 COP ROOT SELECT    1        2        3        4

	PREFIX	ATTRIBUTES
PRI AUTOPATCH	_____	_____
SEC AUTOPATCH	_____	_____
TER AUTOPATCH	_____	_____
PRI EMER A/D	_____	_____
SEC EMER A/D	_____	_____
USER A/D BANK 0	_____	_____
USER A/D BANK 1	_____	_____
USER A/D BANK 2	_____	_____
UAD BNK0 LD/ER	_____	_____
UAD BNK1 LD/ER	_____	_____
UAD BNK2 LD/ER	_____	_____
PATCH UTIL P	_____	_____
PATCH UTIL Q	_____	_____
REV PATCH	_____	_____
PATCH HANGUP	_____	_____
BSR CONTROL	_____	_____
USER FUNCTION	_____	_____
LINK/REM BASE	_____	_____
PAGING	_____	_____
SPARE AUDIO 1	_____	_____
DEMO/BULLETIN	_____	_____
MAILBOX	_____	_____
VOICE TELEMETRY	_____	_____
TT ACCESS MODE	_____	_____
TT PAD TEST	_____	_____
USER MAPPED COP	_____	_____
INDIVID USER ID	_____	_____

\*\*\*\*\*

USER MAPPED COP COMMANDS

USER/COP COMMAND #0	_____
USER/COP COMMAND #1	_____
USER/COP COMMAND #2	_____
USER/COP COMMAND #3	_____
USER/COP COMMAND #4	_____
USER/COP COMMAND #5	_____
USER/COP COMMAND #6	_____
USER/COP COMMAND #7	_____
USER/COP COMMAND #8	_____
USER/COP COMMAND #9	_____

\*\*\*\*\*

UNLOCK CODE SELECT	PRI	SEC
UNLOCK CODE:PRIMARY	(10)	_____
UNLOCK CODE:SECONDARY	(10)	_____

\*\*\*\*\*

ANTIDIAL NUMBERS (11 DIGITS)  
 (\* IN EXPANDED EEPROM)

0	_____	4	_____	*7	_____
1	_____	*5	_____	*8	_____
2	_____	*6	_____	*9	_____
3	_____				

CLOCK FORMAT

12 24

\*\*\*\*\*

I/O SENSE

LINK/RB 1	COS	IN	ACT HI	ACT LO
LINK/RB 2	COS	IN	ACT HI	ACT LO
LINK/RB 3	COS	IN	ACT HI	ACT LO
LINK/RB 4	COS	IN	ACT HI	ACT LO
LINK/RB 1	PTT	OUT	ACT HI	ACT LO
LINK/RB 2	PTT	OUT	ACT HI	ACT LO
LINK/RB 3	PTT	OUT	PRESET TO:	ACT LO
LINK/RB 4	PTT	OUT	PRESET TO:	ACT LO

USER/COP	PL	IN	ACT HI	ACT LO
USER ONLY	PL	IN	ACT HI	ACT LO

PHONE PATCH BOARD	NON-REG	REG
-------------------	---------	-----

UF OUTPUTS	EXPANDED	LATCHED
------------	----------	---------

\*\*\*\*\*

COMMAND CHANNEL ENABLE/DISABLE

COMMAND FROM REPTR REC	E	D
COMMAND FROM TELEPHONE	E	D
COMMAND FROM SERIAL P1	E	D
COMMAND FROM SERIAL P2	E	D
COMMAND FROM AUX TT DECODE	E	D

\*\*\*\*\*

INDIVIDUAL USER ACCESS CODES

MASTER FUNC FOR ALL CODES	E	D
---------------------------	---	---

1ST DIG	SLOT	ENA/DIS	1ST DIG	SLOT	ENA/DIS
_____	00	_____	_____	50	_____
_____	01	_____	_____	51	_____
_____	02	_____	_____	52	_____
_____	03	_____	_____	53	_____
_____	04	_____	_____	54	_____
_____	05	_____	_____	55	_____
_____	06	_____	_____	56	_____
_____	07	_____	_____	57	_____
_____	08	_____	_____	58	_____
_____	09	_____	_____	59	_____
_____	10	_____	_____	60	_____
_____	11	_____	_____	61	_____
_____	12	_____	_____	62	_____
_____	13	_____	_____	63	_____
_____	14	_____	_____	64	_____
_____	15	_____	_____	65	_____
_____	16	_____	_____	66	_____
_____	17	_____	_____	67	_____
_____	18	_____	_____	68	_____







DIAL FORMAT      DTMF      SLO DTMF      10PPS      20PPS  
 DEDICATED LINE                DED      SHARED

LOGICAL PHONE LINE 1:    L1   L2   R1   R2   R3  
 LOGICAL PHONE LINE 2:    L1   L2   R1   R2   R3  
 LOGICAL PHONE LINE 3:    L1   L2   R1   R2   R3

REMOTE PHONE UP CHANNEL:    CR   L1   L2   L3   L4  
 REM. PHONE DOWN CHANNEL:   TX   L1   L2   L3   L4  
 \*\*\*\*\*

REMOTE BASE/LINK HARDWARE ASSIGNMENT

	ASSIGNMENT	COMMANDS ALLOWED
RB/LINK 1	1 2 3 4	0 1 2 3
RB/LINK 2	1 2 3 4	0 1 2 3
RB/LINK 3/SP AUD	1 2 3 4	0 1 2 3
RB/LINK 4/CON RX	1 2 3 4	0 1 2 3

ROTOR CONTROL METHOD:                      DATA STREAM                      RCB-1

PAGER MEMORIES

LOCATION	FORMAT	ADDRESS	FREQ
00	_____	_____	_____
01	_____	_____	_____
02	_____	_____	_____
03	_____	_____	_____
04	_____	_____	_____
05	_____	_____	_____
06	_____	_____	_____
07	_____	_____	_____
08	_____	_____	_____
09	_____	_____	_____
10	_____	_____	_____
11	_____	_____	_____
12	_____	_____	_____
13	_____	_____	_____
14	_____	_____	_____
15	_____	_____	_____
16	_____	_____	_____
17	_____	_____	_____
18	_____	_____	_____
19	_____	_____	_____
20	_____	_____	_____
21	_____	_____	_____
22	_____	_____	_____
23	_____	_____	_____
24	_____	_____	_____
25	_____	_____	_____
26	_____	_____	_____
27	_____	_____	_____
28	_____	_____	_____

LOCATION	FORMAT	ADDRESS	FREQ
29	_____	_____	_____
30	_____	_____	_____
31	_____	_____	_____
32	_____	_____	_____
33	_____	_____	_____
34	_____	_____	_____
35	_____	_____	_____
36	_____	_____	_____
37	_____	_____	_____
38	_____	_____	_____
39	_____	_____	_____
40	_____	_____	_____
41	_____	_____	_____
42	_____	_____	_____
43	_____	_____	_____
44	_____	_____	_____
45	_____	_____	_____
46	_____	_____	_____
47	_____	_____	_____
48	_____	_____	_____
49	_____	_____	_____
50	_____	_____	_____
51	_____	_____	_____
52	_____	_____	_____
53	_____	_____	_____

\*\*\*\*\*

MISC. PROGRAMMING NOTES

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 0

DESCRIPTION

TAIL MESSAGE 4 (X)

PENDING ID 3 (X)

ACCESS MODE	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS				NEVER				AFTER	#	
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE				GENERIC				OFF		
POWER	HIGH				LOW						
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR				MUTE						
PATCH COVER TONE	ALWAYS				NEVER				SELECTABLE		
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 1

DESCRIPTION

TAIL MESSAGE 4 (X)  
PENDING ID 3 (X)

	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS				NEVER			AFTER		#	
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE				GENERIC			OFF			
POWER	HIGH				LOW						
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR				MUTE						
PATCH COVER TONE	ALWAYS				NEVER			SELECTABLE			
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*



CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 2

DESCRIPTION

TAIL MESSAGE 4 (X)  
PENDING ID 3 (X)

	A	B	C	D	E	F	G	H	I	J	K
ACCESS MODE											
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS					NEVER			AFTER #		
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE					GENERIC			OFF		
POWER	HIGH					LOW					
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR					MUTE					
PATCH COVER TONE	ALWAYS					NEVER			SELECTABLE		
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 4

DESCRIPTION

TAIL MESSAGE 4 (X)

PENDING ID 3 (X)

	A	B	C	D	E	F	G	H	I	J	K
ACCESS MODE											
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS				NEVER			AFTER	#		
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE				GENERIC			OFF			
POWER	HIGH				LOW						
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR				MUTE						
PATCH COVER TONE	ALWAYS				NEVER			SELECTABLE			
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 3

DESCRIPTION

TAIL MESSAGE 4 (X)

PENDING ID 3 (X)

ACCESS MODE	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA	DIS									
REPEATER REC	ENA	DIS									
REPEATER TRANS	ENA	DIS									
REPEATER SYS	ENA	DIS									
TT COVER TONE	ENA	DIS									
TT MUTING	ALWAYS				NEVER			AFTER #			
USER COMMAND GRP A	ENA	DIS									
USER COMMAND GRP B	ENA	DIS									
TT PAD TEST	ENA	DIS									
SPARE AUDIO 1	ENA	DIS									
USER MAPPED COP	ENA	DIS									
VOX MODE	ENA	DIS									
ALARM 1	ENA	DIS									
ALARM 2	ENA	DIS									
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE				GENERIC			OFF			
POWER	HIGH				LOW						
CONTROL RX RETRANSMIT	ENA	DIS									
TOOLBOX SIG 1	T	F									
TOOLBOX SIG 2	T	F									
TOOLBOX SIG 3	T	F									
TOOLBOX SIG 4	T	F									
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA	DIS									
CUSTOM HANGUP	ENA	DIS									
DIAL WITHOUT CLICK	ENA	DIS									
FULL DUPLEX ALWAYS ON	ENA	DIS									
PRI AUTOPATCH LD RESRRICT	ENA	DIS									
SEC AUTOPATCH LD RESTRICT	ENA	DIS									
TER AUTOPATCH LD RESTRICT	ENA	DIS									
DIAL TONE/SIGNALLING	HEAR				MUTE						
PATCH COVER TONE	ALWAYS				NEVER			SELECTABLE			
PRI AUTOPATCH	ENA	DIS									
SEC AUTOPATCH	ENA	DIS									
TER AUTOPATCH	ENA	DIS									
USER AD BANK 0	ENA	DIS									
USER AD BANK 1	ENA	DIS									
USER AD BANK 2	ENA	DIS									
PRI EMER AD	ENA	DIS									
SEC EMER AD	ENA	DIS									
REVERSE PATCH	ENA	DIS									
PATCH TIMERS	ENA	DIS									

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS      VERSION 3.4

MACRO SET # 5

DESCRIPTION

TAIL MESSAGE 4 (X) \_\_\_\_\_  
 PENDING ID 3 (X) \_\_\_\_\_

ACCESS MODE	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS					NEVER				AFTER	#
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE					GENERIC				OFF	
POWER	HIGH					LOW					
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8		DESEL	
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR					MUTE					
PATCH COVER TONE	ALWAYS					NEVER				SELECTABLE	
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*



CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 6

DESCRIPTION

TAIL MESSAGE 4 (X)

PENDING ID 3 (X)

ACCESS MODE	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS					NEVER				AFTER #	
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE					GENERIC				OFF	
POWER	HIGH					LOW					
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8		DESEL	
PENDING/SPECIAL ID	1	2	3	SP		1/2/3		1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR					MUTE					
PATCH COVER TONE	ALWAYS					NEVER				SELECTABLE	
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 7

DESCRIPTION

TAIL MESSAGE 4 (X)  
PENDING ID 3 (X)

	A	B	C	D	E	F	G	H	I	J	K
ACCESS MODE											
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS				NEVER			AFTER	#		
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE				GENERIC				OFF		
POWER	HIGH				LOW						
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR				MUTE						
PATCH COVER TONE	ALWAYS				NEVER			SELECTABLE			
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 8

DESCRIPTION

TAIL MESSAGE 4 (X)

PENDING ID 3 (X)

ACCESS MODE	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS				NEVER			AFTER #			
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE				GENERIC			OFF			
POWER	HIGH				LOW						
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR				MUTE						
PATCH COVER TONE	ALWAYS				NEVER			SELECTABLE			
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*

CONTROL OP/SCHEDULER MACRO SETS

VERSION 3.4

MACRO SET # 9

DESCRIPTION

TAIL MESSAGE 4 (X)  
PENDING ID 3 (X)

	A	B	C	D	E	F	G	H	I	J	K
KERCHUNK FILTER	ENA		DIS								
REPEATER REC	ENA		DIS								
REPEATER TRANS	ENA		DIS								
REPEATER SYS	ENA		DIS								
TT COVER TONE	ENA		DIS								
TT MUTING	ALWAYS					NEVER			AFTER #		
USER COMMAND GRP A	ENA		DIS								
USER COMMAND GRP B	ENA		DIS								
TT PAD TEST	ENA		DIS								
SPARE AUDIO 1	ENA		DIS								
USER MAPPED COP	ENA		DIS								
VOX MODE	ENA		DIS								
ALARM 1	ENA		DIS								
ALARM 2	ENA		DIS								
ALL ALARMS			DIS								
COMMAND ACKNOWLEDGE	UNIQUE					GENERIC				OFF	
POWER	HIGH					LOW					
CONTROL RX RETRANSMIT	ENA		DIS								
TOOLBOX SIG 1	T		F								
TOOLBOX SIG 2	T		F								
TOOLBOX SIG 3	T		F								
TOOLBOX SIG 4	T		F								
COURTESY TONE	1	2	3	4	5	6	7	8	DESEL		
PENDING/SPECIAL ID	1	2	3	SP	1/2/3			1/2/3/SP			
PERIODIC ID	ENA		DIS								
CUSTOM HANGUP	ENA		DIS								
DIAL WITHOUT CLICK	ENA		DIS								
FULL DUPLEX ALWAYS ON	ENA		DIS								
PRI AUTOPATCH LD RESRRICT	ENA		DIS								
SEC AUTOPATCH LD RESTRICT	ENA		DIS								
TER AUTOPATCH LD RESTRICT	ENA		DIS								
DIAL TONE/SIGNALLING	HEAR					MUTE					
PATCH COVER TONE	ALWAYS					NEVER			SELECTABLE		
PRI AUTOPATCH	ENA		DIS								
SEC AUTOPATCH	ENA		DIS								
TER AUTOPATCH	ENA		DIS								
USER AD BANK 0	ENA		DIS								
USER AD BANK 1	ENA		DIS								
USER AD BANK 2	ENA		DIS								
PRI EMER AD	ENA		DIS								
SEC EMER AD	ENA		DIS								
REVERSE PATCH	ENA		DIS								
PATCH TIMERS	ENA		DIS								

AUTOPATCH NUMBER READBACK	OPTIONAL	DISABLE	FORCED
USER AD NUMBER READBACK	OPTIONAL	DISABLE	
USER AD LOC READBACK	ENA DIS		
NUMBER READBACK	FEMALE	MALE	MORSE
REVERSE PATCH MODE	0 1 2		
USER AD BANK 0 MODIFY	LOCK	UNLOCK	
USER AD BANK 1 MODIFY	LOCK	UNLOCK	
USER AD BANK 2 MODIFY	LOCK	UNLOCK	
TIMEOUT TIMER	ENA DIS		
TIMEOUT TIMER	LONG	SHORT	
SCHEDULER	ON	OFF	
REPEATER ACTIVITY TIMER	ENA DIS		
SPEECH	ENA DIS		
SPEECH	TALKOVER	INTERRUPT	
TAIL MESSAGE INTERVAL	EACH TAIL	EVERY 4	TIMER
TAIL MESSAGE SELECT	1 2 3 4	OFF	

\*\*\*OPTIONAL\*\*\*

REMOTE BASE/LINK 1	ENA DIS
REMOTE BASE/LINK 2	ENA DIS
REMOTE BASE/LINK 3	ENA DIS
REMOTE BASE/LINK 4	ENA DIS

LINK FREQUENCIES  
LINK PL  
LINK ANTENNA DIR.  
LINK BAND SELECT

USER FUNC (1-32)

\*\*\*\*\*MACRO SET PROGRAMMING NOTES\*\*\*\*\*



SCHEDULER SEQUENCE

SETPOINT	TIME	DOW	MACRO SET/EVENT	LINK/USER FUNC UPDATE
00	_____	_____	_____	_____
01	_____	_____	_____	_____
02	_____	_____	_____	_____
03	_____	_____	_____	_____
04	_____	_____	_____	_____
05	_____	_____	_____	_____
06	_____	_____	_____	_____
07	_____	_____	_____	_____
08	_____	_____	_____	_____
09	_____	_____	_____	_____
10	_____	_____	_____	_____
11	_____	_____	_____	_____
12	_____	_____	_____	_____
13	_____	_____	_____	_____
14	_____	_____	_____	_____
15	_____	_____	_____	_____
16	_____	_____	_____	_____
17	_____	_____	_____	_____
18	_____	_____	_____	_____
19	_____	_____	_____	_____
20	_____	_____	_____	_____
21	_____	_____	_____	_____
22	_____	_____	_____	_____
23	_____	_____	_____	_____
24	_____	_____	_____	_____
25	_____	_____	_____	_____
26	_____	_____	_____	_____
27	_____	_____	_____	_____
28	_____	_____	_____	_____
29	_____	_____	_____	_____

\*\*\*\*\*

PROGRAMMING NOTES\*\*\*\*\*

