

 **MOBILE RADIO**

# **CENTURY II**

**MAINTENANCE MANUAL LBI30935**

DATAFILE FOLDER — DF9053

**148—174 MHz (Domestic)  
146—174 MHz (International)**

**10—WATT TRANSMITTER  
25—WATT TRANSMITTER**




**MOBILE RADIO**



**MICROPHONE**

**TWO-WAY FM  
MOBILE  
COMBINATIONS**



**EXTERNAL  
SPEAKER  
(OPTIONAL)**

**GENERAL  ELECTRIC**

## TABLE OF CONTENTS

SYSTEM SPECIFICATIONS .....	iii
COMBINATION NOMENCLATURE .....	iv
DESCRIPTION .....	1
OPERATION .....	2
INITIAL ADJUSTMENT .....	2
Transmitter Adjustment .....	2
Receiver Adjustment .....	2
Re-Installation .....	2
Noise Suppression .....	2
CIRCUIT ANALYSIS .....	5
Transmitter .....	5
Receiver .....	7
MAINTENANCE .....	12
Disassembly .....	12
PA Transistor Replacement .....	13
Removing IC's .....	13
TEST AND TROUBLESHOOTING PROCEDURES .....	13
Servicing Techniques .....	14
Test Points .....	14
Transmitter Alignment Procedures .....	16 - 17
Receiver Alignment Procedures .....	18
Receiver Test Procedures .....	19
Receiver Audio and Squelch Waveform Checks .....	20
MECHANICAL LAYOUT .....	15
OUTLINE DIAGRAMS .....	
148-174 MHz, High Band Transmitter/Receiver Board .....	24
Interconnect Board (Single Frequency) .....	24
SYSTEM INTERCONNECTION DIAGRAM .....	25 - 26
SCHEMATIC DIAGRAMS .....	
Interconnect Board (Single Frequency) .....	27
148-174 MHz, High Band Transmitter/Receiver Board (Sheets 1, 2 & 3) .....	29 - 31
SERVICE SHEETS .....	32 - 34
PARTS LIST .....	35 - 40
PRODUCTION CHANGES .....	40

## ILLUSTRATIONS

Figure 1 - Ignition Circuit with Noise Suppression Components .....	3
Figure 2 - Generator Circuit with Noise Suppression Components .....	4
Figure 3 - Transmitter/Receiver Block Diagram .....	6
Figure 4 - Simplified CCT Diagram .....	10
Figure 5 - Power Distribution .....	11
Figure 6 - PA Transistor Lead Identification .....	13
Figure 7 - Temperature Compensation Chart .....	16
Figure 8 - Test Equipment Set Up .....	17
Figure 9 - Transmitter Troubleshooting Flow Chart (Sheets 1 & 2) .....	21 - 22
Figure 10 - Receiver Troubleshooting Flow Chart .....	23

## WARNING

Although the highest DC voltage in CENTURY II Mobile Equipment is supplied by the vehicle battery, high currents may be drawn under short circuit conditions. These currents can possibly heat metal objects such as tools, rings, watchbands, etc., enough to cause burns. Be careful when working near energized circuits!

High-level RF energy in the transmitter Power Amplifier assembly can cause RF burns upon contact. Keep away from these circuits when the transmitter is energized!

## ADDENDUM #1 TO LBI30935

This addendum lists the CUSTOMER PREFERRED PACKAGES covered in this manual.

### CUSTOMER PREFERRED PACKAGES

M5A25 through M5A36, and M5A49 through M5A60.

DESCRIPTION	PACKAGE ORDERING NUMBER	PUBLICATION NUMBER
HI BAND	M5A25 - M5A28	LBI30935
MOBILE	M5A29 - M5A32	LBI30935 & LBI30893
	M5A33 - M5A36	LBI30935, LBI30893 & LBI30939
HI BAND	M5A49 - M5A50	LBI30935 & LBI30777
&	M5A51 - M5A52	LBI30935, LBI30893 & LBI30777
POWER	M5A53 - M5A54	LBI30935, LBI30893 & LBI30777
SUPPLY	M5A55 - M5A56	LBI30935 & LBI30777
	M5A57 - M5A58	LBI30935, LBI30893 & LBI30777
	M5A59 - M5A60	LBI30935, LBI30893 & LBI30777

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION  
WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.







## SYSTEM SPECIFICATIONS\*

FREQUENCY RANGE	Combinations with 6th Digit "C"	148-174 MHz (Domestic)
	Combinations with 6th Digit "T"	146-174 MHz (International)
BATTERY DRAIN		
Receiver		
Squelched		0.20 Amperes
Unsquelched		0.65 Amperes
Transmitter		
10 Watt		3.5 Amperes
25 Watt		5.9 Amperes
FREQUENCY STABILITY		0.0005%
TEMPERATURE RANGE		-30°C (-22°F) to +60°C (140°F)
DUTY CYCLE		100% Receive, 20% Transmit (EIA)
DIMENSION, LESS ACCESSORIES (H X W X D)		60 mm X 180 mm X 190 mm (2.3 X 7.3 X 7.4 inches)
WEIGHT, LESS ACCESSORIES		1.7 kg (3.7 pounds)

TRANSMITTER			RECEIVER (ER-111-A)		
POWER OUTPUT			AUDIO OUTPUT (to 4.0 ohms speaker)	3 Watts (less than 5% distortion) EIA 1.5 Watts (less than 5% distortion) CEPT	
KT-171-A	3 to 10 Watt				
KT-172-A	8 to 25 Watt				
CONDUCTED SPURIOUS	-60 dB		SENSITIVITY		
MODULATION	±4.5 kHz (±2.25 kHz***)		12 dB SINAD (EIA Method)	0.30 µV	
AUDIO SENSITIVITY	65 to 120 Millivolts		20 dB Quieting Method	0.35 µV	
AUDIO FREQUENCY CHARACTERISTICS	Within +1 dB to -3 dB of a 6 dB/octave pre-emphasis from 300 to 3000 Hz per EIA standards. Post limiter filter per FCC and EIA (2550 Hz***)		20 dB SINAD (CEPT**)	0.75 µV (1.0 µV***)	
DISTORTION	Less than 3% (1000 Hz) Less than 5% (300 to 3000 Hz)		SELECTIVITY		
DEVIATION SYMMETRY	0.5 kHz maximum		EIA Two-Signal Method	-85 dB @ ±25/30 kHz (EIA) -75 dB (CEPT) -65 dB (CEPT***)	
MAXIMUM FREQUENCY SPREAD:	Full Specifi- cations	1 dB Degra- dation	SPURIOUS RESPONSE	-85 dB	
148-174 MHz	2.5 MHz	3.5 MHz	INTERMODULATION	-77 dB	
RF OUTPUT IMPEDANCE	50 ohms		MODULATION ACCEPTANCE	±6.5 kHz (±4.0 kHz***)	
			SQUELCH SENSITIVITY	8 dB SINAD	
			MAXIMUM FREQUENCY SPREAD	Full Specifi- cations	3 dB Degra- dation
			148-174	1.5 MHz	2.5 MHz
			FREQUENCY RESPONSE	Within +1 and -1.5 dB of a standard CEPT 6 dB per octave de-emphasis curve from 400 to 2700 Hz (1000 Hz reference) Also fits +1 to -3 dB from 300 to 3000 EIA	
			RF INPUT IMPEDANCE	50 ohms	

\* These specifications are intended primarily for use of the serviceman. Refer to the appropriate Specifications Sheet for the complete specifications.

\*\*  $\Delta F$  60% X  $\Delta F$  Max. F mod = 1 kHz. Measured with psophometric filter.

\*\*\* These specifications are for 12.5 kHz channel spacing.

## COMBINATION NOMENCLATURE

DIGITS 1 & 2	DIGIT 3	DIGIT 4	DIGIT 5	DIGIT 6	DIGIT 7-9	DIGIT 10	DIGIT 11	DIGIT 12	DIGIT 13	DIGIT 14	DIGIT 15	DIGIT 16	DIGIT 17
Product Code	Transmit Frequency Range	Receive Frequency Range	Channel Spacing	Type	RF Power Output	Freq. Capacity	Control	Assembled	Oscillator Stability	Mechanical Package	System Voltage	Receiver Type	Audio Power
<b>M5</b>	<b>J</b> 146-174 MHz	<b>J</b> 146-174 MHz	<b>1</b> 30 kHz	<b>C</b> FCC Spec	<b>010</b> 10-watts	<b>A</b> 1 Tx 1 Rx	<b>0</b> Standard	<b>U</b> MRPD	<b>B</b> ±5 PPM	<b>0</b> Standard	<b>0</b> + 12 VDC (Neg. Gnd. only)	<b>0</b> Standard	<b>0</b> 3-watts
			<b>2</b> 25 kHz	<b>T*</b>	<b>025</b> 25-watts	<b>B</b> 2 Tx 1 Rx			<b>D</b> ±10 PPM		<b>1</b> AC Power Supply	<b>T</b> Alt. 2nd Osc. Crystal	
			<b>4</b> 12.5 kHz			<b>C</b> 2 Tx 2 Rx					<b>2</b> AC Power Supply w/ DC Remote		
						<b>D</b> 1 Tx 2 Rx							
						<b>F</b> 4 Tx 4 Rx							
						<b>H</b> 6 Tx 6 Rx							

\* Combinations with the sixth digit "T" are primarily for International use. These combinations have a frequency range of 146-174 MHz.

## STRUCTURED OPTIONS

DIGIT A	DIGIT B	DIGIT C	DIGIT D	DIGIT H	DIGIT J	DIGIT R	DIGIT S	DIGIT T
Transmit Frequencies	Receive Frequencies	Option Deck	Channel Guard	DTMF Encoder	Carrier Control Timer	Mounting Hardware	Front Cap	Universal Tone Cable
<b>0</b> None	<b>0</b> None	<b>0</b> None	<b>0</b> None	<b>0</b> None	<b>0</b> None	<b>0</b> None	<b>0</b> Standard	<b>0</b> None
<b>A</b> 1-Tx	<b>A</b> 1-Rx	<b>A</b> T-99 Dec (2-Tone)	<b>C</b> 1-Freq. Enc/Dec	<b>1</b> DTMF Encoder	<b>1</b> CCT (1-minute)	<b>1</b> Standard Bracket	<b>1</b> Private Brandable	<b>1</b> Tone Cable
<b>C</b> 2-Tx	<b>C</b> 2-Rx	<b>B</b> T-99 Dec (4-Tone)	<b>D</b> 1-Freq. (Dec only)			<b>2</b> Front Access		
<b>E</b> 3-Tx	<b>E</b> 3-Rx	<b>C</b> T-99 Dec (2-Tone w/ Ext. Alarm)	<b>E</b> 1-Freq. (Enc only)			<b>3</b> Desk Top Stand		
<b>F</b> 4-Tx	<b>F</b> 4-Rx	<b>D</b> T-99 Dec (4-Tone w/ Ext. Alarm)	<b>F</b> Tone Reject Filter					
<b>G</b> 5-Tx	<b>G</b> 5-Rx	<b>G</b> PA Int. Spkr. Switch						
<b>H</b> 6-Tx	<b>H</b> 6-Rx	<b>H</b> PA Int.-Ext. Spkr. Switch						
		<b>L</b> Channel Busy Light						

:

!

-

:

-

## DESCRIPTION

General Electric Century II mobile combinations are fully transistored -- utilizing both discrete components and integrated circuits (IC's) for high reliability. The radio is a self-contained, FM transmitter/receiver with built-in controls and speaker. Its small size makes it ideal for front mounting in conventional vehicles. The standard combinations may be equipped with the following:

- One through six frequencies.
- Plug-in crystals for  $\pm 0.0005\%$  oscillator stability.
- Channel Guard (tone squelch).

The radio consists of an effective, heat-dissipating, aluminum die cast "H" frame on which two circuit boards are mounted. The transmitter/receiver board is mounted on the bottom of the "H" frame and includes the complete RF and audio circuitry for a single frequency radio. The top board contains all interconnections, and the multi-frequency oscillator circuits when present. In radios equipped with Channel Guard, the Channel Guard option also mounts in the top section of the "H" frame. All external connectors, controls and indicators are mounted directly on the two boards for reliability and ease of disassembly.

The boards plug into each other, eliminating the need for interconnecting wires. In a standard single frequency model, the only wires used are for the plug-in leads on the internal speaker. Interchangeable top and bottom covers enclose the "H" frame and provide optimum protection for the radio.

The front control panel is made of highly durable plastic and houses the speaker. It has rounded corners and recessed controls for passenger safety requirements.

The panel provides access to three standard operator controls: A POWER ON/OFF pushbutton, a SQUELCH pushbutton (fixed squelch monitor), and a rotary, edge mounted Volume control. A red Transmit indicator LED (Light Emitting Diode) and a green Power On LED are provided.

For multi-frequency radios, a 7-segment display board with a momentary push-to-select switch is provided. Each time the switch is activated, the channel selected advances by one. The LED channel indicator also serves as the Power On indicator.

No power supply is required since the highest supply voltage used in the radio is provided by the vehicle battery. The radio is designed for operation only in 12 Volt, negative ground vehicle systems.

The radio is of modular construction. All major modules and tuning adjustments are

easily accessible. Loosening the two screws in the rear of the top cover provides access to the interconnect or multi-frequency/interconnect board. Loosening of three screws in the rear of the bottom cover provides access to the transmitter/receiver board. An optional set of test probes can be plugged onto the test pins on the board for alignment and troubleshooting. Measurements can be made using GE Test Set 4EX3A11 or a 20,000 ohms-per-volt Multimeter.

## TRANSMITTER

The transmitter consists of an FM exciter with an audio processor and a broadband, fixed-tuned power amplifier. The RF power output level is internally adjustable from 1/3 to rated power. Once the level is set, a sensing control circuit holds it constant as temperature and/or voltage may vary within specified limits.

Frequency stability for both the transmitter and receiver is maintained by an electronic compensation network.

## RECEIVER

The dual conversion receiver consists of a front end section and two mixer/IF sections operating at 10.7 MHz and 455 kHz. The receiver also contains a squelch and audio section. The audio section provides a 3 Watt audio output into a 4 ohm load.

## AC POWER SUPPLY OPTION

To use the radio as a base station, an optional 121 Volt AC, 60 Hertz power supply is available. An eight-foot cable connects the power supply to the radio. The cable length permits the power supply to be located away from the radio. A green Power On LED is located on the front panel of the power supply.

## MICROPHONE

Century II mobile combinations use a dynamic microphone with a built-in transistorized microphone pre-amplifier. The microphone is housed in a sturdy case, and the extendable coiled cord plugs into a jack at the back of the radio. The microphone is secured to the radio by means of a strain relief hook on the microphone cable.

## HOOKSWITCH

In Channel Guard or Type 99 Decoder applications, a microphone hookswitch is supplied with the radio. The hookswitch is equipped with a Channel Guard disable switch.

Placing the switch in the "up" position (towards the small speaker symbol) disables the receive Channel Guard. With the switch in the "down" position, the Channel Guard is disabled when the microphone is removed from the hookswitch.

#### EXTERNAL SPEAKER (OPTIONAL)

A five-inch speaker, contained in a LEXAN® housing, provides an audio output of 3 Watts. The speaker impedance is 3.2 ohms. The speaker leads are connected to pins 3 and 7 of Systems Plug P910. When the External Speaker is used, the jumper from H15 to H16 on the Interconnect/Multi-frequency board is removed to disconnect the built in speaker from the audio output circuit. A LEXAN® bracket is supplied for mounting.

#### OPERATION

Complete operating instructions for the Two-Way Radio are provided in the separate OPERATOR'S MANUAL. The basic procedures for receiving and transmitting messages follows:

##### TO RECEIVE A MESSAGE

1. Turn the radio on by pushing in the POWER pushbutton.
2. Push in the SQUELCH button to disable the SQUELCH circuit (and tone option if present). Adjust the Volume control for a comfortable listening level and then push the SQUELCH button in again and release it for normal operation.

The radio is now ready to receive messages from other radios in the system.

##### TO TRANSMIT A MESSAGE

1. Turn the radio on as directed in the "To Receive a Message" section.
2. Press the push-to-talk button on the microphone and speak across the face of the microphone in a normal voice. Release the button as soon as the message has been given. The red indicator light on the control panel will glow each time the microphone button is pressed, indicating that the transmitter is on the air. The receiver is muted whenever the transmitter is keyed.

#### INITIAL ADJUSTMENT

After the radio has been installed (as described in the Installation Manual), the following adjustments should be made by an electronics technician who holds a First or

Second Class FCC Radiotelephone license (where required).

#### TRANSMITTER ADJUSTMENT

The adjustment for the transmitter includes measuring the forward and reflected power and adjusting the antenna length for optimum ratio, then setting the transmitter to rated power output (or to the specific output or input which may be required by the FCC station authorization or other authority). Next, measuring the frequency and modulation and entering these measurements on the FCC required station records. For the complete transmitter adjustment, refer to the ALIGNMENT PROCEDURE (see Table of Contents).

#### RECEIVER ADJUSTMENT

The initial adjustment for the receiver includes tuning the input circuit to match the antenna. For the Receiver adjustment Procedure, refer to the ALIGNMENT PROCEDURE (see Table of Contents).

#### RE-INSTALLATION

If the mobile combination is ever moved to a different vehicle, always check the battery polarity of the new system.

#### NOISE SUPPRESSION

After completing the initial adjustment of the transmitter and receiver, the serviceman should determine whether additional noise suppression is required. The following information should assist the serviceman in identifying and eliminating undesirable noise interference.

##### Ignition Noise

Ignition noise sounds like a "popping" sound in the speaker, whose frequency varies with engine speed while a weak signal is being received. This type of interference is generated by the spark plugs, distributor and any poor connections in the high-voltage system which might cause arcing. Ignition noise may be identified by noting that the noise disappears as soon as the ignition switch is turned off (Refer to Figure 1).

1. If the vehicle does not have a resistance lead from the coil to the center of the distributor cap, disconnect the lead at the distributor and cut the lead so that a Cable-Type Suppressor may be inserted in it close to the distributor. Screw the cut ends of the lead into the suppressor.




Figure 1 - Ignition Circuit with Noise Suppression Components

## NOTE

A resistance lead operates as a very effective noise suppressor as long as there are no breaks anywhere along its length. Never cut a resistance lead to insert a suppressor. A loose knot is often tied in the lead to prevent excess flexing, which might break the conductor.

## 2. Check to see that:

- the distributor points and condenser are in good condition.
- the high-voltage leads from the distributor are not broken and are making good contact at each end.
- the spark plugs have clean, dry insulators and their electrodes are clean and properly adjusted.
- the timing has been properly adjusted.

3. Use a 0.5 mfd by-pass capacitor to by-pass the battery lead to the ignition coil. Mount the capacitor under a screw which will provide a good ground and connect the capacitor lead to the terminal of the coil which is connected to the ignition.

4. Remove the ignition coil and its mounting bracket. Clean paint from coil (where the bracket

mounts), from the bracket and from the engine block. Remount the coil so as to obtain a good ground for the coil case.

5. If the vehicle has been driven 30,000 or 40,000 miles or more, the cap and rotor of the distributor will probably need replacing. This will not only reduce ignition noise, but also improve the overall performance of the engine.
6. High-voltage ignition wires can become capacitively coupled to the low-voltage systems, causing ignition noise to appear in the low-voltage system. This coupling can be minimized by separating the high- and low-voltage leads, or if necessary, separately shielding the leads.
7. If one of the ignition leads happens to have the critical length for radiating at the receiver's frequency, the noise can be reduced by changing the length of the lead. A noise source of this type is not common and can only be found by using a noise meter or by trial and error.
8. If the preceding steps fail to reduce ignition noise to a satisfactory level, it may be necessary to install resistance-type spark plugs, individual suppressors on each spark plug, or a shielded ignition wire harness.

Alternator Noise

Alternator noise shows up as a high-pitched "whine", whose pitch varies with engine speed. To check for this type of noise, run the engine at a moderate speed and then shut off the engine, while listening to the noise on the receiver. Alternator noise will continue as long as the engine turns, lowering in pitch as the engine slows down.

It may be necessary to install a coaxial type, 0.5 mfd filter capacitor from the ungrounded alternator terminal to ground.

CAUTION

Do not install this capacitor on alternators that are equipped with a factory-supplied capacitor for protecting the rectifiers and suppressing noise.

NOTE

It is recommended that the radio power leads be connected directly to the battery, since alternator noise levels are lowest at the battery. If ignition switch control is required, a special lead is required (refer to Installation Instructions). The high current transmitter should always be connected to the battery.

Generator Noise

Generator noise shows up as a high-pitched "whine", whose pitch varies with engine speed. To check for this type of noise, run the engine at a moderate speed and then shut off the engine, while listening

to the noise on the receiver. Generator noise will continue as long as the engine turns, lowering in pitch as the engine slows down.

By-pass the armature terminal on the generator to ground with a 0.5 mfd, 40 or 50 amp coaxial capacitor. Be sure to scrape the area where the capacitor is to be mounted, so that its case will be well grounded.

CAUTION

Do not by-pass the field terminal (F), as this will damage the voltage regulator contacts.

Generator Regulator Noise

Generator regulator Noise shows up as a "raspy" sound which is generated by the contacts in the regulator and radiated by the leads coming out to the regulator. If suppression of regulator noise is necessary, connect a 5 ohm resistor in series with a .002 mfd capacitor from the field terminal (F) of the regulator to ground. If possible, these components should be mounted inside regulator case. The battery terminal (BAT) and armature terminal (ARM) can be by-passed to ground with 0.5 mfd capacitors (Refer to Figure 2).

CAUTION

If the regulator is opened to install the capacitor or resistor, remember that one wrong connection or shorted wire can damage the regulator or generator.




Figure 2 - Generator Circuit with Noise Suppression Components



Gauge noise produces a "hissing" or "crackling" sound. Tapping the face of each gauge while the engine is running usually shows up which gauge is at fault. By-pass the gauge lead to ground with a 0.5 mfd capacitor, connected close to the sensing element.

#### Static and Arcing Noise

The following suggestions may help to cure other unusual types of interference:

1. Use bonding braid to electrically bond the hood and each corner of the engine block to the vehicle's

frame. Scrape paint and dirt from bonding points to obtain a good ground.

2. Treat noisy tires with anti-static powder.
3. Use front-wheel static collectors for irregular "popping" noise which disappears when the brakes are applied.
4. Use heavily graphited penetrating oil on the exhaust pipe and muffler supports if they are producing noise.

### CIRCUIT ANALYSIS

#### TRANSMITTER

Century II transmitters utilize a crystal controlled frequency modulated exciter, for 1 through 6 frequency operation in the 148-174 MHz frequency band. The solid state transmitter uses integrated circuits and discrete components for increased reliability. The transmitter consists of audio processor U101; oscillator Q151; exciter Q201 through Q204; PA Q205 and Q206, and power control circuit Q207 through Q210. The exciter provides approximately 250 milliwatts modulated RF to the PA which provides rated output power of either 10 or 25 watts. Figure 3 is a block diagram of the Century II radio showing both the transmitter and receiver.

#### AUDIO PROCESSOR U101

The audio processor provides audio pre-emphasis with amplitude limiting and post limiter filtering. A total gain of approximately 24 dB is realized through the audio processor. 20 dB is provided by U101B and 4 dB by U101A.

The 8.5 Volt regulator powers the audio processor and applies regulated +8.5 V through P903-2 to a voltage divider consisting of R108 and R110. The +4.25 V output from the voltage divider establishes the operating reference point for both operational amplifiers. C107 provides an AC ground at the summing input of both operational amplifiers.

Resistors R105, R106 and R107 and diodes D101 and D102 provide limiting for U101B. Diodes D101 and D102 are reverse biased at +1.7 VDC. Voltage divider network R105, R106 and R107, provides +5.9 VDC at the cathode of D101 and +2.6 VDC at the anode of D102. The voltage at the junction of D101 and D102 is 4.25 V. C102 and C103 permit a DC level change between U101B-7 and the voltage divider network for diode biasing.

When the input signal to U101B-6 is of a magnitude such that the amplifier output at U101B-7 does not exceed 4 volts P-P, the amplifier provides a nominal 20 dB gain. When the audio signal level at U101B-7 exceeds 4 volts PP, diodes D101 and D102 conduct on the positive and negative half cycles providing 100% negative feedback to reduce the amplifier gain to 1. This limits the audio amplitude at U101B-7 to 5 volts PP.

Resistors R102, R103 and R104 and C104 comprise the audio pre-emphasis network that enhances the signal to noise ratio. R104 and C104 control the pre-emphasis curve below limiting. R103 and C104 control the cut-off point for high frequency pre-emphasis. As high frequencies are attenuated, the gain of U101 is increased.

Audio from the microphone is coupled to the audio processor through C904 and R903 on the interconnect board to the input of operational amplifier U101B-6.


The amplified output of U101B is coupled through audio MOD ADJ control R116, C106, R112 and R113 to a second operational amplifier U101A. Audio MOD ADJ control R116 is set for a deviation of 4.5 kHz.

The Channel Guard tone input is applied to U101A-2 through P101-2. The CG tone is then combined with the microphone audio. U101A provides a signal gain of approximately 4 dB.

A post limiter filter consisting of U101A, R112-R114, C108 and C109 provide 12 dB per octave roll-off. R109 and C111 provide an additional 6 dB per octave roll-off for a total of 18 dB.

#### SERVICE NOTE

R112-R114 are 1% resistors. This tolerance must be maintained to assure proper operation of the post limiter filter. Use exact replacements.



RC 3765

Figure 3 - Transmitter/Receiver Block Diagram

The output of the post limiter filter is coupled through C110 to the temperature compensated transmitter oscillator Q151, or through P101-4 to multi-frequency board.

#### TRANSMIT OSCILLATOR

The output of the audio processor is coupled to transmit oscillator Q151 through R154 and C153. A temperature compensating network consisting of R151, R152, R153, R160, D152 and C151 maintains oscillator frequency over a temperature range of -30°C to +60°C. The temperature compensating DC voltage and audio is applied to FM modulator D151 through R154. The modulator varactor D151 varies the transmit frequency at the audio rate applied from the audio processor.

#### NOTE

In radios having  $\pm 10$  PPM oscillator stability, diode D152, in the temperature compensating network is removed.

Q151, Y151 and associated circuitry comprise a Colpitts oscillator which generates the third subharmonic of the RF carrier frequency. The Transmit oscillator frequency is adjusted to the assigned operating frequency by L151. A tuned circuit, L153, C157 and C158, selects the 3rd harmonic of the crystal frequency which is coupled through C201 to buffer/amplifier Q201 and Q202. The output of the buffer/amplifier can be monitored at TP201. The voltage at TP201 is typically 1.0 Vrms.

#### EXCITER AMPLIFIERS

The output of Q202 is coupled through a 2nd tuned circuit L204 and L205 to the base of amplifier Q203. L204 and L205 are tuned to the operating frequency. The output of Q203 can be monitored at TP202 and typically is 0.4 Vrms. The amplifier output is taken from the collector of Q203 and coupled to the base of a class C amplifier Q204 through a double tuned circuit L208 and L209. L208 and L209 are tuned to the operating frequency. The output of the exciter is taken from the collector of Q204 and coupled through an impedance matching network (L213, C222, C223 and C224), a 50 ohm micro-strip W201 and a second impedance matching network (T201, L222, C233) that matches the impedance of the micro-strip to the base of PA driver Q205.

The 250 milliwatt output of the exciter is monitored at TP203 using the RF detector probe. The meter reading at TP203 is typically 0.5 VDC. The output frequency may also be monitored here.

#### POWER AMPLIFIER

The two stage power amplifier consists of driver Q205 and power amplifier Q206 and

associated circuitry. The output of driver Q205 is coupled to the base of Power Amplifier Q206 through an impedance matching network consisting of C238-C242, L225-L226. The output of the power amplifier is coupled to the antenna through a low pass filter and antenna Tx/Rx relay K601. The output of the power amplifier is 10 watts for Transmit/Receive board 19D429451G2 and 25 watts for 19D429451G1.

#### RF POWER ADJUST CIRCUIT

The output power adjust circuit allows the RF output power to be set over a 3.1 range from rated to 1/3 of rated output power. The power adjustment is attained by controlling the DC collector voltage to driver Q205 through pass transistor Q207. The pass transistor is controlled by a feedback loop consisting of Q208-Q210. The power is set by potentiometer R215.

A change in output power is sensed by Q210 causing the base voltage of Q210 to change accordingly. For example, if the output power increases the base of Q210 goes more positive causing it to increase conduction which lowers its collector voltage. Q210 controls Q209, therefore as Q210 increases conduction Q209 decreases conduction and raises the voltage applied to the base of Q208. The conduction of Q208 decreases accordingly, lowering the base voltage of pass transistor Q207. The resulting decrease in conduction of Q207 lowers the collector voltage of driver Q205, thereby lowering the output power in proportion to the excessive power originally sensed by the base circuit of Q210.

#### RECEIVER

Century II receivers are dual conversion, superheterodyne FM receivers designed for one through six frequency operation in the 148-174 MHz frequency range. A regulated 8.5 volts is used for all receiver stages except for the audio PA IC, which operates from the A+ supply.

The receiver is a double conversion superheterodyne using intermediate frequencies of 10.7 MHz and 455 kHz. Adjacent channel selectivity is obtained by using two bandpass filters: 10.7 MHz crystal filter and a 455 kHz ceramic filter.

All receiver circuitry is mounted on the transmitter/receiver (Tx/Rx) board. The receiver consists of:

- Receiver Front End
- 10.7 MHz 1st IF circuitry
- 1st and 2nd Oscillators
- 455 kHz 2nd IF circuitry with FM Detector
- Audio PA Circuit
- Squelch Circuit

## RECEIVER FRONT END

An RF signal from the antenna is coupled through two tuned circuits (L401-C414 and L402-C418) to the emitter of common base RF amplifier Q401. The output of Q401 is coupled through three more tuned circuits (L403-C406-C407, L404-C408 and L405-C411) to the gate of 1st Mixer Q402. Front end selectivity is provided by the five tuned circuits.

## OSCILLATOR &amp; MULTIPLIER

In single frequency radios, Q301, Y301 and associated circuitry make up a Colpitts oscillator. The frequency is controlled by a third mode crystal operated at one third of the required output frequency. Voltage-variable capacitor D301, L301 and Y301 are connected in series to provide voltage compensation. Compensated voltage from the transmitter audio processor is applied to D301 for greater stability. L301 adjusts the oscillator frequency. R305 is in parallel with Y301 to insure operation on the third overtone of the crystal.

The output of Q301 is coupled through C308 to the emitter of buffer Q302. The output of Q302 is tuned to the third harmonic of the crystal oscillator frequency by two tuned circuits consisting of L303-C307 and L305-C310. The oscillator output frequency and power can be metered at TP401. The output normally exceeds four milliwatts.

For multi-frequency applications, R309 in the collector circuit of Q302 is removed to disconnect the oscillator circuit on the Tx/Rx board. The output from the multi-frequency oscillator board connects to J301 on the Tx/Rx board.

## 1ST MIXER

The 1st mixer uses a FET (Q402) as the active device. The FET mixer provides a high input impedance, high power gain, and an output relatively free of harmonics (low in intermodulation products).

In the mixer stage, RF from the tuned circuits is applied to the gate of the mixer. Injection voltage from the oscillator and multiplier stages is applied to the source of the mixer. The 10.7 MHz mixer 1st IF output signal is coupled from the drain of Q402 through an impedance matching network (L406-C413) to crystal filter Z501.

The highly-selective-crystal filter provides the first portion of the receiver IF selectivity. The output of the filter is coupled through impedance-matching network L501 to the 1st IF amplifier.

## 1ST &amp; 2ND IF &amp; DETECTOR STAGES

1st IF Amplifier Q501 is a dual-gate FET. The filter output is applied to Gate 1 of the amplifier, and the output is taken from the drain. The biasing on Gate 2 and the drain load determines the gain of the stage. The amplifier provides approximately 20 dB of IF gain. The output of Q501 is coupled through L502 that matches the amplifier output to the input of IC U501.

U501 and associated circuitry consists of the 2nd oscillator, mixer and 2nd IF amplifier. The crystal for the oscillator is Y501. The oscillator operates at 10.245 MHz for low side injection (11.155 for high side injection). This frequency is mixed with the 10.7 MHz input. The output of the mixer is limited by D501 and D502. L503 is tuned for the 455 kHz 2nd IF frequency.

The output of U501 is coupled through ceramic filter Z502 which provides the 455 kHz selectivity, and applied to U502. Test Point TP501 is used in aligning the receiver, and can be used to check the output of U501.

U502 and associated circuitry consists of a 455 kHz limiter, a quadrature type FM detector and an audio pre-amplifier. L504 is the quadrature detector coil. Audio Level Potentiometer R521 is used to set the audio output level to the audio amplifier.

## AUDIO AND SQUELCH CIRCUITS

Audio

In radios without Channel Guard, audio (VOL/SQ HI) is coupled through P903-3 to the interconnect board and then back to P903-7. The audio passes through the de-emphasis network (R902 on the interconnect board, R629, C607 and C608) to Volume Control R630. In radios with Channel Guard, audio is applied to the Channel Guard tone reject filter through P903-3 and back to the de-emphasis network through P903-7.

For system interface with other options, refer to the applicable Option Manual.

The audio amplifier IC (U601) drives the speaker at the desired audio level (up to three watts). The feedback loop containing R633, R634 and C610 determines the amplifiers closed loop gain. R631 and C612 provide the high audio frequency roll-off above 6 kHz.

The audio amplifier can be muted by a DC voltage from the receiver mute gate (Q605) which uses different logic inputs. These inputs are 8.5V Tx, Squelch Cancel or a squelch signal. In Channel Guard applications, the Rx MUTE function from the Channel Guard board is applied through P903-4.

Squelch

The squelch circuit operates on the noise components contained in the FM detector output. The output of U502 is applied to frequency selective noise amplifier Q601 that has a resonant circuit (L601, R604 and C602) as the collector load. The output is noise in a band around 7 kHz.

This noise output is coupled through Squelch control R607 to expander amplifier Q602 which improves the level discrimination characteristics of the circuit. The output of Q602 is applied to a passive voltage doubler circuit (D603 and D604). This circuit has a high source impedance and operates as an average value rectifier.

Following the voltage doubler is a Schmidt Trigger (Q603 and Q604). The Schmidt Trigger provides the necessary hysteresis and a well-defined output signal for Rx mute gate Q605.

With no RF signal present, the detected noise at the voltage doubler output turns on Q603, turning off Q604. This causes Q605 to turn on, applying +1.4 volts to pin 2 of audio amplifier U601. This voltage turns off U601 and mutes the receiver.

When an RF signal is received, the noise at the output of Q601 decreases and drive to Q603 is removed. This turns off Q603 and allows Q604 to turn on. With Q604 turned on, Rx mute gate Q605 turns off. This turns on U601 so that audio is heard at the speaker.

The squelch sensitivity is adjusted by R607 in the base circuit of expander amplifier Q602.

Pressing in the SQUELCH pushbutton on the front of the radio grounds the base of Q601 and disables the squelch function (and Channel Guard if present).

## CHANNEL BUSY INDICATOR

The Channel Busy Indicator turns on each time a carrier is received. When the receiver is unquieted +1.7V is applied to the base of Q1901 through J604 on the Tx/Rx board, Q1901 turning Q1901 on. Q1901 turns on Q1902 which grounds the cathode of Channel Busy Indicator D1902 causing it to light.

## UNIVERSAL TONE CABLE

A Universal Tone Cable is available for use with external encoders and decoders.

When used with external decoders, the speaker muting function is obtained by removing the jumper from H15 to H16 on the Interconnect/Multi-frequency board.

## CARRIER CONTROL TIMER

The Carrier Control Timer (CCT) shuts off the transmitter carrier after a pre-set timing cycle, and alerts the operator that the transmitter is off by an alert tone from the speaker.

The CCT consists of an integrated circuit (IC) and an external timing resistor mounted on the Interconnect/Multi-frequency board. The timing cycle can be set for a duration of 30 seconds to 3 minutes (in five steps) by changing the value of the timing resistor. The CCT is normally shipped from the factory with a one minute timing cycle. A simplified diagram of the CCT with a timing resistor chart is shown in Figure 4.

The CCT is connected in series with the PTT lead, and consists basically of an adjustable frequency oscillator and a counter. The counter consists of a gate latch circuit and a divider (divide by 2048).

Keying the microphone starts the counter, which takes approximately 60 seconds (with 1 minute timing resistor) to count 2048 periods.

When the counting function times out, the switched PTT stage in the IC opens the PTT function and places the radio in the receive mode. At the same time, the CG disable lead goes low to inhibit the CG receiver muting function (if Channel Guard is present). Also, the oscillator output switches to approximately 1000 Hz for the alert tone. The tone is applied to the receiver audio amplifier and then to the loudspeaker.

Releasing the PTT switch shuts off the alert tone and resets all of the circuits so that the sequence will begin again each time the PTT switch on the microphone is pressed.

## POWER DISTRIBUTION SYSTEM

The battery voltage (A+) connects to the radio through J910-1 and J910-11 at the rear system connector to the interconnect board. Both inputs are connected to reverse polarity protection diodes D901 and D902. Refer to the Power Distribution diagram as shown in Figure 5.

The ground lead is coupled through the same connector and is connected to chassis ground through a fusible printed wiring run which will open if the ground wire is accidentally connected to A+.

One battery input goes directly from the interconnect board through a feed-through capacitor in FL907 to the transmitter PA stages. The other input is

connected through P903-6 to the main board for two functions. One branch for the audio amplifier is connected through an RC-ripple filter (R638, and C618) to one of the sections of POWER On/Off switch S602. The other section of the POWER On/Off switch controls the A+ to voltage regulator U602. The regulator output is fixed at 8.5V by means of a selected resistor (R636). Refer to the Receiver Schematic Diagram for resistor selection instructions.

Regulated 8.5 Volts is switched to either the receiver or the transmitter by the antenna relay. The antenna relay is

also powered by the 8.5 Volt regulated supply. The non-latching relay is operated by the PTT switch on the microphone, completing the path to A-.

The squelch circuit, the audio processor and parts of the IF amplifier U502 are supplied directly from the continuous 8.5V supply.

The receiver front-end, the receiver oscillator, the 10.7 MHz IF stages and the second oscillator are supplied from 8.5V RX. The transmitter oscillator and the exciter are supplied from 8.5V TX.




Figure 4 - Simplified CCT Diagram




Figure 5 - Power Distribution

## MAINTENANCE

### PREVENTIVE MAINTENANCE

To insure high operating efficiency and to prevent mechanical and electrical failures from interrupting system operations, routine checks should be made of all mechanical and electrical parts at regular intervals. This preventive maintenance should include the checks as listed in the table of Maintenance Checks.

MAINTENANCE CHECKS	INTERVAL	
	6 Months	As Required
CONNECTIONS - Ground connections and connections to the voltage source should be periodically checked for tightness. Loose or poor connections to the power source will cause excessive voltage drops and faulty operation. When ground connections are not made directly to the battery, the connection from the battery to vehicle chassis must be checked for low impedance. A high impedance may cause excessive voltage drop and alternator noise problems.	X	
ELECTRICAL SYSTEM - Check the voltage regulator and alternator or generator periodically to keep the electrical system within safe and economical operating limits. Over-voltage is indicated when the battery loses water rapidly. Usage of 1 or 2 ounces of water per cell per week is acceptable for batteries in continuous operation. A weak battery will often cause excessive noise or faulty operation.		X
MECHANICAL INSPECTION - Since mobile units are subject to constant shock and vibration, check for loose plugs, nuts, screws and parts to make sure that nothing is working loose.	X	
ANTENNA - The antenna, antenna base and all contacts should be kept clean and free from dirt or corrosion. If the antenna or its base should become coated or poorly grounded, loss of radiation and a weak signal will result.	X	
ALIGNMENT - The transmitter and receiver meter readings should be checked periodically, and the alignment "touched up" when necessary. Refer to the applicable ALIGNMENT PROCEDURE and troubleshooting sheet for typical voltage readings.		X
FREQUENCY CHECK - Check transmitter frequency and deviation as required by FCC or other authority. Normally, these checks are made when the unit is first put into operation, after the first six months and once a year thereafter.		X

### DISASSEMBLY

- To service the transmitter receiver (Tx-Rx) board, remove the three screws securing the bottom cover at the rear of the radio. Then slide the cover out from under the edge of the front panel and lift off.
- To service the interconnect/multi-frequency board, remove the two screws at the rear of the radio and slide the cover out from the edge of the front control panel and lift off.
- To remove the Tx-Rx board:
  1. Remove the top and bottom covers.
  2. Remove the four screws securing the front panel to the "H" frame. Disconnect the speaker plug and remove the panel.
  3. Remove the six screws securing the RF shield.
  4. Unplug the 7-segment leads as well as option leads.
  5. Remove the four screws securing transistors Q205 and Q206.
  6. Remove the 8 screws securing the Tx-Rx board and carefully lift up the board off of the interconnections pins.



- To remove the interconnect/multi-frequency board:
  1. Remove the top cover.
  2. In multi-frequency units, remove the five screws securing the RF shield (if present).
  3. Unplug 7-segment display and option leads.
  4. Remove the five screws securing the board and carefully lift the board up to disconnect the interconnection pins.




Figure 6 - Lead Identification

## PA TRANSISTOR REPLACEMENT

## WARNING

The stud mounted RF Power Transistors used in the transmitter contain Beryllium Oxide, a TOXIC substance. If the ceramic or other encapsulation is opened, crushed, broken or abraded, the dust may be hazardous if inhaled. Use care in replacing transistors of this type.

To replace PA RF transistors Q205 and Q206:

1. Unsolder one lead at a time with a 50 watt soldering iron. Use a scribe or X-acto® knife to hold the lead away from the printed circuit board until the solder cools.
2. Lift out the transistor, and remove the old solder from the printed circuit board with a de-soldering tool such as a SOLDA PULLT®. Special care should be taken to prevent damage to the printed circuit board runs because part of the matching network is included in the base and collector runs.
3. Trim the new transistor leads (if required) to the lead length of the removed transistor. The letter "C" on the top of the transistor also indicates the collector (see Figure 6).
4. Apply a coat of silicon grease to the transistor mounting surface. Place the transistor in the mounting hole. Align the leads as shown on the Outline Diagram. Then hold the body of the transistor and replace the transistor mounting hardware, using moderate torque of 0.678 Newton meters (N.m) or (6 inch pounds). A torque wrench must be used for this adjustment since transistor damage can result if too little or too much torque is used.

5. Solder the leads to the printed circuit pattern. Start at the inner edge of mounting hole and solder the remaining length of transistor lead to the board. Use care not to use excessive heat that causes the printed wire board runs to lift up from the board. Check for shorts and solder bridges before applying power.

## CAUTION

Failure to solder the transistor leads as directed may result in the generation of RF loops that could damage the transistor or may cause low power output.

## REMOVING IC's

Removing IC's (and all other soldered-in components) can be easily accomplished by using a de-soldering tool such as a SOLDA PULLT® or equivalent. To remove an IC, heat each lead separately on the solder side and remove the old solder with the de-soldering tool.

An alternate method is to use a special soldering tip that heats all of the pins simultaneously.

## TEST AND TROUBLESHOOTING PROCEDURES

Maintenance of your Century II radio is facilitated by use of the Troubleshooting Flow Charts and servicing techniques unique to this radio. The Troubleshooting Chart is designed to lead you rapidly to the defective component or circuit. Typical voltage readings are provided on the Schematic Diagram for your reference when troubleshooting.

Troubleshooting charts are provided for most major problems that might arise in the Transmitter/Receiver section of the radio. Refer to Figure 9 when servicing the transmitter and to Figure 10 when servicing the receiver.

## SERVICING TECHNIQUES

The high density plug-in design of the modular radio lends itself well to rapid isolation of malfunctions in the voltage and signal paths. Due to the modular construction of the radio i.e., Tx/Rx board, interconnect/multi-frequency board, Channel Guard board etc., a majority of the signals and voltages go through the connectors on the interconnect/multi-frequency board.

To isolate a signal or voltage path to determine loading effects, locate short circuits, etc. carefully insert an insulator (plastic wand, toothpick) between the appropriate pins of the related molex connector to create an open circuit. Signals paths that may be isolated include: CG Tone, VOLUME SQ HI, filtered VOLUME SQUELCH HI

PTT, Rx MUTE, CG DISABLE, SPKR HI, and on multi-frequency radios, the Tx/Rx oscillator compensation voltage.

## TEST POINTS

RF Detector probes for the transmitter and receiver section are available for alignment purposes and to monitor the exciter output at TP203, 1st receiver injection at TP401 and the 2nd IF at TP501. An RF signal probe also is available to monitor the transmitter frequency.

Five test points are provided at critical circuit locations to monitor operation.

They are as follows:

TRANSMITTER	RECEIVER
TP201 Transmitter Oscillator/Exciter Ampl-1	TP401 Receiver 1st oscillator injection
TP202 Exciter Ampl-2	TP501 455 kHz IF
TP203 Exciter Output	

## CAUTION

Before bench testing the radio, be sure of the output voltage characteristics of your bench power supply.

To protect the transmitter power output transistors from possible instant destruction, the following input voltages must not be exceeded:

Transmitter unkeyed: 20 Volts

Transmitter keyed (50 ohm resistive load): 18 Volts

Transmitter keyed (no load or non-resistive load): 15.5 Volts


These voltages are specified at the normal vehicle battery terminals of the radio and take the voltage drop of standard cables into account. The voltage limits shown for a non-optimum load is for "worst case" conditions. For antenna mismatches likely to be encountered in practice, the actual limit will approach the 18 Volt figure.

Routine transmitter tests should be performed at EIA Standard Test Voltages (13.8 VDC for loads of 0 to 6 amperes: Input voltages must not exceed the limits shown, even for transient peaks of short duration.

Many commonly used bench power supplies cannot meet these requirements for load regulation and transient voltage suppression. Bench supplies which employ "brute force" regulation and filtering may be usable when operated in parallel with a 12 Volt automotive storage battery.

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION  
WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.

**GENERAL  ELECTRIC\***  
U.S.A.



PART NO.	DISCRIPTION
1	UHF, LOW POWER
2	UHF, HIGH POWER
3	HB, LOW AND HIGH POWER
4	FREQ. CAPACITY 2 TX, 1 RX HB, UHF
5	FREQ. CAPACITY 2 TX, 2 RX HB, UHF
6	FREQ. CAPACITY 1 TX, 2 RX HB, UHF
7	FREQ. CAPACITY 4 TX, 4 RX HB, UHF
8	FREQ. CAPACITY 6 TX, 6 RX HB, UHF
9	PROGRAMMABLE ENCODE DECODE C.G.
10	PROGRAMMABLE ENCODE ONLY C.G.
11	PROGRAMMABLE ENCODE ONLY C.G.
12	HOOKSWITCH APPLICATION
13	10 PPM MOD.
14	SHIELDING KIT FOR DOC RADIATION
15	DC REMOTE MOD.
16	DESK MICROPHONE, CG OR T99 DECODER
17	DTMF ENCODER
18	AC POWER SUPPLY MOD.
19	T99 DECODER, 2 TONE
20	T99 DECODER, 4 TONE
21	EXT ALARM SWITCH - T99 DEC.
22	PUBLIC ADDRESS
23	EXT SPKR SWITCH-PA
24	CHANNEL BUSY LIGHT
25	CARRIER CONTROL TIMER
26	UNIVERSAL TONE CABLE
27	EXTERNAL SPKR APPL
28	TONE REJECT FILTER ONLY
29	FREQ. CAPACITY 1 TX/1 RX UHF-X
30	FREQ. CAPACITY 2 TX/1 RX UHF-X
31	FREQ. CAPACITY 2 TX/2 RX UHF-X
32	FREQ. CAPACITY 1 TX/2 RX UHF-X
33	FREQ. CAPACITY 4 TX/4 RX UHF-X
34	FREQ. CAPACITY 6 TX/ 6 RX UHF-X

- NOTES:
- APPLY SILICON GREASE ON THE MOUNTING SURFACES OF SPACER (19A130465P1) AND BETWEEN THE MOUNTING SURFACE OF Q205 AND THE CHASSIS PER CPD PROCESS P6A-EA111. CARE MUST BE USED SO THAT NO GREASE IS APPLIED TO THE THREADED PORTION OF THE MOUNTING STUD OF Q205. (FOR UHF ONLY)
  - PART OF KIT PL19A137470.
  - APPLY SILICON GREASE BETWEEN THE MOUNTING SURFACES OF Q205 AND Q206 AND THE CHASSIS PER CPD PROCESS P6A-EA111. (FOR HIGH BAND ONLY)
  - APPLY THREAD LOCK TO M2.5 SCREWS PER PROC.P7C-EA108P2
  - APPLY THIS NAMEPLATE (LAST) AFTER COMPLETE ASSEMBLY OF THE RADIO WITH PARTICULAR ATTENTION TO ALIGNMENT TO THE MULTI-FREQUENCY SWITCH PUSHBUTTON. REMOVE PROTECTIVE FILM AFTER INSTALLATION OF THE NAMEPLATE.
  - NOT PRESENT FOR 1 FREQ UHF-X (P29)
  - MARK PER 19A122529.
  - APPLY PER P7D-EA100.
  - TIGHTEN TRANSISTOR MTG NUT TO WITHIN  $1.0 \pm 0.1$  N.M. FOR #8-32 NUT AND  $0.6 \pm 0.1$  N.M. FOR M2.5 SCREWS.

## MECHANICAL LAYOUT

CRYSTAL OSCILLATOR FREQUENCY ADJUSTMENT

First, check the frequency to determine if any adjustment is required. The frequency should be set with a frequency meter or counter with an absolute accuracy that is 5 to 10 times better than the tolerance to be maintained, and with the entire radio as near as possible to an ambient temperature of 27.0°C (80.6°F).

The oscillator should be reset only when the frequency shows deviation in excess of the following limits:

- ±0.5 PPM, when the radio is at 27.0°C (80.6°F)
- The specification limit of ±5 PPM at any temperature within the ranges of -30°C (-22°F) to +60°C (+140°F).

If the radio is at an ambient temperature of 27.0°C (80.6°F), set the oscillator for the correct operating frequency.

If the radio is not at an ambient temperature of 27.0°C, offset the oscillator, as a function of actual temperature, by the amount shown in the Frequency Offset Chart.

For example: Assume the ambient temperature of the radio is 22°C (71.6°F). At that temperature, the curve shows a correction factor of +0.75 PPM. (At 138 MHz, 1 PPM is 138 Hz. At 174 MHz, 1 PPM is 174 Hz.)

With an operating frequency of 160 MHz, set the oscillator for a reading of 120 Hz (0.75 x 160 Hz) higher than the licensed operating frequency. If a negative correction factor is obtained (at temperatures above 27.0°C), set the oscillator for the indicated PPM lower than the licensed operating frequency.

When setting the transmitter oscillator frequency, adjust L151 (single frequency unit) or L921-L926 (multi-frequency units) to the assigned operating frequency.

To set the frequency of the receiver 1st injection oscillator, connect the RF signal probe to TP401 and adjust L301 (single frequency) or L961 thru L966 (multi-frequency) for the assigned receiver frequency -10.7 MHz.

MODULATION LEVEL ADJUSTMENT

TEST EQUIPMENT

1. Audio Oscillator
2. Deviation Monitor

CG ENCODE DISABLE

The Channel Guard Encode Disable circuit has been incorporated as a maintenance aid to allow the service technician to make transmitter distortion and modulation checks without removing the cover from the radio.

CAUTION

DO NOT remove the microphone from the hookswitch or place the CG MON switch on the desk microphone to the MONITOR position while making these adjustments. Damage to the equipment will result.

The CG encode circuit can be easily disabled by temporarily connecting a jumper from J910-11 (A+) to the applicable CG DISABLE lead on P910 (see Schematic and Outline Diagram).

CAUTION

This feature is not compatible with the Type 99 decoder option.

MOD ADJUST CONTROL R116 has been adjusted to the proper setting before shipment and normally does not require readjustment. This setting permits approximately 75% modulation for the average voice level.

NOTE

The Channel Guard modulation level adjustment should be checked each time the tone frequency is changed.

PROCEDURE

1. Connect the audio oscillator and the AC voltmeter across audio input terminals J911-4 (Hi) and J911-3 (Lo) on the interconnect/multi-frequency board.
2. Adjust the audio oscillator for a 1 Volt RMS at 1000 Hz.

DEVIATION ADJUSTMENT

Single Frequency Radios without Channel Guard

(25, 30 kHz channel spacing.) Set MOD ADJUST control R116 for 4.5 kHz deviation using the deviation polarity that provides the highest reading on the deviation monitor.

NOTE

If the deviation reading plus (+) or minus (-) differs more than 0.5 kHz, recheck Step 1 as shown in the Transmitter Alignment Chart.

(12.5 kHz channels.) Set MOD ADJUST control R116 for 2.25 kHz.

Single Frequency Radios with Channel Guard

(25, 30 kHz channel spacing.) Set the CHANNEL GUARD MOD ADJUST control (on the CG board) for zero tone deviation. Then, set MOD ADJUST control R116 for 3.75 kHz deviation using the deviation polarity that provides the highest reading on the deviation monitor. Disconnect audio oscillator. Enable encoder and set the Channel Guard MOD ADJUST for 0.75 kHz tone deviation.

(12.5 kHz channels.) Same as above except adjust R116 for 1.9 kHz deviation and CG MOD Control for 0.35 kHz tone deviation.

Multi-Frequency Radios without Channel Guard

(25, 30 kHz channel spacing.) Set MOD ADJUST controls R956-R961 to maximum clockwise position. SET MOD ADJUST control R116 for 5.0 kHz deviation on channel with lowest deviation and with polarity switch set to the position that provides the highest reading. Step through each channel and set R956-R961 to provide 4.5 kHz deviation.

(12.5 kHz channel spacing.) Same as above except adjust R116 for 2.5 kHz and R956-R961 for 2.25 kHz deviation.

Multi-Frequency Radios with Channel Guard

(25, 30 kHz channel spacing.) Set the CG MOD ADJUST control (on CG board) for zero tone deviation. Set MOD ADJUST control R116 on Tx/Rx board for 5 kHz deviation on channel with lowest deviation and with polarity switch on deviation monitor set to the position that provides the highest reading. Step through each channel and adjust R956-R961 for 3.75 kHz deviation. Disconnect audio oscillator. Enable CG encoder and adjust CG MOD Control for 0.75 kHz tone deviation.

(12.5 kHz channel spacing.) Same as above except adjust R116 for 2.5 kHz, R956-R961 for 1.9 kHz and CG MOD Control for 0.35 kHz.

AUDIO CHECKS

TEST EQUIPMENT REQUIRED

- Audio Oscillator
- AC Voltmeter
- Oscilloscope
- Deviation Monitor

AUDIO AC VOLTAGES

1. Connect audio oscillator output across J911-4 (Mic Hi) and J911-3 (Mic Lo).

SCOPE SETTING		U101-7	C110 (+)
	HORIZONTAL	200 U SEC/DIV	200 U SEC/DIV
	VERTICAL	2 VOLTS/DIV	2 VOLTS/DIV
SET AUDIO OSCILLATOR AT 1000 Hz WITH OUTPUT OF 1.0 VRMS. R116 ADJUSTED FOR 4.5 kHz DEVIATION.			
NOTE: AN RMS OR PEAK READING VOLT METER WILL READ 1/2 TO 1/3 OF PEAK-TO-PEAK READINGS.			

AUDIO SENSITIVITY

1. Connect audio oscillator output across J911-4 (Mic Hi) and J911-3 (Mic Lo). Adjust output for 1000 Hz at 1.0 VRMS.
2. Reduce generator output until deviation falls to 3.0 kHz for radios without Channel Guard or to 2.25 kHz for radios with Channel Guard. Voltage should be less than 120 millivolts.






Figure 7 - Temperature Compensation Chart



TRANSMITTER ALIGNMENT

TEST EQUIPMENT

- 1. 50 ohm Wattmeter
- 2. RF Detector Probe (Transmitter)
- 3. Voltmeter
- 4. Power Supply 13.8 V Regulated
- 5. Audio Signal Generator

PRELIMINARY CHECKS AND ADJUSTMENTS

NOTE

Refer to photographs to locate CONTROLS, TEST POINTS and CRYSTALS.

- 1. Place crystal for single frequency units on Transmitter/Receiver board. For multi-frequency units all transmitter crystals are installed on the multi-frequency board. In multi-frequency trans-

- mitters with a Channel spacing greater than 1.25 MHz but less than 2.5 MHz, the transmitter must be aligned to the center frequency. If a center frequency is available on an existing channel, use it. If not, a center frequency crystal must be installed to properly align the transmitter. These limits can be extended to 3.5 MHz with 1 dB degradation.
- 2. For a large change in frequency or a badly misaligned transmitter, preset all slugs to the top of the coil form.
  - 3. Set power adjust control R215 to minimum - fully counter-clockwise.
  - 4. All adjustments are made with transmitter keyed. Unkey the transmitter between steps to avoid overheating.
  - 5. A Voltmeter is used on TP201 and a VOM and DC probe on TP202 when monitoring or aligning the transmitter. The Transmit RF Detector probe connected to a VOM is used to monitor TP203.

ALIGNMENT PROCEDURE

STEP	TEST POINT	TUNING CONTROL	METER READING	PROCEDURE
1.	TP201	L151, L153	PEAK	Tune L151 (or L921 thru L926 for multi-frequency) then L153 for peak meter reading.
2.	TP201	L204	DIP	Tune L204 for a dip in the meter reading.
3.	TP202	L205, L204	PEAK	Tune L205 then L204 for peak meter reading. <div>NOTE A better peak can sometimes be obtained by detuning L153 slightly. Repeak L153 before proceeding to Step 4.</div>
4.	TP202	L208	DIP	Tune L208 for a dip in the meter reading.
5.	TP203	L209, L208	PEAK	Tune L209 then L208 for a peak in the meter reading.
6.	WATTMETER	R215		Set R215 for maximum power output. Next, <u>re-peak</u> all adjustments and then set R215 for rated power output.
7.	TP203	L151		Connect RF signal probe to TP203 and set L151 for assigned operating frequency. Refer to Oscillator Frequency Adjustment section to determine actual frequency setting.
8.	TP201	L153		Repeak L153 for MAXIMUM meter reading.
9.	TP202	L204, L205		Repeak L204 then L205 for MAXIMUM meter reading.
10.	TP203	L208, L209		Repeak L208 then L209 for MAXIMUM meter reading.
11.	WATTMETER	R215		If necessary, readjust R215 for rated power output.

TRANSMITTER QUICK CHECKS

TEST POINT	NORMAL METER READING	PROBABLE DEFECTIVE STAGE		
		HIGH METER READING	LOW METER READING	ZERO METER READING
TP201	1.0 V	Q202	Q151, Q201 Q202	Q202, Q201 Q151
TP202	0.4 V	Q203	Q203	Q203
TP203	0.5 V		Q204	Q204




Figure 8 - Test Equipment Set Up

RECEIVER ALIGNMENT

EQUIPMENT REQUIRED

1. RF Signal Generator (148-174 MHz)

2. DC Voltmeter

3. AC Voltmeter

4. Receiver RF Detector Probe

5. RF Signal Probe

are located on the multi-frequency board.

2. In multi-frequency receivers with a channel spacing greater than 750 kHz and less than 1.5 MHz, the receiver must be tuned to the center frequency. If a center frequency is available on an existing channel, use it. If not, a center frequency crystal must be installed to properly align the receiver. These limits can be extended to 2.5 MHz with 3 dB degradation.

3. Disable Channel Guard by removing microphone from hookswitch or by connecting ground to CG Disable on J910.

4. Disconnect internal speaker from J904 on interconnect/multi-frequency board. Terminate J904 with a 4-ohm, 5 watt resistor.

NOTE

Refer to photographs to locate CONTROLS, TEST POINTS and CRYSTALS.

PRELIMINARY CHECKS

1. Verify all crystals are in place. In single frequency radios the crystal (Y301) is located on the Transmitter/Receiver board. In multi-frequency radios all crystals

ALIGNMENT PROCEDURE

STEP	METERING TEST POINT	PROBE	TUNING CONTROLS(S)	PROCEDURE
1ST OSCILLATOR MULTIPLIER				
1.	TP401	RF DETECTOR	L301	With voltmeter on lowest range, adjust L301 (In Multi-Frequency units L961-L966 for channels 1-6) for maximum meter reading. <div>NOTE If no meter indication can be obtained at TP401, connect positive lead of probe (red dot) to J301 using a short piece of DA jumper wire (AWG # 18 or smaller - 1.024 mm). See photograph for access point to J301 from multi-frequency board. Adjust L301 and L303 for maximum meter reading and L305 for a dip. Then re-connect probe to TP401.</div>
2.	TP401	RF DETECTOR	L303, L305	Adjust L303 then L305 for maximum meter reading (typically 1 to 2 Volts). The peak VOM reading must be greater than 0.5 Volt.
3.	TP401	RF SIGNAL	L301	Connect a frequency counter to TP401 using RF Signal Probe. Adjust L301 (Single Frequency Units) or L961-L966 (Multi-Frequency Units) for channel operating frequency -10.7 MHz.
4.	TP401	RF DETECTOR	L303, L305,	Adjust L303, then L305 for maximum meter reading. Meter reading should be approximately 2.0 V.
IF ALIGNMENT				
5.	TP401, TP501	RF SIGNAL RF DETECTOR	L406, L503	Connect RF signal generator to TP401 using RF Signal Probe. Connect RF DETECTOR Probe (and VOM) to TP501. Use 0.5 or 1.0 V scale. Set RF Signal generator output RF to channel frequency at the minimum level sufficient to provide a mid-scale meter indication. Adjust L406 and then L503 for maximum indication.
6.	Same as Step 5	Same as Step 5	L502, L501, L406	Reduce the output of the signal generator as required to keep the detected RF level within the 0.5 to 1.0 volt range. Adjust L502, L501 and L406 respectively for maximum indication on meter. Alternately adjust L406 and L501 to obtain maximum meter reading. Disconnect RF Signal Generator and RF Signal Probe from TP401.

RECEIVER ALIGNMENT PROCEDURES

STEP	METERING TEST POINT	PROBE	TUNING CONTROLS(S)	PROCEDURE
FRONT END ALIGNMENT				
7.	TP501	RF DETECTOR	--	Connect signal generator to Antenna input jack J601. Verify RF Detector Probe is connected to TP501 and VOM. Adjust signal generator to RF channel frequency or to center frequency. Adjust output level of signal generator for an indication on meter. A VOM reading should not exceed 0.5 and 1.0 Volts during this procedure.
8.	TP501	RF DETECTOR	L403, L404 L405	Detune L403 and L405 as much as possible. Adjust L404 for maximum meter reading. <u>DO NOT</u> readjust. Alternately readjust L405 and L403 for maximum VOM reading.
9.	TP501	RF DETECTOR	L402, L401	Alternately adjust L402 and L401 for maximum VOM reading. Reduce signal generator output level as required. <div>NOTE Connect a 4-ohm resistor across J910-3 and J910-7. Set audio level control R521 and volume control R630 to mid position. Connect AC voltmeter/audio distortion analyzer across 4-ohm load. Switch generator modulation to "off". Adjust generator output for a level of 1.0 volts as indicated on AC voltmeter.</div>
10.	TP501	RF DETECTOR	L401, L405	Adjust L401, L402, L405, L404 and L403 for minimum quieting.
11.	TP401	RF DETECTOR	L303, L305	Adjust L303 and L305 for maximum VOM reading.
12.	TP501	RF DETECTOR	L401, L405	Repeat Step 10. Remove all test equipment. Replace center frequency crystal if used.
DETECTOR/AUDIO ALIGNMENT				
13.	Audio Output	--	L504	Apply a 1000 $\mu$ V RF signal modulated with 1000 Hz to antenna input jack J601. Connect external speaker leads J910-3, J910-7 to a four ohm resistive load. Set audio level control R521 and volume control to mid position. Connect AC Voltmeter/distortion analyzer across four ohm load.  Adjust L504 for maximum meter reading. Reduce volume control as necessary to keep output voltage from exceeding 2.0 VRMS.
14.		--	L501, L406	Adjust volume control for a level of 2.0 VRMS on AC voltmeter. Note the position of tuning slugs in L501 and L406. Slowly adjust L501 and L406 $\pm$ 1/4 turn for minimum distortion on distortion analyzer. If no improvement is noted return slugs to original position.
15.	P903-3	--	R521	Connect AC Voltmeter having a minimum input impedance of 1 megohm (Do <u>NOT</u> use the AC scale of a VOM) to P903-3. Adjust audio level control R521 for a meter reading of 300 mV rms $\pm$ 5 mV.
16.				Reconnect AC Voltmeter across external speaker leads, J910-3 (SPKR HI) and J910-7 (SPEAKER LO). Adjust volume control for 3 Watts (3.46 VRMS across 4 ohm load).
17.				Measure audio distortion using Distortion Analyzer. Distortion should be less than 5%. Disconnect all test equipment.

FIXED SQUELCH ADJUSTMENT

- Connect a signal generator to antenna jack J601 and adjust for a nominal 9 dB SINAD signal.
- Set SQUELCH CONTROL pushbutton to its "out" position.
- Adjust squelch control R607 to maximum squelch. Receiver must be muted.
- Adjust squelch control R607 slowly until receiver unmutes.
- Check that the squelch circuit opens with an input signal level corresponding to 8 dB SINAD  $\pm$ 1 dBs.



## TEST PROCEDURES

These Test Procedures are designed to help you to service a receiver that is operating---but not properly. The problems encountered could be low power, poor sensitivity, distortion, limiter not operating properly, and low gain. By following the sequence of test steps starting with Step 1, the defect can be quickly localized. Once the defective stage is pin-pointed, refer to the "Service Check" listed to correct the problem. Additional corrective measures are included in the Troubleshooting Procedure. Before starting with the Receiver Test Procedures, be sure the receiver is tuned and aligned to the proper operating frequency.

## TEST EQUIPMENT REQUIRED

- Distortion Analyzer
- Signal Generator
- 6 dB attenuation pad, and 4.0 ohm, 5 Watt resistor

## PRELIMINARY ADJUSTMENTS

### NOTE

These procedures are written around the Heathkit Distortion Analyzer. If a Distortion Analyzer other than the Heath IM-12 is used, measure the sensitivity and modulation acceptance bandwidth in accordance with manufacturer's instructions.

1. PUSH SQUELCH PUSHBUTTON "in" to defeat Squelch Circuit. Do not adjust squelch control.

## STEP 1

### AUDIO POWER OUTPUT AND DISTORTION

#### TEST PROCEDURE

Measure Audio Power Output as follows:

- A. Apply a 1000 microvolt, on-frequency test signal modulated by 1,000 hertz with  $\pm 3.0$  kHz deviation to antenna jack J601.

- B. With 3 Watt Speaker

Disconnect speaker J904.

Connect a 4.0 ohm, 5 Watt load resistor across J904-1 & 2.

Connect the Distortion Analyzer input across the resistor as shown.

- C. Adjust the VOLUME control for 3 Watt output 3.46 VRMS using the Distortion Analyzer as a voltmeter.
- D. Make distortion measurements according to manufacturer's instructions. Reading should be less than 5%. If the receiver sensitivity is to be measured, leave all controls and equipment as they are.

#### SERVICE CHECK

If the distortion is more than 5%, or maximum audio output is less than 3 Watts, make the following checks:

- E. Battery and regulator voltage---low voltage will cause distortion. (Refer to Receiver Schematic Diagram for voltages.)
- F. Audio Gain (Refer to Receiver Troubleshooting Procedure).
- G. FM Detector Alignment (Refer to Receiver Alignment).

## STEP 2

### USABLE SENSITIVITY (12 DB SINAD)

If STEP 1 checks out properly, measure the receiver sensitivity as follows:

- A. Apply a 1000 microvolt, on-frequency signal modulated by 1000 Hz with 3.0 kHz deviation to J601.
- B. Place the RANGE switch on the Distortion Analyzer in the 200 to 2000 Hz distortion range position (1000 Hz filter in the circuit). Tune the filter for minimum reading or null on the lowest possible scale (100%, 30%, etc.)
- C. Place the RANGE switch to the SET LEVEL position (filter out of the circuit) and adjust the input LEVEL control for a +2 dB reading on a mid range (30%).
- D. Set signal generator output to 0.3  $\mu$ V. Switch the RANGE control from SET LEVEL to the distortion range. Readjust Distortion Analyzer SET LEVEL as required until a 12 dB difference (+2 dB to -10 dB) is obtained between the SET LEVEL and distortion range positions (filter out and filter in).
- E. The 12 dB difference (Signal plus Noise and Distortion to noise plus distortion ratio) is the "usable" sensitivity level. The sensitivity should be less than rated 12 dB SINAD specifications with an audio output of at least 1.5 Watts (0.56 Volts RMS across the 4.0 ohm receiver load using the Distortion Analyzer as a Voltmeter).
- F. Leave all controls as they are and all equipment connected if the Modulation Acceptance Bandwidth test is to be performed.

#### SERVICE CHECK

If the sensitivity level is more than rated 12 dB SINAD, check the alignment of the RF stages as directed in the Alignment Procedure.

## STEP 3

### MODULATION ACCEPTANCE BANDWIDTH (IF BANDWIDTH)


If STEPS 1 and 2 check out properly, measure the bandwidth as follows:

- A. Set the Signal Generator output for twice the microvolt reading obtained in the 12 dB SINAD measurement.
- B. Set the RANGE control on the Distortion Analyzer in the SET LEVEL position (1000 Hz filter out of the circuit), and adjust the input LEVEL control for a +2 dB reading on the 30% range.
- C. While increasing the deviation of the Signal Generator, switch the RANGE control from SET LEVEL to distortion range until a 12 dB difference is obtained between the SET LEVEL and distortion range readings (from +2 dB to -10 dB).
- D. The deviation control reading for the 12 dB difference is the Modulation Acceptance Bandwidth of the receiver. It should be more than  $\pm 6.5$  kHz.

#### SERVICE CHECK

If the Modulation Acceptance Bandwidth test does not indicate the proper width, refer to the Receiver Troubleshooting Procedure.

AUDIO AND SQUELCH WAVEFORMS









RC-3774

SQUELCH CIRCUIT TEST WITH 7 kHz SIGNAL

PRELIMINARY STEPS







- 1. Quiet receiver with 1000 uV unmodulated signal.
- 2. Squelch Adjust R607 to maximum (Rotate control toward rear of radio.)
- 3. Squelch pushbutton in OUT position.
- 4. Use 10 megohm probe.



SQUELCH CIRCUIT CHECKS WITH NOISE

PRELIMINARY STEPS






- 1. No input signal applied.
- 2. Squelch Adjust R607 to maximum (Rotate toward rear of radio.)
- 3. Squelch pushbutton in OUT position.
- 4. Use 10 megohm probe.




AUDIO CIRCUIT CHECKS

PRELIMINARY STEPS


- 1. Apply 1000 uV on frequency signal with 1000 Hz modulation and 3 kHz deviation to antenna jack J601.
- 2. Squelch pushbutton "IN".
- 3. Output set for 3-Watts (3.46 VRMS) into 4-ohm load.
- 4. Use 1 megohm probe.








RC-3770



NOTES:  
1. CONNECT TEST EQUIPMENT AS SHOWN IN FIGURE 8.  
2. SINGLE FREQUENCY UNITS: CHECK ADJUSTMENT OF R116.  
MULTI-FREQUENCY UNITS AND RADIOS OPERATING IN THE 470-512 MHz RANGE: R116 IS SET FOR 5.0 kHz DEVIATION ON CHANNEL WITH LOWER MODULATION LEVEL. DEVIATION IS THEN SET INDIVIDUALLY FOR EACH CHANNEL BY CONTROLS ON THE MULTI FREQUENCY BOARD.


RC-3771C

TRANSMITTER TROUBLESHOOTING FLOW CHART



RC-3773A






OUTLINE DIAGRAM

148—174 MHz HIGH BAND  
TRANSMITTER/RECEIVER BOARD

(19D432169, Rev. 3)  
(19A143269, Sh. 1, Rev. 1)  
(19A143269, Sh. 2, Rev. 1)

LEAD IDENTIFICATION  
FOR Q151, Q301, Q302, Q201, Q202,  
Q203, Q204, Q208, Q209, Q210, Q601,  
Q602, Q603, Q604 & Q605

FLAT E B C  
OR  
IN-LINE TRIANGULAR  
TOP VIEW




OUTLINE DIAGRAM

INTERCONNECT BOARD (SINGLE FREQUENCY)


(19D900171, Rev. 1)  
(19A701344, Sh. 1, Rev. 1)  
(19A701344, Sh. 2, Rev. 1)






# SYSTEM INTERCONNECTION DIAGRAM

CENTURY II STANDARD COMBINATIONS





△ FOR T99 DECODER, ADD JUMPERS H7 TO H9, H12 TO H14, H39 TO H40. OMIT JUMPER H25 TO H26, H55 TO H56.

△ FOR PUBLIC ADDRESS OPTION, ADD JUMPERS H3 TO H4, H8 TO H9, H12 TO H14. OMIT JUMPERS H10 TO H11, H27 TO H28, H29 TO H30.

△ FOR SINGLE TONE PROGRAMMABLE CHANNEL GUARD, OMIT JUMPER H33 TO H34 IN ENCODE/DECODE & ENCODE ONLY APPLICATIONS; OMIT JUMPER H35 TO H36 IN ENCODE/DECODE, DECODE ONLY, TONE REJECT FILTER ONLY APPLICATIONS.

△ FOR CARRIER CONTROL TIMER OPTION, OMIT JUMPER H31 TO H32. ADD R1903 SUPPLIED WITH THE TIMER BETWEEN H53 AND H54. TO CHANGE THE CCT TIME OUT TIME, SEE CHART BELOW FOR VALUE OF R1903.


ALL RESISTORS ARE 1/4 WATT UNLESS OTHERWISE SPECIFIED.  
RESISTOR VALUES IN  $\Omega$  UNLESS FOLLOWED BY MULTIPLIER k OR M.  
CAPACITOR VALUES IN F UNLESS FOLLOWED BY MULTIPLIER  $\mu$ , n OR p.  
INDUCTANCE VALUES IN H UNLESS FOLLOWED BY MULTIPLIER m OR  $\mu$ .

SCHEMATIC DIAGRAM

INTERCONNECT BOARD (SINGLE FREQUENCY)








# SCHEMATIC DIAGRAM

(19D432168, Sh. 1, Rev. 2)

148-174 MHz HIGH BAND TRANSMITTER

Issue 1


29



SCHEMATIC DIAGRAM

148—174 MHz HIGH BAND RECEIVER

(19D432168, Sh. 2, Rev. 1)



NOTES:

- 1 Z501A, Z502A - 25kHz CHANNEL SPACING (G1,G2)  
Z501B, Z502B - 12.5kHz CHANNEL SPACING (G3,G4)
- 2 VALUE OF R636 DEPENDS ON COLOR CODE ON U602.

U602 COLOR CODE	R636 VALUE $\Omega$
BROWN	OMIT R636
RED	270
ORANGE	100
YELLOW	47
GREEN	22
BLUE	6.8

- 3 PART OF PRINTED CIRCUIT BOARD.
- 4 TO MODIFY FOR MULTIFREQUENCY, REMOVE R157 (DISABLES TX OSC) AND/OR R309 (DISABLES RX OSC).
- 5 FOR 25W TRANSMITTER (GP 1,3) USE L225A, L229A, L230A, & Q206A  
FOR 10W TRANSMITTER (GP 2,4) USE L225B, L229B, L230B, & Q206B

COMPONENT VALUES

COMP	GROUPS 1 & 3 (25 W)	GROUPS 2 & 4 (10 W)
C238	100 P	68 P
C241	240 P	150 P
C242	240 P	150 P
C247	130 P	82 P
	GROUPS 1 & 2 (25 KHZ CHANNEL SPACING)	GROUPS 3 & 4 (12.5 KHZ CHANNEL SPACING)
C108	6.8n	10n
R109	1.3K	1.8K

ALL RESISTORS ARE 1/4 WATT UNLESS OTHERWISE SPECIFIED.  
RESISTOR VALUES IN  $\Omega$  UNLESS FOLLOWED BY MULTIPLIER k OR M.  
CAPACITOR VALUES IN F UNLESS FOLLOWED BY MULTIPLIER u, n OR p.  
INDUCTANCE VALUES IN H UNLESS FOLLOWED BY MULTIPLIER m OR u.

VOLTAGE READINGS

VOLTAGE READINGS ARE TYPICAL READINGS MEASURED TO SYSTEM NEGATIVE WITH A 20,000 OHMS-PER-VOLT DC VOLTMETER UNDER THE FOLLOWING CONDITIONS:


1. NO SIGNAL INPUT
2. VOLUME CONTROL (R630) SET TO MINIMUM
3. SQUELCH CANCEL (S601) SWITCHED OFF
4. UNSQUELCHED (US)-SQUELCH ADJUST (R607) SET TO MINIMUM (CCW)
5. SQUELCHED (S)-SQUELCH ADJUST (R607) SET TO MAXIMUM (CW)

THIS ELEM DIAG APPLIES TO


MODEL NO	REV LETTER
19D432167G1	
19D432167G2	
19D432167G3	
19D432167G4	

SCHEMATIC DIAGRAM

148—174 MHz HIGH BAND RECEIVER





(19B227626, Rev. 0)




(19A142809, Rev. 0)

CHANNEL BUSY LIGHT




- NOTES:
1. PART OF OPTION KIT PL19C850634.
  2. DISCARD TWO 19A134589P3008 SCREWS AT "T" AND REPLACE WITH 19A700036P422.




(19D432543, Sh. 7, Rev. 0)

OUTLINE DIAGRAM





LEAD IDENTIFICATION  
FOR Q1 AND Q2



NOTE:  
PARTIAL REFERENCE DESIGNATIONS ARE  
SHOWN. FOR COMPLETE DESIGNATION  
PREFIX WITH 1900 SERIES.  
EXAMPLE: R1-R1901 ETC.

(19C850636, Rev. 1)  
(19A701379, Sh. 1, Rev. 0)  
(19A701379, Sh. 2, Rev. 0)



ALL RESISTORS ARE 1/4 WATT UNLESS OTHERWISE SPECIFIED.  
RESISTOR VALUES IN  $\Omega$  UNLESS FOLLOWED BY MULTIPLIER k OR M.  
CAPACITOR VALUES IN F UNLESS FOLLOWED BY MULTIPLIER  $\mu$ , n OR p.  
INDUCTANCE VALUES IN H UNLESS FOLLOWED BY MULTIPLIER m OR  $\mu$ .


(19B800592, Rev. 1)

SERVICE SHEET


CHANNEL BUSY LIGHT

Issue 1

33




EXTERNAL SPEAKER



SERVICE SHEET

CARRIER CONTROL TIMER,  
EXTERNAL SPEAKER & UNIVERSAL TONE CABLE

UNIVERSAL TONE CABLE



PARTS LIST

148-174 MHz AND 420-512 MHz CENTURY II RADIO  
ISSUE 1

SYMBOL	GE PART NO.	DESCRIPTION
LS901		TRANSMIT/RECEIVE ASSEMBLY (See Transmit/Receive Assembly Parts List shown separately)
		FRONT CAP ASSEMBLY 19B233129G2
		----- LOUDSPEAKERS -----
	19A138181G1	Permanent magnet: 4 ohms ±10% imp, resonant frequency 400 Hz at 1 VRMS, 3 watt max.
		----- MISCELLANEOUS -----
	19B800585G1	Grille.
	19B209572P1	Nameplate. (CENTURY II).
		CHASSIS 19B233230G1 420-512 MHz 19B233230G2 148-174 MHz
		CAPACITOR ASSEMBLY 19A138190G1
		----- CAPACITORS -----
C1 and C2	19A116699P2	Ceramic, feed-thru: 1000 pf ±20%, 250 VDCW; sim to Aerovox Style 7405.
		----- MISCELLANEOUS -----
	19D429801G1	Frame.
	19C328666P1	Insulator. (Locates under Transmit/Receive Board).
	19A134661P3	Nut, hex (Metric): M2.5. (Secures Q205 & Q206 on Transmit/Receive Board).
	19A134748P2004	Screw, machine, (Pozidriv, Metric): M2 x 0.4 x 4. (Secures capacitor assembly 19A138190G1).
	19A134657P1	Lockwasher, internal tooth, Metric: M2.2. (Secures capacitor assembly 19A138190G1).
		POWER CABLE 19B232925G2
	19A116659P143	Connector, printed wiring; sim to Molex 09-50- 3111.
		----- MISCELLANEOUS -----
P910	19A137818G3	Lead, black. (Includes 19A116781P5 contact).
		FUSED LEAD ASSEMBLY (RED) 19A137818G9
	19A116781P5	Contact, electrical: wire range No. 18-24 AWG; sim to Molex 08-50-0106. (Hung in wiring on red & yellow wires).
	19A115776P3	Contact, electric: sim to Littelfuse 904-88. (Located in fuseholder- Quantity 2).
	7484390P1	Fuse cartridge.
	19A115776P6	Fuseholder: sim to Bussman 9835. (Mates with 19A115776P5 knob).
	19A115776P7	Spring: sim to Bussman 1A1853. (Used with fuse- holder).
	19A115776P5	Spring: sim to Bussman 9953 1/2. (Used with fuse- holder).

SYMBOL	GE PART NO.	DESCRIPTION
S6		MIKE HANGER/HOOKSWITCH 19C320318G3
	19A134398P1	----- SWITCHES ----- Push: sim to Chicago Switch S-1527-1.
W1		----- CABLES -----
	19A129414G1	Cable: approx 5 feet. (Includes (2) contacts 19A116781P5).
S1		----- MISCELLANEOUS -----
	19B209261P18	Switch, slide: 1 pole, 2 positions, 0.5 amp VDC or 3 amp VAC at 125 v; sim to Switchcraft 46202LH.
	19B219694P1	Base plate.
	19B219698G4	Housing.
	19B219693P2	Spring.
	19A116768P6	Strain relief. (W1).
	N193P1410C	Tap screw, phillip head: No. 6-18 x 5/8. (Secures assembly to mounting surface).
	19A134398P101	Plate. (Located on S6).
		FRONT ACCESS MOUNTING HARDWARE KIT 19A138051G1
		----- MISCELLANEOUS -----
	19A134653P4008	Bolt, machine, hex: Metric, 8MM (Secures radio to mounting bracket).
	19A134657P5	Lockwasher, internal tooth: No. M2.2 (Metric). (Secures radio to mounting bracket).
	N193P1210C	Tap screw, phillip head: No. 6-20 x 5/8. (Secures mounting bracket to mounting surface- with thin mounting surface).
	N193P1216C	Tap screw, phillip head: No. 6-20 x 1. (Secures mounting bracket to mounting surface- when thick carpet is on mounting surface).
	5490407P17	Rubber grommet: neoprene. (Located in fire wall).
	19A115185P9	Retaining strap: sim to Dennison BAR-LOK 08471. (Secures power leads under dash).
		DESK TOP STAND MOUNTING HARDWARE KIT 19A138051G2
	19A134653P4008	Bolt, machine, hex: Metric, 8MM. (Secures radio to mounting bracket).
	19A134657P5	Lockwasher, internal tooth: No. M2.2 (Metric) (Secures radio to mounting bracket).
		STANDARD MOUNTING HARDWARE KIT 19A138051G3
	19A134653P4008	Bolt, machine, hex: Metric, 8MM. (Secures radio to mounting bracket).
	19A134657P5	Lockwasher, internal tooth: No. M2.2 (Metric) (Secures radio to mounting bracket).
	19A115185P9	Retaining strap; sim to Dennison BAR-LOK 08471. (Secures power leads under dash).
	N130P1610C6	Screw, thread forming: No. 10-16 x 5/8. (Secures mounting bracket to mounting surface with thin mounting surface).
	N130P1624C6	Screw, thread forming: No. 10-16 x 1-1/2. (Secures mounting bracket to mounting surface when thick carpet is on mounting surface).
	5490407P6	Rubber grommet. (Located in fire wall).
	19C850638P1	Mounting bracket.
		LOCKING BRACKET MOUNTING HARDWARE KIT 19A138051G4
	19A134653P4008	Bolt, machine, hex: Metric, 8MM. (Secures radio to mounting bracket).

SYMBOL	GE PART NO.	DESCRIPTION
	19A115185P9	Retaining strap; sim to Dennison BAR-LOK 08471. (Secures power leads under dash).
	N130P1610C6	Screw, thread forming: No. 10-16 x 5/8. (Secures mounting bracket to mounting surface with thin mounting surface).
	N130P1624C6	Screw, thread forming: No. 10-16 x 1-1/2. (Secures mounting bracket to mounting surface when thick carpet is on mounting surface).
	5490407P6	Rubber grommet. (Located in fire wall).
	19A134653P4012	Bolt, machine, hex: Metric.
	19A701543G1	Spacer assembly.
	5491682P4	Rim lock.
	19D900104P1	Mounting bracket. (Inner).
	19C850645G1	Mounting bracket. (Outer- with lock).
		MECHANICAL PARTS
	19B232859P1	Bushing. (Secures Transmit LED Light).
	19A137825P1	Insulator. (Band Pass Filter).
	19C328661P1	Insulator. (Receiver - L Shape).
	19B232964P1	Insulator. (MULTI-FREQ).
	19B232927P1	Insulator. (P.A.).
	19B232962P1	Insulator. (Interconnect assembly).
	19B232928P1	Insulator. (Exciter).
	19A134589P3028	Tap screw, Metric: No. size 3-28MM. (Secures P.A. shield).
	19A134483P3005	Screw, machine, Metric: No. size 3-5MM. (Secures top & bottom covers).
	19A134589P3008	Tap screw, Metric: No. size 3-8MM. (Secures front cap & Transmit/Receive assembly).
	19A134657P3	Lockwasher, internal tooth: No. M3. (Secures top & bottom covers).
	19A134483P2508	Screw, machine, Metric: No. size 2.5-8MM. (Secures Q205 & Q206).
	19A138241P1	Pin. (Used with Multi-Freq. Knob).
	4038831P5	Alignment tool.
	19A142928G1	Transmit/Receive Shield.
	19C328556P1	Cover. (Top & Bottom).
	19B233372G1	Faceplate, standard. (Includes GENERAL ELECTRIC nameplate- 19B209572P3).
	19D430583P5	Faceplate, Multi-Frequency.
	19B209687P1	Mounting bracket. (Standard).
	19B209687P2	Mounting bracket. (Front Access- includes installation tool 19A134652P17).
	19B209687P3	Mounting bracket. (DESK).
	19A134652P17	Allen wrench. (Used with 19B209687P2 mounting bracket).

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

PARTS LIST

146-174 MHz TRANSMIT/RECEIVE BOARD  
19D432167G1 25 WATT (25 KHz)  
19D432167G2 10 WATT (25 KHz)  
19D432167G3 25 WATT (12.5 KHz)  
19D432167G4 10 WATT (12.5 KHz)  
ISSUE 1

SYMBOL	GE PART NO.	DESCRIPTION
		- - - - - CAPACITORS - - - - -
C102 and C103	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C104	19A116080P205	Polyester: 0.047 $\mu$ f $\pm$ 5%, 50 VDCW.
C106	19A700003P4	Tantalum: 1 $\mu$ f $\pm$ 20%, 35 VDCW.
C107	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C108A	19A116080P216	Polyester: 0.0068 $\mu$ f $\pm$ 5%, 50 VDCW.
C108B	19A116080P201	Polyester: 0.01 $\mu$ f $\pm$ 5%, 50 VDCW.
C109	19A116080P218	Polyester: 0.001 $\mu$ f $\pm$ 5%, 50 VDCW.
C110	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C111	19A116080P203	Polyester: 0.068 $\mu$ f $\pm$ 5%, 50 VDCW.
C112	19A700001P2	Ceramic, high dielectric, disc: 150 pf, $\pm$ 20%, 50 VDCW.
C113	19A700002P16	Ceramic, temp compensating, disc: 18 pf $\pm$ 5%, 50 VDCW.
C114	19A700001P2	Ceramic, temp compensating, disc: 150 pf $\pm$ 20%, 50 VDCW.
C151	19A700003P7	Tantalum: 10 $\mu$ f $\pm$ 20%, 16 VDCW.
C152	19A700005P7	Polyester: 0.01 $\mu$ f $\pm$ 10%, 50 VDCW.
C153	19A700002P28	Ceramic, disc: 180 pf $\pm$ 5%, 50 VDCW.
C154	19A700001P6	Ceramic, high dielectric, disc: 680 pf, $\pm$ 20%, 50 VDCW.
C155	19A134725P2	Ceramic, disc: 68 pf $\pm$ 5%, 50 VDCW.
C156	19A134725P1	Ceramic, disc: 18 pf $\pm$ 5%, 50 VDCW.
C157	19A700002P12	Ceramic, disc: 8.2 pf $\pm$ 0.25 pf, 50 VDCW.
C158	19A700002P20	Ceramic, temp compensating, disc: 39 pf $\pm$ 5%, 50 VDCW.
C161	19A700002P3	Ceramic, disc: 1.5 pf $\pm$ 0.25 pf, 50 VDCW.
C201	19A700001P2	Ceramic, high dielectric, disc: 150 pf, $\pm$ 20%, 50 VDCW.
C203	19A700002P19	Ceramic, disc: 33 pf $\pm$ 5%, 50 VDCW.
C204 and C205	19A700001P7	Ceramic, high dielectric, disc: 1000 pf, $\pm$ 20%, 50 VDCW.
C206	19A700002P16	Ceramic, temp compensating, disc: 18 pf $\pm$ 5%, 50 VDCW.
C207	19A700002P19	Ceramic, temp compensating, disc: 33 pf, $\pm$ 20%, 50 VDCW.
C208	19A700013P8	Phenolic: 0.39 pf $\pm$ 5%, 500 VDCW.
C209	19A700002P15	Ceramic, temp compensating, disc: 15 pf $\pm$ 5%, 50 VDCW.
C210	19A700002P19	Ceramic, temp compensating, disc: 33 pf, $\pm$ 20%, 50 VDCW.
C211	19A700003P5	Tantalum: 2.2 $\mu$ f $\pm$ 20%, 35 VDCW.
C212 and C213	19A700001P7	Ceramic, high dielectric, disc: 1000 pf, $\pm$ 20%, 50 VDCW.
C214	19A700001P5	Ceramic, high dielectric, disc: 470 pf $\pm$ 20%, 50 VDCW.
C215	19A700002P16	Ceramic, temp compensating, disc: 18 pf $\pm$ 5%, 50 VDCW.
C216	19A700002P21	Ceramic, temp compensating, disc: 47 pf $\pm$ 5%, 50 VDCW.
C217	19A700013P10	Phenolic: 0.56 pf $\pm$ 5%, 500 VDCW.

SYMBOL	GE PART NO.	DESCRIPTION
C218	19A700002P14	Ceramic, temp compensating, disc: 12 pf $\pm$ 5%, 50 VDCW.
C219	19A700002P20	Ceramic, temp compensating, disc: 39 pf $\pm$ 5%, 50 VDCW.
C220 thru C222	19A700001P7	Ceramic, disc: 1000 pf, $\pm$ 20%, 50 VDCW.
C223 and C224	19A700002P16	Ceramic, temp compensating, disc: 18 pf $\pm$ 5%, 50 VDCW.
C225	19A700001P7	Ceramic, disc: 1000 pf, $\pm$ 20%, 50 VDCW.
C231	19A700002P13	Ceramic, temp compensating, disc: 10 pf $\pm$ 5%, 50 VDCW.
C232	19A700002P22	Ceramic, temp compensating, disc: 55 pf $\pm$ 5%, 50 VDCW.
C233	19A700015P30	Metallized teflon: 110 pf $\pm$ 5%, 250 VDCW.
C234	19A700004P2	Metallized polyester: 0.1 $\mu$ f $\pm$ 10%, 63 VDCW.
C235	19A700001P2	Ceramic, disc: 150 $\mu$ f $\pm$ 20%, 50 VDCW.
C236	19A700003P7	Tantalum: 10 $\mu$ f $\pm$ 20%, 16 VDCW.
C237	19A700015P37	Metallized teflon: 220 pf $\pm$ 5%, 250 VDCW.
C238A	19A700103P34	Mica: 100 pf $\pm$ 5%, 500 VDCW.
C238B	19A700105P30	Mica: 68 pf $\pm$ 5%, 500 VDCW.
C239	19A700105P6	Mica: 10 pf $\pm$ 5%, 500 VDCW.
C240	19A700015P30	Teflon/mica: 110 pf $\pm$ 5%, 250 VDCW.
C241A	19A700014P38	Teflon/mica: 240 pf $\pm$ 5%, 250 VDCW.
C241B	19A700014P33	Teflon/mica: 150 pf $\pm$ 5%, 250 VDCW.
C242A	19A700014P38	Teflon/mica: 240 pf $\pm$ 5%, 250 VDCW.
C242B	19A700014P33	Teflon/mica: 150 pf $\pm$ 5%, 250 VDCW.
C243	19A700004P2	Metallized polyester: 0.1 $\mu$ f $\pm$ 10%, 63 VDCW.
C244	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C245	19A700001P2	Ceramic, high dielectric, disc: 130 $\mu$ f $\pm$ 20%, 50 VDCW.
C246	19A700015P37	Teflon/mica: 220 pf $\pm$ 5%, 250 VDCW.
C247A	19A700015P32	Teflon/mica: 130 pf $\pm$ 5%, 250 VDCW.
C247B	19A700015P27	Teflon/mica: 82 pf $\pm$ 5%, 250 VDCW.
C248	19A700015P16	Teflon/mica: 30 pf $\pm$ 5%, 250 VDCW.
C249	19A700015P37	Teflon/mica: 220 pf $\pm$ 5%, 250 VDCW.
C250	19A116679P8D	Metallized teflon: 8 pf $\pm$ 5 pf, 250 VDCW.
C251	19A700015P12	Teflon/mica: 22 pf $\pm$ 5%, 250 VDCW.
C252	19A116952P29	Metallized teflon: 29 pf $\pm$ 2%, 250 VDCW; sim to Underwood Type J1HF.
C253	19A116679P8D	Metallized teflon: 8 pf $\pm$ 5 pf, 250 VDCW.
C254	19A700001P2	Ceramic, high dielectric, disc: 150 $\mu$ f $\pm$ 20%, 50 VDCW.
C255	19A700002P3	Ceramic, temp compensating, disc: 1.5 pf $\pm$ 0.25 pf, 50 VDCW.
C258	19A700003P7	Tantalum: 10 $\mu$ f $\pm$ 20%, 16 VDCW.
C301	19A700001P6	Ceramic, high dielectric, disc: 680 $\mu$ f $\pm$ 20%, 50 VDCW.
C302	19A700005P7	Polyester: 0.01 $\mu$ f $\pm$ 10%, 50 VDCW.
C303	19A700002P28	Ceramic, temp compensating, disc: 180 pf $\pm$ 5%, 50 VDCW.
C304	19A700001P6	Ceramic, high dielectric, disc: 680 $\mu$ f $\pm$ 20%, 50 VDCW.
C305	19A134725P2	Ceramic, disc: 68 pf $\pm$ 5%, 50 VDCW.
C306	19A134725P1	Ceramic, disc: 18 pf $\pm$ 5%, 50 VDCW.
C307	19A700002P11	Ceramic, disc: 6.8 pf $\pm$ 0.25 pf, 50 VDCW.
C308	19A700002P28	Ceramic, temp compensating, disc: 180 pf $\pm$ 5%, 50 VDCW.
C309	19A700013P10	Phenolic: 0.56 pf $\pm$ 5%, 500 VDCW.
C310	19A700002P13	Ceramic, temp compensating, disc: 10 pf $\pm$ 5%, 50 VDCW.
C312	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C313	19A700002P17	Ceramic, disc: 22 pf $\pm$ 5%, 50 VDCW.

SYMBOL	GE PART NO.	DESCRIPTION
C404	19A700002P29	Ceramic, disc: 220 pf $\pm$ 5%, 50 VDCW.
C405	19A700002P10	Ceramic, temp compensating, disc: 5.6 pf $\pm$ 0.25 pf, 50 VDCW.
C406	19A700001P5	Ceramic, high dielectric, disc: 470 $\mu$ f $\pm$ 20%, 50 VDCW.
C407 and C408	19A700002P12	Ceramic, temp compensating, disc: 8.2 pf $\pm$ 0.25 pf, 50 VDCW.
C409	19A700013P3	Phenolic: 0.15 pf $\pm$ 5%, 500 VDCW.
C410	19A700013P5	Phenolic: 0.22 pf $\pm$ 5%, 500 VDCW.
C411	19A700002P10	Ceramic, temp compensating, disc: 5.6 pf $\pm$ 0.25 pf, 50 VDCW.
C412 and C413	19A700005P7	Polyester: 0.010 $\mu$ f $\pm$ 10%, 50 VDCW.
C414	19A700002P20	Ceramic, disc: 39 pf $\pm$ 5%, 50 VDCW.
C415	19A700002P12	Ceramic, temp compensating, disc: 8.2 pf $\pm$ 5%, 50 VDCW.
C416	19A700013P9	Phenolic: 0.47 pf $\pm$ 5%, 500 VDCW.
C417	19A700002P12	Ceramic, disc: 8.2 pf $\pm$ 0.25 pf, 50 VDCW.
C418	19A700002P19	Ceramic, disc: 33 pf $\pm$ 5%, 50 VDCW.
C419	19A700002P30	Ceramic, disc: 270 pf $\pm$ 5%, 50 VDCW.
C501	19A700002P17	Ceramic, temp compensating, disc: 22 pf $\pm$ 5%, 50 VDCW.
C502	19A700001P5	Ceramic, high dielectric, disc: 470 $\mu$ f $\pm$ 20%, 50 VDCW.
C503 thru C505	19A700005P7	Polyester: 0.01 $\mu$ f $\pm$ 10%, 50 VDCW.
C506	19A700002P21	Ceramic, temp compensating, disc: 47 pf $\pm$ 5%, 50 VDCW.
C507	19A700002P25	Ceramic, temp compensating, disc: 100 pf $\pm$ 5%, 50 VDCW.
C508	19A700002P29	Ceramic, temp compensating, disc: 220 pf $\pm$ 5%, 50 VDCW.
C509	19A700005P5	Polyester: 4700 pf $\pm$ 10%, 50 VDCW.
C510	19A700003P4	Tantalum: 1 $\mu$ f $\pm$ 20%, 35 VDCW.
C511	19A700003P2	Tantalum: 0.22 $\mu$ f $\pm$ 20%, 35 VDCW.
C512 thru C514	19A700003P4	Tantalum: 1 $\mu$ f $\pm$ 20%, 35 VDCW.
C515 and C516	19A700003P2	Tantalum: 0.22 $\mu$ f $\pm$ 20%, 35 VDCW.
C517 and C518	19A700001P3	Ceramic, high dielectric, disc: 220 pf $\pm$ 20%, 50 VDCW.
C519	19A700001P7	Ceramic, high dielectric, disc: 1000 pf $\pm$ 20%, 50 VDCW.
C520	19A700003P4	Tantalum: 1 $\mu$ f $\pm$ 20%, 35 VDCW.
C521	19A134730P3	Electrolytic: 470 $\mu$ f +100% -10%, 16 VDCW.
C522	19A700005P4	Polyester: 3300 pf $\pm$ 10%, 50 VDCW.
C601	19A700003P5	Polyester: 4700 pf $\pm$ 10%, 50 VDCW.
C602	19A700005P6	Polyester: 6800 pf $\pm$ 10%, 50 VDCW.
C603	19A700005P11	Polyester: 0.047 $\mu$ f $\pm$ 10%, 50 VDCW.
C604	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C605	19A134730P1	Electrolytic: 47 $\mu$ f +100% -10%, 16 VDCW.
C606	19A700003P4	Tantalum: 1 $\mu$ f $\pm$ 20%, 35 VDCW.
C607	19A700003P3	Tantalum: 0.47 $\mu$ f $\pm$ 20%, 35 VDCW.
C608	19A700004P2	Metallized polyester: 0.1 $\mu$ f $\pm$ 10%, 63 VDCW.
C609	19A700003P6	Tantalum: 4.7 $\mu$ f $\pm$ 20%, 35 VDCW.
C610	19A700003P9	Tantalum: 47 $\mu$ f $\pm$ 20%, 6.3 VDCW.

(Cont'd on Page 37)



SYMBOL	GE PART NO.	DESCRIPTION	SYMBOL	GE PART NO.	DESCRIPTION	SYMBOL	GE PART NO.	DESCRIPTION
C611	19A700004P2	Metallized polyester: 0.1 $\mu$ f $\pm$ 10%, 63 VDCW.	L224	19A138304P1	Coil.	Q301 and Q302	19A115330P1	Silicon, NPN.
C612	19A700003P2	Tantalum: 0.22 $\mu$ f $\pm$ 20%, 35 VDCW.	L225A	19A138302P1	Coil.	Q401	19A116859P1	Silicon, NPN; sim to Type 2N5032 or 2N3570.
C613	19A700004P6	Metallized polyester: 0.47 $\mu$ f $\pm$ 10%, 63 VDCW.	L225B	19A138302P2	Coil.	Q402	19A700060P2	N-Type, field effect.
C614	19A134730P3	Electrolytic: 470 $\mu$ f +100% -10%, 16 VDCW.	L226	19A138296P1	Coil.	Q501	19A134760P1	N Channel, field effect: sim to Type 3N205.
C615 and C616	19A700004P1	Metallized polyester: 0.038 $\mu$ f $\pm$ 10%, 63 VDCW.	L227	19A129773G1	Coil.	Q601 and Q602	19A116774P1	Silicon, NPN; sim to Type 2N5210.
C617	19A134730P1	Electrolytic: 47 $\mu$ f +100% -10%, 16 VDCW.	L228	19A138303P2	Coil.	Q603 thru Q605	19A134749P1	Silicon, PNP; sim to Type 2N5087.
C618	19A134730P2	Electrolytic: 220 $\mu$ f +100% -10%, 25 VDCW.	L229A	19A138296P1	Coil.			----- RESISTORS -----
C620 and C621	19A700001P5	Ceramic, high dielectric, disc: 470 pf, $\pm$ 20%, 50 VDCW.	L229B	19A138300P1	Coil.	R102	19A700106P95	Composition: 22K ohms $\pm$ 5%, 1/4 w.
		----- DIODES AND RECTIFIERS -----	L230A	19A138301P3	Coil.	R103	19A700105P51	Composition: 330 ohms $\pm$ 5%, 1/4 w.
D101 and D102	4037822P1	Silicon, 1000 mA, 400 PIV.	L230B	19A138303P1	Coil.	R104	3R152P513J	Composition: 51K ohms $\pm$ 5%, 1/4 w.
D151	19A116785P2	Silicon, capacitive.	L232	19A138298P1	Coil.	R105	19C314256P21052	Metal film: 10.5K ohms $\pm$ 1%, 1/4 w.
D152	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.	L234	19A138298P1	Coil.	R106	19C314256P21272	Metal film: 12.7K ohms $\pm$ 1%, 1/4 w.
D201	19A115775P1	Silicon, fast recovery, 225 mA, 50 PIV.	L235	19A138297P1	Coil.	R107	19C314256P21052	Metal film: 10.5K ohms $\pm$ 1%, 1/4 w.
D301	19A116785P2	Silicon, capacitive.	L236	19A138298P1	Coil.	R108	19C314256P25111	Metal film: 5.1K ohms $\pm$ 1%, 1/4 w.
D501 and D502	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.	L237	19A138296P1	Coil.	R109A	3R152P132J	Composition: 1.3K ohms $\pm$ 5%, 1/4 w.
D601 thru D605	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.	L238	19A138298P1	Coil.	R109B	19A700106P69	Composition: 1.8K ohms $\pm$ 5%, 1/4 w.
D606	19A134738P1	Diode, optoelectronic: red sim to Siemens LD41/11.	L239	19A138297P1	Coil.	R110	19C314256P25111	Metal film: 5.1K ohms $\pm$ 1%, 1/4 w.
D607	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.	L301	19A134728P2	Coil.	R112	19C314256P22002	Metal film: 20K ohms $\pm$ 1%, 1/4 w.
		----- JACKS AND RECEPTACLES -----	L302	19B209420P119	Coil, RF: 3.30 $\mu$ h $\pm$ 10%, 0.80 ohms DC res max; sim to Jeffers 4433-6K.	R113	19C314253P21242	Metal film: 12.4K ohms $\pm$ 1%, 1/4 w.
J151	19A116428P4	Contact, electrical: sim to AMP 86031-1.	L303	19A134727P6	Coil, RF: variable.	R114	19A700106P99	Composition: 33K ohms $\pm$ 5%, 1/4 w.
			L305	19A134727P9	Coil, RF: variable.	R115	19A700103P71	Composition: 2.2K ohms $\pm$ 5%, 1/4 w.
			L401	19A134727P12	Coil, RF: variable.	R116	19A134752P1	Variable, carbon film: 4.7K ohms $\pm$ 20%, 0.1 watt; sim to Phillips 2322410033.
			L402	19A134727P11	Coil, RF: variable.	R117	19A700106P73	Composition: 2.7K ohms $\pm$ 5%, 1/4 w.
			L403	19A134727P10	Coil, RF: variable.			
			L404	19A134727P4	Coil, RF: variable.			
J301	19A116428P4	Contact, electrical: sim to AMP 86031-1.	L405	19A134727P5	Coil, RF: variable.	R118	19A700019P25	Deposited carbon: 100 ohms $\pm$ 5%, 1/4 w.
J601	19A700067P2	Connector, receptacle; sim to Amphenol 83-876-1002.	L406	19A134729P2	Coil, RF: variable.	R151 and R152	19A700106P83	Composition: 6.8K ohms $\pm$ 5%, 1/4 w.
J602 thru J604	19A142706P5	Contact, electrical.	L501 and L502	19A134747P2	Transformer, IF: 10.7 MHz; sim to Toko Inc. 154 PC-470073N3.	R153	19A134732P1	Thermistor: 3.3K ohms $\pm$ 10% at 0 Power, color code red; sim to Phillips No. 2322-842-12332.
		----- RELAYS -----	L503 and L504	19A134747P1	Transformer, IF: 455 KHz; sim to Toko Inc. 452252N0.	R154	19A700106P103	Composition: 47K ohms $\pm$ 5%, 1/4 w.
K601	19A700061P1	Hermetic sealed: 180 to 341 ohms coil res, 8-16.3 VDC; sim to GE 3SAV1760A2, CP Clare HFW-1201558, or Potter-Brumfield HCM6160.	L601	19A134741P1	Reactor, Audio Freq; sim to Festinduktivitaten No. DR 275/5K 75 mH $\pm$ 10% 37.0.	R155	19A700106P49	Composition: 270 ohms $\pm$ 5%, 1/4 w.
		----- INDUCTORS -----			----- PLUGS -----	R156	19A700106P85	Composition: 8.2K ohms $\pm$ 5%, 1/4 w.
L151	19A134728P1	Coil, RF: variable.	P101	19A116659P15	Connector, printed board: 4 contacts; sim to Molex 09-52-3042.	R157	19A700106P83	Composition: 6.8K ohms $\pm$ 5%, 1/4 w.
L152	19A700024P15	Coil, RF: 1.5 $\mu$ h $\pm$ 10%, 0.22 ohms DC res max.	P201	19A116659P1	Connector, printed board: 3 contacts; sim to Molex 09-52-3032.	R158	19A700106P49	Composition: 270 ohms $\pm$ 5%, 1/4 w.
L153	19A134727P6	Coil, RF: variable.	P901	19A116659P15	Connector, printed board: 4 contacts; sim to Molex 09-52-3042.	R160	19A700106P91	Composition: 15K ohms $\pm$ 5%, 1/4 w.
L154	19A700024P25	Coil, RF: 10 $\mu$ h $\pm$ 10%, 3.70 ohms DC res max.	P903	19A116659P83	Connector, printed board: 7 contacts; sim to Molex 09-52-3072 (SPECIAL).	R161	19A700106P79	Composition: 4.7K ohms $\pm$ 5%, 1/4 w.
L155	19A700024P15	Coil, RF: 1.5 $\mu$ h $\pm$ 10%, 0.22 ohms DC res max.			----- TRANSISTORS -----	R201	19A700106P75	Composition: 3.3K ohms $\pm$ 5%, 1/4 w.
L202	19B209420P101	Coil, RF: 0.10 $\mu$ h $\pm$ 10%, 0.08 ohms DC res max; sim to Jeffers 4416-1K.	Q151	19A115330P1	Silicon, NPN.	R202	19A700106P53	Composition: 390 ohms $\pm$ 5%, 1/4 w.
L203	19A129773G1	Coil.	Q201	19A115910P1	Silicon, NPN; sim to Type 2N3904.	R203	19A700106P31	Composition: 47 ohms $\pm$ 5%, 1/4 w.
L204 and L205	19A134727P3	Coil, RF: variable.	Q202 and Q203	19A116201P1	Silicon, NPN.	R204	19A700106P23	Composition: 22 ohms $\pm$ 5%, 1/4 w.
L206	19A700024P13	Coil, RF: 1.0 $\mu$ h $\pm$ 10%, 1.00 ohms DC res max.	Q204	19A118868P1	Silicon, NPN; sim to Type 2N4427.	R205	19A700106P47	Composition: 220 ohms $\pm$ 5%, 1/4 w.
L207	19B209420P101	Coil, RF: 0.10 $\mu$ h $\pm$ 10%, 0.08 ohms DC res max; sim to Jeffers 4416-1K.	Q205	19A134340P1	Silicon, NPN: VHF Amplifier, 4 watts, 12.5 v.	R206	3R152P242J	Composition: 2.4K ohms $\pm$ 5%, 1/4 w.
L208 and L209	19A134727P3	Coil, RF: variable.	Q203A	19A134340P2	Silicon, NPN: VHF Amplifier, 25 watts, 12.5 v.	R207	19A700106P15	Composition: 10 ohms $\pm$ 5%, 1/4 w.
L211	19A700024P13	Coil, RF: 1.0 $\mu$ h $\pm$ 10%, 1.00 ohms DC res max.	Q206B	19A134340P3	Silicon, NPN: VHF Amplifier, 12 watts.	R208	19A700106P25	Composition: 27 ohms $\pm$ 5%, 1/4 w.
L212 and L213	19A138299P1	Coil.	Q207	19A116742P1	Silicon, NPN.	R209	19A700106P39	Composition: 100 ohms $\pm$ 5%, 1/4 w.
L221	19A700024P25	Coil, RF: 10 $\mu$ h $\pm$ 10%, 3.70 ohms DC res max.	Q208	19A115852P1	Silicon, PNP; sim to Type 2N3906.	R210	19A700106P25	Composition: 27 ohms $\pm$ 5%, 1/4 w.
L222		(Part of printed board 19D432166P1).	Q209 and Q210	19A115910P1	Silicon, NPN; sim to Type 2N3904.	R211	19A700105P32	Composition: 51 ohms $\pm$ 5%, 1/4 w.
						R213	19A700013P15	Phenolic: 1.50 pf $\pm$ 5%, 500 VDCW.
						R215	19A116412P3	Variable, cermet: 5K ohms $\pm$ 10%, 1/2 w; sim to Helipot Model 62 PR.
						R216	19A700106P71	Composition: 2.2K ohms $\pm$ 5%, 1/4 w.
						R217	19A700106P79	Composition: 4.7K ohms $\pm$ 5%, 1/4 w.
						R218	19A700106P83	Composition: 6.8K ohms $\pm$ 5%, 1/4 w.

(Cont'd on Page 38)

SYMBOL	GE PART NO.	DESCRIPTION	SYMBOL	GE PART NO.	DESCRIPTION	SYMBOL	GE PART NO.	DESCRIPTION
R219	19A700106P69	Composition: 1.8K ohms $\pm 5\%$ , 1/4 w.	R604	19A700106P93	Composition: 18K ohms $\pm 5\%$ , 1/4 w.			----- INTEGRATED CIRCUITS -----
R220	19A700106P47	Composition: 220 ohms $\pm 5\%$ , 1/4 w.	R605	19A700106P87	Composition: 10K ohms $\pm 5\%$ , 1/4 w.	U101	19A116297P6	Linear, Dual OP Amp, 8 Pin Minidip Package; sim to Raytheon.
R221	19A700106P55	Composition: 470 ohms $\pm 5\%$ , 1/4 w.	R606	3R152P274J	Composition: 270K ohms $\pm 5\%$ , 1/4 w.	U501	19A134759P1	Linear, Dual Differential Amplifier: 14 pin dip.
R222	19A700106P57	Composition: 530 ohms $\pm 5\%$ , 1/4 w.	R607	19A134755P1	Variable, carbon film: 10K ohms $\pm 20\%$ , 0.1 w; sim to Ruwido Type 0052-300.	U502	19A134766P1	Linear, IF Amplifier & Detector: sim to Amperex TBA 750.
R223	19A700106P63	Composition: 1K ohms $\pm 5\%$ , 1/4 w.	R608	19A700106P83	Composition: 6.8K ohms $\pm 5\%$ , 1/4 w.	U601	19A134769P2	Linear, Audio Amplifier.
R224	19A700113P15	Phenolic: 1.50 pf $\pm 5\%$ , 500 VDCW.	R609	19A134732P2	Thermistor: 470 ohms $\pm 20\%$ at 0 Power, color code brown; sim to Philips No. 2322-842-11471.	U602	19A138414G1	Linear, Positive Voltage Regulator: 8.5 v; sim to $\mu$ A7805U.
R301	19A700106P83	Composition: 6.8K ohms $\pm 5\%$ , 1/4 w.	R610	19A700106P85	Composition: 8.2K ohms $\pm 5\%$ , 1/4 w.			----- CABLES -----
R302	19A700106P75	Composition: 3.3K ohms $\pm 5\%$ , 1/4 w.	R611	19A700106P41	Composition: 120 ohms $\pm 5\%$ , 1/4 w.	W201 thru W203		(Part of printed board 19D432166P1).
R303	19A700106P49	Composition: 270 ohms $\pm 5\%$ , 1/4 w.	R612	19A700106P55	Composition: 470 ohms $\pm 5\%$ , 1/4 w.	W401		(Part of printed board 19D432166P1).
R304	19A700106P103	Composition: 47K ohms $\pm 5\%$ , 1/4 w.	R613	19A700106P61	Composition: 820 ohms $\pm 5\%$ , 1/4 w.	W601		(Part of printed board 19D432166P1).
R305	19A700106P59	Composition: 680 ohms $\pm 5\%$ , 1/4 w.	R614	19A700103P77	Composition: 3.9K ohms $\pm 5\%$ , 1/4 w.			----- SOCKETS -----
R306	19A700106P85	Composition: 8.2K ohms $\pm 5\%$ , 1/4 w.	R615	19A700106P103	Composition: 47K ohms $\pm 5\%$ , 1/4 w.	X151		Socket. Includes:
R307	19A700106P83	Composition: 6.8K ohms $\pm 5\%$ , 1/4 w.	R616	19A700106P87	Composition: 10K ohms $\pm 5\%$ , 1/4 w.		19A134806P1	Pin. (Quantity 2).
R308	19A700106P49	Composition: 270 ohms $\pm 5\%$ , 1/4 w.	R617	3R152P394J	Composition: 390K ohms $\pm 5\%$ , 1/4 w.		19B232322P1	Spring. (Quantity 1).
R309	19A700103P23	Composition: 22 ohms $\pm 5\%$ , 1/4 w.	R618	19A700106P89	Composition: 12K ohms $\pm 5\%$ , 1/4 w.	X301		Socket. Includes:
R310	19A700106P15	Composition: 10 ohms $\pm 5\%$ , 1/4 w.	R619 and R620	19A700106P97	Composition: 27K ohms $\pm 5\%$ , 1/4 w.		19A134806P1	Pin. (Quantity 2).
R401	19A700106P77	Composition: 3.9K ohms $\pm 5\%$ , 1/4 w.	R621	19A700106P69	Composition: 1.8K ohms $\pm 5\%$ , 1/4 w.		19B232322P1	Spring. (Quantity 1).
R402	19A700106P81	Composition: 5.6K ohms $\pm 5\%$ , 1/4 w.	R622	19A700106P51	Composition: 330 ohms $\pm 5\%$ , 1/4 w.	X501		Socket. Includes:
R403	19A700106P63	Composition: 1K ohms $\pm 5\%$ , 1/4 w.	R623	19A700106P83	Composition: 6.8K ohms $\pm 5\%$ , 1/4 w.		19A134806P1	Pin. (Quantity 2).
R404	3R152P432J	Composition: 4.3K ohms $\pm 5\%$ , 1/4 w.	R624	19A700103P87	Composition: 10K ohms $\pm 5\%$ , 1/4 w.		19B232322P1	Spring. (Quantity 1).
R405	19A700106P31	Composition: 47 ohms $\pm 5\%$ , 1/4 w.	R625	3R152P302J	Composition: 3K ohms $\pm 5\%$ , 1/4 w.			----- FILTERS -----
R406	19A700106P47	Composition: 220 ohms $\pm 5\%$ , 1/4 w.	R626	19A700106P63	Composition: 1K ohms $\pm 5\%$ , 1/4 w.	Z201 and Z202		FILTER ASSEMBLY 19A133228G1
R407	19A700106P39	Composition: 100 ohms $\pm 5\%$ , 1/4 w.	R627	19A700106P45	Composition: 180 ohms $\pm 5\%$ , 1/4 w.			----- INDUCTORS -----
R408	19A700106P65	Composition: 1.2K ohms $\pm 5\%$ , 1/4 w.				L1	19A129773G5	Coil.
R501	19A700106P63	Composition: 1K ohms $\pm 5\%$ , 1/4 w.	R628	19A700106P43	Composition: 150 ohms $\pm 5\%$ , 1/4 w.			----- RESISTORS -----
R502 and R503	19A700106P97	Composition: 27K ohms $\pm 5\%$ , 1/4 w.	R629	19A700106P85	Composition: 8.2K ohms $\pm 5\%$ , 1/4 w.	R1	19A700113P15	Composition: 10 ohms $\pm 5\%$ , 1/2 w.
R504	19A700106P51	Composition: 330 ohms $\pm 5\%$ , 1/4 w.	R630	19A134753P1	Variable, carbon film: 47K ohms $\pm 20\%$ , 0.1 w.	Z501A	19A134745P2	Filter, bandpass: freq. 10.7 MHz; sim to ITT No. 033CA without Transformers.
R505	19A700106P49	Composition: 270 ohms $\pm 5\%$ , 1/4 w.	R631	19A700103P23	Composition: 22 ohms $\pm 5\%$ , 1/4 w.	Z501B	19A134745P3	Filter, bandpass: freq. 10.7 MHz; sim to ITT No. 033DD without Transformers.
R506	19A700106P85	Composition: 8.2K ohms $\pm 5\%$ , 1/4 w.	R632	19A116216P1R0J	Deposited carbon: 1.0 ohms $\pm 5\%$ , .25 w; sim to Mepco Electra Type CR25.	Z502A	19A134742P1	Filter, bandpass: freq. 455 $\pm$ 1.5 KHz; sim to Murata No. CFU455D2 or Matsushita No. EFC-L455K41EA
R507	19A700103P83	Composition: 6.8K ohms $\pm 5\%$ , 1/4 w.	R633	19A700106P41	Composition: 120 ohms $\pm 5\%$ , 1/4 w.	Z502B	19A134742P2	Filter, bandpass: freq. 455 $\pm$ 1.5 KHz; sim to Murata No. CFU455F2 or Matsushita No. EFC-L455K41C.
R508 and R509	19A700106P71	Composition: 2.2K ohms $\pm 5\%$ , 1/4 w.	R634	19A116216P1R0J	Deposited carbon: 1.0 ohms $\pm 5\%$ , .25 w; sim to Mepco Electra Type CR25.			ASSOCIATED ASSEMBLIES
R510	19A700106P89	Composition: 12K ohms $\pm 5\%$ , 1/4 w.	R635	19A700106P33	Composition: 56 ohms $\pm 5\%$ , 1/4 w.			----- CRYSTALS -----
R511	19A700106P59	Composition: 680 ohms $\pm 5\%$ , 1/4 w.	R636A	19A700106P49	Composition: 270 ohms $\pm 5\%$ , 1/4 w.	Y151	19B233066G1	Transmitter: 5 PPM. Crystal Freq= $\frac{\text{Oper. Freq}}{3}$
R512 and R513	19A700106P51	Composition: 330 ohms $\pm 5\%$ , 1/4 w.	R636B	19A700106P39	Composition: 100 ohms $\pm 5\%$ , 1/4 w.		19B233066G3	Transmitter: 10 PPM. Crystal Freq= $\frac{\text{Oper. Freq}}{3}$
R514	19A700103P69	Composition: 1.8K ohms $\pm 5\%$ , 1/4 w.	R636C	19A700106P31	Composition: 47 ohms $\pm 5\%$ , 1/4 w.	Y301	19B233066G2	Receiver: 5 PPM. Crystal Freq= $\frac{\text{Fo}-10.7}{3}$
R515	19A700103P89	Composition: 12K ohms $\pm 5\%$ , 1/4 w.	R636D	19A700106P23	Composition: 22 ohms $\pm 5\%$ , 1/4 w.		19B233066G4	Receiver: 10 PPM. Crystal Freq= $\frac{\text{Fo}-10.7}{3}$
R516	19A700106P59	Composition: 680 ohms $\pm 5\%$ , 1/4 w.	R636E	19A116216P6R8J	Deposited carbon: 6.8 ohms $\pm 5\%$ , .25 w; sim to Mepco Electra Type CR25.	Y501	19A134802P1	Crystal unit, Quartz: 10.245 MHz.
R517	19A700106P83	Composition: 6.8K ohms $\pm 5\%$ , 1/4 w.	R637	19A700106P59	Composition: 680 ohms $\pm 5\%$ , 1/4 w.			(Cont'd on Page 39)
R518	19A700106P85	Composition: 8.2K ohms $\pm 5\%$ , 1/4 w.	R638	7147161P19	Composition: 1.0 ohms $\pm 5\%$ , 1/2 w.			
R519	19A700106P69	Composition: 1.8K ohms $\pm 5\%$ , 1/4 w.	R639	19A700106P39	Composition: 100 ohms $\pm 5\%$ , 1/4 w.			
R520	19A700106P87	Composition: 10K ohms $\pm 5\%$ , 1/4 w.						
R521	19A134755P2	Variable, carbon film: 25K ohms $\pm 20\%$ , 0.1 w; sim to Ruwido Type 0052-300.	S601 and S602	19B800563P1	Push: DPDT, 1 station, push-push alternate action; sim to IEEE/SCHADOW 51281.			
R522	19A700103P87	Composition: 10K ohms $\pm 5\%$ , 1/4 w.			----- SWITCHES -----			
R523	19A700106P75	Composition: 3.3K ohms $\pm 5\%$ , 1/4 w.	T201	19A129534G1	Transformer.			
R524 and R525	19A700106P101	Composition: 39K ohms $\pm 5\%$ , 1/4 w.	TP201 and TP202	19A700152P1	Contact. (Quantity 1 each).			
R526	19A700106P7	Composition: 4.7 ohms $\pm 5\%$ , 1/4 w.	TP203	19A700152P1	Contact. (Quantity 2).			
R527	19A700106P39	Composition: 100 ohms $\pm 5\%$ , 1/4 w.	TP401	19A700152P1	Contact. (Quantity 2).			
R601	19A700106P103	Composition: 47K ohms $\pm 5\%$ , 1/4 w.	TP501	19A700152P1	Contact. (Quantity 2).			
R602	19A700106P95	Composition: 22K ohms $\pm 5\%$ , 1/4 w.			----- TEST POINTS -----			
R603	19A700106P51	Composition: 330 ohms $\pm 5\%$ , 1/4 w.			Contact. (Quantity 1 each).			
					Contact. (Quantity 2).			
					Contact. (Quantity 2).			

SYMBOL	GE PART NO.	DESCRIPTION
		----- MISCELLANEOUS -----
	19C330536P1	Shield. (Shield center located at L203).
	19A137813P1	Shield. (Located at C252).
	19B232901P1	Support. (Used with Q207, U601, U602).
	19A116023P3	Insulator. (Used with Q207, U602).
	19A134016P1	Insulator. (Used with Q207, U602).
	19A134655P4	Flat washer. M2.5. (Used with Q207, U602).
	19A134661P3	Hex nut. M2.5. (Used with Q207, U601, U602).
	19A134483P2508	Machine screw. M2.5 x 8 MM. (Used with Q207, U601, U602).
	19A134657P2	Lockwasher. M2.5. (Used with Q207, U601, U602).
	19A134772P1	Can. (Used with L153, L204, L203, L206, L209, L303, L305, L401, L402, L403, L405, L406).
	19A138274P1	Insulator. (Used with L153, L204, L205, L208, L209, L303, L305, L401, L402, L403, L405, L406).
	N330P1905F22	Eyelet. (Located in corner of printed board at J601).
	19B232830P1	Support. (J601).
	19A134589P3006	Tap screw. M3 x 6MM.
	19C328587P1	Push button. (Used with S601, S602).
	NP280878P2	Label. (S601 - SQUELCH).
	NP280878P1	Label. (S602 - POWER).
	19D429826P1	Knob. (R630 - VOLUME).
	4036555P1	Insulator, washer: nylon. (Used with Q204).
	4035656P45	Spacer. (Located between L401 & L405).
	19A134753P5	Machine screw. (Used with R630 knob).
	19A134753P2	Flatwasher. (Used with R630 knob).
	19A134751P1	Washer, tension. (Used with R630 knob).

PARTS LIST

CENTURY II EXTERNAL SPEAKER OPTION  
19C320302G9  
ISSUE 1

SYMBOL	GE PART NO.	DESCRIPTION
LS2	19A116910P1	----- LOUSPEAKERS ----- Permanent magnet: 5 inch, 3.2 ohms ±15% imp, 5 w max operating; sim to Pioneer 002009.
W1	19A129414G1	----- CABLES ----- 2 conductor cable: approx 5 feet long, includes (2) 19A116781P3 contacts.
		----- MISCELLANEOUS -----
	19B227593G2	Housing.
	19B219692G2	Grille.
	19C320016P2	Mounting bracket. (Mounts speaker to mounting surface).
	N187P1610C6	Machine screw: No. 10-32 x 5/8. (Secures speaker to mounting bracket).
	N403P19C6	Lockwasher, external tooth: No. 10. (Secures speaker to mounting bracket).
	N402P39C6	Flatwasher: No. 10. (Secures speaker to mounting bracket).
	N130P1610C6	Tap screw, thread forming: No. 10-16 x 5/8. (Secures mounting bracket to mounting surface).
	19A116986P108	Tap screw, with lockwasher: No. 7-19 x 1/2. (Secures speaker to grille).
	19A116986P112	Tap screw, with lockwasher: No. 7-19 x 3/4. (Secures housing to grille).

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST		
SYSTEM INTERCONNECT BOARD 19D900138G1 ISSUE 1		
SYMBOL	GE PART NO.	DESCRIPTION
C901	19A700001P6	----- CAPACITORS ----- Ceramic, high dielectric disc: 680 pf ±20%, 50 VDCW.
C902	19A134730P2	Electrolytic: 220 µf +100% -10%, 25 VDCW.
C903	19A700001P6	Ceramic, high dielectric disc: 680 pf ±20%, 50 VDCW.
C904	19A700005P9	Polyester: 0.022 µf ±10%, 50 VDCW.
C905	19A700001P7	Ceramic, high dielectric disc: 1000 pf ±20%, 50 VDCW.
C913	19A700003P7	Tantalum: 10 µf ±20%, 16 VDCW.
C914	19A700001P6	Ceramic, high dielectric disc: 680 pf ±20%, 50 VDCW.
C916	19A700002P19	Ceramic, temperature compensating disc: 33 pf ±5%, 50 VDCW.
C917	19A700226P65	Ceramic: 100 pf ±5%, 100 VDCW; temp coef -750 PPM/°C.
C919 and C920	19A700001P1	Ceramic, high dielectric disc: 100 pf ±20%, 50 VDCW.
C952	19A700001P1	Ceramic, high dielectric disc: 100 pf ±20%, 50 VDCW.
C953	19A700001P7	Ceramic, high dielectric disc: 1000 pf ±20%, 50 VDCW.
D901	19A116783P1	----- DIODES AND RECTIFIERS ----- Rectifier, silicon: 100 VDC blocking, 6 amps.
D902	4037822P1	Silicon, 1000 mA, 400 PIV.
D903	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.
D905	19A134354P3	Diode, optoelectronic: green; sim to Hew. Packard 5082-4955.
J901 and J902	19A134734P1	----- JACKS AND RECEPTACLES ----- Contact, electrical: sim to Molex A 2461 (09-67-1042).
J903	19A134735P1	Contact, electrical: sim to Molex A 2461 (09-67-1072).
J904	19A134736P1	Contact, electrical: sim to Molex 6410 (22-27-2021).
J905	19A700072P9	Connector, printed wiring: sim to Molex 22-03-2101.
J906	19A134733P1	Contact, electrical: sim to Molex A4030 (22-03-2121).
J910	19A116659P151	Connector, printed wiring: sim to Molex 09-75-1111.
J911	19A116659P145	Connector, printed wiring: sim to Molex 09-75-1081.
L905	19B209420P114	----- INDUCTORS ----- Coil, RF: 1.20 µh ±10%, 0.18 ohms DC res max; sim to Jeffers 4436-1K.
P907	19A116659P1	----- PLUGS ----- Connector, printed wiring: 3 contacts; sim to Molex 09-52-3032.
R901	19A700106P57	----- RESISTORS ----- Composition: 560 ohms ±5%, 1/4 w.
R902	19A700106P63	Composition: 1K ohms ±5%, 1/4 w.
R903	19A700106P97	Composition: 27K ohms ±5%, 1/4 w.
R904	19A700106P49	Composition: 270 ohms ±5%, 1/4 w.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST		
MIKE HANGER/HOOKSWITCH 19C320318G3 ISSUE 1		
SYMBOL	GE PART NO.	DESCRIPTION
S6	19A134398P1	----- SWITCHES ----- Push: sim to Chicago Switch S-1527-1.
W1	19A129414G1	----- CABLES ----- Cable: approx 5 feet. Includes (2) contacts 19A116781P5.
S1	19B209261P18	----- MISCELLANEOUS ----- Switch, slide: 1 pole, 2 positions, 0.5 amp VDC or 3 amp VAC at 125 v; sim to Switchcraft 46202LH.
	19B219694P1	Base plate.
	19B219698G4	Housing.
	19B219693P2	Spring.
	19A116768P6	Strain relief. (W1).
	N193P1410C6	Tap screw, phillip head: No. 8-18 x 5/8. (Secures assembly to mounting surface).
	19A134398P101	Plate. (Located on S6).
		ASSOCIATED PARTS
		MIKE KIT 7141414G2
	4031457P1	Support.
	4031458P1	Spring.
	N193P1408C6	Tap screw, phillip head: No. 8-18 x 1/2.
	19A116773P105	Tap screw, Phillips POZIDRIV®: No. 7-19 x 5/16.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST		
TRANSISTORIZED MICROPHONE 19B209670P1 ISSUE 2		
SYMBOL	GE PART NO.	DESCRIPTION
	19A116659P20	Cable connector shell; sim to Molex 09-50-3081.
	19A116781P6	Contact, electrical: wire range No. 22-26 AWG; sim to Molex 08-50-0107. (Quantity 4- Used with 19A116659P20 connector shell).
	NP280575	Faceplate. (GENERAL ELECTRIC).
	4033271G1	Strain relief. (Located on cable 10 inches from connector).
	MP101	Case, front & back with push to talk switch.
	MP102	Cartridge, with leads.
	MP103	Cable assembly.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST

CHANNEL BUSY LIGHT  
19C850634G1  
ISSUE 1

SYMBOL	GE PART NO.	DESCRIPTION
D1901	19A700028P1	----- DIODES ----- Silicon, fast recovery, Fwd. current 75 mA, 75 PIV.
D1902	19A134354P2	Diode, optoelectronic: yellow; sim to HEW. Packard 5082-4555,
P1906	19A134152P63	----- PLUGS ----- Connector, printed wiring: sim to Molex 22-02-2121.
Q1901	19A700022P1	----- TRANSISTORS ----- Silicon, PNP; sim to Type 2N3906.
Q1902	19A700023P1	Silicon, NPN; sim to Type 2N3904.
R1901	19A700019P63	----- RESISTORS ----- Deposited carbon: 0.15M ohms $\pm 5\%$ , 0.25 w.
R1902	19A700019P58	Deposited carbon: 56K ohms $\pm 5\%$ , 0.25 w.
R1903	19A700019P48	Deposited carbon: 8.2K ohms $\pm 5\%$ , 0.25 w.
R1904	19A700019P30	Deposited carbon: 270 ohms $\pm 5\%$ , 0.25 w.
W1901	19A701340G4	----- CABLES ----- Cable, includes 19A127042P2 terminal.
	19B232859P1	----- MISCELLANEOUS ----- Bezel. (Used with D1902).
	19A143463P2	Spacer, sleeve.
	19A700036P422	Screw, thd. forming, Pozidriv: M3-0.5.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST

CARRIER CONTROL TIMER  
19B227440G4  
ISSUE 1

SYMBOL	GE PART NO.	DESCRIPTION
R1903A	19A700019P71	----- RESISTORS ----- Deposited carbon: 0.68 megohm $\pm 5\%$ , 0.25 w.
R1903B	19A700019P68	Deposited carbon: 0.39 megohm $\pm 5\%$ , 0.25 w.
R1903C	3R152P125J	Composition: 1.2 megohms $\pm 5\%$ , 1/4 w.
R1903D	3R152P155J	Composition: 1.5 megohms $\pm 5\%$ , 1/4 w.
R1903E	3R152P235J	Composition: 2.2 megohms $\pm 5\%$ , 1/4 w.
U1902	19D432291G2	----- INTEGRATED CIRCUITS ----- Carrier Control Timer, Century II.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST

UNIVERSAL TONE CABLE  
19B800593G1  
ISSUE 1

SYMBOL	GE PART NO.	DESCRIPTION
	7489183P7	Plug: 9 contacts rated at 7.5 amps max; sim to Winchester M9S-LR-H19C.
	4029851P8	Cable dip.
	19A701430G1	Rubber channel.
	19C301208P6	Insulated sleeving, electrical (Specify length).
	7134854P4	Wire stranded. (Shield).
	19A115871P1	Wire, stranded, white-orange.
	19A115871P3	Wire, stranded, white-brown.
	19A115871P5	Wire, stranded, white-green.
	19A115871P9	Wire, stranded, white-orange-red.
	19A115871P29	Wire, stranded, orange.
	19A115871P30	Wire, stranded, black.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PARTS LIST

SYMBOL	GE PART NO.	DESCRIPTION
		132-512 MHz ANTENNA 19B209568P1
		Whip assembly. 068110-001.
		Whip nut assembly. 068047-001.
		Base nut assembly. 068048-001.
		"O" Ring (LARGE). 007059-122.
		Stud assembly. 068046-001.
		RG58/U Cable, 15 feet. 068115-001.