

## ***Operator's Manual***

**AEGIS™ EDACS® M-PA™  
SELECT MODEL  
PORTABLE RADIO**



## TABLE OF CONTENTS

INTRODUCTION . . . . .	5
CONTROLS . . . . .	5
INDICATORS . . . . .	7
OPERATION . . . . .	10
POWER-UP . . . . .	10
VOICE MODES . . . . .	10
Clear Mode . . . . .	10
Aegis Digital Mode . . . . .	10
Aegis Private And Voice Guard Private Modes (Optional) . . . . .	11
TRUNKED MODE OPERATION . . . . .	13
Receiving A Message . . . . .	14
Sending A Message . . . . .	15
Emergency Operation (Trunked Mode) . . . . .	16
Dynamic Regrouping . . . . .	16

This manual is published by **Ericsson Inc.**, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by **Ericsson Inc.**, at any time and without notice. Such changes will be incorporated into new editions of this manual. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of **Ericsson Inc.**

Copyright © May 1992, Ericsson GE Mobile Communications Inc.

## TABLE OF CONTENTS (Cont.)

Wide Area System Scanning . . . . .	17
Receiving A Message . . . . .	17
Sending A Message . . . . .	18
Emergency Operation (Conventional Mode) . . . . .	19
OPERATING TIPS . . . . .	19
OPERATING RULES AND REGULATIONS . . . . .	20
BATTERY PACKS . . . . .	21
INSTALLING THE BATTERY PACK . . . . .	21
REMOVING THE BATTERY PACK . . . . .	21
CHARGING THE BATTERY PACKS . . . . .	22
RECHARGEABLE BATTERY PACK DISPOSAL . . . . .	22
SWIVEL MOUNT REMOVAL AND REPLACEMENT . . . . .	23
INTRINSICALLY SAFE USAGE . . . . .	23
GLOSSARY . . . . .	25
WARRANTY . . . . .	30
NICKEL-CADMIUM BATTERY WARRANTY . . . . .	31

## **PRODUCT SPECIFICATION FOR CE MARKED EQUIPMENT**

*The M-PA Portable conforms to the following  
Product Specifications.*

### **EUROPEAN STANDARDS:**

*Safety: Not applicable  
EMC: prETS 300 279 (August 1995)  
TTD: Not applicable*

### **SUPPLEMENTARY INFORMATION**

*At this time, the M-PA portable radio may not  
be operated while in a vehicular charger in the  
European Community since it has not been evalu-  
ated for operation in this mode.*

*The M-PA portable radio may be used in both  
trunked and conventional applications.*




Figure 1 - Aegis EDACS M-PA System Model Radio

## **INTRODUCTION**

*The Aegis™ EDACS M-PA™ Select model portable radio is a high-performance two-way radio that provides clear voice, Aegis digital, and Aegis private communications. The radio is also compatible with Voice Guard® communication systems. Personality programming allows maximum integration flexibility into EDACS and conventional radio systems.*

*The radio must be equipped with the encrypt/decrypt option before operation in Aegis private or Voice Guard modes is possible. This option allows the radio to communicate using highly secure state-of-the-art Aegis and Voice Guard encryption and decryption techniques.*

*Operating controls on the radio include a rotatable system/group/channel control knob, rotatable volume control, 16-button keypad, push-to-talk, emergency and monitor buttons. The on/off power switch for the unit is located on the removable battery pack.*

*The 8-digit alphanumeric liquid crystal display (LCD) on the front of the radio displays the operating status of the radio. This backlit display also has sixteen status flags that indicate various op-*

*erating conditions such as private communications enabled, transmitter on, scanning, or emergency mode enabled.*

*The exact operation of your radio will vary depending upon the mode of operation, the radio's programming, and the particular radio system. Consult your radio system's representative for particular features that are programmed into your radio.*

## **CONTROLS**

### **ON/OFF SWITCH**

*The ON/OFF SWITCH is located on the battery pack. Sliding this switch up will supply power to the radio from the battery pack. An audible click will be heard and the "ON" indicator will be exposed. When the radio is turned on, it will perform a power-up self test and then resume operation on the previous operating system, group or channel as displayed in the LCD. Sliding the switch down will turn the radio off.*

### **VOLUME CONTROL KNOB**

*The VOLUME CONTROL KNOB is a rotatable control on the top of the radio used to adjust the*

receiver's audio level in the speaker. Rotating this knob in a clockwise direction will increase the audio level. Counter-clockwise rotation will decrease the audio level. Minimum levels may be programmed into the radio to prevent missed calls due to too low of a volume setting.

## **CONTROL KNOB**

The rotatable 16-position CONTROL KNOB located on the top of the radio may be programmed to select trunked groups and conventional channels or it may be programmed to select systems. See **SYSTEM/GROUP/CHANNEL SELECTION** for details.

A stop plate may be installed under the knob to limit the maximum number of positions to less than sixteen (16). It is normally factory installed for fifteen (15) positions.

## **PTT BUTTON**

Pressing the PTT BUTTON on the side of the radio will enable the radio's transmitter. The "TX" status flag in the display will turn on when the radio is transmitting. Releasing the PTT BUTTON will return operation to receive mode.

When operating in a trunked system, the radio may be programmed to automatically transmit (without the operator pressing the PTT BUTTON) to maintain communication with the site controller. The "TX" status flag will turn on when the radio is transmitting.

## **MONITOR BUTTON**

### Trunked Mode

When operating in trunked mode, pressing the MONITOR BUTTON after an individual call has been received will return the radio to the group call mode. The radio will not respond on an individual basis, but will then transmit group calls when the PTT BUTTON is pressed. The radio will also automatically return to the group call mode after the programmed call-back time-out period expires.

Pressing the MONITOR BUTTON will also clear any digits entered from the numeric keypad and return the radio to the selected group display.

In addition, this button is used to toggle between group and regroup settings if the Dynamic Regrouping mode (with deselect capability) has been enabled by the site controller.

## **Conventional Mode**

*When the radio is operating in conventional mode the MONITOR BUTTON is used to un-squelch the receiver. If programmed for the selected channel, it will also toggle Channel Guard (CG) and/or Type 99 (T99) signaling on and off.*

*Momentarily pressing the MONITOR BUTTON will unsquelch the receiver. If programmed, pressing and holding the button for at least one (1) second will toggle CG and/or T99 signaling on or off. After a T99 call has been received, pressing the MONITOR BUTTON will reset the radio for the next call. Note: Selecting another channel will turn CG and T99 signaling back on if programmed for the channel.*

## **EMERGENCY BUTTON**

*When operating in trunked mode, pressing and holding the red EMERGENCY BUTTON on top of the radio for approximately one (1) second will initiate an emergency call with voice operation on the programmed home group. If no home group is programmed into the radio, voice operation will be on the selected group.*

*In conventional mode, initiating an emergency call by pressing the EMERGENCY BUTTON will cause the radio to transmit GE-STAR signaling on the programmed emergency channel. If no emergency channel is programmed, GE-STAR will be transmitted on the selected channel.*

## **INDICATORS**

*The radio's liquid crystal display (LCD) located on the front panel has eight (8) alphanumeric characters and sixteen (16) status flags. This display provides indications of the current operating system, group or channel and it displays various other messages such as special call ID names or numbers, and telephone interconnect numbers.*

*LCD backlighting will turn on for a short period anytime an active button is pressed or the CONTROL KNOB is rotated. Backlighting may be programmed to remain off at all times.*

*The sixteen (16) status flags located along the top and bottom of the display indicate operating modes and conditions as follows:*




Figure 2 - Liquid Crystal Display

- EMG** EMerGency mode - On indicates an emergency call has been initiated by the user. Flashing indicates an emergency call has been received.
- NC** No Control channel - On indicates the radio is not receiving the trunked control channel. Flashing indicates the trunked system is in a failsoft condition (supervisory radios only).
- HI** High power transmit - On indicates the selected system or channel has been programmed for high power transmit operation. Off indicates low power transmit.
- MSG** MeSsaGe - Flashing indicates an individual call has been received (trunked mode).

**T99** Type 99 tone decode - On indicates Type 99 tone decoding is enabled on the selected conventional channel. Flashing indicates a T99 selective call has been received and the radio must be reset to receive another T99 call.

**CNV** CoNVenTional mode - On indicates the radio is operating in the conventional mode.

**SPC** SPecial Call mode - On indicates the special call mode has been enabled (trunked mode).

**PVT** PriVaTe mode - On indicates private mode is enabled and the radio will transmit encrypted messages on the selected group or channel. Flashing indicates an encrypted message is being received.

**TX** Transmitter enabled - On when the radio is transmitting.

**BSY** BuSY - When in trunked mode, on indicates the radio is receiving a call; flashing indicates a call has been queued. In conventional mode, on indicates a carrier is being received.



**CG** Channel Guard - On indicates Channel Guard encode/decode is enabled on the selected conventional channel.

**BAT** BATTERY low - On indicates the battery pack's charge is low.

## **UNIVERSAL DEVICE CONNECTOR**

The Universal Device Connector (UDC) is located on the side of the radio just above the PTT and MONITOR BUTTONS. This connector provides connections for the external accessories such as a headset, a speaker-mike, or an emergency lanyard. When the radio is locked in a vehicular charger/repeater, the UDC provides the audio and control connections between the radio and the vehicular charger/repeater. The UDC is also used by the maintenance personnel when the radio is programmed.

## **ALERT TONES**

The radio sounds five (5) basic alert tones or "beeps" to indicate various operating conditions. Alert tones may be programmed to remain off at all times.

- 500 Hz Tone – trunked failure tone - sounds when a trunked failure has occurred (call

denied, failed confirmation).

- low battery - sounds when the battery pack's charge is low.

- 800 Hz Tone – private mode disabled - on a conventional channel, sounds when the PTT BUTTON is pressed if private transmit mode has previously been disabled.

- 1000 Hz Tone – alert tone - sounds when a button is pressed and a status change occurs
  - channel access tone - sounds when a trunked channel has been assigned and it is clear to talk.

- 1200 Hz Tone – private mode channel access tone - sounds when the radio is in the private transmit mode, a trunked channel has been assigned and it is clear to talk.

- *2500 Hz Tone – call queued tone - sounds when a trunked call is queued.*

## **OPERATION**

### **POWER-UP**

*After the battery pack and antenna have been installed, turn the radio on by sliding the ON/OFF SWITCH on the battery pack up. After the radio has completed a power-up self-test, it will begin operation on the last operating state as displayed in the LCD. If programmed on, the power-up alert tone (beep) will be heard.*

*If the radio was previously operating in a trunking system and communication with this system's control channel cannot be established, the "NC" status flag will turn on. This may occur if, for example, the radio is out of range of the previous trunking site. It may be necessary move to another location, select another trunking system, or a conventional channel.*

### **VOICE MODES**

*Each system (trunked or conventional) in the radio is programmed for either Aegis or Voice*

*Guard communications. Aegis programmed systems have three (3) different voice modes: clear, digital and private. Voice Guard systems have two (2) voice modes: clear and private. The voice modes are programmed on a per-group basis within each trunked system and on a per-channel basis within each conventional system. A radio must be equipped with the encrypt/decrypt option before it will operate in Aegis private or Voice Guard modes.*

#### **Clear Mode**

*Aegis clear and Voice Guard clear modes are identical voice modes in which the radio transmits and receives only clear (analog) voice signals. These analog signals are non-digitized and non-encrypted. Clear mode transmissions can be easily monitored by unauthorized persons. Groups and channels programmed for clear operation cannot transmit or receive Aegis digital or private messages.*

#### **Aegis Digital Mode**

*Aegis digital mode allows the radio to transmit and receive digitized voice signals. Aegis digital signals provide improved weak signal performance and they cannot be easily monitored with a*

standard receiver. Groups and channels programmed for Aegis digital operation transmit only digital signals and they can receive clear and digital signals. In other words, with a certain group or channel selected, the operator cannot change from the digital transmit mode but the radio will receive clear or digital signals. Private (encrypted) messages cannot be received when the radio is in Aegis digital mode.

### Aegis Private And Voice Guard Private Modes (Optional)

The Aegis private and Voice Guard private modes allow the radio to transmit and receive encrypted messages. To operate in these voice

#### **TRANSMIT/RECEIVE MODE COMPATIBILITY FOR AEGIS OPERATION**

GROUP/CHANNEL PROGRAMMING (TRANSMIT)	RECEIVE CAPABILITY		
	CLEAR	DIGITAL	PRIVATE
CLEAR	Yes	No	No
DIGITAL	Yes	Yes	No
PRIVATE	Yes	No	Yes *

\* assumes the proper cryptographic key is loaded

modes, the radio must be equipped with the optional encrypt/decrypt feature and the transmitting and receiving units must have identical cryptographic keys.

Aegis transmissions cannot be received by a radio set to receive a Voice Guard transmission. Accordingly, a Voice Guard transmission cannot be received by a radio set to receive an Aegis transmission.

Cryptographic keys are transferred into the radio using a cryptographic Keyloader. Up to seven (7) different cryptographic keys, numbered 1 - 7, can be transferred from a Keyloader and stored in the radio. An individual key is automatically selected on a per-group/channel basis according to the radio's programming. Groups and

#### **TRANSMIT/RECEIVE MODE COMPATIBILITY FOR VOICE GUARD OPERATION**

GROUP/CHANNEL PROGRAMMING (TRANSMIT)	RECEIVE CAPABILITY	
	CLEAR	PRIVATE
CLEAR	Yes	No
PRIVATE	Yes	Yes *

\* assumes the proper cryptographic key is loaded

*channels within Aegis systems can be programmed for keys 1 - 6. Groups and channels within Voice Guard systems can be programmed for keys 1 - 7.*

*DES radios require a DES Keyloader (option V4025). Operating details on the DES Keyloader are contained in LBI-31541. VGE radios require a VGE Keyloader (option V4028). See LBI-31685 for operating details on the VGE Keyloader.*

*When operating on a group or channel programmed for private mode, all transmissions will be private transmissions and the radio will receive clear and private signals. The "PVT" status flag in the display turns on when the private mode is enabled.*

**NOTE**

*Before private messages can be sent or received, one or more cryptographic keys must be transferred into the radio from the Keyloader.*

## ***Transferring Keys Into The Radio***

*The following procedure outlines basic key transferring steps.*

- 1. Turn the radio off.*
- 2. Plug the modular connector of the Keyloader cable into the Keyloader's modular jack.*
- 3. Connect the Keyloader cable to the UDC on the radio.*
- 4. Press the PWR button on the Keyloader and wait for the Keyloader to display "MASTER MODE".*
- 5. Press the TRN button on the Keyloader. If necessary, select a different cryptographic key to be transferred into the radio.*
- 6. Turn the radio on. The display should read "KEY LOAD".*

7. *Press the EXE button on the Keyloader to transfer the key. The Keyloader will display "GOOD 1.x TRANSFER" where "x" is the selected cryptographic key number.*
8. *Disconnect the cable from the radio's UDC. A single beep will be heard from the radio's speaker if the power-up alert tone is enabled. The radio will change to the selected group or channel as indicated in the display.*

## **Key Zero**

*The cryptographic keys stored in DES version radios can be zeroed or "dumped" by removing the battery pack for several minutes (typically three) or disassembling the radio. Either action will clear all of the keys stored in a DES radio.*

*The cryptographic keys stored in VGE version radios cannot be zeroed once they are transferred into the unit. A different key must be loaded into the same location(s) to prevent unauthorized communications.*

## **Receiving An Encrypted Message**

*When receiving, the radio automatically switches between clear or private operation. If the transmission being received is an encrypted transmission, it will be decrypted, the "PVT" status flag will flash, the receiver will unsquelch, and the message will be heard in the speaker. For this to occur, the selected group or channel must be programmed for private operation and the correct cryptographic key must be loaded into the radio.*

## **Transmitting An Encrypted Message**

*Select the desired group or channel that has been programmed for private operation. The "PVT" status flag will turn on when a group or channel programmed for private operation is selected. Continue with standard transmission procedures.*

## **TRUNKED MODE OPERATION**

*Digital trunking provides fast communication access. In this mode the operator selects a communication system and group and the communication channel is allocated through digital signaling with the site. The following operation is*

*applicable to clear, digital and private operation unless otherwise noted.*

### **Receiving A Message**

- 1. Slide the ON/OFF SWITCH on the battery pack to the on position. The radio will initiate and complete the power-up self-test then the system's name and "NC" status flag will be displayed until a control channel is located. When the control channel is located, the "NC" status flag disappears and the group name is displayed.*
- 2. Adjust the VOLUME CONTROL to an approximate mid-range position.*
- 3. Select the desired system and group using the CONTROL KNOB. The display indicates the selected group.*
- 4. The radio is now ready to receive messages.*
- 5. GROUP CALL - When a group call is received, the radio unscquelches on the assigned channel and the "BSY" status flag turns on. The group name or the*

*originator's ID (depending on programming) is displayed. Adjust the volume as necessary.*

*INDIVIDUAL CALL - If an individual call (a call directed to only one radio) is received, the radio will unscquelch on the assigned channel and the "BSY" status flag will turn on. "\*\*INDV\*\*", originators ID, or the caller's name (if programmed) is displayed and the "MSG" status flag flashes. Adjust the volume as necessary.*

*Responding to an individual call prior to the programmed call-back time-out will automatically direct the transmission to the originating unit on an individual basis.*

*Pressing the MONITOR BUTTON after an individual call has been received will return the radio to the group call mode. The radio will not respond on an individual basis, but will then transmit group calls when the PTT BUTTON is pressed. The radio will also automatically return to the group call mode after the pro-*

*grammed call-back time-out period expires.*

*ENCRYPTED MESSAGE - If the transmission being received is an encrypted transmission and the selected group is programmed for private operation and the correct cryptographic key is loaded into the radio, then the receiver will un-squelch, the "PVT" status flag will flash and the private message will be heard in the speaker. The radio automatically switches between clear or private operation when it is receiving on a group or channel programmed for private operation.*

### **Sending A Message**

- 1. Turn the radio on, set the receive audio level and select the desired system and group. If the selected group is programmed for private transmit mode, the "PVT" status flag in the display will turn on.*
- 2. Observe the display for the absence of the "BSY" status flag to ensure no one is transmitting on the selected group.*

- 3. Press and hold the PTT BUTTON. The radio will perform the necessary signaling required to obtain a communication channel.*
- 4. When the channel has been acquired, the "TX" and "BSY" status flags are displayed and the channel access alert tone (one beep) is heard.*
- 5. Hold the radio approximately three inches from your mouth and speak into the microphone in a normal voice.*
- 6. Release the PTT BUTTON when the transmission is complete. If the transmission exceeds the programmed Carrier Control Timer limit, the radio will unkey and an alert tone will sound.*
- 7. Listen for a reply.*

## **NOTE**

*If a group programmed for private operation has been selected and there is no key in the radio for the selected group, "NO KEY x" (where "x" is the key number) will periodically flash in the display. If a transmission is attempted, "NO KEY x" will show in the display and the radio will emit a series of beeps and will not transmit.*

## **Emergency Operation (Trunked Mode)**

### **Receiving An Emergency Call**

*If the radio receives an Emergency Channel Assignment in trunked mode, an alert tone sounds and the "EMG" status flag starts flashing. Follow standard emergency procedures.*

### **Sending An Emergency Call**

- 1. To enable an emergency transmission, press and hold the EMERGENCY BUTTON (small red button near antenna) for approximately one second. The radio*

*transmits an emergency message until an Emergency Channel Assignment is received. Upon receipt, the "EMG" status flag turns on and the radio begins operation on the selected group or the home group, depending upon programming.*

- 2. Press the PTT BUTTON and speak into the microphone in a normal voice.*
- 3. Release the PTT BUTTON when the transmission is complete and listen for a reply.*

## **Dynamic Regrouping**

*Dynamic Regrouping is a feature which allows the System Manager to dynamically program new groups into selected radios. Upon development of the regrouping plan, the site controller sends each radio the regroup plan number, knob setting(s), and activate/deactivate commands.*

*When the radio is regrouped, it will alert the user and the display will indicate "REGRP nn" (nn = 01 - 08 depending upon the CONTROL KNOB setting).*



*If the regroup plan has deselect capability active on the selected system, press the MONITOR BUTTON to toggle between the group and regroup modes.*

### **Wide Area System Scanning**

*EDACS M-PA radios may be programmed for wide area system scan operation for multi-site applications. Upon the loss of the currently selected system's control channel, radios may be programmed to automatically scan the control channels of up to six other systems. If a new control channel is found, the radio will switch to the new system and sound an alert tone. Group selection may change upon switching to the new system.*

*The radio may also be programmed for priority wide area system scan. A priority system may be assigned to each system programmed into the radio. Radios programmed in this manner will scan the priority trunked system's control channel once every one, two, three or four minutes (programmable). This priority scan timer is reset each time the PTT BUTTON is pressed.*

### **CONVENTIONAL MODE OPERATION**

*The procedures that follow describe conventional mode operation. Follow these procedures if operating in a conventional system. Each conventional channel many have one or more features, such as Channel Guard, programmed when the channel is selected. The following operation is applicable to clear, digital and private operation unless otherwise noted.*

#### **Receiving A Message**

- 1. Slide the ON/OFF SWITCH on the battery pack to the on position. The radio will initiate and complete the power-up self-test and beep if the power-up alert tone is programmed on.*
- 2. Using the CONTROL KNOB select a conventional channel. The display will indicate the selected channel's name.*
- 3. Press the MONITOR BUTTON to disable squelch and adjust the VOLUME CONTROL for the approximate desired speaker audio level.*

## NOTE

Pressing the MONITOR BUTTON may affect Channel Guard and/or Type 99 tone signalling if programmed for the selected channel.

4. When a message is received (and the correct Channel Guard or Type 99 signal is decoded, if programmed and enabled), the receiver will unsquelch and the message will be heard in the speaker.

If the transmission being received is an encrypted transmission and the selected channel is programmed for private operation and the correct cryptographic key is loaded into the radio, then the receiver will unsquelch, and the "PVT" status flag will flash and the Voice Guard message will be heard in the speaker. The radio automatically switches between clear or private operation when it is receiving.

5. Adjust the volume as necessary.

## Sending A Message

1. Turn the radio on, set the receive audio level and select the desired channel. If the selected channel is programmed for private mode operation, the "PVT" status flag in the display will turn on.
2. Ensure no one is transmitting on the selected channel by pressing the MONITOR BUTTON to disable squelch or observing the display for the absence of the "BSY" status flag. If the Channel Busy Lockout feature is programmed for the selected channel, the radio will not transmit when the channel is busy.
3. Press and hold the PTT BUTTON. The "TX" and "BSY" status flags are displayed.
4. Hold the radio approximately three inches from your mouth and speak into the microphone in a normal voice.
5. Release the PTT BUTTON when the transmission is complete. If the transmission exceeds the programmed Car-

rier Control Timer limit, the radio will unkey and an alert tone will sound.

6. Listen for a reply.

**NOTE**

*If a channel programmed for private operation has been selected and there is no key in the radio for the selected channel, "NO KEY x" (where "x" is the key number) will periodically flash in the display. If a transmission is attempted, "NO KEY x" will show in the display and the radio will emit a series of beeps and will not transmit.*

*If a channel programmed for Aegis digital operation is selected, all transmissions will be digital transmissions and the radio will receive clear and digital signals.*

**Emergency Operation (Conventional Mode)**

To enable an emergency transmission, press the EMERGENCY BUTTON for approximately one (1) second. If an emergency channel is pro-

grammed, the radio will switch to the emergency channel, turn on the "EMG" status flag and transmit GE-STAR emergency signaling. If no emergency channel is programmed, the radio will transmit GE-STAR emergency signaling on the selected channel.

**OPERATING TIPS**

*Antenna location and condition is important when operating a portable radio. Operating the radio in low areas of terrain, under power lines or bridges, inside of a vehicle or in a metal or steel framed building can severely reduce the range of the unit. Mountains and buildings can also reduce the range of the unit.*

*In areas where transmission or reception is poor, some improvement may be obtained by insuring that the antenna is vertical. Moving a few yards in another direction or moving to a higher elevation may also improve communication. Vehicular operation can be aided with the use of an externally mounted antenna.*

*Battery condition is another important factor in the trouble free operation of a portable radio. Always properly charge the batteries.*

*Always observe all of the Federal Communication Commission's rules and regulations.*

## **OPERATING RULES AND REGULATIONS**

*Two-way FM radio systems must be operated in accordance with the rules and regulations of the Federal Communications Commission (FCC). As an operator of two-way radio equipment, you must be thoroughly familiar with the rules that apply to your particular type of radio operation. Following these rules will help eliminate confusion, assure the most efficient use of the existing radio channels, and result in a smoothly functioning radio network.*

*When using your two-way radio, remember these rules:*

- 1. It is a violation of FCC rules to interrupt any distress or emergency message. As your radio operates in much the same way as a telephone "party line", always listen to make sure that the channel is clear and/or observe the display for the absence of the "BSY" status flag before transmitting. Emergency calls have priority over all other messages. If someone is sending an emergency message*

*- such as reporting a fire or asking for help in an accident - KEEP OFF THE AIR!*


- 2. The use of profane or obscene language is prohibited by Federal law.*
- 3. It is against the law to send false call letters, or false distress or emergency messages.*
- 4. The FCC requires that you keep conversations brief and confine them to business. To save time, use coded messages whenever possible.*
- 5. Using your radio to send personal messages (except in an emergency) is a violation of FCC rules. You may send only those messages that are essential for the operation of your business.*
- 6. It is against Federal law to repeat or otherwise make known anything you overhear on your radio. Conversations between others sharing your channel must be regarded as confidential.*

7. *The FCC requires that you identify yourself at certain specific times by means of your call letters. Refer to the rules that apply to your particular type of operation for the proper procedure.*
8. *No changes or adjustments shall be made to the equipment except by an authorized or certified electronic technician.*

## **BATTERY PACKS**

### **INSTALLING THE BATTERY PACK**

1. *Ensure the ON/OFF SWITCH on battery pack is in the off position.*
2. *Hold the radio and battery pack with the back of them facing you.*
3. *Align the battery pack and radio slide grooves. See Figure 3.*
4. *Slide the battery pack fully into the radio until the battery release latch clicks into place.*



*Figure 3 - Installing the Battery Pack*

### **REMOVING THE BATTERY PACK**

1. *Ensure the ON/OFF SWITCH on the battery pack is in the off position.*
2. *Press down on the battery release latch and slide the battery pack out in the direction of the release latch. See Figure 4.*



Figure 4 - Removing the Battery Pack

## **CHARGING THE BATTERY PACKS**

After receiving a new rechargeable battery pack from the factory, it should be fully charged before placing it into service. This also applies to rechargeable batteries that have been stored for long periods. When the battery pack requires charging the radio will signal the operator with an alert tone and the "BAT" status flag will turn on.

Chargers are available with nominal charge times of 1 hour (rapid) and 14 hours (standard).

Combinations include single (1) and multi (5) position, standard and rapid charge units. In addition, the vehicular chargers/repeaters simultaneously charge the battery packs while the radio is operating. For specific instructions refer to the applicable charger Operating Manual.

The rechargeable batteries used with the radio can develop a reduced capacity condition sometimes called the "Memory Effect". This condition can occur when a battery is continuously charged for long periods or when a regularly performed duty cycle allows the battery to expend only a limited portion of its capacity. The battery pack may show a severe decrease in its ability to deliver full capacity for an extended period. Any rechargeable battery pack showing signs of reduced capacity should be returned to a qualified service center for inspection.

## **RECHARGEABLE BATTERY PACK DISPOSAL**



The product you have purchased contains a rechargeable, recyclable battery. At the end of its useful life under various state and local laws it may be illegal to dispose of

*this battery into the municipal waste stream. Check with your local solid waste officials for details concerning recycling options or proper disposal in your area. Call Toll Free 1-800-8-BATTERY for information and/or procedures for returning rechargeable batteries in your state.*

### **SWIVEL MOUNT REMOVAL AND REPLACEMENT**

*To remove the swivel mount, slide a flat blade screwdriver underneath the spring retainer and twist. While twisting, slide the swivel mount out from under the holder.*

*To replace the swivel mount, place the end of the swivel in the grooves in the radio and slide the mount up until it snaps in place.*

### **INTRINSICALLY SAFE USAGE**

*Selected portable radios with appropriate factory installed F4 Options are certified as Intrinsically Safe by the Factory Mutual Research Corporation. Intrinsically Safe approval includes Class I, II, III, Division 1 hazardous locations in the presence of Groups C, D, E, F and G atmospheres. Non-Incendive approval includes Class I,*



*Figure 5 - Swivel Mount Removal and Replacement*

*Division 2 hazardous locations in the presence of Groups A, B, C and D atmospheres.*

*Hazardous locations are defined in the National Electrical Code. Useful standards NFPA 437A and NFPA 437M for the classifications of hazardous areas can be ordered from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.*

## **BATTERY PACKS**

*Only battery packs identified with a green latch shall be used with a portable radio that is rated and labeled as Factory Mutual Intrinsically Safe. Use of nonspecified battery packs voids Factory Mutual approval. The following battery pack options are approved for use in intrinsically safe radios.*

PAPA1F	<i>Rechargeable Battery Pack, Extra High Capacity (Tall Case)</i>
PAPA1G	<i>Rechargeable Battery Pack, High Capacity (Short Case)</i>

## **ACCESSORIES**

*The accessories that follow are approved for use with intrinsically safe radios. Use of accessories other than those listed voids Factory Mutual approval.*

PAAB1A	<i>Headset/Microphone</i>
PAAC1J	<i>Earpiece Kit</i>
PAAC1B	<i>GE-STAR Lanyard</i>
PAAE3R	<i>Speaker/Microphone</i>

PAAE1B	<i>Speaker/Microphone with GE-STAR Lanyard</i>
PAAE3T	<i>Speaker/Microphone/Antenna</i>
PANC1B	<i>Antenna, 136- 151 MHz, Helical</i>
PANC1F	<i>Antenna, 440-470MHz, Helical</i>
PANC1L	<i>Antenna,378-440MHz, Whip</i>
PANC1N	<i>Antenna,440-512MHz, Whip</i>
PANC1H	<i>Antenna, 806 - 870 MHz, Elevated Feed</i>
PANC1K	<i>Antenna, 806-870MHz, Flex</i>
PANC1U	<i>Antenna, 378-440MHz, Helical</i>
PANC1Z	<i>Antenna,896-941MHz, Whip</i>
PAHC1C	<i>Belt Clip</i>
PAHC1D	<i>Swivel Mount with Belt Loop</i>
PAHC3W	<i>Case, Leather, with Belt Loop (Short Case)</i>
PAHC1K	<i>Shoulder Strap, Leather, with Mounting Plate</i>
PAHC5R	<i>Holster, Plastic.</i>



## GLOSSARY

<i>clear mode -</i>	<i>communicating in an analog format which is non-digitized and non-encrypted.</i>	<i>CCT -</i>	<i>Carrier Controlled Timer - a programmable timer that will disable a transmission if the timer length is exceeded.</i>
<i>control channel -</i>	<i>a radio channel in a trunked system that is used to digitally communicate with the radios operating on the system when they are not engaged in active voice communications.</i>	<i>CG -</i>	<i>Channel Guard - a method of controlling squelch with a tone or digital code (Channel Guard is the tradename for coded squelch).</i>
<i>conventional channel -</i>	<i>a radio channel (transmit/receive) that is allocated for conventional (non-trunked) use and may be manually selected by the operator.</i>	<i>DES -</i>	<i>Data Encryption Standard - a Federally accepted encryption/decryption algorithm used to scramble or de-scramble a signal.</i>
<i>conventional mode -</i>	<i>communicating on radio channels allocated for conventional use.</i>	<i>decryption -</i>	<i>the process of decoding or descrambling a signal according to a predetermined algorithm.</i>
<i>cryptographic key -</i>	<i>the number or code used by the encryption and decryption circuitry to encode and decode a signal.</i>	<i>digital mode -</i>	<i>communicating using digitized voice signals.</i>
		<i>encryption -</i>	<i>the process of encoding or scrambling a signal according to a predetermined algorithm.</i>

<i>private mode -</i>	<i>communicating in an encrypted format (scrambled).</i>	<i>trunked system -</i>	<i>a set of one or more trunked groups.</i>
<i>queuing -</i>	<i>the process that occurs when all channels in a trunked system are busy and calls must be addressed on a priority basis.</i>	<i>VGE -</i>	<i>a proprietary encryption/decryption algorithm used to scramble or descramble a signal.</i>
<i>site controller -</i>	<i>the computer controlled radio equipment at the repeater site that controls a trunking system.</i>	<i>T99 -</i>	<i>Type 99 - a method of opening squelch for selective page operations using sequential tones.</i>
<i>System Manager -</i>	<i>a computer that performs the data basing and system monitoring for the site controller.</i>	<i>working channel -</i>	<i>a radio channel (transmit/receive) that is automatically assigned by the site controller for voice or data communications.</i>
<i>trunked group -</i>	<i>a radio communications path shared by two or more users</i>		
<i>trunked radio system -</i>	<i>a radio system in which a limited number of radio channels is dynamically allocated to groups of people for communication purposes.</i>		



## *NOTES*

## *NOTES*

## WARRANTY

- A. *Ericsson Inc. (hereinafter "Seller") warrants to the original purchaser for use (hereinafter "Buyer") that Equipment manufactured by Seller shall be free from defects in material, workmanship and title, and shall conform to its published specifications. With respect to any Equipment not manufactured by Seller (except for integral parts of Seller's Equipment to which the warranties set forth above shall apply). Seller gives no warranty, and only the warranty, if any, given by the manufacturer shall apply. Batteries are excluded from this warranty but are warranted under a separate Nickel-Cadmium Battery Warranty.*
- B. *Seller's obligations set forth in Paragraph C below shall apply only to failures to meet the above warranties (except as to title) occurring within the following periods of time from date of sale to the Buyer and are conditioned on Buyer's giving written notice to Seller within thirty (30) days of such occurrence:*
- 1. for fuses, incandescent lamps, vacuum tubes and non-rechargeable batteries, operable on arrival only.*
  - 2. for parts and accessories (except as noted in B.1) sold by Seller's Service Parts Operation, ninety (90) days.*
  - 3. for all other Equipment of Seller's manufacture, one (1) year.*
- C. *If any Equipment fails to meet the foregoing warranties, Seller shall correct the failure at its option (i) by repairing any defective or damaged part or parts thereof, or (ii) by making available at Seller's factory any necessary repaired or replacement parts. Any repaired or replacement part furnished hereunder shall be warranted for the remainder of the warranty period of the Equipment in which it is installed. Where such failure cannot be corrected by Seller's reasonable efforts, the parties will negotiate an equitable adjustment in price. Labor to perform warranty service will be provided at no charge only for the Equipment covered under Paragraph B.3, and only during the first three (3) months following the date of sale to the Buyer. Thereafter, labor will be charged at prevailing rates. To be eligible for no-charge labor, service must be performed by an Authorized Service Center or other Servicer approved for these purposes either at its place of business during normal business hours, for mobile or personal equipment, or at the Buyer's location, for fixed location equipment. Service on fixed location equipment more than thirty (30) miles from the Service Center or other approved Servicer's place of business will include a charge for transportation. .*
- D. *Seller's obligations under Paragraph C shall not apply to any Equipment, or part thereof, which (i) has been modified or otherwise altered other than pursuant to Seller's written instructions or written approval or, (ii) is normally consumed in operation or, (iii) has a normal life inherently shorter than the warranty periods specified in Paragraph B, or (iv) is not properly stored, installed, used, maintained or repaired, or, (v) has been subjected to any other kind of misuse or detrimental exposure, or has been involved in an accident.*
- E. *The preceding paragraphs set forth the exclusive remedies for claims (except as to title) based upon defects in or nonconformity of the Equipment, whether the claim is in contract, warranty, tort (including negligence), strict liability or otherwise, and however instituted. Upon the expiration of the warranty period, all such liability shall terminate. The foregoing warranties are exclusive and in lieu of all other warranties, whether oral, written, expressed, implied or statutory. NO IMPLIED OR STATUTORY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE SHALL APPLY. IN NO EVENT SHALL THE SELLER BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, INDIRECT OR EXEMPLARY DAMAGES.*

*This warranty applies only within the United States.  
1-800-592-7711 (Outside USA, 804-592-7711)*

ECX-362S

## NICKEL-CADMIUM BATTERY WARRANTY

- A. Ericsson Inc. (hereinafter "Seller") warrants to the original purchaser for use (hereinafter "Buyer") that nickel-cadmium batteries supplied by Seller shall be free from defects in material and workmanship, and shall conform to its published specifications for a period of twelve (12) months from the date of purchase.
- B. For purposes of this warranty, batteries shall be deemed defective if (1) the battery capacity is less than 80% of rated capacity, or (2) the battery develops leakage.
- C. If any battery fails to meet the foregoing warranty, Seller shall correct the failure by issuing a replacement battery upon receipt of the defective battery at an Authorized Service Center (ASC). To obtain the name and address of an ASC, ask your salesperson, consult the Yellow Pages, or call the number printed at the bottom of this page.
- D. Replacement batteries shall be warranted only for the remaining unexpired warranty period of the original battery. This warranty becomes void if:
  - (1) The battery has been subjected to any kind of misuse, detrimental exposure, or has been involved in an accident.
  - (2) The battery is used in equipment or service other than the radio equipment for which it is specified.
- E. The preceding paragraphs set forth the exclusive remedies for claims (except as to title) based upon defects in or non-conformity of any battery, whether the claim is in contract, warranty, tort (including negligence), strict liability or otherwise, and however instituted. Upon the expiration of the warranty period, all such liability shall terminate. The foregoing warranties are exclusive and in lieu of all other warranties, whether oral, written, expressed, implied or statutory. **NO IMPLIED OR STATUTORY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE SHALL APPLY. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, INDIRECT OR EXEMPLARY DAMAGES.**

*This warranty applies only within the United States.  
1-800-592-7711 (Outside USA, 804-592-7711)*

# EMERGENCY NUMBERS

---

Police

---

State Police

---

Fire

---

Poison Control

---

Ambulance

---

Life Saving and  
Rescue Squad

---

**Ericsson Inc.**

Private Radio Systems

Mountain View Road

Lynchburg, Virginia 24502

1-800-592-7711 (Outside USA, 804-592-7711)

Printed in U.S.A.