


# MAINTENANCE MANUAL

## C-800 SERIES CONTROL UNIT (PUSHBUTTON CONTROL)



### SPECIFICATIONS \*

Pushbutton Control Module	19D417661G1-3
Number of Frequencies	1, 2 or 4
Supply Voltage	13.8V $\pm 20\%$
Current Drain (Control Module Only)	90 Milliamperes (Maximum)
Controls	Power-On Volume Squelch Channel Selector Switch Option Switch Blanker Disable Switch (Optional)
Indicators	Power On Light Transmit Light Channel Busy Light Option Light
Dimensions (H X W X D)	3 1/8" x 7 1/4" x 7 1/8"

\*These specifications are intended primarily for the use of the serviceman. Refer to the appropriate Specification Sheet for the complete specifications.

**C-800 SERIES CONTROL UNIT  
(PUSHBUTTON CONTROL)**

## TABLE OF CONTENTS

SPECIFICATIONS .....	Cover
COMBINATION NOMENCLATURE .....	iii
DESCRIPTION .....	1
CIRCUIT ANALYSIS .....	2
Pushbutton and Switch Options .....	2
Component Board Options .....	3
MAINTENANCE .....	6
OUTLINE DIAGRAMS	
C-800 Series Pushbutton Control Unit .....	8
C-800 Series Backplane Board .....	12
SCHEMATIC DIAGRAMS	
Pushbutton Control Module .....	9
Backplane Board and Power/Control Cable (MASTR II) .....	13
Channel Guard Monitor Switch .....	11
Dual Control Switch .....	11
Fixed Squelch Modification .....	11
Power/Control Cable (MASTR Executive II Interface) .....	18
Control Module Extender Board .....	19
PARTS LIST & PRODUCTION CHANGES	
Control Unit & Associated Assemblies .....	10
Backplane Board 19D423729G1 .....	14
MICROPHONE & HOOKSWITCH .....	15
HANDSET & HOOKSWITCH .....	16
SPEAKER .....	17

## WARNING

Although the highest DC voltage in the radio is supplied by the vehicle battery, high current may be drawn under short circuit conditions. These currents can possibly heat metal objects such as tools, rings, watchbands, etc. enough to cause burns. Be careful when working near energized circuits!

High-level RF energy in the transmitter Power Amplifier assembly can cause RF burns. KEEP AWAY FROM THESE CIRCUITS when the transmitter is energized!

## COMBINATION NOMENCLATURE

1st Digit	2nd Digit	3rd Digit	4th Digit	5th Digit	6th Digit	7th Digit	8th & 9th Digits
<b>Mechanical Package</b>	<b>System Voltage</b>	<b>Channel Capacity</b>	<b>Number of Operating Channels</b>	<b>Microphone or Handset</b>	<b>Option Deck</b>	<b>Upper Option Deck</b>	<b>Control Unit Series</b>
<b>R</b> Control Unit with Bracket, Speaker and Cables MASTR II App.	<b>1</b> ±12 VDC MASTR II App.	<b>A</b> 1 Channel	<b>A</b> One	<b>1</b> None	<b>S</b> No Option	<b>S</b> No Option	<b>18</b> C-800
<b>M</b> Control Unit with Brackets only	<b>2</b> ±24 to 48 VDC	<b>C</b> 2 Channel	<b>C</b> Two	<b>2</b> Std. Microphone		<b>A</b> PSLM, 4-Freq.	
<b>T</b> Control Unit with Bracket, Speaker and Cables MASTR Executive II App.	<b>3</b> +12 VDC (Negative Gnd.)	<b>F</b> 4 Channel	<b>E</b> Three	<b>3</b> Std. Mike w/HS		<b>C</b> T99 Decoder, 2-Tone	
	<b>4</b> -12 VDC (Positive Gnd)		<b>F</b> Four	<b>4</b> Handset & Hookswitch		<b>D</b> T99 Decoder, 4-Tone	
				<b>5</b> Noise Canc Microphone		<b>E</b> T90 Enc./Dec.	
				<b>6</b> Noise Canc Mike w/HS		<b>F</b> T90 Decoder	
						<b>G</b> T90 Encoder	
						<b>H</b> Channel Guard 2 Encode Tones	
						<b>J</b> Channel Guard 8 Encode Tones	
						<b>K</b> Public Address and Ext. Speaker	
						<b>L</b> Five Auxiliary Switches	

## DESCRIPTION

The C-800 Control Unit with pushbutton control is an attractively styled, highly functional unit that provides maximum versatility in radios with up to four RF channels. (See Figure 1). This control unit can be used to control either the MASTR II or MASTR Executive II "S" Series radios. The C-800 series control unit may be equipped with up to three different pushbutton switch options, one of six different component board options, a Noise Blanker Disable switch, a Universal tone connector and may be modified to include the Fixed Squelch option.

The pushbutton switch options include Channel Guard Monitor (MON), Internal/External Speaker (EXT) or Dual Control (CONT) when two control units are used to control a single radio. The component board options include the following:

- Multi-tone Channel Guard Encoders (2 or 8 tones)
- Priority Search Lock Monitor (4 or 8 channels)
- Type 90 Tone Encoder/Decoder
- Type 99 Tone Decoder (Selective call)
- Public Address
- Auxiliary Switch Board

A control module occupies the control deck (lower) and provides the volume, squelch, and power ON-OFF controls; the channel selector switch, and the Transmit and Channel Busy indicators. The component board options occupy the option deck.

All pushbutton switches are backlitged with light-emitting diodes (LED's) for reliability, long life and low power consumption.

### CONTROL UNIT

The control unit consists of a front panel, a sheet metal housing, a printed wire board backplane, a rear cover, associated subassemblies (Component boards which plug into the printed wire board backplane) and mounting brackets with hardware.

The front panel is made of molded plastic and contains clearance holes for pushbutton switches and applicable indicator lights (LEDs). Slots for the thumbwheel type VOLUME and SQUELCH controls are also provided.

Mounted on the front of the plug-in modules are switches, controls, and indicators. Necessary controls and pushbutton switches protrude through holes and slots in the front panel of the control unit. Light emitting diodes (LEDs) are mounted behind the pushbutton assemblies to provide illumination. Normally the indicators glow at reduced intensity until selected (depressed), then full illumination is provided. The VOLUME and SQUELCH controls are part of the control module and are mounted horizontally.

The control unit rear cover backplane assembly provides a means for connecting the Power/Control Cable, microphone connector, and universal tone connector. Cable plugs are secured to the rear cover by plastic locking clips. Plugs are equipped with indexing tabs to assure connection to the correct jack. The control cable is equipped with a strain relief hook that attaches to the flange at the bottom of the rear cover.




Figure 1 - C-800 Control Unit (Pushbutton Control)

The microphone plug is secured to the microphone jack located on the rear cover by means of a captive locking screw. A nine pin connector (optional) is available to permit use of external tone equipment.

The backplane board is attached to the inside of the rear cover, and interconnects the control and option modules with the control cable and microphone cable.

Power/Control Cable connections are made to the connectors (J902 and J903) located along the bottom of the backplane board. Three sets of 19 feed-through posts permit connection of the control cable to the control module (plugged in from the front of the housing). These connections are shown on the backplane board and the control cable Wiring Diagrams.

## CIRCUIT ANALYSIS

The Control Module is equipped with a VOLUME control (R701), SQUELCH control (R702), PWR ON-OFF pushbutton switch and indicator (S701 and CR704), a yellow Channel Busy indicator (CR706), a red Transmit indicator (CR705) and Channel Selector pushbutton switches (S702 and S703).

When the PWR ON-OFF switch is in the "off" position, power is removed from the radio except for the transmitter PA, which is connected to the vehicle battery at all times. Pushing the switch in to the "on" position applies power to the radio and lights the power-on LED behind the pushbutton switch.

CR701 and CR708 are protective diodes and will cause the fuse in the yellow lead to blow if the polarity is reversed.

### TRANSMIT INDICATOR

Pressing the PTT switch on the microphone energizes the antenna switch, keys the transmitter, mutes the receiver, and lights the transmit indicator LED.

Releasing the PTT switch turns off the transmitter and transmit indicator, de-energizes the antenna switch and when receiving, unmutes the receiver.

### CHANNEL BUSY INDICATOR

When no signal is applied to the receiver, the Carrier Activity Sensor (CAS) voltage from the receiver squelch IC is near A-. This forward biases diode CR702 in the control unit, keeping Q701 turned off. When a signal is applied to the receiver (with or without audio), the CAS voltage rises to approximately 10 Volts. This reverse biases CR702, allowing Q701 to conduct, turning on Channel Busy indicator CR706. The indicator will remain on as long as a signal is applied to the receiver, or until the transmitter is keyed.

## CHANNEL SELECTOR SWITCH

The Channel Selector pushbutton switches select the desired channel for both transmitting and receiving. The switch connects A- to the selected transmitter and receiver oscillators so that the radio operates on the selected channel.

### PUSHBUTTON AND SWITCH OPTIONS

The pushbutton and switch options identified below consist of a switch and associated components.

#### Pushbutton options

- Channel Guard Monitor
- Internal/External speaker
- Dual Control

#### Switch options

- Noise Blanker Disable
- Fixed Squelch

### CHANNEL GUARD MONITOR

For radios equipped with the Channel Guard monitor option, the control unit is equipped with a separate pushbutton switch (MON) located just to the right of the channel selector switch. When pressed, the MON switch overrides the Channel Guard and permits monitoring the selected channel. The MON pushbutton switch is paralleled by an alternate channel guard monitor switch mounted on the microphone hang-up bracket. The switch on the microphone hang-up bracket activates when the microphone is removed. Since these switches operate in parallel, either switch monitors the channel selected.

### INTERNAL/EXTERNAL SPEAKER

In radios with the Internal/External Speaker option, the control unit is equipped with a pushbutton switch marked EXT, and an external speaker mounted outside of the vehicle passenger compartment (on the roof, under the hood, etc.).

When the pushbutton switch is not operated, all of the messages received will be heard on the speaker mounted in the vehicle, and the pushbutton light will be backlit at a low level.

Pressing the switch in applies all received messages to both the external and internal speaker, and turns the light on to maximum brightness. This allows the received messages to be heard while the operator is inside or outside of the vehicle.

For complete details, refer to the Maintenance Manual for the Internal/External Speaker option.

## DUAL CONTROL

In radio systems with two control units, a Dual Control pushbutton switch mounted on each control unit is used to transfer control of the radio from one control unit to the other.

When the pushbutton is pressed, the pushbutton light turns on to indicate control of the radio. Control remains with this control unit until the Dual Control switch on the second control unit is operated. At this time the pushbutton light will turn off on the first control unit and the second control unit will assume control.

## FIXED SQUELCH

In radios with the Fixed Squelch option, a two-position rotary switch replaces the standard variable squelch potentiometer. A squelch potentiometer is mounted on J904 on the system board (see Front Panel & System Board Maintenance Manual).

Turning the optional squelch switch on the control unit to the right applies A- to the squelch disable lead. A- is connected to pin 2 of the receiver audio IC (U604), disabling the squelch circuit (and Channel Guard if present). Turning the switch to the left removes the A- from pin 2 of the squelch IC, enabling the squelch circuit (and Channel Guard).

## NOISE BLANKER DISABLE (MASTR II ONLY)

In radios with Noise Blanker Disable option, the noise blanker disable switch is mounted on the back of the control unit (see Outline Diagram). Placing the switch in the DISABLE position applies A- to the blanker disable lead, disabling the noise blanker circuit. A- is connected to the blanker disable circuit by a jumper from H63 to H66 on the system board.

Placing the switch in the ENABLE position removes A- from the blanker disable lead allowing the blanker to operate.

## COMPONENT BOARD OPTIONS

The component board options are:

- Multi-Frequency Channel Guard Encoder
- Priority Search Lock Monitor
- Type 90 Tone Encoders/Decoders
- Type 99 Tone Decoders
- Public Address
- Auxiliary Switch

## PRIORITY SEARCH LOCK MONITOR (PSLM)

In radios with four frequency PSLM, the PSLM component board is equipped with back-lighted pushbutton switches (push-push) for control and non-priority channel selection.

The search switch (SRCH) turns the PSLM "on" or "off"; the remaining pushbutton light switches select the non-priority channels to be searched. The priority channel is selected by the channel selector switch or strapped to a specific channel. For complete details, refer to the PSLM Maintenance Manual.

## PUBLIC ADDRESS (MASTR II ONLY)

In radios equipped with the Public Address option, the component board is equipped with a volume control and two backlighted pushbutton switches; PA (Public Address) and EXT (External). The volume control for the external speaker is independent of the receiver volume control. A reentrant type speaker with 20-foot of speaker cable is provided with this option.

When neither pushbutton switch is pressed, the radio operates normally.

When the EXT and PA pushbutton switches are pressed, the receiver audio is split between the internal and external speakers. Pressing the PTT switch connects the microphone to the external speaker through the audio amplifier. The transmitter is not keyed.

When only the "EXT" pushbutton switch is pressed, the received audio is split (approximately 30% to internal speaker). Pressing the PTT switch keys the transmitter.

When the PA pushbutton switch is pressed, the received audio is heard only in the internal speaker. Pressing the PTT switch connects the microphone to the external speaker through the audio amplifier. The transmitter is not keyed.

The pushbutton switches are normally backlit at a low level and become brighter when selected to indicate the selected mode of operation.

For complete details, refer to the Maintenance Manual for the Public Address option.

## TYPE 90 TONE ENCODERS AND DECODERS

Type 90 Tone equipment provides tone coded message transmissions to eliminate receipt of unwanted calls. A single tone burst precedes the first transmission. The TONE pushbutton allows the tone to be sent manually if desired. All Type 90 Tone Encoders and Decoders generate or decode a single tone, selectable from ten standard Type 90 tones.

Two pushbutton switches (CALL and TONE) are used to control the encode and decode functions. The CALL pushbutton is not present on encoder only units. The TONE pushbutton is not included on decode only units. The CALL pushbutton light is

normally off, and flashes on and off when a properly tone coded message is received. The CALL pushbutton also provides the manual reset and monitor functions. When momentarily pressed, it resets the decoder; when held in it allows the operator to monitor the receive channel(s). Automatic reset and manual monitoring functions may also be provided by a separate microphone or handset hookswitch.

Optionally, there may be two additional pushbutton switches to control the selection of the type of external alarm desired - horn or light. The TONE, HORN and LITE pushbuttons are backlighted and become brighter when selected. When the HORN pushbutton is selected and a properly tone coded message is received, the horn will sound for approximately one-second. If the LITE pushbutton is selected, the lights will come on and remain on until reset.

#### TYPE 99 TONE DECODERS

Type 99 Tone equipment provides individual or group call capability using either two or four Versatone networks (Versatone networks determine the tone frequencies). A CALL light, normally off, will flash on and off when a properly tone coded message is received. Momentarily pressing the CALL pushbutton switch provides the manual reset functions. When held in, it enables the user to monitor the receiver channel(s). Automatic reset and manual monitoring functions may also be provided by a separate microphone or handset hookswitch.

Optionally, there may be two additional pushbutton switches to select the type of external alarm desired - horn or light. Both switches are backlighted and become brighter when selected.

When the HORN pushbutton is selected and a properly tone coded message is received, the horn will sound for approximately one-second; if the LITE pushbutton is selected the lights will turn on and remain on until reset.

#### MULTI-FREQUENCY CHANNEL GUARD ENCODERS

Channel Guard is a continuous tone-controlled squelch system that provides communications control by enabling the user to monitor or receive only the tone coded messages intended for him. One of two Channel Guard encoders may be used to provide two-tone or up to eight-tone capability.

Each Channel Guard encoder consists of a program board mounted on top of the channel selector board. The program board may be programmed for all standard Channel Guard tone frequencies in accordance with EIA standard RS-220. It may also be re-programmed in the field as required.

The Channel Selector board contains a Channel Guard control and up to eight pushbutton switches to select one of the programmed Channel Guard tones for transmission.

When the CG pushbutton switch is pressed, power is applied to the component board and the CG light is at maximum brightness. The tone selector pushbuttons are backlighted at a somewhat lower level to indicate the unit is operable.

When a tone selector pushbutton switch (A-H) is pressed, the selected pushbutton will light at maximum brightness to indicate the tone selected for transmission. The tone selector pushbuttons are mechanically interlocked so that only one switch may be operated at a time.

#### AUXILIARY SWITCH BOARD

The Auxiliary Switch option consists of a component board equipped with five pushbutton switches, an interconnecting cable harness, 20-feet of 15-conductor cable and a sheet of peel-off labels.

The five pushbutton switches, two momentary and three push-push, are all backlighted and increase to maximum brightness when depressed. This arrangement of switches allows the user to select and control external devices.

#### UNIVERSAL TONE CONNECTOR OPTION 9409

A nine pin jack (J750) is mounted on the rear cover to provide interface connections to external tone equipment. J750 interconnects with J910 on the backplane board through a small cable harness.

#### DC CONVERTER MODIFICATIONS (MASTR II ONLY)

In radios equipped with the DC converter, the POWER-ON switch is modified so that the input voltage is applied directly to the DC converter. Instructions for the modification are shown on the control unit Schematic Diagram.

#### 12-VOLT IGNITION SWITCH CONNECTIONS

In 12-Volt vehicle systems, the control unit may be connected for two different modes of operation, depending on the way the ignition switch cables are connected in the vehicle system. (See Figures 2 and 3). The black cable provides the system ground connection. The yellow fused lead provides the receiver hot connections and the transmitter PTT hot connection. The two types of operation are:

1. Ignition Switch Control - For ignition switch control, the yellow fused lead connects to the ACCESSORY or ON terminal of the ignition switch. The transmitter and receiver will operate only when the ignition switch is in the

ACCESSORY or ON position. Turning the ignition switch OFF removes all power to the radio.

2. **Ignition Switch Bypass** - For ignition switch bypass, the yellow fused lead connects to the "hot" side of the ignition switch or the vehicle fuse block assembly. Both the transmitter and receiver operate independently of the ignition switch and are turned on and off only by the POWER-ON switch on the control unit.

If the radio is moved to a vehicle with different battery polarity, it will be necessary to change the ignition switch leads to the vehicle system plug. Use an extraction tool as shown in Figure 4, and change the leads as required.

#### DC CONVERTER CONNECTIONS (MASTR II ONLY)

For combinations equipped with the DC converter, a single red fused lead is used. The fused lead always connects to battery plus in either positive or negative ground systems.

#### RE-INSTALLATION

##### ±12-Volt Systems (MASTR II only)

If the radio is moved to a different vehicle, always check the battery polarity and voltage of the new system before using the radio.

#### CAUTION

When using the DC Converter, do not connect battery ground to Control Unit A-. To do so may cause failure of the current limiting circuit in the converter.




Figure 2 - 12-Volt, Negative Ground Connections




Figure 3 - 12-Volt, Positive Ground Connections






Figure 4 - Using Extraction Tool

## MAINTENANCE

### DISASSEMBLY

To disassemble the control unit, remove the four allen head screws (7/64") from the corners of the front panel and remove front panel.

### REMOVAL AND REPLACEMENT OF OPTION MODULES

To remove an option module (center and upper decks), grasp the outer corners of the printed wire board and pull firmly until loose. Slide module out of guide slots. Be careful not to grasp any components or switches when removing module.

#### NOTE

Each module is notched on the outer right edge. In some instances where the module is seated very tightly, it may be necessary to insert a flat blade screw driver in the notch and, using the side of the control unit as a fulcrum, pry the module loose. It will now slide out easily.

To replace an option module, carefully insert module in appropriate guide slots and, with thumbs positioned on top outer

edge of the printed wire board, press firmly until module seats. Be careful not to apply pressure to any components or switches.


### REMOVAL AND REPLACEMENT OF CONTROL MODULE

To remove the control module (lower deck), insert a flat blade screw driver in the notch located on the outer right edge of module and, using the side of the control unit housing as a fulcrum, pry the control module loose. Considerable force may be required since there are three 21-pin connectors making contact with the backplane board.

To replace the control module, carefully insert module in guide slots and make sure connectors mate properly. Hold a dull instrument (such as a flat blade screw driver) on the edge of the control module directly below the volume and then the squelch control and using your other hand push the module into place. In some instances it may be necessary to drive or tap the module squarely into place.


#### NOTE

There are two rows of contacts to be engaged. When the module is seated properly, the connectors on the control module will be flush with the backplane board.






- NOTES:
1. WHEN THE UNIVERSAL TONE CONNECTOR IS USED, THE JUMPER "C" (H79-H80) AND JUMPER "H" (H70-H71) ARE REMOVED.
  2. WHEN THE STANDARD HANDSET & HOOK-SWITCH IS USED, THE JUMPER "C" (H79-H80), JUMPER "A" (H77-H78) AND JUMPER "H" (H70-H71) ARE REMOVED.
  3. LOCKOUT RIVETS MAY BE USED TO LOCK OUT UNUSED CHANNELS. WHEN PLACING THESE CHANNELS IN SERVICE, UNSOLDER AND REMOVE THE LOCK OUT RIVET.

WIRE CONNECTION CHART			
LETTER	FROM	TO	REMARKS
A	H77	H10	GROUP 1 ONLY
B	H68	H69	1.2&3
C	H79	H80	1.2&3
D	H66	H67	1.2&3
E	H64	H65	1.2&3
F	H60	H61	1.2&3
G	H58	H59	1.2&3
H	H70	H71	1.2&3
J	H62	H63	1.2&3
K	H72	H73	1.2&3
L	H74	H75	1.2&3
M	H91	H92	1.2&3
	H40	H41	2&3
	H42	H43	2&3
	H44	H45	2&3
	H46	H47	3 ONLY
	H48	H49	3 ONLY
	H50	H51	3 ONLY
	H52	H53	3 ONLY
	H54	H55	3 ONLY
	H7	H136	GROUP 3 ONLY
	H46	H55	GROUPS 2 & 3
			GROUP 2 ONLY



OPTION SWITCH CONNECTION CHART				
OPTION	SWITCH POSITION	WIRE	FROM	TO
CG MONITOR (MON) S706	A	SF22-BL SF22-BK DA	H52 H54 H56	J733 J729 H57
OPTION 9404	B	SF22-BL SF22-BK	H49 H50	J733 J729
	C	SF22-BL SF22-BK	H45 H46	J733 J729
DUAL CONTROL (CONT) S704	A	SF22-R SF22-BL SF22-BK	J735 H52 H54	J737 J736 H37
OPTION 9412				
INTERNAL/EXTERNAL SPKR (EXT) S705	A	SF22-R SF22-O SF22-BL DA	H52 H54 H51 H56	J714 J716 J715 H57
OPTION 9413	B	SF22-R SF22-O SF22-BL DA	H49 H50 H47 H81	J714 J716 J715 H82
	C	SF22-R SF22-O SF22-BL DA	H45 H46 H43 H81	J714 J716 J715 H82
		INSTALL R710 REMOVE DA JUMPER "B"	H81 H68	H82 H69
		INSTALL R710 REMOVE DA JUMPER "B"	H45 H46 H43 H81	J714 J716 J715 H82
		INSTALL R710 REMOVE DA JUMPER "B"	H45 H46 H43 H81	J714 J716 J715 H82





ALL RESISTORS ARE 1/2 WATT UNLESS OTHERWISE SPECIFIED AND RESISTOR VALUES IN OHMS UNLESS FOLLOWED BY K=1000 OHMS OR MEG=1,000,000 OHMS. CAPACITOR VALUES IN PICO FARADS (EQUAL TO MICROMICROFARADS) UNLESS FOLLOWED BY UF= MICROFARADS. INDUCTANCE VALUES IN MILLIHENRYS UNLESS FOLLOWED BY MH= MILLIHENRYS OR H=HENRYS.

IN ORDER TO RETAIN RATED EQUIPMENT PERFORMANCE, REPLACEMENT OF ANY SERVICE PART SHOULD BE MADE ONLY WITH A COMPONENT HAVING THE SPECIFICATIONS SHOWN ON THE PARTS LIST FOR THAT PART.

THIS ELEM DIAG APPLIES TO	
MODEL NO	REV LETTER
19D417661	

- NOTES:
- ★ PRESENT IN GROUP 1 ONLY (SINGLE FREQ)
  - ▲ PRESENT IN GROUP 2 ONLY (TWO FREQ)
  - PRESENT IN GROUP 3 ONLY (FOUR FREQ)
  - LETTERED DA JUMPERS ON PW BD ARE TO BE REMOVED WHEN SPECIFIED ON OPTIONS.
  - DC CONVERTER MODIFICATIONS. WHEN USED THE FOLLOWING MODIFICATIONS ARE INCORPORATED:

CUT OR REMOVE WIRE RUN BETWEEN	DA WIRE CONNECTED BETWEEN
H95 & H102	H5 & H6
R703 & H105	H103 & H106
	H108 & H111

## SCHEMATIC DIAGRAM

### C-800 SERIES PUSHBUTTON CONTROL UNIT

PARTS LIST		
LBI-30225		
C-800/C-900 SERIES CONTROL UNIT (PUSHBUTTON) AND ACCESSORIES		
SYMBOL	GE PART NO.	DESCRIPTION
		CONTROL MODULE 19D417661G1 1 FREQ 19D417661G2 2 FREQ 19D417661G3 4 FREQ
C701	19A116080P106	----- CAPACITORS ----- Polyester: 0.068 µf ±10%, 50 VDCW.
CR701	4037822P1	----- DIODES AND RECTIFIERS ----- Silicon.
CR702 and CR703	19A115250P1	Silicon.
CR704	19A134146P14	Diode, optoelectronic: yellow.
CR705	19A134146P8	Diode, optoelectronic: red.
CR706	19A134146P15	Diode, optoelectronic: yellow.
CR708	4037822P1	Silicon.
CR709 thru CR712	19A134146P14	Diode, optoelectronic: yellow.
J714 thru J716	4033513P4	----- JACKS AND RECEPTACLES ----- Contact, electrical: sim to Bead Chain L93-3.
J723	4033513P4	Contact, electrical: sim to Bead Chain L93-3.
J729	4033513P4	Contact, electrical: sim to Bead Chain L93-3.
J732 and J733	4033513P4	Contact, electrical: sim to Bead Chain L93-3.
J735 thru J738	4033513P4	Contact, electrical: sim to Bead Chain L93-3.
P701 thru P703	19C321106P1	----- PLUGS ----- Connector, printed wiring: 20 terminals rated at 5 amps per terminal.
Q701	19A115910P1	----- TRANSISTORS ----- Silicon, NPN; sim to Type 2N3904.
R701	19S209535P2	----- RESISTORS ----- Variable, carbon film: 10,000 ohms ±20%, 1/4 w; sim to Mallory Style LCN-TM4.
R702	19S209535P1	Variable, carbon film: 10,000 ohms ±20%, 0.5 w; sim to Mallory Style LCN-TM4.
R703	3R77P152K	Composition: 1500 ohms ±10%, 1/2 w.
R704	3R77P511J	Composition: 510 ohms ±5%, 1/2 w.
R705	3R77P393K	Composition: 39,000 ohms ±10%, 1/2 w.
R706	3R77P100K	Composition: 10 ohms ±10%, 1/2 w.
R707 and R708	3R77P511J	Composition: 510 ohms ±5%, 1/2 w.
R709	3R152P102J	Composition: 1000 ohms ±5%, 1/4 w.
R711 thru R713	3R152P102J	Composition: 1000 ohms ±5%, 1/4 w.
S701	19S209563P7	----- SWITCHES ----- Push: 4PDT, momentary, 1.1 amp at 14 VDC.
S702	19S209563P4	Push: 2PDT, 2 stations, 1.1 amp at 14 VDC.
S703	19S209563P5	Push: 2PDT, 4 stations, 1.1 amp at 14 VDC.

SYMBOL	GE PART NO.	DESCRIPTION
		----- MISCELLANEOUS ----- Housing (C-800 SERIES). Housing (C-900 SERIES). Rear Cover (C-800 SERIES). Rear Cover (C-900 SERIES). Front Panel (C-800 SERIES). Front Panel (C-900 SERIES WITHOUT FIXED SQUELCH). Front Panel (C-900 SERIES WITH FIXED SQUELCH). Cap screw. (Secures Front Panel to Housing-Part of front panel). Knob. (Used with R701 and R702). Lens. (S701-PWR). Nameplate. (PWR). Contact. (Located between P701, P702, P703 and Control Module Board). Nameplate (F1). Nameplate (F2). Nameplate (F3). Nameplate (F4).
		ASSOCIATED ASSEMBLIES  POWER/CONTROL CABLE MASTER II INTERFACE 30 CONDUCTOR 19D423424G8
P702	19S226516P1	----- PLUGS ----- Connector. Includes: Shell.
P703	19A116781P5	Contact, electrical: wire size No. 16-20 AWG; sim to Molex 08-50-0106. Connector. Includes: Shell.
		----- MISCELLANEOUS ----- Cable: 27 conductor, 20 feet. Clip loop (strain relief). Terminal, solderless: sim to AMP 33460. (Quantity 2). Connector. Includes: Shell.
P901	19C307162P1	Contact, electrical: wire size 24-20 AWG; sim to AMP 350657-1. (Quantity 34).
		POWER/CONTROL CABLE MASTER II INTERFACE 38 CONDUCTOR 19D423424G14
P702	19S226516P1	----- PLUGS ----- Connector. Includes: Shell.
		DC CONVERTER IGNITION SWITCH CABLE 19S219537G3
P703	19S226516P1	Shell.
		Connector. Includes: Shell. Jumper.

SYMBOL	GE PART NO.	DESCRIPTION
	19A116781P6	Contact, electrical: wire size No. 22-26 AWG; sim to Molex 08-50-0108.
		----- MISCELLANEOUS ----- Cable: 34 conductor, 20 feet. Clip loop (strain relief). Terminal, solderless: sim to AMP 33460. (Quantity 2).
		POWER/CONTROL CABLE NEGATIVE GND EXECUTIVE II INTERFACE 19C321880G1
P1	19C311409P1	----- PLUGS ----- Connector. Includes: Shell.
		Connector cover. (Nut side). Connector cover. (Screw side).
P702	19S226516P1	Shell.
		Contact, electrical: wire range No. 18-20 AWG; sim to Molex 08-50-0106.
P703	19A116781P5	Contact, electrical: wire range No. 22-26 AWG; sim to Molex 08-50-0108.
		Connector. Includes: Shell.
		Contact, electrical: wire range No. 16-20 AWG; sim to Molex 08-50-0106.
		Contact, electrical: wire range No. 22-26 AWG; sim to Molex 08-50-0108.
		Clip loop. (strain relief). Solderless terminal: wire size No. 12-10 AWG; sim to AMP 35772.
		Terminal, solderless: wire range No. 12-10; sim to AMP 31828- LOOSE PC.
		12-VOLT 2-WIRE IGNITION SWITCH CABLE 19S219537G4
P701	19S226516P3	----- PLUGS ----- Connector. Includes: Shell.
		Y Cable. (BLACK).
		FUSED LEAD ASSEMBLY 19A129480G2 5 AMP (YELLOW) (Used with 19S219537G1)
		Fuse, quick blowing: 5 amps at 250 v; sim to Littelfuse 312005 or Bussmann MTH-5.
		Fuseholder, phen: sim to Bussmann Type HHJ.
		Contact, electrical: sim to Littelfuse 904-83. (Located inside fuseholder).
		Ring terminal, solderless: wire size No. 16-14 AWG.
		Ring terminal, solderless: wire size No. 16-14 AWG.
		Terminal, quick connect: wire size 14-18 AWG; fits 1/4 x .032 tab; sim to AMP 41274.
		Insulated splice.
		Contact, electrical: wire size No. 16-20 AWG; sim to Molex 08-50-0106.
		DC CONVERTER IGNITION SWITCH CABLE 19S219537G3
P701	19S226516P3	Shell.
		Connector. Includes: Jumper.


SYMBOL	GE PART NO.	DESCRIPTION
		FUSED LEAD ASSEMBLY 19A129480G1 (Used with 19S219537G3)
		Fuse, quick blowing: 1 amp 250 v; sim to Littelfuse 312001 or Bussmann AGC-1.
		Fuseholder, phen: sim to Bussmann Type HHJ.
		Contact, electrical: sim to Littelfuse 904-83. (Located inside fuseholder).
		Ring terminal, solderless: wire size No. 16-14 AWG.
		Ring terminal, solderless: wire size No. 16-14 AWG.
		Terminal, quick connect: wire size 14-18 AWG; sim to AMP 41274.
		Insulated splice.
		Contact, electrical: wire size No. 16-20 AWG; sim to Molex 08-50-0106.
P701	19S226516P3	Shell.
		Y Cable. (BLACK).
		FUSED LEAD ASSEMBLY 19A129480G2 5 AMP (YELLOW) (Used with 19S219537G1)
		Fuse, quick blowing: 1 amp 250 v; sim to Littelfuse 312001 or Bussmann AGC-1.
		Fuseholder, phen: sim to Bussmann Type HHJ.
		Contact, electrical: sim to Littelfuse 904-83. (Located inside fuseholder).
		Ring terminal, solderless: wire size No. 16-14 AWG.
		Ring terminal, solderless: wire size No. 16-14 AWG.
		Terminal, quick connect: wire size 14-18 AWG; sim to AMP 41274.
		Insulated splice.
		Contact, electrical: wire size No. 16-20 AWG; sim to Molex 08-50-0106.
		BATTERY CABLES
		Battery cable. (BLACK), 3 feet.
		Battery cable. (RED), 3 feet.

SYMBOL	GE PART NO.	DESCRIPTION
		NOISE BLANKER DISABLE OPTION 19S227179G1
		Switch, slide: SPST, 1 pole, 2 positions, .5 amp VDC or 3 amp VAC at 125 v; sim to Switchcraft 46202LH.
		Contact, electrical: sim to Amp 42827-2.
		Nut, sheet spring: sim to Vector Electronic Co. No. 440.
		FIXED SQUELCH OPTION 19A130896G1
		----- PLUGS ----- Contact, electrical: sim to Bead Chain M125-34.
P1723	4033348P1	Contact, electrical: sim to Bead Chain M125-34.
P1729	4033348P1	----- RESISTORS ----- Composition: 10,000 ohms ±5%, 1/2 w.
R702	3R77P103J	----- SWITCHES ----- Rotary: 1 section, 1 pole, 2 positions, non-shorting contacts, 2 amp at 28 VDC or 1 amp at 110 Vrms; sim to Oak Mfg. 5-11158-210.
S1701	19A116906P2	DUAL CONTROL OPTION 19S227037G5
		Switch, pushbutton: 2PDT, 1 station, momentary action, 1.1 amp at 14 VDC.
		Pushbutton.
		Lens.
		Insert.
		Diode, optoelectronic: yellow.
		Nameplate. (CONT).
		CHANNEL GUARD MONITOR OPTION 19S227037G4
		Switch, pushbutton: 2PDT, 1 station, alternate action, 1.1 amp at 14 VDC.
		Pushbutton.
		Lens.
		Insert.
		Diode, optoelectronic: yellow.
		Nameplate. (MON).
		INTERNAL/EXTERNAL SPEAKER OPTION 19S227037G6
		Switch, pushbutton: 2PDT, 1 station, alternate action, 1.1 amp at 14 VDC.
		Pushbutton.
		Lens.
		Insert.
		Diode, optoelectronic: yellow.
		Nameplate. (EXT).
		UNIVERSAL TONE CONNECTOR 19S227159G1
		----- JACKS AND RECEPTACLES ----- Plug: 9 contacts rated at 7.5 amps max; sim to Winchester M8S-LBN.
J750	7489183P5	----- PLUGS ----- Connector. Includes:
P910	19A116659P89	Connector, printed wiring: 10 contacts; sim to Molex 09-50-3101.
	19A116781P6	Contact, electrical: wire range No. 22-26 AWG; sim to Molex 08-50-0108.

SYMBOL	GE PART NO.	DESCRIPTION
		25 - 50 MHz ANTENNA
		Antenna: includes stainless steel rod approx 96-1/2 inches long; ball tip; lockwasher; No. 10-32 hex socket set screw; sim to Antenna Specialist ASPA3EGE.
		Adapter, antenna: approx 2-5/16 inches long. (Used with GE Dwg 7491074P1).
		Loading coil: 25-33 MHz; sim to Antenna Specialists ASPA87.
		Antenna hook kit.
		Antenna hook.
		Antenna Package: Includes base and ball assembly, adapter spring assembly, cable assembly, horseshoe plate, and rubber gasket.
		Ease and ball assembly. Newtronics 5495.
		Adapter spring assembly. Newtronics 3327.
		Cable assembly. Newtronics 183-RAO.
		Horseshoe plate. Newtronics 3323-3.
		Rubber gasket. Newtronics 3320.
		132-512 MHz ANTENNA 19S209568P1
		Whip assembly. Decibel Products 068110-001.
		Whip nut assembly. Decibel Products 068047-001.
		Ease nut assembly. 068048-001.
		"O" Ring (LARGE). 007059-122.
		Stud assembly. 068046-001.
		RG58/U Cable, 15 feet. 068115-001.
		12 VOLT FUSE ASSEMBLY 19S216021G4 (Fuses must be ordered separately)
		----- FUSES -----
F1	1R11P4	Quick blowing: 15 amps, 250 v; sim to Bussmann RKN15. (Used with low power transmitters, 16-38 w).
F3	1R11P7	Quick blowing: 30 amps, 250 v; sim to Bussmann RKN30. (Used with high power transmitters, 66-128 w).
F4	1R11P5	Quick blowing: 20 amps, 250 v; sim to Bussmann RKN20. (Used with medium power transmitters, 38-66 w).
		DASH MOUNTING KIT FOR CONTROL HEAD 19A130201G2
		Mounting bracket. (Mates with dash).
		Mounting racket. (Mates with C-900 control head).
		Tap screw: No. 10-16 x 5/8. (Secures mounting bracket to dash when extended length is not needed).
		Tap screw: No. 10-16 x 1-1/2. (Secures mounting bracket to dash when extended length is needed).
		Machine screw: No. 10-32 x 5/16. (Secures mounting bracket to control head).
		Lockwasher: No. 10. (Secures mounting bracket to control head).
		Machine screw: No. 1/4-20 x 5/8. (Secures the two mounting brackets together).
		Lockwasher, external tooth: 1/4 inch. (Secures the two mounting brackets together).
		HUMP MOUNTING KIT FOR CONTROL HEAD 19A130201G2 19A130896G1
		Mounting bracket. (Mates with hump racket).
		Mounting bracket. (Mates with control head).


SYMBOL	GE PART NO.	DESCRIPTION
		N80P16005C6
		Machine screw: No. 10-32 x 5/16. (Secures mounting bracket to control head).
		N403P19C6
		Lockwasher: No. 10. (Secures mounting bracket to control head).
		19A115495P1
		Machine screw: No. 1/4-20 x 5/8. (Secures 19C321086P2 bracket to 19C321089G2 bracket).
		N403P25C6
		Lockwasher, external tooth: 1/4 inch. (Secures 19C321086P2 bracket to 19C321089G2 bracket).
		19A130890G1
		Mounting bracket. (Mates with floor hump).
		19S227124G1
		Screw, thread forming: No. 10-16 x 5/8. (Secures mounting bracket to hump when extended length is not needed).
		N130P1610C6
		Tap screw: No. 10-16 x 1-1/2. (Secures mounting bracket to hump when extended length is needed).
		N130P1624C6
		Tap screw, thread forming: No. 10-32 x 3/8. (Secures 19C321086P2 to hump bracket).
		N80P16005C6
		Machine screw: No. 10-32 x 5/16. (Secures mounting bracket to control head).
		N403P19C6
		Lockwasher: No. 10. (Secures mounting bracket to control head).
		19A115495P1
		Machine screw: No. 1/4-20 x 5/8. (Secures the two mounting brackets together).
		N403P25C6
		Lockwasher, external tooth: 1/4 inch. (Secures the two mounting brackets together).
		HUMP MOUNTING KIT FOR CONTROL HEAD 19A130201G2 19A130896G1
		Mounting bracket. (Mates with hump racket).
		Mounting bracket. (Mates with control head).

CHANNEL GUARD MONITOR OPTION




(19B227170, Rev. 1)

DUAL CONTROL OPTION



(19B227167, Rev. 1)


SQUELCH SWITCH




(19A130899, Rev. 1)

SCHEMATIC DIAGRAM

CHANNEL GUARD MONITOR,  
DUAL CONTROL AND  
FIXED SQUELCH OPTIONS




(19D423937, Rev. 2)  
(19B227238, Sh. 1, Rev. 0)  
(19B227238, Sh. 2, Rev. 0)



OUTLINE DIAGRAM  
C-800 SERIES CONTROL UNIT  
BACKPLANE BOARD





SCHEMATIC DIAGRAM

C-800 SERIES CONTROL UNIT  
BACKPLANE BOARD

LBI-30235

## PARTS LIST


LBI-30226

C-800 SERIES BACKPLANE BOARD  
19D423729G1


SYMBOL	GE PART NO.	DESCRIPTION
J901 thru J903	19A116659P34	----- JACKS AND RECEPTACLES ----- Connector. Includes: Connector, printed wiring: 10 contacts; sim to Molex 2402-10.
	19A116659P35	Connector, printed wiring: 11 contacts; sim to Molex 2402-11.
J904	19B219627G1	Connector: 6 contacts.
J906A	19A116446P5	Connector, printed wiring: 14 contacts.
J906B	19A116446P5	Connector, printed wiring: 14 contacts.
J906C	19A116446P5	Connector, printed wiring: 14 contacts.
J906D	19A116446P5	Connector, printed wiring: 14 contacts.
J908 and J909	4033513P4	Contact, electrical: sim to Bead Chain L93-3.
J910	19A116659P54	Connector, printed wiring: 10 contacts; sim to Molex 09-65-1101.



OUTLINE DIAGRAM



SCHEMATIC DIAGRAM



PARTS LIST

LBI-4483A  
MICROPHONE HOOKSWITCH  
19C320318G1

SYMBOL	GE PART NO.	DESCRIPTION
----- SWITCHES -----		
S1	19B219698G1	Slide: SPST, 3 amp at 125 VAC, 2.2 amp at 14 VAC; sim to Switchcraft 46202LH. (S1 includes switch and housing).
S2	19A116676P1	Sensitive: SPDT, 5 amp at 24 VDC or 5 amp at 250 VRMS; sim to Microswitch 111SM1-T2.
----- CABLES -----		
W1	19A129414G1	2 conductor cable: approx 5 feet long, includes (2) 19A116781P3 contacts.
----- MISCELLANEOUS -----		
	19A116768P6	Strain relief: sim to Heyco SR-3P-4. (Used with W1).
	N193P1410C	Tap screw, phillips: No. 8 x 5/8.
	N84P5008C6	Screw, phillips: No. 2-56 x 1/2. (Secures S2).
	N210P5C6	Hexnut: No. 2-56. (Secures S2).
	N404P8C6	Lockwasher, internal tooth: No. 2. (Secures S2).

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

PARTS LIST


LBI-4481A

TRANSISTORIZED DYNAMIC MICROPHONE  
19C320270G1  
(SEE RC-2454)

SYMBOL	GE PART NO.	DESCRIPTION
1		Front Case Assembly. RP127. (includes items 14, 15).
2		Retaining spring. (Part of item 18).
3		Tap screw, phillips. (Part of item 16).
4		Retaining bar. (Part of item 16).
5	19D416766P1	Connector base.
6	19A129435P1	Contact.
7	7109043P1	Retaining ring.
8	19D416767P1	Connector cover.
9	19B219723G1	Screw.
10	N136AP905C	Tap screw, phillips: No. 4 x 5/16.
11	19A116937P1	Cable clip.
12	19B219749P1	Strain relief.
13		Switch button kit. RP126.
14		Rear Case Assembly. (Part of item 1).
15		Tap screw, phillips. (Part of item 1).
16	19C321016G1	Cable assembly: Includes items 3-12 and cable RP129.
17		Switch Assembly. RP128.
18		Grille Assembly. RP130. (includes items 2, 19, 21).
19		"O" Ring. (Part of item 18).
20		Transistorized Cartridge. RP117.
21		Washer. (Located under cartridge- part of item 18).
22	19C321016G3	Connector assembly: Includes items 5-12.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

LBI-30235




RC-2454A

SERVICE SHEET

MICROPHONE & HOOKSWITCH


Issue 1

OUTLINE DIAGRAM



(19B226131, Rev. 0)

SCHEMATIC DIAGRAM



(19B219842, Rev. 4)


SERVICE SHEET

HANDSET & HOOKSWITCH

PARTS LIST

LBI-4484A  
HANDSET HOOKSWITCH  
19B219846G1

SYMBOL	GE PART NO.	DESCRIPTION
R1	5493035P11	----- RESISTORS ----- Wirewound: 40 ohms $\pm 5\%$ , 5 w; sim to Hamilton Hall Type HR. Earlier than REV A:
	5493035P12	Wirewound: 60 ohms $\pm 5\%$ , 5 w; sim to Hamilton Hall Type HR.
S1	19A129586P1	----- SWITCHES ----- Holder and switch; Thermoplastic case, contact rating 1 amp at 125 v.
	19A116877P6	Toggle: DPDT, 1 ma at 6 VDC; sim to C and K Components 7201G. (CHANNEL GUARD DISABLE).
TBI	7775500P203	----- TERMINAL BOARDS ----- Phen: 5 terminals.
W1	19B219841G1	----- CABLES ----- 6 conductor, 5 feet long.
	N190AP1312C	----- MISCELLANEOUS ----- Tap screw, phillips pozidriv; No. 6 x 3/4. (Secures housing to base plate).
	N101P1510P	Tap screw, phillips; No. 8 x 5/8. (Used for mounting base plate).
	19A129586P1	Bumper, rubber. (2).



THESE INSTRUCTIONS COVER THE MODIFICATION OF MASTR II HANDSET HOOKSWITCH TO BE APPLIED TO EXEC II

INSTRUCTIONS:

1. REMOVE FOUR #6-32 SCREWS AND COVER.
2. REMOVE R1 RESISTOR (40 OHM) AND DISCARD. REPLACE WITH R1701 RESISTOR (8.2 OHM) AND SOLDER TO TBI-5 AND TBI-2 AS SHOWN.
3. REPLACE COVER AND SCREWS.
4. ADD LABEL (19A136775) AS SHOWN.


(19B227530, Rev. 1)

PARTS LIST

LBI-4482A  
TRANSISTORIZED DYNAMIC HANDSET  
19C320478G1

SYMBOL	GE PART NO.	DESCRIPTION
1		Case Assembly. Includes items 1, 2, 4, 5, 11, 12, 26. Shure Brothers RP142.
2		Adapter. Part of item 1.
3		Receiver Cartridge. Shure Brothers RP140.
4		Receiver Cap. Part of item 1.
5		Washer. Part of item 1.
6		Escutcheon. Part of item 27.
7		Flat head screw, socket cap: No. 4-40 x 1/4. Part of item 27.
8		Actuator. Part of item 27.
9		Spring. Part of item 27.
10		Plunger bar. Part of item 27.
11		Transmitter cap. Part of item 1.
12		Washer. Part of item 1.
13		Transmitter cartridge. Shure Brothers RP139.
14	19C321016G2	Cable assembly: Includes items 14-23 and cable RP141.
15	19B219749P1	Flex relief.
16	19A116937P1	Cable clamp: sim to Malco 21012-3.
17	3R77P472K	Resistor, (R1) Composition, 4700 ohms $\pm 10\%$ , 1/2 w.
18	19D416766P1	Connector case.
19	N136AP905C	Screw.
20	19A129435P1	Pin contact.
21	7109043P1	Retaining ring. 3/16 inch, sim to National Lockwasher WA 510.
22	19D416767P1	Connector Cover.
23	19B219723G1	Screw. (Secures cover, item 22 to case, item 18).
24		Screw. Part of item 14.
25		Cable clamp. Part of item 14.
26		Shield. Part of item 1.
27		Switch Assembly. Includes items 6-10. Shure Brothers RP143.
28	19C321016G3	Connector assembly: Includes items 15, 16, 18-23. Does not include resistor, item 17.

\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES



PRODUCTION CHANGES

Changes in the equipment to improve performance or to simplify circuits are identified by a "Revision Letter", which is stamped after the model number of the unit. The revision stamped on the unit includes all previous revisions. Refer to the Parts List for descriptions of parts affected by these revisions.

REV. A - Handset Hookswitch 19B219846G1  
To improve the operation of the audio output stage by lowering the off-hook terminating resistance. Changed R1.

## PARTS LIST


LBI-30235

LBI-4488

SPEAKER  
19C320302G1

SYMBOL	GE PART NO.	DESCRIPTION
LS1	19A116694P1	----- LOUDSPEAKERS ----- Permanent magnet, 5 inch: 20 watts, 8 ohms ±10% imp, 100 to 10,000 Hz response; sim to Oaktron T2877.
		----- CABLES ----- 2 conductor cable: approx 5 feet long, includes (2) 19A116781P3 contacts.
W1	19A129414G1	----- MISCELLANEOUS ----- Grille.
		Housing.
		Mounting bracket. (Located between housing and retaining bracket).
		Retaining bracket. (Located between mounting bracket and safety release disc).
		Safety Release Disc.
		Tap screw, with lockwasher: No. 7-19 x 1/2. (Secures speaker to housing).
		Tap screw, with lockwasher: No. 7-19 x 3/4. (Secures grille to housing).
		Tap screw, with lockwasher: No. 13-16 x 3/4. (Secures mounting bracket to housing).
		Screw, hexhead, slotted: No. 10-32 x 5/8. (Quantity 1- used with safety release disc and retaining bracket).
		Screw, hexhead, slotted: No. 10-16 x 3/4. (Secures mounting bracket or retaining bracket).


\*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES




## SCHEMATIC DIAGRAM

POWER/CONTROL CABLE  
(MASTR EXECUTIVE II INTERFACE)


OUTLINE DIAGRAM



(19D424212, Rev. 0)  
(19C321093, Sh. 1, Rev. 0)  
(19C321093, Sh. 2, Rev. 0)



SCHEMATIC DIAGRAM



(19D417789, Rev. 1)

SCHEMATIC & OUTLINE DIAGRAM

CONTROL MODULE EXTENDER BOARD

## ORDERING SERVICE PARTS

Each component appearing on the schematic diagram is identified by a symbol number to simplify locating it in the parts list. Each component is listed by symbol number, followed by its description and GE Part Number.

Service parts may be obtained from Authorized GE Communication Equipment Service Stations or through any GE Radio Communication Equipment Sales Office. When ordering a part, be sure to give:

1. GE Part Number for component
2. Description of part
3. Model number of equipment
4. Revision letter stamped on unit

---

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance.

Should further information be desired, or should particular problems arise which are not covered sufficiently for the purchaser's purposes, contact the nearest Radio Communication Equipment Sales Office of the General Electric Company.

---

# MAINTENANCE MANUAL

LBI-30235

DF-4104

---

MOBILE RADIO DEPARTMENT  
GENERAL ELECTRIC COMPANY • LYNCHBURG, VIRGINIA 24502

GENERAL  ELECTRIC

PRINTED IN U.S.A.