



LBI-38377C

Mobile Communications

**M-PA™ SERIES
PORTABLE RADIO**

Operator's Manual

TABLE OF CONTENTS

<i>INTRODUCTION</i>	3
<i>CONTROLS</i>	3
<i>INDICATORS</i>	11
<i>UNIVERSAL DEVICE CONNECTOR</i> . . .	12
<i>ALERT TONES</i>	13
<i>OPERATION</i>	13
<i>POWER-UP</i>	13
<i>MODE/CHANNEL/CG SELECTION</i> . .	14
<i>RECEIVING A MESSAGE</i>	15
<i>TRANSMITTING A MESSAGE</i>	16
<i>EMERGENCY OPERATION</i>	16
<i>SCANNING CHANNELS</i>	17
<i>TELEPHONE INTERCONNECT</i>	
<i>CALLS</i>	20
<i>"KEY LOCK" MENU</i>	22
<i>"ALERT" MENU</i>	23
<i>PROGRAMMABLE FEATURES</i>	23

TABLE OF CONTENTS (CONT.)

<i>OPERATING TIPS</i>	25
<i>OPERATING RULES AND</i>	
<i>REGULATIONS</i>	25
<i>BATTERY PACKS</i>	26
<i>INSTALLING THE BATTERY PACK</i> . .	26
<i>REMOVING THE BATTERY PACK</i> . .	27
<i>CHARGING THE BATTERY PACKS</i> .	27
<i>RECHARGEABLE BATTERY PACK</i>	
<i>DISPOSAL</i>	28
<i>SWIVEL MOUNT REMOVAL AND</i>	
<i>REPLACEMENT</i>	28
<i>INTRINSICALLY SAFE USAGE</i>	29
<i>WARRANTY</i>	31
<i>NICKEL-CADMIUM BATTERY</i>	
<i>WARRANTY</i>	32

INTRODUCTION

This manual describes the operation of the M-PA™ two-way FM Select, Scan, and System model portable radios.

Operating controls on the radio include a rotatable control knob, rotatable volume control, a 4-button keypad (Scan model) or 16-button keypad (System model), push-to-talk, emergency and monitor buttons. The on/off power switch for the unit is located on the removable battery pack.

The 8-digit alphanumeric liquid crystal display (LCD) on the front of the radio displays the operating status of the radio. This backlit display also has status flags for indicating the various operating conditions such as transmitter on, scanning, or emergency mode enabled.

The exact operation of your radio will vary depending upon the mode of operation, the radio's programming, and the particular radio system. Consult your radio system's representative for particular features that are programmed into your radio.

CONTROLS

ON/OFF SWITCH

The ON/OFF SWITCH is located on the battery pack. Sliding this switch up will supply power to the radio from the battery pack. An audible click will be heard and the "ON" indicator will be exposed. When the radio is turned on, it will perform a power-up self test and then resume operation on the previous operating channel as displayed in the LCD. Sliding the switch down will turn the radio off.

VOLUME CONTROL KNOB

The VOLUME CONTROL KNOB is a rotatable control on the top of the radio used to adjust the receiver's audio level in the speaker. Rotating this knob in a clockwise direction will increase the audio level. Counter-clockwise rotation will decrease the audio level. Minimum levels may be programmed into the radio to prevent missed calls due to too low of a volume setting.

CONTROL KNOB

The rotatable 16-position CONTROL KNOB located on the top of the radio is programmed to select

the operating channel, mode, or specific Channel Guard encode/decode tones. See **MODE/CHANNEL/CG SELECTION** for details. A stop plate may be installed under the knob to limit the maximum number of positions to less than sixteen (16). It is normally factory installed for fifteen (15) positions. Some radios may be programmed with this knob disabled.

PTT BUTTON

Pressing the PTT BUTTON on the side of the radio will enable the radio's transmitter. The "TX" status flag in the display will turn on when the radio is transmitting. Releasing the PTT BUTTON will return operation to receive mode.

MONITOR BUTTON

The MONITOR BUTTON is used to unsquelch the receiver. Momentarily pressing this button will disable squelch and the receiver noise will be heard in the speaker.

If programmed enabled for the selected channel, Channel Guard (CG) and/or Type 99 (T99) signalling

will be enabled when the channel is selected. If CG and/or T99 are enabled, the appropriate status flag "CG" and/or "T99" will turn on. The MONITOR BUTTON may then be used to toggle CG and/or T99 between disabled and enabled by pressing and holding it for at least one (1) second; the appropriate status flag will toggle on or off. The MONITOR BUTTON is also used to reset T99 operation after a call is received.

EMERGENCY BUTTON

The EMERGENCY BUTTON is the small red button located on top of the radio near the antenna. If this button is programmed for emergency operation, pressing it for at least one (1) second will cause the radio to transmit GE-STAR emergency signalling. The "EMG" status flag will turn on. GE-STAR is transmitted according to one of several different programmable methods. See **EMERGENCY OPERATION** for details.

This button may also be programmed as an home mode button. If programmed in this manner, pressing it will switch operation to the programmed home mode.




Figure 1 - M-PA Personal Radio




Figure 2 - M-PA Radio (Top View)

SIDE VIEW

FRONT VIEW

Figure 3 - M-PA Scan Model Radio

MENU BUTTON (Scan Model)

Pressing the MENU button causes the radio to scroll through up to six (6) different menus programmed into the radio. After the desired menu is displayed, the feature within the menu is selected with the SEL button. The menus that may be programmed are:

Menu Display

Function Or Use

"CHANNEL"

The MENU and SEL buttons are programmed for channel selection. When this display appears, select the desired channel with the SEL button and then press EXIT.

"MODE"

The MENU and SEL buttons are programmed for mode selection. When this display appears, select the desired mode by pressing the SEL button and then press EXIT.

"PHONE"

Allows selection of one (1) of the ten (10) programmed telephone numbers for automatic dialling.

"KEY LOCK"

Allows the keypad buttons to be locked or unlocked.

"SCAN A/D"

Allows channels to be added to or deleted from the scan list for the current mode. The priority-one channel and the priority-two channel are also set within this menu.

"ALERT"

Allows the alert tones to be disabled or enabled.




Figure 4 - M-PA Scan Model Keypad

SELECT BUTTON

Selecting different features within each menu is accomplished with the SEL button. First, the menu mode must be enabled and the desired menu must be chosen by pressing and releasing the MENU button until the desired menu appears in the display.

After the menu is chosen, the desired function or feature is selected by pressing the SEL button. For example, to disable the alert tones, press MENU until "ALERT" is displayed then press SEL to select "DISABLED". Next press the EXIT button.

EXIT BUTTON

Pressing the EXIT button will cause the radio to exit the current menu display and return operation to the channel currently selected. If the menu mode is not enabled when the button is pressed, pressing this button will turn the display and keypad backlighting on for thirty (30) seconds if the backlight is programmed on.

SCAN BUTTON

Pressing the SCAN button on the keypad will toggle scan operation on and off. When the radio is scanning, the "SCN" status flag in the display will show and all channels on the scan list will be scanned. See **SCANNING CHANNELS** for additional details.

MENU BUTTON (System Model)

Pressing the MENU button causes the radio to scroll through up to seven (7) different menus programmed into the radio. After the desired menu is displayed, the feature within the menu is selected with the SEL button. The menus that may be programmed are:

Menu Display

Function Or Use

"CHANNEL"

The MENU and SEL buttons are programmed for channel selection. When this display appears, select the desired channel with the SEL button and then press EXIT.

"MODE"

The MENU and SEL buttons are programmed for mode selection. When this display appears, select the desired mode by pressing the SEL button and then press EXIT.

"PHONE"

Allows selection of one(1) of the ten (10) programmed or user entered telephone numbers for automatic dialling.

SIDE VIEW

FRONT VIEW

Figure 5 - M-PA System Model Radio

"KEY LOCK"

Allows the keypad buttons to be locked or unlocked.

"SCAN A/D"

Allows channels to be added to or deleted from the scan list for the current mode. The priority-one channel and the priority-two channel are also set within this menu.

"ALERT"

Allows the alert tones to be disabled or enabled.

"PHN EDIT"

Allows editing of the telephone phone numbers programmed into the radio.

EXIT BUTTON

Pressing the EXIT button will cause the radio to exit the current menu display and return operation to the channel currently selected. If the menu mode is not enabled when the button is pressed, pressing this button will turn the display and keypad backlighting on for thirty (30) seconds (if the backlight is programmed on).




Figure 6 - M-PA Scan Model Keypad

SCAN BUTTON

*Pressing the SCAN button on the keypad will toggle scan operation on and off. When the radio is scanning, the "SCN" status flag in the display will show and all channels on the scan list will be scanned. See **SCANNING CHANNELS** for additional details.*

SELECT BUTTON

Selecting different features within each menu is accomplished with the SEL button. First, the menu mode must be enabled and the desired menu must be chosen by pressing and releasing the MENU

button until the desired menu appears in the display. After the menu is chosen, the desired function or feature is selected by pressing the SEL button. For example, to disable the alert tones, press MENU until "ALERT" is displayed then press SEL to select "DISABLED". Next press the EXIT button.

DTMF KEYPAD

Telephone interconnect calls can be made using the 12-button DTMF keypad. This keypad is enabled when a channel programmed for DTMF operation is selected. See **TELEPHONE INTERCONNECT CALLS** for details.

INDICATORS

The radio's liquid crystal display (LCD) located on the front panel has eight (8) alphanumeric characters and eleven (11) status flags. This display indicates the current operating channel and it displays the menu information when this mode is enabled. It also displays telephone interconnect numbers and various other messages.

LCD backlighting will turn on for a short period anytime an active button is pressed or the CONTROL KNOB is rotated. Backlighting may be programmed to remain off at all times. Pressing the EXIT button when the menu mode is not enabled will turn display and keypad backlighting on for thirty (30) seconds (if backlight programming is on).




Figure 7 - Liquid Crystal Display

The status flags located along the top and bottom of the display indicate operating status as follows:

- EMG** EMerGency mode - On indicates emergency GE-STAR signalling has been initiated by the user.
- HI** High power transmit - On indicates the selected channel has been programmed for high power transmit operation. Off indicates low power transmit.

T99 *Type 99 tone decode - On indicates Type 99 tone decoding is enabled on the selected channel. Flashing indicates a T99 selective call has been received and the radio must be reset to receive another T99 call.*

TX *Transmitter enabled - On when the radio is transmitting.*

BSY *BuSY - On indicates a carrier is being received (the channel is busy). Note that if the selected channel is programmed for Channel Guard (CG), Digital Channel Guard (DCG), or Type 99 (T99) tone decode operation, the radio will not un-squelch if a valid tone or code is not received; the BSY status flag will be on.*

CG *Channel Guard - On indicates tone Channel Guard (CG) or Digital Channel Guard (DCG) encode/decode is enabled on the selected channel.*

BAT *BATtery low - On indicates the battery pack's charge is low.*

The following status flags are for use with Scan and System model radios:

S *Scan list - On indicates the selected channel is on the scan list.*

1 *priority 1 - On indicates the selected channel is designated as the priority-one scan channel.*

2 *priority 2 - On indicates the selected channel is designated as the priority-two scan channel.*

SCN *SCaN mode - On indicates the radio is scanning.*

UNIVERSAL DEVICE CONNECTOR

The Universal Device Connector (UDC) is located on the side of the radio just above the PTT and MONITOR BUTTONS. This connector provides connections for the external accessories such as a headset, a speaker-mike, or an emergency lanyard. When the radio is locked in a vehicular charger/repeater the UDC provides the audio and control connections between the radio and the vehicular charger/repeater. The UDC is also used by the maintenance personnel when the radio is programmed.

ALERT TONES

The M-PA uses alert tones or "beeps" to indicate various operating conditions. Alert tones may be enabled or disabled via the menu mode if the "ALERT" feature is programmed. See "ALERT" MENU for details. The alert tones may be disabled when the radio is programmed.

CARRIER CONTROL TIMER

This feature, programmable on a per channel basis, prevents unnecessary channel traffic and radio damage in the event of a "stuck" mic. If the programmed timer times-out during a transmission the radio will sound an alert tone and disable the transmission. The beeping tone will continue until the PTT BUTTON is released. Releasing the PTT BUTTON resets the timer.

CHANNEL BUSY

If the radio is receiving a signal when the PTT BUTTON is pressed, an alert tone will warn the operator that the radio is receiving a carrier and the transmission will not occur. "RX BUSY" is displayed and the alarm is sounded as long as the PTT BUT-

TON is pressed. This feature is programmable on or off on a per channel basis.

RECEIVE ONLY CHANNEL

If the selected channel is programmed as receive only, the radio will sound an alert tone if a transmission is attempted. "RX ONLY" is displayed.

RADIO/CHANNEL FAILURE

If the synthesizer is unable to lock correctly on the selected channel, or another radio failure occurs, an alert tone will sound. If incorrect programming is detected or the synthesizer fails to lock, the display flashes "NO LOCK" then the selected channel's name.

OPERATION

POWER-UP

After the battery pack and antenna have been installed, turn the radio on by sliding the ON/OFF SWITCH on the battery pack up. After the radio has completed a power-up self-test, it will begin operation on the last operating state as displayed in the LCD.

If programmed on, the power-up alert tone (beep) will be heard.

MODE/CHANNEL/CG SELECTION

The M-PA Scan and System model radios may be programmed with up to 192 different radio channels. A maximum of 12 modes of 16 channels each or 16 modes of 12 channels each may be programmed into the radio ($12 \times 16 = 192$). Select the desired mode (bank of channels) and channel, or channel and Channel Guard (CG), according to the radio's programming as follows:

MENU And SEL Selects Mode

CONTROL KNOB Selects Channel (And CG)

- 1. Press the MENU button until "MODE" appears in the display.*
- 2. Press the SEL button to select the desired mode. The selected mode's name will appear in the display.*
- 3. Press the EXIT button to switch radio operation to the selected mode and exit the menu.*

- 4. Select the desired channel by rotating the CONTROL KNOB until the desired channel's name appears in the display.*

CONTROL KNOB Selects Mode

MENU And SEL Selects Channel (And CG)

- 1. Select the correct mode by rotating the CONTROL KNOB until the desired mode's name appears in the display.*
- 2. Press the MENU button until "CHANNEL" appears in the display.*
- 3. Press the SEL button until the desired channel's name appears in the display.*
- 4. Press the EXIT button to switch radio operation to the displayed channel and exit the menu.*

MENU and SEL Selects Modes And Channels

CONTROL KNOB Selects Channel Guard

- 1. Press the MENU button until "MODE" appears in the display.*

2. Press the SEL button until the desired mode's name appears in the display.
3. Press the MENU button until "CHANNEL" appears in the display.
4. Press the SEL button until the desired channel's name appears in the display.
5. Press the EXIT button to switch radio operation to the new mode and channel, and exit the menu.
6. Select the desired Channel Guard using the CONTROL KNOB. The "CG" status flag will turn on if the selected position has CG programmed. Position fifteen (15) is a non-CG position; it may not be programmed with a Channel Guard. Position sixteen (16) is a default channel CG position; selecting it will switch CG to the CG programmed for the selected channel.

RECEIVING A MESSAGE

1. Slide the ON/OFF SWITCH on the battery pack to the on position. The radio will initi-

ate and complete the power-up self-test and beep if the power-up alert tone is programmed on.

2. Select the desired operating mode, channel, and/or Channel Guard. See the **MODE/CHANNEL/CG SELECTION** for details.
3. Press the MONITOR BUTTON to disable squelch and adjust the VOLUME CONTROL KNOB for the approximate desired speaker audio level. Pressing the MONITOR BUTTON may affect Channel Guard and/or Type 99 tone operation if programmed for the selected channel.
4. When a transmission is received, the receiver will unsquelch and it will be heard in the speaker. However, if the selected channel is programmed for Channel Guard or Type 99 tone operation, the receiver will not unsquelch unless the correct CG or T99 tone is received.

5. Adjust the volume as necessary.

TRANSMITTING A MESSAGE

1. *Select the desired mode, channel, and/or Channel Guard. See the **MODE/CHANNEL/CG SELECTION** for details..*
2. *Ensure no one is transmitting on the selected channel by pressing the MONITOR BUTTON to disable squelch or observing the display for the absence of the "BSY" status flag. If the Channel Busy Lockout feature is programmed for the selected channel, the radio will not transmit when the channel is busy.*
3. *Press and hold the PTT BUTTON. The "TX" and "BSY" status flags are displayed.*
4. *Hold the radio approximately three inches from your mouth and speak into the microphone in a normal voice.*
5. *Release the PTT BUTTON when the transmission is complete. If the transmission exceeds the programmed Carrier Control Timer limit, the radio will unkey and an alert tone will sound.*
6. *Listen for a reply.*

EMERGENCY OPERATION

The radio may be programmed to transmit GE-STAR emergency signalling when the EMERGENCY BUTTON is pressed or from a UDC connected lanyard. If the EMERGENCY BUTTON is programmed for GE-STAR emergency activation, press it for approximately one (1) second to activate the transmission. If the lanyard is programmed for activation, follow the instructions provided with it. GE-STAR is programmed to transmit in one of the following methods:

- *GE-STAR is transmitted on a predetermined mode and channel regardless of the selected channel. In this case the selected channel is available for voice and the radio will periodically "jump" to the predetermined channel and send the emergency message and then "jump back" to the selected channel for voice operation.*
- *GE-STAR is transmitted on the selected channel. If the channel is changed the emergency bursts will follow the newly selected channel.*
- *The radio switches to and stays on a predetermined mode and channel and GE-STAR*

is transmitted on that channel. Rotating the CONTROL KNOB will not change channels. Turning the radio off and back on will reset this condition.

- *GE-STAR is sent on the selected channel and the radio locks onto that channel. Rotating the CONTROL KNOB will not change channels. Turning the radio off and then back on will reset this condition.*

SCANNING CHANNELS (Scan and System models)

The M-PA may be programmed for non-priority scan, dual-priority scan, or scan operation may be disabled. Scan programming options include a keypad entered scan list or a fixed scan list. Priority scan programming options include a fixed priority-one channel or the selected channel as the priority-one channel.

The radio may be programmed to scan only the channels in the current mode or it may be programmed to scan across modes.

Scan rate will vary depending upon the number of channels on the scan list and whether or not the radio is programmed to scan for Channel Guard.

Fewer channels will result in a faster scan rate. All scan functions are retained in memory when the battery pack is removed.

The radio will not scan when the emergency mode is enabled ("EMG" status flag is on).

Adding Channels To And Deleting Channels From The Scan List

If the "SCAN A/D" menu is programmed, channels may be added to and deleted from the scan list of each mode as follows:

1. *Select the desired mode and channel. If the selected channel is currently on the list, the "S" status flag will be on.*
2. *Press the MENU button until "SCAN A/D" is displayed.*
3. *Press the SEL button until the desired priority indicator appears: "S" for non-priority, "2" for priority-two, "1" for a priority-one, or no indicator to remove the channel from the scan list. If a new priority channel is selected the previous corresponding priority channel will become a non-priority scan*

channel. One of the following messages may be momentarily displayed:

"SCAN DIS" - – The radio is not programmed to scan.

"FIXED P1" - – A priority-one channel has been programmed into the radio. A new priority-one channel can not be selected.

"FIXD LST" - – A fixed scan list is programmed into the radio. It is not possible to change the list without reprogramming the radio.

4. To add or delete additional channels, repeat steps 2 through 4.

5. Press the EXIT button to return to normal operation.

Using Scan

Toggle scan on or off by pressing SCAN. The "SCN" status flag turns on when the radio is scanning.

TELEPHONE INTERCONNECT CALLS

SCAN Model

Telephone interconnect calls can be placed on radio channels equipped with this capability. Each channel programmed into the radio can be programmed for telephone interconnect by enabling it for DTMF dial operation. One (1) of the ten (10) programmed telephone numbers can be selected and automatically dialled.

Communication takes place in a simplex mode. In other words, the PTT BUTTON must be pressed each time you wish to transmit and it must be released to receive.

Placing A Call

Ten (10) telephone numbers can be programmed in the radio for automatic dial operation. Typically, telephone numbers programmed into the radio by the maintenance personnel each have a specific name (8 characters maximum) assign. For example: "OFFICE" or "HOME". To recall a number and complete a call, proceed as follows:

1. If the "SCN" status flag is on, press SCAN to turn scan off.
2. Select a channel in your radio system that has telephone interconnect capability. The radio should be programmed for DTMF operation on this channel.
3. Press the MENU button until "PHONE" appears in the display.
4. Press the SEL button to scroll through the phone list until the programmed name for the desired telephone number appears in the display.
5. Press and release the PTT BUTTON to automatically dial the selected number.
6. When the called party answers, press the PTT BUTTON to transmit and release it to receive. Repeat as needed.
7. At the completion of the call, press the EXIT button. The radio will then transmit the disconnect digit to hang-up.

If programmed for dual-priority scan operation, the priority-one, priority-two and the remaining channels will be scanned. Once a carrier is detected and if programmed, the correct Channel Guard is decoded, the display will indicate the channel. Scanning of the priority-one and priority-two channels will continue. Should a priority-one or two channel carrier, regardless of Channel Guard, be detected while a non-priority channel is being received, the display name is updated, the applicable status indicator, "1" or "2" lights, and the channel is switched to the priority channel. Scanning of the priority-one channel will continue if a message is being received on the priority-two channel.

If programmed for non-priority scan operation, once a carrier is detected, and if programmed, the correct Channel Guard is decoded, the display will indicate the detected channel. Scanning will stop and the radio will remain on the channel until the carrier ceases. Scanning will then resume with the selected channel's name displayed.

TELEPHONE INTERCONNECT CALLS

SYSTEM MODELS

Telephone interconnect calls can be placed on radio channels equipped with this capability. Each channel programmed into the radio can be programmed for telephone interconnect by enabling it for DTMF dial operation. One (1) of the ten (10) programmed telephone numbers can be selected and automatically dialled.

Communication takes place in a simplex mode. In other words, the PTT BUTTON must be pressed each time you wish to transmit and it must be released to receive.

The keypad on the radio's front panel allows the operator to make telephone interconnect calls on radio systems equipped with this capability. Telephone numbers may be manually dialed using the DTMF numeric keypad, or one (1) of the ten (10) programmed or stored numbers can be selected and automatically dialed. Each channel may be programmed for telephone interconnect by enabling it for DTMF dial operation.

Most systems require an "" to be sent at the beginning of a transmission to get a dial tone. Others require "#". After the dial tone is received, the number is sent.*

Communication takes place in a simplex mode. In other words, the PTT BUTTON must be pressed each time you wish to transmit and it must be released to receive.

At the completion of the call most systems require a "#" to be sent to disconnect the user from the telephone system. Others require "".*

Placing A Manually Dialed Call

- 1. If the "SCN" status flag is on, press SCAN to turn scan off.*
- 2. Select a channel in your radio system that has telephone interconnect capability. The radio should be programmed for DTMF operation on this channel.*
- 3. Press and hold the PTT BUTTON to key the transmitter.*

4. While holding the PTT BUTTON, press either the "*" button or the "#" button as required by the radio system to obtain a telephone line. The radio will transmit the selected tone.
5. Release the PTT BUTTON and listen for a dial tone.
6. When the dial tone is received, press and hold the PTT BUTTON and dial the desired telephone number. As you dial each number, the DTMF sidetone will be heard in the speaker as the radio transmits the DTMF tone.
7. Release the PTT BUTTON when the dial sequence is complete.
8. When the called party answers, press the PTT BUTTON each time you wish to talk (transmit) and release it when you wish to listen (receive). If desired, enable private mode by pressing the PVT button.
9. At the completion of the call, press and hold the PTT BUTTON and then press the "#" or "*" button as the telephone interconnect system requires. Release the PTT BUTTON.

Placing An Automatically Dialed Call

Ten (10) telephone numbers can be programmed or stored in the radio for automatic dial operation. Typically, telephone numbers that are programmed into the radio by the maintenance personnel each have a specific name (8 characters maximum) assigned. For example: "OFFICE" or "HOME". Telephone numbers that are stored in the radio using the numeric keypad are named "PHONE x" (where "x" is the storage location 1 - 10) when they are stored. When stored numbers are later recalled using the "PHONE" menu, the last eight (8) entered digits of the number will be the name that appears in the display. To recall a programmed or stored number and complete a call, proceed as follows:

1. If the "SCN" status flag is on, press SCAN to turn scan off.
2. Select a channel in your radio system that has telephone interconnect capability. The radio should be programmed for DTMF operation on this channel.
3. Press the MENU button until "PHONE" appears in the display.

4. Press the SEL button to scroll through the phone list until the programmed or stored name for the desired telephone number appears in the display.
5. Press and release the PTT BUTTON to automatically dial the selected number.
6. When the called party answers, press the PTT BUTTON to transmit and release it to receive. Repeat as needed.
7. At the completion of the call, press the EXIT button. The radio will then transmit the disconnect digit to hang-up.

Editing The Programmed Telephone Numbers Or Storing A New Telephone Number

Any of the programmed or stored telephone numbers may be edited using the "PHN EDIT" menu. This menu also allows new phone numbers to be stored (added) to the list. Up to a maximum of ten (10) different numbers can be programmed and/or stored in the radio.

1. Press the MENU button until "PHN EDIT" appears in the display.

2. Press the SEL button until the name for the desired telephone number appears in the display.
3. Enter the new number using the numeric keypad. If a mistake is made, press the MONITOR BUTTON to abort and then enter the correct number.
4. After the correct number has been entered, press EXIT to enter the new number and return to normal operation.

"KEY LOCK" MENU (Scan and System models)

The "KEY LOCK" menu allows the keypad (SCAN button and the twelve (12) numeric buttons) to be locked or disabled to prevent accidental activation. If this menu is programmed into the radio, lock and unlock the keypad as follows:

Lock The Keypad

1. If the "SCN" status flag is on, press SCAN to turn scan off.
2. Press the MENU button until "KEY LOCK" appears in the display.

3. Press the SEL button until "LOCKED" is displayed.
4. To lock the keypad press the EXIT button.

Unlock The Keypad

1. Press the MENU button until "KEY LOCK" appears in the display.
2. Press the SEL button until "UNLOCKED" is displayed.
3. To unlock the keypad press the EXIT button.

"ALERT" MENU (Scan and System models)

The "ALERT" menu allows the alert tones to be disabled or enabled. If this menu is programmed into the radio, disable and enable the alert tones as follows:

Disable The Alert Tones

1. If the "SCN" status flag is on, press SCAN to turn scan off.

2. Press the MENU button until "ALERT" appears in the display.
3. Press the SEL button until "DISABLED" is displayed.
4. To disable the tones press the EXIT button.

Enable The Alert Tones

1. Press the MENU button until "ALERT" appears in the display.
2. Press the SEL button until "ENABLED" is displayed.
3. To enable the tones press the EXIT button.

PROGRAMMABLE FEATURES

The radio's features or "personality" are programmed using an IBM PC or compatible computer. For field programming, a full screen portable PC can be used. Programming software is provided on 5-1/4 floppy or 3-1/2 inch disks. This software uses a series of screens and windows to guide you through a programming session.

PROGRAMMABLE BY CHANNEL

- *Transmit and Receive Frequencies*
- *8-Character Alphanumeric Display (Channel Designator)*
- *Tone or Digital Channel Guard Encode/Decode*
- *Type 99 Tone Decode*
- *Transmit Power Level High or Low*
- *Transmit STE On or Off*
- *Channel Busy Lockout*
- *Carrier Control Timer*
- *Backlight On or Off*
- *Alert Tones On or Off*
- *Switch Crystal Frequency*
- *GE-STAR*
- *GE-STAR sent with Channel Guard*
- *Channel Scan (Scan or System Radio)*

RADIO PROGRAMMABLE

- *Minimum Volume Level*
- *GE-STAR Lanyard*
- *Emergency Channel*
- *Vehicular Charger Backlight*
- *Control Knob Selects Channels, Modes or Channel Guard*
- *Mode Control (Scan or System Radio)*
- *Menu Selections (Scan or System Radio)*
- *Home Mode or Home Channel (Depending on Control Knob Programming (Scan or System Radio))*
- *Scan Enabled or Disabled (Scan or System Radio)*
- *Priority-One and Priority-Two Scan Channel (Scan or System Radio)*
- *Selected Channel is Priority-One Scan Channel (Scan or System Radio)*
- *DTMF Enabled Per Mode (Scan or System Radio)*
- *Ten (10) Telephone Numbers (Scan or System Radio)*

OPERATING TIPS

Antenna location and condition is important when operating a portable radio. Operating the radio in low areas of terrain, under power lines or bridges, inside of a vehicle or in a metal or steel framed building can severely reduce the range of the unit. Mountains and buildings can also reduce the range of the unit.

In areas where transmission or reception is poor, some improvement may be obtained by insuring that the antenna is vertical. Moving a few yards in another direction or moving to a higher elevation may also improve communication. Vehicular operation can be aided with the use of an externally mounted antenna.

Battery condition is another important factor in the trouble free operation of a portable radio. Always properly charge the batteries.

Always observe all of the Federal Communication Commission's rules and regulations.

OPERATING RULES AND REGULATIONS

Two-way FM radio systems must be operated in accordance with the rules and regulations of the Federal Communications Commission (FCC). As an operator of two-way radio equipment, you must be thoroughly familiar with the rules that apply to your particular type of radio operation. Following these rules will help eliminate confusion, assure the most efficient use of the existing radio channels, and result in a smoothly functioning radio network.

When using your two-way radio, remember these rules:

- 1. It is a violation of FCC rules to interrupt any distress or emergency message. As your radio operates in much the same way as a telephone "party line", always listen to make sure that the channel is clear and/or observe the display for the absence of the "BSY" status flag before transmitting. Emergency calls have priority over all other messages. If someone is sending an emergency message - such as reporting a fire or asking for help in an accident - KEEP OFF THE AIR!*

- 2. The use of profane or obscene language is prohibited by Federal law.*
- 3. It is against the law to send false call letters, or false distress or emergency messages.*
- 4. The FCC requires that you keep conversations brief and confine them to business. To save time, use coded messages whenever possible.*
- 5. Using your radio to send personal messages (except in an emergency) is a violation of FCC rules. You may send only those messages that are essential for the operation of your business.*
- 6. It is against Federal law to repeat or otherwise make known anything you overhear on your radio. Conversations between others sharing your channel must be regarded as confidential.*
- 7. The FCC requires that you identify yourself at certain specific times by means of your*

call letters. Refer to the rules that apply to your particular type of operation for the proper procedure.

- 8. No changes or adjustments shall be made to the equipment except by an authorized or certified electronic technician.*

BATTERY PACKS

INSTALLING THE BATTERY PACK

- 1. Ensure the ON/OFF SWITCH on battery pack is in the off position.*
- 2. Hold the radio and battery pack with the back of them facing you.*
- 3. Align the battery pack and radio slide grooves. See Figure 8.*
- 4. Slide the battery pack fully into the radio until the battery release latch clicks into place.*




Figure 8 - Installing the Battery Pack

REMOVING THE BATTERY PACK

1. *Ensure the ON/OFF SWITCH on the battery pack is in the off position.*
2. *Press down on the battery release latch and slide the battery pack out in the direction of the release latch. See Figure 9.*




Figure 9 - Removing the Battery Pack

CHARGING THE BATTERY PACKS

After receiving a new rechargeable battery pack from the factory, it should be fully charged before placing it into service. This also applies to rechargeable batteries that have been stored for long periods. When the battery pack requires charging the radio will signal the operator with an alert tone and the "BAT" status flag will turn on.

Chargers are available with nominal charge times of 1 hour (rapid) and 14 hours (standard). Combinations include single (1) and multi (5) position, standard and rapid charge units. In addition, the vehicular chargers/repeaters simultaneously charge the battery packs while the radio is operating. For specific instructions refer to the applicable charger Operating Manual.

The rechargeable batteries used with the radio can develop a reduced capacity condition sometimes called the "Memory Effect". This condition can occur when a battery is continuously charged for long periods or when a regularly performed duty cycle allows the battery to expend only a limited portion of its capacity. The battery pack may show a severe decrease in its ability to deliver full capacity for an extended period. Any rechargeable battery pack showing signs of reduced capacity should be returned to a qualified service center for inspection.

RECHARGEABLE BATTERY PACK DISPOSAL



Ni-Cd The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal. Call Toll Free 1-800-822-9362 for information and/or procedures for returning rechargeable batteries in your state.

SWIVEL MOUNT REMOVAL AND REPLACEMENT

To remove the swivel mount, slide a flat blade screwdriver underneath the spring retainer and twist. While twisting, slide the swivel mount out from under the holder. See Figure 10.

To replace the swivel mount, place the end of the swivel in the grooves in the radio and slide the mount up until it snaps in place.




Figure 10 - Swivel Mount Removal and Replacement

INTRINSICALLY SAFE USAGE

Selected portable radios with appropriate factory installed F4 Options are certified as Intrinsically Safe by the Factory Mutual Research Corporation. Intrinsically Safe approval includes Class I, II, III, Division 1 hazardous locations in the presence of Groups C,

D, E, F and G atmospheres. Non-Incendive approval includes Class I, Division 2 hazardous locations in the presence of Groups A, B, C, and D atmospheres.

Hazardous locations are defined in the National Electrical Code. Useful standards NFPA 437A and NFPA 437M for the classifications of hazardous areas may be ordered from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

BATTERIES

Only batteries identified with a green latch shall be used with a portable radio that is rated and labeled as Factory Mutual Intrinsically Safe. Use of nonspecified batteries voids Factory Mutual approval. The following battery pack options are approved for use in intrinsically safe radios:

- PAPA1F (19A704860P6) Rechargeable Battery, Extra High Capacity (Tall Case)
- PAPA1G (19A704850P6) Rechargeable Battery, High Capacity (Short Case)

ACCESSORIES

The following accessories are approved for use with intrinsically safe radios. Use of accessories other than those listed voids Factory Mutual approval.

- | | | | |
|---------------------------|--|----------------------------|---|
| • PAAB1A
(19B801508P3) | Headset/Microphone | • PANC1F
(19B234804P12) | Antenna, 440 - 470 MHz,
Helical |
| • PAAC1A
(19B801508P2) | Earpiece Kit | • PANC1G
(19B234804P13) | Antenna, 470 - 494 MHz,
Helical |
| • PAAC1B
(19B801508P8) | GE-STAR Lanyard | • PANC1L
(19A149061P10) | Antenna, 403 - 440 MHz,
Whip |
| • PAAE1A
(19B801508P1) | Speaker/Microphone | • PANC1N
(19A149061P12) | Antenna, 440 - 512 MHz,
Whip |
| • PAAE1B
(19B801508P4) | Speaker/Microphone with
GE-STAR Lanyard | • PAHC1C | Belt Clip |
| • PAAE1C
(19B801508P6) | Speaker/Microphone/
Antenna | • PAHC1D | Swivel Mount with Belt Loop |
| • PANC1B
(19B234804P1) | Antenna, 136 - 151 MHz,
Helical | • PAHC1E | Case, Leather, with Belt Loop
(Short Case) |
| • PANC1C
(19B234804P2) | Antenna, 146 - 162 MHz,
Helical | • PAHC1F | Case, Leather, with Belt Loop
(Tall Case) |
| • PANC1D
(19B234804P3) | Antenna, 157 - 174 MHz,
Helical | • PAHC1G | Case, Leather, with Swivel
Mount and Belt Loop
(Short Case) |
| | | • PAHC1H | Case, Leather, with Swivel
Mount and Belt Loop
(Tall Case) |
| | | • PAHC1K | Shoulder Strap, Leather, with
Mounting Plate |
| | | • PAHC1N | Holster, Plastic. |

WARRANTY

- A. Ericsson GE Mobile Communications Inc. (hereinafter "Seller") warrants to the original purchaser for use (hereinafter "Buyer") that Equipment manufactured by Seller shall be free from defects in material, workmanship and title, and shall conform to its published specifications. With respect to any Equipment not manufactured by Seller (except for integral parts of Seller's Equipment to which the warranties set forth above shall apply). Seller gives no warranty, and only the warranty, if any, given by the manufacturer shall apply. Batteries are excluded from this warranty but are warranted under a separate Nickel-Cadmium Battery Warranty.
- B. Seller's obligations set forth in Paragraph C below shall apply only to failures to meet the above warranties (except as to title) occurring within the following periods of time from date of sale to the Buyer and are conditioned on Buyer's giving written notice to Seller within thirty (30) days of such occurrence:
1. for fuses, incandescent lamps, vacuum tubes and non-rechargeable batteries, operable on arrival only.
 2. for parts and accessories (except as noted in B.1) sold by Seller's Service Parts Operation, ninety (90) days.
 3. for all other Equipment of Seller's manufacture, one (1) year.
- C. If any Equipment fails to meet the foregoing warranties, Seller shall correct the failure at its option (i) by repairing any defective or damaged part or parts thereof, or (ii) by making available at Seller's factory any necessary repaired or replacement parts. Any repaired or replacement part furnished hereunder shall be warranted for the remainder of the warranty period of the Equipment in which it is installed. Where such failure cannot be corrected by Seller's reasonable efforts, the parties will negotiate an equitable adjustment in price. Labor to perform warranty service will be provided at no charge only for the Equipment covered under Paragraph B.3, and only during the first three (3) months following the date of sale to the Buyer. Thereafter, labor will be charged at prevailing rates. To be eligible for no-charge labor, service must be performed by an authorized General Electric Service Station or other Servicer approved for these purposes either at its place of business during normal business hours, for mobile or personal equipment, or at the Buyer's location, for fixed location equipment. Service on fixed location equipment more than thirty (30) miles from the Service Station or other approved Servicer's place of business will include a charge for transportation. Equipment located off-shore is not eligible for no-charge labor.
- D. Seller's obligations under Paragraph C shall not apply to any Equipment, or part thereof, which (i) has been modified or otherwise altered other than pursuant to Seller's written instructions or written approval or, (ii) is normally consumed in operation or, (iii) has a normal life inherently shorter than the warranty periods specified in Paragraph B, or (iv) is not properly stored, installed, used, maintained or repaired, or, (v) has been subjected to any other kind of misuse or detrimental exposure, or has been involved in an accident.
- E. The preceding paragraphs set forth the exclusive remedies for claims (except as to title) based upon defects in or nonconformity of the Equipment, whether the claim is in contract, warranty, tort (including negligence), strict liability or otherwise, and however instituted. Upon the expiration of the warranty period, all such liability shall terminate. The foregoing warranties are exclusive and in lieu of all other warranties, whether oral, written, expressed, implied or statutory. NO IMPLIED OR STATUTORY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE SHALL APPLY. IN NO EVENT SHALL THE SELLER BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, INDIRECT OR EXEMPLARY DAMAGES.

*This warranty applies only within the United States.
1-800-528-7711 (1-800-237-0138 in Virginia).*

NICKEL-CADMIUM BATTERY WARRANTY

- A. *Ericsson GE Mobile Communications Inc. (hereinafter "Seller") warrants to the original purchaser for use (hereinafter "Buyer") that nickel-cadmium batteries supplied by Seller shall be free from defects in material and workmanship, and shall conform to its published specifications for a period of twelve (12) months from the date of purchase.*
- B. *For purposes of this warranty, batteries shall be deemed defective if (1) the battery capacity is less than 80% of rated capacity, or (2) the battery develops leakage.*
- C. *If any battery fails to meet the foregoing warranty, Seller shall correct the failure by issuing a replacement battery upon receipt of the defective battery at an authorized General Electric Service Station (GESS). To obtain the name and address of a GESS, ask your salesperson, consult the Yellow Pages, or call the number printed at the bottom of this page.*
- D. *Replacement batteries shall be warranted only for the remaining unexpired warranty period of the original battery. This warranty becomes void if:*
 - (1) *The battery has been subjected to any kind of misuse, detrimental exposure, or has been involved in an accident.*
 - (2) *The battery is used in equipment or service other than the radio equipment for which it is specified.*
- E. *The preceding paragraphs set forth the exclusive remedies for claims (except as to title) based upon defects in or non-conformity of any battery, whether the claim is in contract, warranty, tort (including negligence), strict liability or otherwise, and however instituted. Upon the expiration of the warranty period, all such liability shall terminate. The foregoing warranties are exclusive and in lieu of all other warranties, whether oral, written, expressed, implied or statutory. NO IMPLIED OR STATUTORY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE SHALL APPLY. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, INDIRECT OR EXEMPLARY DAMAGES.*

*This warranty applies only within the United States.
1-800-528-7711 (1-800-237-0138 In Virginia).*

NOTES

NOTES

NOTES



Ericsson GE Mobile Communications Inc.
Mountain View Road • Lynchburg, Virginia 24502

Printed in U.S.A.