

Maintenance Manual



MASTR® III
EMERGENCY POWER OPTIONS
CH1L - Automobile Battery 120 VAC/60 Hz
CH1M - Automobile Battery 230 VAC/50 Hz
CH1R - GEL CELL Battery 120 VAC/60 Hz
CH3A - GEL CELL Battery 230 VAC/50 Hz

CAUTION

THESE SERVICE INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID ELECTRIC SHOCK DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN THE OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO. REFER ALL SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION: TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

| | | |
|--|---|---|
|  <p>The lightning flash and arrowhead within the triangle is a warning sign alerting you of "dangerous voltage" inside the product.</p> | <p>CAUTION</p> <p>RISK OF ELECTRIC SHOCK DO NOT OPEN</p> <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK. DO NOT REMOVE COVER (OR BACK). NO USER-SERVICABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p> |  <p>The exclamation point within the triangle is a warning sign alerting you of important instructions accompanying the product.</p> |
| See Marking On Bottom/Back Of Product | | |

NOTICE!

This manual covers Ericsson and General Electric products manufactured and sold by Ericsson Inc.

NOTICE!

Repairs to this equipment should be made only by an authorized service technician or facility designated by the supplier. Any repairs, alterations or substitution of recommended parts made by the user to this equipment not approved by the manufacturer could void the user’s authority to operate the equipment in addition to the manufacturer’s warranty.

NOTICE!

The software contained in this device is copyrighted by the Ericsson Inc. Unpublished rights are reserved under the copyright laws of the United States.

This manual is published by **Ericsson Inc.**, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by **Ericsson Inc.**, at any time and without notice. Such changes will be incorporated into new editions of this manual. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of **Ericsson Inc.**

TABLE OF CONTENTS

| | Page |
|---|------|
| MIII BASE STATION EMERGENCY POWER OPTIONS | 1 |
| CHARGER SPECIFICATIONS | 2 |
| EMERGENCY POWER OPTION SYSTEM DESCRIPTION | 2 |
| CIRCUIT DESCRIPTION AND THEORY OF OPERATION | |
| FOR THE BATTERY CHARGER | 2 |
| GENERAL | 2 |
| MAIN CHARGING CIRCUITRY | 3 |
| OVERCURRENT PROTECTION | 3 |
| INPUT OVERVOLTAGE PROTECTION | 3 |
| OVERTEMPERATURE PROTECTION | 4 |
| BATTERY SWITCHING OPERATION | 4 |
| DEEP DISCHARGE PROTECTION | 4 |
| ERROR FLAG SIGNALS | 4 |
| INTERNAL BIAS VOLTAGE SOURCES | 4 |
| FLOAT VOLTAGE ADJUST | 4 |
| TROUBLESHOOTING PROCEDURE | 5 |
| PARTS LIST | |
| BATTERY & HARDWARE KITS | 5 |
| BATTERY CHARGER | 10 |
| SCHEMATIC DIAGRAM | |
| 50 Hz CHARGER | 6 |
| 60 Hz CHARGER | 7 |
| ASSEMBLY DIAGRAM | |
| 50 Hz CHARGER | 8 |
| 60 Hz CHARGER | 9 |
| MASTR III STATION | 13 |
| INTERCONNECTION DIAGRAM | 12 |
| INSTALLATION INSTRUCTIONS | 16 |

EMERGENCY POWER OPTIONS

- CH1L - AUTOMOBILE BATTERY EMERGENCY POWER (120 Vac/60 Hz VERSION); Adds a charger and power harness cabling. The automobile battery is external to the base station cabinet and is purchased separately by the customer for field installation.
- CH1M - AUTOMOBILE BATTERY EMERGENCY POWER (230 Vac/50 Hz VERSION) Same as CH1L except for international version charger.

- CH1R - GEL CELL BATTERY EMERGENCY POWER (120 Vac/60 Hz VERSION) Adds a charger, power cable harnessing, and a gel cell shelf. The four 12V 25 AH gel cell batteries are not included in this option. Each of the batteries can be ordered for field installation per drop ship index item, V2401.
- CH3A - GEL CELL BATTERY EMERGENCY POWER (230 Vac/50 Hz VERSION) Same as CH1R except for international version charger.

NOTICE!

Options CH1L, CH1M, CH1R & CH3A are emergency power backup options only. They are activated only when their AC power is interrupted. To insure proper operation the options AC power cord MUST be connected to the same receptacle, or at a minimum the same MAIN, as the station that its batteries are backing up. Also for proper charging the charger MUST remain connected to the AC MAIN when the MAIN is active.

| | | CH1L | CH1M | CH1R | CH3A |
|-------------|-----------------------|------|------|------|------|
| 344A3168P1 | 10 AMP CHARGER, 60 Hz | 1 | | 1 | |
| 344A3168P2 | 10 AMP CHARGER, 50 Hz | | 1 | | 1 |
| 344A3696G1 | CHARGER KIT | 1 | 1 | | |
| 344A3696G2 | CHARGER KIT | | | 1 | 1 |
| 19C852074P1 | SUPPORT | 1 | 1 | 1 | 1 |
| 19C852074P2 | SUPPORT | 1 | 1 | 1 | 1 |
| 19D903719P1 | BATTERY STANDBY SHELF | | | 1 | 1 |
| 19C852193P1 | BATTERY COVER PANEL | | | 1 | 1 |
| 19D903635 | INTERCONNECT DIAGRAM | X | X | X | X |
| 19D902845P5 | APPLICATION ASSEMBLY | X | X | | |
| 19D424751P6 | APPLICATION ASSEMBLY | | | X | X |
| 344A4051P1 | INSTALLATION INSTRUC. | | | X | X |

344A3168 CHARGER SPECIFICATIONS

| | |
|---|--|
| Input Voltage Range (For Normal Operation State) | P1: 121 Vac ±10% for trickle charge or full rated charge 121 Vac ±20% for trickle charge only P2: 230 Vac ± 10% for trickle charge or full rated charge 230 Vac ± 15% for trickle charge only |
| Input Voltage Range (For Emergency Power State) | < 70% of nominal line voltage |
| Line Voltage Surge Protection | P1: 150 Vac rated M.O.V. P2: 275 Vac rated M.O.V. |
| Charger Output Voltage | 13.6 Vdc |
| Rated Charger Current | 10.0 amps |
| Load Current Knee | 11.0 ±1.0 amps |
| Short Circuit Current | 4.0 amps max |
| Charger Output Voltage Ripple | < 100 mV p-p (@ + 25°C) < 200 mV p-p (@ - 30°C) |
| Duty Cycle (Full Charge) (Trickle Charge) | 100% for 8 hours 100% continuously |
| Status Line Output (Normal Operation) (Emergency Power) | 23.5 ±0.5 Vdc Impedance >1 Mohm |
| Current Sourcing Capability (A+ to SW A+ port in Emergency Power State) | 33 amps max |
| Deep Discharge Cutout Voltage | 10.5 Vdc |
| Temperature Range | -30° to +60°C |
| Weight | 22 lbs. |

EMERGENCY POWER OPTION
SYSTEM DESCRIPTION

The 344A3168 series of chargers are designed to interface with 19A149978P1, Rev. B or later, or 19A149978P2, Rev. A or later series power supplies. To retrofit the charger with 19A149978P1, Rev. 0 or A power supplies, or 19A149978P2, Rev. 0 power supplies, Field Mod Kit 344A4123G1 with mod instructions 344A4124P1 must be used. Under normal operating conditions (defined as having the nominal input line voltage plus a tolerance) the relays K1, K2, and K3 are energized. 344A3168 becomes a charger, providing a full charge of up to 10 amps out of the A + port to the battery system at a constant voltage until the battery system is fully charged. If the charger attempts to source more than 10 amps because, for example, a battery has been deep discharged, then the charger’s current foldback circuitry will drop the charger voltage for a short time until the battery has been recharged enough to no longer sink more than 10 amps. The charger will then revert to providing a constant voltage charge. The charger then maintains a trickle charge indefinitely on the battery system to maintain a full charge.

Without the emergency power options, the power supply’s 10 ohm, 50 watt bleeder resistor R1 is tied to ground through an external strap, P802. With the emergency power options, P802 is removed, allowing K3, the SW GND (switched ground) relay in the charger to ground the bleeder resistor through J2-3 to provide normal operation of the supply. The STATUS line (J2-1) provides a + 24 Vdc signal to the alarm tone circuitry indicating the system is in the normal operating state.

When the input line voltage drops below 70% of the nominal line voltage, the charger reverts to the emergency power state. Current, instead of being sourced from the A + port to the battery system, is now being delivered from the battery. K1 de-energizes, and K2 remains energized. This allows up to 33 amps to flow from the battery to the charger A + port, out of the SW A + (SWitched A +) port and through the SW A + port of the power supply. The current is then fed through the power supply’s load fuses and out through the harnesses to run the base station’s power amplifier and receiver/system circuitry. K3 also de-energizes, opening the bleeder resistor circuit. This removes the 1.2 amp load on the battery that would have drained the battery at a faster rate. The STATUS line becomes an open circuit to the alarm tone circuitry indicating the system is in the emergency power state.

When the battery system has discharged to approximately 10.5 Vdc the charger de-energizes K2 to prevent a deep discharge of the battery system. This is important for both gel cells and automobile batteries but especially for automobile batteries. Any deep discharge of an automobile battery will affect its capacity to store energy. Several deep discharges would result in a

premature replacement of the battery. The charger then sits in "limbo" waiting for the normal operating range line voltage to reappear.

If the charger has:

- 1) an overheating condition, or
- 2) an overvoltage condition which would lead to an over heating condition;

then the charger will revert to a "shutdown" mode until conditions return to normal. Under normal conditions the SHUTDOWN line (J2-2) is at 0.1-0.2 Vdc. When the charger reverts to the shutdown mode, J2-2 rises to around 2-3 VDC. The charger remains in shutdown until the condition is corrected.

WARNING

Extreme care must be exercised when using an automobile battery for backup emergency power. The automobile battery must not be installed in the base station cabinet because a buildup of acidic fumes during outgassing would damage the base station circuitry. Also, there could be a dangerous buildup of hydrogen gas in the cabinet during outgassing which could lead to an explosion. Even for an automobile battery correctly installed outside of the cabinet, there could be a dangerous concentration of hydrogen gas if the room is not properly ventilated. It may even be necessary to provide a "hood" over the battery and an exhaust system to vent the gas to the out-side world. Follow OSHA (or other equivalent agency) safety construction rules to determine a proper design.

CIRCUIT DESCRIPTION AND
THEORY OF OPERATION FOR THE
344A3168P1 OR P2 BATTERY
CHARGER

GENERAL

The 344A3168 battery charger has been designed to provide both system battery charging and relay switched, emergency power via automobile battery or gel cell battery for the MASTR II/IIe/MIII series of base stations.

The charger monitors system line voltage for possible interruptions. During normal operation, the charger maintains full charge on the emergency power battery by providing a trickle charge current. In the event of a power source interruption, the charger sets the STATUS line to the emergency power mode, discontinues battery charging, and switches the battery on line to provide emergency backup power for the base station.




Figure 1 - 344A3168 Charger

Several general rules can be applied to estimate charge time of a lead acid battery system. There is almost a 100% conversion of electrical energy to stored chemical energy for the first 80% of battery capacity. If usable capacity is defined to be at least 80 % of full charge, then the time to reach usable capacity is: $T = 0.8 \times AH/C$, where T is in hours, AH is in amp-hours, and C is the average charge rate in amps. To charge the remaining 20 % to a full charge takes longer because the electrical energy is no longer close to 100 % conversion to stored chemical energy. The time to a full charge can be estimated as, $T = 1.1 \times AH/C$, where again T is in hours, AH is in amp-hours, and C is the average charge rate in amps. Using these estimates for a ten amp charger, a standard 55 Amp-Hour automobile battery and a gel cell system that uses four 25 Amp-Hour batteries in parallel would recharge in the following times:

Estimates can be provided for air time for a MII/MIII station. Assuming a worst case scenario of a 100% transmit duty cycle, the station air time with a 55 Amp-Hour automobile battery would be approximately one hour and considerably longer for a smaller transmit duty cycle. With a four-in-parallel 25 Amp-Hour gel cell system, the station air time for a 100% transmit duty cycle would be approximately three hours with again a correspondingly longer air time for a smaller transmit duty cycle.

| Qty. | Type | Usable Capacity | Full Capacity |
|------|--------------------------------|-----------------|---------------|
| 1 | 55 Amp-Hour Auto Battery | 4.4 Hours | 6.0 Hours |
| 4 | 25 Amp-Hour Gel Cell Batteries | 8.0 Hours | 11.0 Hours |

NOTE

With the four-in-parallel gel cell battery system, if one gel cell becomes defective before the other three, the customer can run with only three gel cells in parallel (with reduced air time, of course). It is not advisable to run with only two gel cells in parallel because of excessive charge current from the charger which would damage the gel cells. It is good practice when one gel cell battery becomes defective to replace all four gel cell batteries because of uneven charge and discharge characteristics of new versus old gel cells. For that same reason it is also advisable not to mix different brands of gel cells.

MAIN CHARGING CIRCUITRY

Power to the charging circuitry is provided from a 120 Vac, 60 Hz (P1) or 230 Vac/50 Hz (P2) line source connected to the main power cord (W801). Input power is passed through fuse F1 (and F2 for P2), which limits input current to 5 amps, and past varistor VR1. VR1 is a voltage transient surge protector which clamps the line at approximately 150 Vac (P1) or 275 Vac (P2). This protects the internal circuitry from potentially harmful line voltage surges.

Line voltage is then applied to transformers T1 and T2 which in parallel step the line voltage down to approximately 38 Vac. This voltage is then applied to rectifiers D1 and D2 as well as filter capacitors C1, C2, and C3. After rectification and filtering, the unregulated DC voltage is approximately 20 Vdc.

Charging current then flows through the linear regulator stage on its way to the battery. The linear regulator is composed of two basic groups. These groups are the series pass regulator group and the series pass control group.

The series pass regulator group consists of Q1, Q2, Q3, R1, R2, and R3. In order to control the output voltage of the charger, the series pass transistors are operated as variable resistors. If the load on the charger is increased, causing a drop in the output voltage, the resistance of the series pass transistors is automatically decreased. With a decrease in series pass resistance, less voltage is dropped across the transistors thus increasing the output voltage back to the desired value.

This implementation has one major drawback, a major percentage of the total power drawn by the charger is dissipated across the series pass transistors. In order to more effectively handle this dissipation, three transistors are used. Resistor R1, R2, and R3 provide negative feedback to the base of the appropriate transistor preventing unequal current flow and unequal power dissipation.

The series pass control circuitry is comprised of U3, Q4 and their associated bias resistors and decoupling capacitors. U3 continuously monitors the output voltage being developed by the interaction between the load and series pass transistors. When more output voltage is required to maintain regulation, U3 increases drive to transistor Q4. Q4 provides the amount of series pass transistor base drive necessary to decrease their resistance and boost the output voltage back up to the desired value.

This continuous interaction between the control circuitry and series pass state forms a closed loop control group which provides the regulated output voltage to the battery. Potentiometer R12 varies the amount of voltage feedback in the control loop thus allowing precise adjustment of the output voltage at which regulation is maintained.

OVERCURRENT PROTECTION

Overcurrent protection is provided via a current foldback scheme. Resistors R4, R5, and R6 form a current sensing element. The amount of voltage developed across these resistors is directly proportional to the amount of current flowing through them. This sense voltage is applied to the regulator control integrated circuit, U3, by means of R9, R10, and R50. As the current through these sense resistors increases above approximately 10.5 amps, the sense voltage

and output current to decrease. This current foldback approach for overcurrent protection decreases the amount of power dissipated across the series pass transistors during a faulted condition. The maximum allowable short circuit current is less than 3 amps.

INPUT OVERVOLTAGE PROTECTION

Overvoltage protection circuitry is provided to protect the charger from abnormally high AC line voltages. These voltages could cause premature failure of the series pass transistors due to excessive power dissipation. When the line voltage exceeds the limits specified for normal operation, the charger senses an abnormal condition and reverts to the SHUTDOWN mode. The charging current to the battery is cut off by disabling the regulator control integrated circuit, U3.

AC line voltage is applied to the input of transformer T3 which then steps down the voltage. This voltage is then rectified and filtered into a DC voltage by D10 and C18. Resistor R27 sets the response time of the filter to decreasing line voltages. The resultant DC voltage is directly proportional to the value of AC line voltage being seen by the charging circuitry. The DC voltage is then divided by the series combination of R28, R29, and R30. Potentiometer R29 is used to adjust for transformer winding ratio tolerances from unit to unit and is factory set. Capacitor C14 provides addition filtering of the line sense voltage.

CAUTION

Potentiometer R29 is specifically adjusted per internal factory specs to set the proper trip voltages to send the charger into the SHUTDOWN mode if the limits are exceeded. With the line voltage and the line frequency set at nominal values, R29 is adjusted for 3.24 ± 0.02 V(@ 230 Vac 50Hz) or 3.20 ± 0.02 Vdc (@ 121 Vac 60 Hz) at TP1. AN IMPROPER TUNING OF R29 COULD CAUSE THE CHARGER'S PASS TRANSISTORS TO DISSIPATE EXCESSIVE HEAT, RESULTING IN LOWERED RELIABILITY. THERE SHOULD BE NO NEED TO ADJUST R29 IN THE FIELD.

The same sense voltage signal provides information for both the overvoltage and undervoltage sensing circuitry. U8A provides current buffering to eliminate degradation of the signal. This buffered signal is then applied to the overvoltage comparator U7B. When a line overvoltage condition is sensed, the output of U7B, normally a high impedance, becomes a very low impedance. This low impedance removes base drive to transistor Q7. When Q7 loses base drive it turns off allowing the shutdown pin of U3 to go high and disabling drive to the series pass transistors. This effectively turns off all charging current to the battery.

Charger overvoltage sensing depends on whether the charger is in the trickle or full charge mode. The first mode of operation is for a trickle charge condition in which the battery charging current is less than 200 milliamps. The allowable line voltage range for this mode of operation is $\pm 20\%$ (P1) or $\pm 15\%$ (P2). The second mode of operation is for charging of the battery at current up to the maximum output current of 10 amps. The line voltage tolerance range for this mode of operation is $\pm 10\%$. It is critical for the charger to be able to operate over both ranges yet protect itself from excessive series pass transistor heat dissipation.

The method by which the charger discerns the appropriate line voltage tolerance is by monitoring the amount of charging current flowing through the current sense resistors R4, R5, and R6. The current sense voltage developed across these resistors is applied across the differential amplifier of U8B. The output of U8B is normally biased at 2.5 Vdc. However, as the amount of current through the sense resistors increases, (sense voltage increases) the output of U8B begins to decrease. At approximately 6 amps of charging current, the output of U8B is low enough to trip the output of comparator U6B. This normally low impedance output goes to a high impedance state removing resistor R41 from its parallel placement with resistor R40. With R40 removed, the line voltage sense voltage is now only divided by the series combination of resistors R38 and R40. This decreases the amount of line sense voltage needed to trip the overvoltage comparator U7B. This sets up the $\pm 10\%$ line voltage tolerance range. When the charging current is less than 6 amps, the output of comparator U6B remains a low impedance, placing R41 in parallel with R40 and setting up the $\pm 20\%$ ($\pm 15\%$) line voltage tolerance.

OVERTEMPERATURE PROTECTION

To protect the charger from abnormal ambient temperature operating conditions it is equipped with overtemperature protection. A thermostat, S1, has been attached to the heat sink in order to monitor the operating temperature of the series pass transistors. This thermostat is normally closed. When an abnormal operating temperature is reached, the thermostat's switch contacts open and remove base drive to Q7. As described earlier, removing base drive to Q7 causes shutdown of the charging regulator. When the temperature of the heat sink returns to a safe value, the contacts of S1 close and operation resumes.

BATTERY SWITCHING OPERATION

When the AC line voltage drops below 70% of nominal voltage, the charger interrupts the charging mode of operation and switches the battery on line for emergency power operation. The AC line voltage is sensed as described under overvoltage protection. The U8A buffered sense voltage is

applied to undervoltage comparator U7A. When the sense voltage drops below the specified limit, the normally low impedance output of U7A switches to a high impedance state. This interrupts base drive current being sourced from transistor Q5. With the interruption of its base drive current, Q5 shuts off removing the 24 volt signal coming from U4.

Switching transistor Q5 off also removes drive to relay K1 and K3. With removal of relay drive the contacts associated with K1 and K3 switch to their normally closed states. When this happens, battery charging current can no longer flow through K1 to the battery. With the K1 relay contacts in their normally closed position, current flows from the battery through K2 to the system. In addition, the K3 relay contacts open thus isolating the switched ground signal from ground.

DEEP DISCHARGE PROTECTION

The battery voltage is sensed at the charger's A + port. This voltage provides both bias voltage and signal input to voltage comparator U6A. The battery voltage is stepped down by resistors R20 and R21 and compared with the 2.5 Vdc output of voltage reference U5. When the base station reverts to emergency power, the fully charged battery voltage starts at around 12.7 Vdc and slowly drops as the battery discharges. The output of U6A remains an open circuit, allowing pull up resistors R24 and R26 to provide drive to Q6 to energize relay K2. When the battery has discharged to around 10.5 Vdc the voltage comparator output pulls low, disabling the drive to Q6 and de-energizing K2. The charger and base station remain "in limbo" until the line voltage is restored to the station power supply and charger. The charger A + port must be greater than 12.25 Vdc before K2 is re-energized to await the next emergency power state.

NOTE

The first 344A3168P1, Rev. 0 chargers do not have reverse polarity protection designed into the circuitry. This may allow blowing at transistor Q6 if customers accidentally reverse the battery cable leads. This prevents the charger from properly switching relay K2 for emergency power. A production change on 344A3168P1, Rev. A chargers and all 344A3168P2 chargers adds a diode similar to a 1N4004 to the collector of Q6. Contact Ericsson GE Technical Support for any additional information.

ERROR FLAG SIGNALS

In the event of abnormal system operation, the charger provides two error flag signals as output to the system controller. The first, SHUTDOWN, is an indication of emergency power operation. During normal operation from AC line voltage the 24 volt signal from transistor Q5 is present

at connector J2-1. When the system is in the emergency power mode, this signal is removed and becomes a high impedance, greater than one Megohm.

The second error flag is provided at connector J2-2. This signal, SHUTDOWN, indicates whether the charger is operating normally or has been shutdown due to excessive operating temperature or high line voltage. During normal operation, the 24 VDC output of voltage regulator U4 is applied through R15 to and U3. Due to the U3 interface, this voltage becomes approximately 3 volts. This signal is independent of transistor Q5. During shutdown of the charger, this output is pulled down by transistor Q7 becoming an active low impedance signal. With removal of the shutdown conditions, this signal automatically returns to the normal operating state.

INTERNAL BIAS VOLTAGE SOURCES

There are three internal bias voltage sources implemented within the charger to provide internal housekeeping supply voltages and references. The first is the previously mentioned 24 volt source provided by voltage regulator U4. This source is supplied directly off the AC line via transformer T1 and T2 as well as rectifier D6 and filter C10. This source supplies power for regulator control integrated circuit U3, relays K1, K2 and also the error flag output signal.

The second source is provided by linear regulator U1. This regulator supplies power for all the additional control circuitry. It also acts as a buffer between the control circuitry and the unregulated charging voltage from which it draws its own power. Voltage excursions on the charging bliss are not transmitted to the control circuitry thus insuring the charger's ability to protect itself.

Lastly, is the precision voltage reference provided by regulator U2. This precision 2.5 volt source creates the reference voltage that is used by all the AC line voltage comparators. The

ability to hold reasonable tolerances on line voltage sense point requires the use of a high tolerance reference voltage.

FLOAT VOLTAGE ADJUST

Both the automobile batteries and gel cells used with the new charger are lead acid based batteries. The chemical reaction rates for converting the electrical energy to stored chemical energy during charging are functions of temperature. Nominally either battery should be seeing a float voltage of 13.6 Vdc when the ambient temperature of the battery is 77°F (25° C). As the temperature increases past nominal room temperature the chemical reaction rates increase past nominal and the float voltage should be lowered to compensate. Conversely, the float voltage should be increased if the batteries are to see an average temperature of less than 77°F, but the float voltage should never exceed 14.4 Vdc. For a nominal 12 Vdc, 6 cell, lead acid battery the slope of float voltage versus ambient temperature is around -18 mV/°F (-32.4 mV/°C).

By use of the proper float voltage optimum battery usage can be obtained. If the float voltage is set too high, the battery can be overcharged, resulting in outgassing and reduction in lifetime of the battery. If the float voltage is set too low the battery recharges at a slower rate but more importantly the battery will permanently lose some of its storage capacity. Most manufacturers recommend a float voltage between 13.5 and 13.8 Vdc at room temperature.

The factory has preset the float voltage for 13.6 Vdc. If the battery will be in an environment where the AVERAGE ambient temperature will not be 77°F, then the option exists to adjust the FLOAT VOLTAGE ADJUST pot for optimum float voltage. Cable W1 (19B801937P3) is removed from J1 of charger 344A3168 to present an open circuit load. A high impedance DC voltmeter is attached to -1 (A +) and J1-2 (A-) and the pot adjusted for optimum float voltage.


TROUBLESHOOTING PROCEDURE

| SYMPTOM | PROCEDURE |
|--|---|
| NO CHARGING OUTPUT VOLTAGE | CHECK THE FOLLOWING: PROPER LINE VOLTAGE OPEN FUSE F1 OPEN TRANSISTOR A1Q4 BAD I.C. A1U3 SHORTED A1Q7 OPEN THERMISTOR A2S1 BAD RELAY A1K1 BAD I.C. A1U4 BAD I.C. A1U7 |
| OUTPUT VOLTAGE TOO HIGH (GREATER THAN 14 Vdc) | CHECK THE FOLLOWING: SHORTED TRANSISTOR A2Q1 SHORTED TRANSISTOR A2Q2 SHORTED TRANSISTOR A2Q3 BAD POTENTIOMETER A1R12 BAD I.C. A1U7 |
| OUTPUT VOLTAGE TOO LOW (GREATER THAN 1 Vdc LESS THAN 13.6 Vdc) | CHECK THE FOLLOWING: LOAD TOO HIGH (IN FOLDBACK) BAD POTENTIOMETER A1R12 BAD I.C. A1U3 SHORTED A1C4 |
| BLOWN FUSE F1 | CHECK THE FOLLOWING: SHORTED VARISTOR A1RV1 SHORTED TRANSFORMER T1 SHORTED TRANSFORMER T2 SHORTED TRANSFORMER A1T3 SHORTED DIODE A1D1 SHORTED DIODE A1D2 SHORTED DIODE A1D6 SHORTED DIODE A1D10 SHORTED CAPACITOR A1C1 SHORTED CAPACITOR A1C2 SHORTED CAPACITOR A1C3 SHORTED CAPACITOR A1C10 SHORTED CAPACITOR A1C18 |
| BATTERY NOT SWITCHING TO SYSTEM BACKUP | CHECK THE FOLLOWING: BAD RELAY A1K1 BAD RELAY A1K2 OPEN TRANSISTOR A1Q6 BAD I.C. U5 BAD I.C. U6 SHORTED TRANSISTOR A1Q5 |
| STATUS ERROR FLAG NOT PRESENT | CHECK THE FOLLOWING: LINE VOLTAGE TOO LOW OPEN TRANSISTOR A1Q5 BAD I.C. A1U4 BAD I.C. A1U7 OPEN DIODE A1D9 |
| SWITCHED GROUND NOT CONNECTED | CHECK THE FOLLOWING: LINE VOLTAGE TOO LOW BAD RELAY A1K3 OPEN TRANSISTOR A1Q5 BAD I.C. A1U4 |
| ANY OTHER FAULT | CONSULT THE FACTORY |

BATTERY AND HARDWARE KITS


| SYMBOL | PART NO. | DESCRIPTION |
|---|-------------|---------------|
| MIII AUTOMOBILE BATTERY KIT 344A3696G1 | | |
| W1 | 19B801937P4 | Power Cable |
| W2 | 19B801970P1 | Power Cable |
| W3 | | |
| W4 | 19B801970P3 | Power Cable |
| W5 | 19B801970P4 | Power Cable |
| W6 | | Not Used |
| W7 | | Not Used |
| W8 | | Not Used |
| 1 | 344A3450G1 | Hardware Kit |
| 2 | | Not Used |
| 3 | | Not Used |
| 4 | | Not Used |
| MIII GEL CELL BATTERY KIT 344A3696G2 | | |
| W1 | 19B801937P4 | Power Cable |
| W2 | 19B801970P1 | Power Cable |
| W3 | | Not Used |
| W4 | | Not Used |
| W5 | | Not Used |
| W6 | 19B801970P5 | Power Cable |
| W7 | 19B801970P6 | Power Cable |
| W8 | 19C327801G1 | Harness |
| 1 | | Not Used |
| 2 | 344A3450G5 | Hardware Kit |
| 3 | 19B802073P1 | Rear support |
| 4 | 19B802067P1 | Cover |
| HARDWARE KIT 344A3450G1 | | |
| 1 | 7160861P33 | SPRING NUT |
| 2 | 19A134011P2 | SCREW |
| 3 | 7160861P4 | SPRING NUT |
| 4 | N145P1507B6 | TAPPED SCREW |
| HARDWARE KIT 344A3450G5 | | |
| 1 | 7160861P33 | SPRING NUT |
| 2 | 19A134011P2 | SCREW |
| I5 | N403P16B6 | LOCK WASHER |
| 17 | N80P16008B6 | MACHINE SCREW |
| 18 | N403P19B6 | LOCK WASHER |
| 19 | N402P39B6 | FLAT WASHER |
| 20 | N80P15012B6 | MACHINE SCREW |
| 21 | N402P38B6 | FLAT WASHER |

*COMPONENTS, ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES



50 Hz CHARGER
344A3168P2

(289PS10, Rev. A)




60 Hz CHARGER
344A3168P1

(289PS5, Rev. C)

| REF DES | CEN. TO CEN/ LEADFORM # | ITEM NO | REF DES | CEN. TO CEN/ LEADFORM # | ITEM NO |
|------------|----------------------------|------------|------------|----------------------------|------------|
| R1 | - | 15 | U1 | - | 25 |
| R2 | - | 15 | U2 | - | 26 |
| R3 | - | 15 | U3 | - | 27 |
| R4 | - | 14 | U5 | - | 28 |
| R5 | - | 14 | U6 | - | 29 |
| R6 | - | 14 | U7 | - | 29 |
| R12 | - | 12 | U8 | - | 30 |
| R29 | - | 13 | U9 | - | 24 |
| C1 | - | 18 | J3 | - | 31 |
| C2 | - | 18 | J4 | - | 31 |
| C3 | - | 18 | J5 | - | 32 |
| C4 | 92038500 | 17 | J6 | - | 32 |
| C10 | - | 16 | J7 | - | 33 |
| C11 | - | 16 | J8 | - | 33 |
| C18 | - | 16 | J9 | - | 33 |
| K1 | - | 9 | J10 | - | 33 |
| K2 | - | 10 | J11 | - | 33 |
| K3 | - | 11 | J12 | - | 33 |
| T3 | - | 8 | J13 | - | 33 |
| D6 | 92038300 | 19 | J14 | - | 33 |
| RV1 | - | 23 | J15 | - | 33 |
| Q5 | 92038000 | 20 | J16 | - | 33 |
| Q6 | 92037800 | 21 | J17 | - | 33 |
| Q7 | 92037800 | 21 | TP1 | - | 33 |
| Q8 | 92037700 | 22 | | | |
| Q9 | 92037800 | 21 | | | |


| QTY | ITEM NO. | PART NUMBER | DESCRIPTION | NOTES |
|-----|-------------|-------------|------------------------------------|-------|
| 4 | 35 | | NUT, KEEPER, #10 | |
| 4 | 34 | | STUD, PEM, #10-32 | |
| 12 | 33 | | CONNECTOR, FASTON | |
| 2 | 32 | | CONNECTOR, HEADER, 8 PIN (J5, J6) | |
| 2 | 31 | | CONNECTOR, HEADER, 6 PIN (J3, J4) | |
| 1 | 30 | | INT. CKT. LM358 | |
| 2 | 29 | | INT. CKT. LM393 | |
| 1 | 28 | | INT. CKT. TL431 | |
| 1 | 27 | | INT. CKT. SG3532 | |
| 1 | 26 | | INT. CKT. AD680 | |
| 1 | 25 | | INT. CKT. 78L15 | |
| 1 | 24 | | INT. CKT. MC4013 | |
| 1 | 23 | | VARISTOR, 275V | |
| 1 | 22 | | TRANSISTOR, MPS2907A | |
| 3 | 21 | | TRANSISTOR, MPS2222A | |
| 1 | 20 | | TRANSISTOR, TIP32C | |
| 1 | 19 | | BRIDGE RECTIFIER | |
| 3 | 18 | | CAPACITOR, 10,000 UF, 35V | |
| 1 | 17 | | CAPACITOR, 2200 UF, 25V | |
| 3 | 16 | | CAPACITOR, 470 UF, 50V | |
| 3 | 15 | | RESISTOR, .15 OHM, 5 W, 1% | |
| 3 | 14 | | RESISTOR, .12 OHM, 5 W, 1% | |
| 1 | 13 | | RESISTOR, POTENTIOMETER, 2.0 K OHM | |
| 1 | 12 | | RESISTOR, POTENTIOMETER, 1.0 K OHM | |
| 1 | 11 | | RELAY, SPST, 24 V/5 A | |
| 1 | 10 | | RELAY, SPDT, 12 V/30 A | |
| 1 | 9 | | RELAY, SPDT, 24 V/30 A | |
| 1 | 8 | | TRANSFORMER | 4 |
| 3 | 7 | | LEADWIRE ASSEMBLY (W2,W5,W8) | |
| 3 | 6 | | LEADWIRE ASSEMBLY (W1,W4,W7) | |
| 3 | 5 | | LEADWIRE ASSEMBLY (W3,W6,W9) | |
| 1 | 4 | | HEATSINK ASSEMBLY (Q4) | |
| 1 | 3 | | HEATSINK ASSEMBLY (U4) | |
| 2 | 2 | | HEATSINK ASSEMBLY (D1,D2) | |
| 1 | 1 | | PWB AUTOINSERT ASSEMBLY, A1 | 2 |



NOTES:

- 1 ITEM (21) IS USED TO ATTACH ITEM (2) TO ITEM (10) AND (11) ONLY.
- 2 ITEM (20) IS USED TO ATTACH ITEM (11) AND (12) TO ITEM (10) ONLY.
- 3 ITEM (20) TO BE INSTALLED AFTER ITEM (9).

| ITEM | TORQUE IN/LBS |
|--------|--------------------|
| 20, 21 | 6 - 8 (M3.5) |
| 23 | 6 - 8 (#6 - 32) |
| 24 | 14 - 16 (#8 - 32) |
| 25 | 17 - 20 (#10 - 32) |
| 22 | 6 - 8 (#4 - 40) |

**CHARGER**

(XP-289PS5, Rev. 5)

BATTERY CHARGER
344A3168P1 & P2
ISSUE 3

| SYMBOL | PART NO. | DESCRIPTION |
|--|-----------------------------|---|
| Battery Charger Top Assembly | | |
| PS5A1 | M29/91035300 | Printed Circuit Card Assembly. |
| PS5A2 | M29/91037100 | Power Transistor Heat Sink Assembly. |
| PS5W1 | M29/25011200 | J1 Output Power Conn. Harness Assembly. |
| PS5W2 | M29/25011300 | J2 Test Connector Harness Assembly. |
| PSW801 | M29/11022301 | AC Cord Set. |
| PS5T1 | M29/289P1 | Main Power Transformer. |
| PS5T2 | M29/289P1 | Main Power Transformer. |
| | M29/7064200 | Chassis. |
| | M29/7064300 | Top Cover. |
| | M29/7064400 | Front Panel. |
| | M29/9014200 | Fuse Holder. |
| | M29/9013900 | Fuse, Bussman, MDL-5. |
| | M29/31023000 | Insulator, PWB To Chassis. |
| | M29/11022000 | Strain Relief, HEYCO, 1200. |
| | M29/7064700 | Heat Sink Skid. |
| | M29/11024500 | Cable Tie. |
| | M29/22045900 | Spacer, #10 X .375, Nylon. |
| | M29/22046000 | Spacer, #10 X .125, Nylon. |
| | M29/22046401 | Screw, M3-5 X .500, TORX Head. |
| | M29/22046400 | Screw, M3-5 X 390, TORX Head. |
| | M29/22028900 | Screw, #4-40 X .375, HEX Head, Thd. Rolling. |
| | M29/22046000 | Washer, Shoulder, #10. |
| | M29/22041501 | Nut, #6-32, Keeper, 1/8 Tbk. |
| | M29/22041502 | Nut, #8-32, Keeper, 1/8 Thk. |
| | M29/22041503 | Nut, #10-32, Keeper, 1/8 Thk. |
| Printed Circuit Card Assembly PS5A1 M29/91035300 | | |
| C1 | M29/17033400 | Capacitor, 10,000 µF, 35 V., Electrolytic. |
| C2 | M29/17033400 | Capacitor, 10,000 µF, 35 V., Electrolytic. |
| C3 | M29/17033400 | Capacitor, 10,000 µF, 35 V., Electrolytic. |
| C4 | M29/17031901 | Capacitor, 2,200 µF, 25 V., Electrolytic. |
| C5 | M29/17018100 | Capacitor, 0.1 µF, 50 V., Ceramic. |
| C6 | M29/17018107 | Capacitor, .001 µF, 100 V., Ceramic. |
| C7 | M29/17018100 | Capacitor, 0.1 µF, 50 V., Ceramic. |
| C8 | M29/17018100 | Capacitor, 0.1 µF, 50 V., Ceramic. |
| C9 | M29/17018107 | Capacitor, .001 µF, 100 V., Ceramic. |
| C10 | M29/17016202 | Capacitor, 470 µF, 50 V., Electrolytic. |
| C11 | M29/17016202 | Capacitor, 470 µF, 50 V., Electrolytic. |
| C12 | M29/17018107 | Capacitor, .001 µF, 100 V., Ceramic. |
| C13 | M29/17018214 | Capacitor, .0022 µF, 100 V., Ceramic. |
| C14 | M29/17018100 | Capacitor, 0.1 µF, 50 V., Ceramic. |
| C15 | M29/17018214 | Capacitor, .0022 µF, 100 V., Ceramlc. |
| C16 | M29/17018214 | Capacitor, .0022 µF, 100 V., Ceramic. |
| C17 | M29/17018214 | Capacitor, .0022 µF, 100 V., Ceramic. |
| C18 | M29/17016202 19A703314P3 | Capacitor, 470 µF, 50 V., Electrolytic. Electrolytic: .33µF, 16 VDCW (Install across R21). |
| D1 | M29/18027200 | Rectifier, Dual Gen. Instruments, 30CPQ000. |

| SYMBOL | PART NO. | DESCRIPTION |
|--------|---------------|---|
| D2 | M29/18027200 | Rectifier, Dual Gen. Instrument., 30CPQ090. |
| D3 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D4 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D5 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D6 | M29/19007500 | Rectifier Bridge, Gen. Instrument., W04M. |
| D7 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D8 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D9 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D10 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D11 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D12 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D13 | M29/18018004 | Rectifier, General Purpose, UF4002. |
| D14 | M29/13048104 | Rectifier, General Purpose, UF4002. |
| J1 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J2 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J3 | M29/40024401 | Connector, 6 Pos., Amp, 640445-6. |
| J4 | M29/40024401 | Connector, 6 Pos., Amp, 640445-6. |
| J5 | M29/40024402 | Connector, 8 Pos., Amp, 640445-8. |
| J6 | M29/40024402 | Connector, 8 Pos., Amp, 640445-8. |
| J7 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J8 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J9 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J10 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J11 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J12 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J13 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J14 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| J15 | M29/13048100 | Connector, Faston Tab, Amp, 62650-1. |
| K1 | M29/20003700 | Relay, 12 V., 40 A., SPDT, P&B, VF4-15H13. |
| K2 | M29/20004000 | Relay, 12 V., 40 A., SPST, AROMAT, CB1AF-P-12V. |
| K3 | M29/20003600 | Relay, 12 V., 5 A., SPST, AROMAT, J S1AE-DC24V. |
| Q1 | M29/18030800 | Transistor, Power, NPN, 2N5885. |
| Q2 | M29/18030800 | Transistor, Power, NPN, 2N5885. |
| Q3 | M29/18030800 | Transistor, Power, NPN, 2N5885. |
| Q4 | M29/18017600 | Transistor, Power, NPN, TIP31C. |
| Q5 | M29/18023500 | Transistor, Power, PNP, TIP32C. |
| Q6 | M29/18023200 | Transistor, Gen. Purpose, NPN, MPS2222A. |
| Q7 | M29/18023200 | Transistor, Gen. Purpose, NPN, M352222A. |
| R1 | M29/16013001 | Resistor, 0.15, 5 W., 1%, Ceramic Wire Wound. |
| R2 | M29/16013001 | Resistor,.0.15.,SW., 1%, Ceramic Wire Wound. |
| R3 | M29/16013001 | Resistor, 0.15, 5 W.,1%, Ceramic Wire Wound. |
| R4 | M29/16013900 | Resistor, 0.12, 5 W., 1%, Ceramic Wire Wound. |
| R5 | M29/16013900 | Resistor, 0.12, 5 W., 1%, Ceramic Wire Wound. |
| R6 | M29/16013900 | Resistor, 0.12, 5 W., 1%, Ceramic Wire Wound. |
| R7 | M29/16001573 | Resistor, 1K, 1/2 W., 5%, Carbon Film. |
| R8 | M29/16001464 | Resistor, 3.09K, 1/4 W., 1%, Metal Film. |
| R9 | M29/16001456 | Resistor, 274, 1/4 W., 1%, Metal Film. |
| R10 | M29/16001525 | Resistor, 10K, 1/4 W., 1%, Metal Film. |
| R11 | M29/16001448 | Resistor, 38.3K, 1/4 W., 1%, Metal Film. |
| R12 | M29/16013500 | Potentiometer, 1K, 1 Turn, Cermet. |
| R13 | M29/160011449 | Resistor, 8.25K, 1/4 W., 1%, Metal Film. |
| R14 | M29/160011456 | Resistor, 274, 1/4 W., 1%, Metal Film. |

| SYMBOL | PART NO. | DESCRIPTION |
|--------|---------------|--|
| R15 | M29/16001525 | Resistor, 10K, 1/4 w., 1%, Metal Film. |
| R16 | M29/16001447 | Resistor, 4.32K, 1/4 W., 1%, Metal Film. |
| R17 | M29/16001459 | Resistor, 237, 1/4 W., 1%, Metal Film. |
| R18 | M29/16001595 | Resistor, 5.11K, 1/4 W., 1%, Metal Film. |
| R19 | M29/16001595 | Resistor, 5.11K, 1/4 W., 1%, Metal Film. |
| R20 | M29/16001458 | Resistor, 56.5K, 1/4 W., 1%, Metal Film. |
| R21 | 19A701250P296 | Resistor, 9.76K, 1/ 4W., 1%, Metal Film. |
| R22 | M29/16001577 | Resistor, 7.5K, 1/4 W., 1%, Metal Film. |
| R23 | M29/16001577 | Resistor, 7.5K, 1/4 W., 1%, Metal Film. |
| R24 | M29/16001595 | Resistor, 5.1K, 1/4 W., 1%, Metal Film. |
| R25 | 19A701250P439 | Resistor, 249K, 1/4 W., 1%, Metal Film. |
| R26 | M29/16001525 | Resistor, 10K, 1/4 W., 1%, Metal Film. |
| R27 | M29/16001595 | Resistor 5.11K, 1/4 W., 1%, Metal Film. |
| R28 | M29/16001446 | Resistor, 45.3K, 1/4 W., 1%, Metal Film. |
| R29 | M29/16007503 | Potentiometer, 2K, 10 Turn, Cermet. |
| R30 | M29/16001477 | Resistor, 3.24K, 1/4 W., 1%, Metal Film. |
| R31 | M29/16001525 | Resistor, 10K, 1/4 W., 1%, Metal Film. |
| R32 | M29/16001591 | Resistor, 1.27K, 1/4 W., 1%, Metal Film. |
| R33 | M29/16001591 | Resistor, 1.27K, 1/4 W., 1%, Metal Film. |
| R34 | M29/16001599 | Resistor, 2.00K, 1/4 W., 1%, Metal Film. |
| R35 | M29/16001591 | Resistor, 1.27K, 1/4 W., 1%, Metal Film. |
| R36 | M29/16001590 | Resistor, 4.75K, 1/4 W., 1%, Metal Film. |
| R37 | M29/16001595 | Resistor, 5.11K, 1/4 W., 1%, Metal Film. |
| R38 | M29/16001591 | Resistor, 1.27K, 1/4 W., 1%, Metal Film. |
| R39 | M29/16001595 | Resistor, 5.11K, 1/4 W., 1%, Metal Film. |
| R40 | M29/16001478 | Resistor, 3.09K, 1/4 W., 1%, Metal Film. |
| R41 | M29/16001479 | Resistor, 7.15K, 1/4 W., 1%, Metal Film. |
| R42 | M29/16001470 | Resistor, 9.31K, 1/4 W., 1%, Metal Film. |
| R43 | M29/16001464 | Resistor, 3.57K, 1/4 W., 1%, Metal Film. |
| R44 | M29/16001471 | Resistor, 21.3K, 1/4 W., 1%, Metal Film. |
| R45 | M29/16001525 | Resistor, 10K, 1/4 W., 1%, Metal Film. |
| R46 | M29/16001582 | Resistor, 49.9K, 1/4 W., 1%, Metal Film. |
| R47 | M29/16001582 | Resistor, 49.9K, 1/4 W., 1%, Metal Film. |
| R48 | M29/16001525 | Resistor, 10K, 1/4 W., 1%, Metal Film. |
| R49 | M29/16001525 | Resistor, 10K, 1/4 W., 1%, Metal Film. |
| R50 | M29/16001526 | Resistor, 100, 1/4 W., 1%, Metal Film. |
| RV1 | M29/18008013 | Metal Oxide Variator, 150 V., GE, V150LA20A. |
| T1 | M29/FS56-020 | Transformer. |
| U1 | M29/19005701 | Int. Circuit, Voltage Regulator, LM78L15. |
| U2 | M29/19010500 | Int. Circuit, Reference Voltage, AD680. |
| U3 | M29/19009900 | Int. Circuit, Lin. Reg. Controller, SG3532. |
| U4 | M29/19002101 | Int. Circuit, Voltage Regulator, LM317. |
| U5 | M29/19009100 | Int. Circuit, Voltage Reference, TL431C. |
| U6 | M29/19010000 | Int. Circuit, Dual Comparator, LM393. |
| U7 | M29/19010000 | Int. Circuit, Dual Comparator, LM393. |
| U8 | M29/19006000 | Int. Circuit, Dual Operational Amp., LM358. |
| VR1 | M29/18001443 | Zener Diode, 13 V., 1N964B. |
| | M29/33019700 | Printed Circuit Card. |
| | M29/11023500 | Heat Sink, Thermalloy. |
| | M29/11022400 | Heat Sink. |
| | M29/31016703 | Thermal Pad. |
| | M29/22027710 | Screw, #44-40 X .500, HEX Head, Zinc Plated. |

| SYMBOL | PART NO. | DESCRIPTION |
|--|--------------|---|
| | M29/22041500 | Nut, #4-40, Keeper, 1/8 Thk. |
| | M29/22041503 | Nut, #10-32, Keeper, 1/8 Thk. |
| | M29/22045500 | Stud, Pem, #10-32 X .500. |
| | M29/13040200 | Terminal, Wire, Amp, 640311-1. |
| | M29/27185266 | Wire, 18 AWG, Blue, UL1452BL. |
| | M29/27185222 | Wire, 18 AWG, Red, UL1452RD. |
| | M29/27185244 | Wire, 18 AWG, Yellow, UL1452YL. |
| Power Transistor Heat Sink Assembly PS5A2 M29/91037100 | | |
| Q1 | M29/18030800 | Transistor, Power, NPN, 2N5885. |
| Q2 | M29/18030800 | Transistor, Power, NPN, 2N5885. |
| Q3 | M29/18030800 | Transistor, Power, NPN, 2N5885. |
| S1 | M29/9016700 | Thermostat, SPST, Norm. Closed. |
| | M29/11024700 | Heat Sink. |
| | M29/11024800 | Heat Sink. |
| | M29/11025000 | Corner Block. |
| | M29/31023200 | Thermal Pad. |
| | M29/13051800 | Socket, T0-3. |
| | M29/7062500 | Cover, T0-3. |
| | M29/22040000 | Screw, #6-32 X .250, Pan Head, Zinc Plated. |
| | M29/22009008 | Screw, #6-32 X .500, Pan Head, Zinc Plated. |
| | M29/22009007 | Screw, #6-32 X .625, Pan Head, Zinc Plated. |
| J1 Output Conn. Harness Assembly PS5W1 M29/25011200 | | |
| J1 | M29/40028600 | Connector, 4 Pos., Amp, 641685-2. |
| | M29/13052600 | Terminal, Connector, Amp, 350650-1. |
| | M29/13053900 | Terminal, Ring, Amp, 52263. |
| | M29/26080499 | Wire, 8 AWG, White, UL1028WH. |
| | M29/26080400 | Wire, 8 AWG, Black, UL1028BK. |
| | M29/26080422 | Wire, 8 AWG, Red, UL1028RD. |
| J2 Test Connector Harness Assembly PS5W2 M29/23011300 | | |
| J2 | M29/40013002 | Connector, 3 Pcs., Amp, 1-480701-0. |
| | M29/13037600 | Terminal, Connector, Amp, 350218-1. |
| | M29/13024900 | Terminal, Faston, Amp. |
| | M29/26160355 | Wire, 16 AWG, Green, UL1015GN. |
| | M29/26160399 | Wire, 16 AWG, White, UL1015WH. |
| | M29/26160300 | Wire, 16 AWG, Black, UL1015BK. |
| F1 AC Fuse Wire Assembly W3, W4 M29/250074271 | | |
| | M29/13024900 | Terminal, Faston, Amp. |
| | M29/26166600 | Wire, 16 AWG, Black, UL1509BK. |
| Thermostat Wire Assembly W5, W6 M29/250074272 | | |
| | M29/13024900 | Terminal, Faston, Amp. |
| | M29/26166600 | Wire, 16 AWG, Black, UL1509BK. |


*COMPONENTS, ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

| SYMBOL | PART NO. | DESCRIPTION |
|--|---------------|--|
| Printed Circuit Card Assembly PS10A1 M29/91040000 | | |
| ----- CAPACITORS ----- | | |
| C1 thru C3 | M29/17033400 | Electrolytic: 10,000 uF, 35 VDCW, +/- 10%. |
| C4 | M29/17031901 | Electrolytic: 2200 uF, 25 VDCW. |
| C5 | M29/17018100 | Ceramic: 0.1 uF, 50 VDCW, +/- 20%. |
| C6 | M29/17018107 | Ceramic: 0.001 uF, 100 VDCW. |
| C7 and C8 | M29/17018100 | Ceramic: 0.1 uF, 50 VDCW, +/- 20%. |
| C9 | M29/17018214 | Ceramic: 2200 pF, 100 VDCW, +/- 20%. |
| C10 and C11 | M29/17016202 | Electrolytic: 470 uF, 50 VDCW. |
| C12 | M29/17018107 | Ceramic: 0.001 uF, 100 VDCW. |
| C13 | M29/17018214 | Ceramic: 2200 pF, 100 VDCW, +/- 20%. |
| C14 | M29/17018100 | Ceramic: 0.1 uF, 50 VDCW, +/- 20%. |
| C15 thru C17 | M29/17018214 | Ceramic: 2200 pF, 100 VDCW, +/- 20%. |
| C18 | M29/17016202 | Electrolytic: 470 uF, 50 VDCW. |
| C20 and C21 | M29/17018100 | Ceramic: 0.1 uF, 50 VDCW, +/- 20%. |
| C22 | M29/17012412 | Ceramic: 1.0 uF, 50 VDCW, +/- 20%. |
| C23 thru C26 | M29/17014503 | Ceramic: 220 pF. |
| ----- DIODES ----- | | |
| D1 and D2 | M29/18207200 | Rectifier: 30CPQ090. |
| D3 thru D5 | M29/18018004 | Rectifier: 1A, 150 V. UF4002. |
| D6 | M29/19007500 | Rectifier, Bridge: 1A, 400V. W04G. |
| D7 thru D19 | M29/ 18018004 | Rectifier: 1A, 150V. UF4002. |
| ----- CONNECTORS ----- | | |
| J3 and J4 | M29/40024401 | Connector: 6 pos. AMP 640445-6. |
| J5 and J6 | M29/40024402 | Connector: 8 pos. AMP 640445-8. |
| J7 thru J17 | M29/13048100 | Connector: Faston Tab. AMP 62650-1. |
| ----- RELAYS ----- | | |
| K1 | M29/20003700 | Relay: SPDT, 24V, 30A. |
| K2 | M29/20004000 | Relay: SPST, 12V, 40A. |
| K3 | M29/20003600 | Relay: SPST, 24V, 5A. |

| SYMBOL | PART NO. | DESCRIPTION |
|-------------------------|--------------|------------------------------------|
| ----- TRANSISTORS ----- | | |
| Q4 | M29/18017600 | Power: NPN. TIP-31C. |
| Q5 | M29/18203500 | Power: PNP. TIP-32C. |
| Q6 and Q7 | M29/18023200 | Gen. Purpose: NPN. MPS2222A. |
| Q8 | M29/18023300 | Gen. Purpose: PNP. MPS2907A. |
| Q9 | M29/18023200 | Gen. Purpose: NPN. MPS2222A. |
| ----- RESISTORS ----- | | |
| R1 thru R3 | M29/16013901 | Wirewound: 0.15 ohms, 5w, 5%. |
| R4 thru R6 | M29/16013900 | Wirewound: 0.12 ohms, 5w, 1%. |
| R7 | M29/16001573 | Metal Film: 1k ohm, 1/2w, 5%. |
| R8 | M29/16001464 | Metal Film: 3.89K ohms, 1/4w, 1%. |
| R9 | M29/16001443 | Metal Film: 274 ohms, 1/4w, 1%. |
| R10 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R11 | M29/16001448 | Metal Film: 38.3K ohms, 1/4w, 1%. |
| R12 | M29/16013500 | Potentiometer: 1K ohms, 10%. |
| R13 | M29/16001449 | Metal Film: 8.25K ohms, 1/4w, 1%. |
| R14 | M29/16001465 | Metal Film: 274K ohms, 1/4w, 1%. |
| R15 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R16 | M29/16001447 | Metal Film: 4.32K ohms, 1/4w, 1%. |
| R17 | M29/16001459 | Metal Film: 237 ohms, 1/4w, 1%. |
| R18 and R19 | M29/16001595 | Metal Film: 5.11K ohms, 1/4w, 1%. |
| R20 | M29/16001458 | Metal Film: 36.5K ohms, 1/4w, 1%. |
| R21 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R22 and R23 | M29/16001577 | Metal Film: 7.5K ohms, 1/4w, 1%. |
| R24 | M29/16001595 | Metal Film: 5.11K ohms, 1/4w, 1%. |
| R25 | M29/16001465 | Metal Film: 274K ohms, 1/4w, 1%. |
| R26 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R27 | M29/16001595 | Metal Film: 5.11K ohms, 1/4w, 1%. |
| R28 | M29/16001446 | Metal Film: 45.3K ohms, 1/4w, 1%. |
| R29 | M29/16007503 | Potentiometer: 2K ohms, 1/2w, 10%. |
| R30 | M29/16001477 | Metal Film: 3.24K ohms, 1/4w, 1%. |
| R31 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R32 and R33 | M29/16001591 | Metal Film: 1.27K ohms, 1/4w, 1%. |
| R34 | M29/16001599 | Metal Film: 2K ohms, 1/4w, 1%. |
| R35 | M29/16001591 | Metal Film: 1.27K ohms, 1/4w, 1%. |
| R36 | M29/16001445 | Metal Film: 37.4K ohms, 1/4w, 1%. |
| R37 | M29/16001595 | Metal Film: 5.11K ohms, 1/4w, 1%. |
| R38 | M29/16001493 | Metal Film: 1.47K ohms, 1/4w, 1%. |
| R39 | M29/16001469 | Metal Film: 20k ohms, 1/4w, 1%. |
| R40 | M29/16001478 | Metal Film: 3.09K ohms, 1/4w, 1%. |
| R41 | M29/16001437 | Metal Film : 15.4K ohms, 1/4w, 1%. |
| R42 | M29/16001470 | Metal Film: 9.31K ohms, 1/4w. 1%. |
| R43 | M29/16001464 | Metal Film: 3.57K ohms, 1/4w, 1%. |


| SYMBOL | PART NO. | DESCRIPTION |
|---------------------------------|--|---|
| R44 | M29/16001471 | Metal Film: 21.3K ohms, 1/4w, 1%. |
| R45 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R46 and R47 | M29/16001582 | Metal Film: 49.9K ohms, 1/4w, 1%. |
| R48 and R49 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R50 | M29/16001526 | Metal Film: 100 ohms, 1/4w, 1%. |
| R51 thru R53 | M29/16001525 | Metal Film: 10K ohms, 1/4w, 1%. |
| R54 | M29/16001469 | Metal Film: 20K ohms, 1/4w, 1%. |
| ----- VARISTORS ----- | | |
| RV1 | M29/18008011 | Varistor. GE V275LA2UA. |
| ----- TRANSFORMER ----- | | |
| T1 and T2 | M29/FS56-020 | Transformer, Power. |
| ----- INTEGRATED CIRCUITS ----- | | |
| U1 | M29/19005701 | Voltage Regulator: +15V. LM78L15. |
| U2 | M29/19010500 | Reference Voltage. AD680JT. |
| U3 | M29/19009900 | Regulator. SG3532J. |
| U4 | M29/19019676 | Regulator. LM317T. |
| U5 | M29/19009100 | Voltage Regulator. TL431C. |
| U6 and U7 | M29/19010000 | Dual Comparator. LM393AN. |
| U8 | M29/19006000 | Dual Operational Amp. LM358. |
| U9 | M29/19008100 | Regulator. MC14013. |
| ----- ZENER DIODES ----- | | |
| VR1 | M29/18001443 | Zener: 13V, 1/2w, +/-5%. |
| VR2 | M29/18001425 | Zener: 6.8V, 1/2w, +/-10%. |
| ----- MISCELLANEOUS ----- | | |
| Q1 thru Q3 S1 | M29/11023500 | Heatsink, Thermalloy. |
| | M29/31016703 | Heatsink Thermal Pad. |
| | M29/91031600 | Heatsink Assembly. |
| | M29/91035700 | Heatsink Assembly. |
| | M29/22041503 | Nut: #10-32, Keeper, 1/8" thick. |
| | M29/22045500 | Stud, Pem: #10-32. |
| | Power Transistor Heat Sink Assembly PS10A2 M29/91037100 | |
| | M29/18030800 | Transistor, Power: NPN. 2N5885. |
| | M29/09017000 | Thermostat: SPST, normally closed. 1NT01L-1928. |
| | M29/11025900 | Heatsink. |
| | M29/11026000 | Heatsink. |
| | M29/13051800 | Socket, TO-3. |


| SYMBOL | PART NO. | DESCRIPTION |
|--|--------------|------------------------|
| | M29/31023200 | Insulator. |
| | M29/07062500 | Cover, TO-3. |
| | M29/22009007 | Screw, #6-32 x 0.625. |
| | M29/22021508 | Screw, #4-40 x 0.25. |
| | M29/22047900 | Screw, #6-32 x 5/8. |
| AC Fuse Wire Assembly M29/250074270 | | |
| | M29/09017300 | Fuseholder. HTB-36M. |
| | M29/09016000 | Fuse: 5A, 250V. GDA-5. |



**MASTR III STATION
WITH EMERGENCY POWER**



(19D903635, Sh. 3, Rev. 2)







MASTR III STATION

(19D902845, Sh. 11, Rev. 1)



SECTION K - K






FIGURE 1

- 1 FIELD INSTALLATION OF GEL CELL BATTERIES IN THE EMERGENCY POWER GEL CELL BATTERY SHELF FOR A MIII 37 in. HIGH INDOOR FIXED LAND CABINET.
1. REMOVE GEL CELL SHELF FRONT COVER PANEL 19C852193P1.
 2. INSTALL BT1, BATTERY 19B209590P1, INTO GEL CELL SHELF 19D903719P1 AS SHOWN IN FIGURE 1. ATTACH A RED WIRE FROM HARNESS W8 (19C327801G1) TO THE "(+)" TERMINAL. ATTACH A BLACK WIRE FROM HARNESS W8 (19C327801G1) TO THE "(-)" TERMINAL.
 3. IN ORDER, INSTALL BT2, BT3, AND BT4 PER STEP 2 INSTRUCTIONS. IT IS ADVISABLE TO POSITION THE GEL CELLS SO THAT THEY ARE NOT TOUCHING EACH OTHER OR THE GEL CELL SHELF WALLS AND ARE APPROXIMATELY 0.15" AWAY FROM EACH OTHER.
 4. REINSTALL GEL CELL SHELF FRONT COVER PANEL 19C852193P1.

BATTERY SHELF

(344A4051, Sh. 1, Rev. 1)

This page intentionally left blank