

Professional Digital Two-Way Radio System

MOTOTRBO™ Repeater

Installation Guide

XPR™ 8300 Repeater



6816814H01-G



Foreword

This manual is intended for use by experienced technicians familiar with similar types of equipment. Specifically, it contains installation information required for the MOTOTRBO XPR 8300 Repeater.

For information related to the service of the XPR 8300 Repeater, refer to the list applicable manuals available separately. This list is provided in the [Related Publications](#) section on page vii.

Product Safety and RF Exposure Compliance

See [Installation Requirements for Compliance with Radio Frequency \(RF\) Energy Exposure Safety Standards](#) on page ii.

Manual Revisions

Changes which occur after this manual is printed are described in PMRs (Publication Manual Revisions). These PMRs provide complete replacement pages for all added, changed, and deleted items.

To obtain PMRs, go to:

<http://www.motorola.com/businessonline>

Parts Ordering

See [Appendix A: Replacement Parts Ordering](#) for information on how to obtain replacement parts. For part numbers, refer to the XPR 8300 Repeater Basic Service Manual (Motorola publication part number 6816810H01).

Computer Software Copyrights

The Motorola products described in this manual may include copyrighted Motorola computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted computer programs, including, but not limited to, the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Motorola computer programs contained in the Motorola products described in this manual may not be copied, reproduced, modified, reverse-engineered, or distributed in any manner without the express written permission of Motorola. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Motorola, except for the normal non-exclusive license to use that arises by operation of law in the sale of a product.

Document Copyrights

No duplication or distribution of this document or any portion thereof shall take place without the express written permission of Motorola. No part of this manual may be reproduced, distributed, or transmitted in any form or by any means, electronic or mechanical, for any purpose without the express written permission of Motorola.

Disclaimer

The information in this document is carefully examined, and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Motorola reserves the right to make changes to any products herein to improve readability, function, or design. Motorola does not assume any liability arising out of the applications or use of any product or circuit described herein; nor does it cover any license under its patent rights nor the rights of others.

Trademarks

MOTOROLA, the Stylized M logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners.

© 2006 – 2009 by Motorola, Inc.

Installation Requirements for Compliance with Radio Frequency (RF) Energy Exposure Safety Standards

ATTENTION!

This radio is intended for use in occupational/controlled conditions, where users have full knowledge of their exposure and can exercise control over their exposure to meet FCC limits. This radio device is NOT authorized for general population, consumer, or any other use.

To ensure compliance to RF Energy Safety Standards:

- Install only Motorola approved antennas and accessories
- Be sure that Product Safety and RF Safety Booklet enclosed with this radio is available to the end user upon completion of the installation of this radio

Before using this product, the operator must be familiar with the RF energy awareness information and operating instructions in the Product Safety and RF Exposure booklet enclosed with each radio (Motorola Publication part number 6881095C99) to ensure compliance with Radio Frequency (RF) energy exposure limits.

For a list of Motorola-approved antennas and other accessories, visit the following web site which lists approved accessories for your radio model:

<http://www.motorola.com/governmentandenterprise>

Declaration of Conformity

This declaration is applicable to your radio only if your radio is labeled with the FCC logo shown below.

DECLARATION OF CONFORMITY

Per FCC CFR 47 Part 2 Section 2.1077(a)



Responsible Party
Name: Motorola, Inc.

Address: 1301 East Algonquin Road, Schaumburg, IL 60196-1078, U.S.A.
Phone Number: 1-888-567-7347

Hereby declares that the product:

Model Name: **XPR 8300**

conforms to the following regulations:

FCC Part 15, subpart B, section 15.107(a), 15.107(d) and section 15.109(a)

Class B Digital Device

As a personal computer peripheral, this device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notes

Table of Contents

Foreword	i
Product Safety and RF Exposure Compliance	i
Manual Revisions	i
Parts Ordering	i
Computer Software Copyrights	i
Document Copyrights	i
Disclaimer	i
Trademarks	i
 Installation Requirements for Compliance with Radio Frequency (RF) Energy Exposure Safety Standards	 ii
 Declaration of Conformity	 iii
 List of Figures	 vii
 Related Publications	 vii
 Repeater Model Numbering Scheme	 ix
 Commercial Warranty	 xi
Limited Warranty	xi
MOTOROLA COMMUNICATION PRODUCTS	xi
I. What This Warranty Covers and For How Long	xi
II. General Provisions	xi
III. State Law Rights	xii
IV. How to Get Warranty Service	xii
V. What This Warranty Does Not Cover	xii
VI. Patent and Software Provisions	xiii
VII. Governing Law	xiii
 Chapter 1 Pre-Installation Considerations	 1-1
1.1 Installation Overview	1-1
1.2 Environmental Conditions at Intended Installation Site	1-1
1.2.1 Operating Temperature Range	1-1
1.2.2 Humidity	1-1
1.2.3 Air Quality	1-2
1.3 Equipment Ventilation	1-2
1.4 AC Input Power Requirements	1-2
1.4.1 Circuit Overloading	1-2
1.5 Equipment Mounting Methods	1-2
1.6 Site Grounding and Lightning Protection	1-3
1.6.1 Electrical Ground	1-3
1.6.2 RF Ground	1-3
1.6.3 Lightning Ground	1-3

Chapter 2	Mechanical Installation.....	2-1
2.1	Unpacking Equipment.....	2-1
2.2	Transferring Equipment from Shipping Container to Rack or Cabinet.....	2-1
Chapter 3	Indicators and Connectors.....	3-1
3.1	Front Panel	3-1
3.1.1	LED Indicator Descriptions	3-1
3.2	Rear Panel	3-2
3.2.1	Rear Panel Part	3-2
3.2.2	Rear Accessory Connector	3-3
Chapter 4	Electrical Connections	4-1
4.1	Power Supply Connections.....	4-1
4.1.1	AC Input Power Connection.....	4-1
4.1.2	Ground Connection.....	4-2
4.1.3	Battery Backup Connection	4-2
4.2	RF Antenna Connections.....	4-3
4.2.1	Duplexer Selection.....	4-3
4.2.2	Antenna Selection.....	4-3
Chapter 5	Post-Installation Checklist	5-1
5.1	Applying Power.....	5-1
5.2	Verifying Proper Operation	5-1
5.2.1	Front Panel LEDs.....	5-1
5.3	Archiving	5-1
5.3.1	Copying the Repeater Codeplug Data to a Computer	5-1
Chapter 6	Accessories.....	6-1
	Antennas	6-1
	Cables	6-1
	Miscellaneous Accessories	6-1
Appendix A	Replacement Parts Ordering.....	A-1
A.1	Basic Ordering Information	A-1
A.2	Motorola Online.....	A-1
A.3	Mail Orders	A-1
A.5	Fax Orders	A-1
A.6	Parts Identification	A-2
A.7	Product Customer Service	A-2
Appendix B	Motorola Service Centers.....	B-1
B.1	Servicing Information	B-1
B.2	Motorola Service Center	B-1
B.3	Motorola Federal Technical Center.....	B-1
B.4	Motorola Canadian Technical Logistics Center	B-1

List of Figures


Figure 4-1	Locations of Connectors on the Rear Panel of the Repeater	4-1
Figure 4-2	Making Connections to a Backup Battery	4-2

Related Publications

MOTOTRBO XPR 8300 Repeater Basic Service Manual	6816810H01
Motorola Quality Standards Fixed Network Equipment Installation Manual R56	6881089E50
Product Safety and RF Exposure booklet	6881095C99

Notes

Repeater Model Numbering Scheme



Notes

Commercial Warranty

Limited Warranty

MOTOROLA COMMUNICATION PRODUCTS

I. What This Warranty Covers and For How Long

MOTOROLA INC. ("MOTOROLA") warrants the MOTOROLA manufactured Communication Products listed below ("Product") against defects in material and workmanship under normal use and service for a period of time from the date of purchase as scheduled below:

XPR 8300 Repeater	Two (2) Years
-------------------	---------------

Motorola, at its option, will at no charge either repair the Product (with new or reconditioned parts), replace it (with a new or reconditioned Product), or refund the purchase price of the Product during the warranty period provided it is returned in accordance with the terms of this warranty. Replaced parts or boards are warranted for the balance of the original applicable warranty period. All replaced parts of Product shall become the property of MOTOROLA.

This express limited warranty is extended by MOTOROLA to the original end user purchaser only and is not assignable or transferable to any other party. This is the complete warranty for the Product manufactured by MOTOROLA. MOTOROLA assumes no obligations or liability for additions or modifications to this warranty unless made in writing and signed by an officer of MOTOROLA. Unless made in a separate agreement between MOTOROLA and the original end user purchaser, MOTOROLA does not warrant the installation, maintenance or service of the Product.

MOTOROLA cannot be responsible in any way for any ancillary equipment not furnished by MOTOROLA which is attached to or used in connection with the Product, or for operation of the Product with any ancillary equipment, and all such equipment is expressly excluded from this warranty. Because each system which may use the Product is unique, MOTOROLA disclaims liability for range, coverage, or operation of the system as a whole under this warranty.

II. General Provisions

This warranty sets forth the full extent of MOTOROLA'S responsibilities regarding the Product. Repair, replacement or refund of the purchase price, at MOTOROLA's option, is the exclusive remedy. THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER EXPRESS WARRANTIES. IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL MOTOROLA BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, FOR ANY LOSS OF USE, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS, LOST PROFITS OR SAVINGS OR OTHER INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE SUCH PRODUCT, TO THE FULL EXTENT SUCH MAY BE DISCLAIMED BY LAW.

III. State Law Rights

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION OR EXCLUSIONS MAY NOT APPLY.

This warranty gives specific legal rights, and there may be other rights which may vary from state to state.

IV. How to Get Warranty Service

You must provide proof of purchase (bearing the date of purchase and Product item serial number) in order to receive warranty service and, also, deliver or send the Product item, transportation and insurance prepaid, to an authorized warranty service location. Warranty service will be provided by Motorola through one of its authorized warranty service locations. If you first contact the company which sold you the Product, it can facilitate your obtaining warranty service. You can also call Motorola at 1-888-567-7347 US/Canada.

V. What This Warranty Does Not Cover

- A. Defects or damage resulting from use of the Product in other than its normal and customary manner.
- B. Defects or damage from misuse, accident, water, or neglect.
- C. Defects or damage from improper testing, operation, maintenance, installation, alteration, modification, or adjustment.
- D. Breakage or damage to antennas unless caused directly by defects in material workmanship.
- E. A Product subjected to unauthorized Product modifications, disassemblies or repairs (including, without limitation, the addition to the Product of non-Motorola supplied equipment) which adversely affect performance of the Product or interfere with Motorola's normal warranty inspection and testing of the Product to verify any warranty claim.
- F. Product which has had the serial number removed or made illegible.
- G. Rechargeable batteries if:
 - any of the seals on the battery enclosure of cells are broken or show evidence of tampering.
 - the damage or defect is caused by charging or using the battery in equipment or service other than the Product for which it is specified.
- H. Freight costs to the repair depot.
- I. A Product which, due to illegal or unauthorized alteration of the software/firmware in the Product, does not function in accordance with MOTOROLA's published specifications or the FCC type acceptance labeling in effect for the Product at the time the Product was initially distributed from MOTOROLA.
- J. Scratches or other cosmetic damage to Product surfaces that does not affect the operation of the Product.
- K. Normal and customary wear and tear.

VI. Patent and Software Provisions

MOTOROLA will defend, at its own expense, any suit brought against the end user purchaser to the extent that it is based on a claim that the Product or parts infringe a United States patent, and MOTOROLA will pay those costs and damages finally awarded against the end user purchaser in any such suit which are attributable to any such claim, but such defense and payments are conditioned on the following:

- A. that MOTOROLA will be notified promptly in writing by such purchaser of any notice of such claim;
- B. that MOTOROLA will have sole control of the defense of such suit and all negotiations for its settlement or compromise; and
- C. should the Product or parts become, or in MOTOROLA's opinion be likely to become, the subject of a claim of infringement of a United States patent, that such purchaser will permit MOTOROLA, at its option and expense, either to procure for such purchaser the right to continue using the Product or parts or to replace or modify the same so that it becomes noninfringing or to grant such purchaser a credit for the Product or parts as depreciated and accept its return. The depreciation will be an equal amount per year over the lifetime of the Product or parts as established by MOTOROLA.

MOTOROLA will have no liability with respect to any claim of patent infringement which is based upon the combination of the Product or parts furnished hereunder with software, apparatus or devices not furnished by MOTOROLA, nor will MOTOROLA have any liability for the use of ancillary equipment or software not furnished by MOTOROLA which is attached to or used in connection with the Product. The foregoing states the entire liability of MOTOROLA with respect to infringement of patents by the Product or any parts thereof.

Laws in the United States and other countries preserve for MOTOROLA certain exclusive rights for copyrighted MOTOROLA software such as the exclusive rights to reproduce in copies and distribute copies of such Motorola software. MOTOROLA software may be used in only the Product in which the software was originally embodied and such software in such Product may not be replaced, copied, distributed, modified in any way, or used to produce any derivative thereof. No other use including, without limitation, alteration, modification, reproduction, distribution, or reverse engineering of such MOTOROLA software or exercise of rights in such MOTOROLA software is permitted. No license is granted by implication, estoppel or otherwise under MOTOROLA patent rights or copyrights.

VII. Governing Law

This Warranty is governed by the laws of the State of Illinois, USA.

Notes

Chapter 1 Pre-Installation Considerations

Proper installation ensures the best possible performance and reliability of the MOTOTRBO Repeater. Pre-installation planning is required. This includes considering the mounting location of the repeater in relation to input power and antennas. Also consider the site environmental conditions, the particular mounting method (several available), and required tools and equipment.

If this is the first time this type of equipment is being installed, it is highly recommended that the user read:

- this entire installation section before beginning the actual installation, and
- the Motorola Quality Standard Fixed Network Equipment Installation manual, R56 (6881089E50), specifically refer to the information on ground connection for lightning protection.

1.1 Installation Overview

The following information is an overview for installing the MOTOTRBO Repeater and ancillary equipment.

- Plan the installation, paying particular attention to environmental conditions at the site, ventilation requirements, and grounding and lightning protection.
- Unpack and inspect the equipment.
- Mechanical install the equipment at the site.
- Make necessary electrical and cabling connections, including the following:
 - AC input cabling
 - Coaxial cables to transmit and receive antennas
- Perform a post-installation function checkout test of the equipment to verify proper installation.
- Proceed to customize the repeater parameters per customer specifications (e.g. operating frequency, PL, codes, color code, etc.).

1.2 Environmental Conditions at Intended Installation Site

The repeater may be installed in any location suitable for electronic communications equipment, provided that the environmental conditions do not exceed the equipment specifications for temperature, humidity, and air quality.

NOTE: Since mid 2008, the XPR 8300 Repeater has been manufactured with a power-saving main fan. The fan powers ON temporarily as a self-check after user initially turns the repeater power ON. If the repeater's internal ambient temperature remains below 30°C (86°F), the fan does not operate. It powers ON and remains operational only after the repeater's internal ambient temperature rises above 30°C (86°F), and its speed increases as the temperatures rises. At 50°C (122°F), the fan runs at full speed.

1.2.1 Operating Temperature Range

-30°C (-22°F) to +60°C (+140°F)

This is the temperature measured in close proximity to the repeater. For example, if the repeater is mounted in a cabinet, the temperature within the cabinet is measured.

1.2.2 Humidity

Humidity conditions should not exceed 95% relative humidity @ 50°C (122°F).

1.2.3 Air Quality

For equipment operating in an area which is environmentally controlled and with the repeater(s) rack mounted, the airborne particle level must not exceed $25 \mu\text{g}/\text{m}^3$.

For equipment operating in an area which is not environmentally controlled and with the repeater(s) cabinet mounted, airborne particle level must not exceed $90 \mu\text{g}/\text{m}^3$.



If the repeater is to be installed in an environment which is usually dusty, dirty, or does not meet the air quality requirements, then the air used to cool the repeater modules must be treated using appropriate filtering devices. Dust or dirt accumulating on the internal circuit boards and modules is not easily removed, and can cause such malfunctions as overheating and intermittent electrical connections.

1.3 Equipment Ventilation

The repeater is equipped with a cooling fan that is used to provide forced convection cooling. When planning the installation, observe the following ventilation guidelines:

- Customer-supplied cabinets must be equipped with ventilation slots or openings in the front (for air entry) and back or side panels (for air to exit). If several repeaters are installed in a single cabinet, ensure ventilation openings surrounding each repeater allow for adequate cooling.
- All cabinets must have a least 15 cm (6 inches) of open space between the air vents and any wall or other objects.
- When multiple cabinets (each equipped with several repeaters) are installed in an enclosed area, ensure appropriate ventilation and consider air conditioning or other climate control equipment to satisfy the temperature requirements stated under [Section 1.2.1 Operating Temperature Range](#) on page 1-1.

1.4 AC Input Power Requirements

The repeater is equipped with a switching power supply, and this assembly operates from 100 – 240 V_{AC} at 47– 63 Hz AC input power. A standard 3-prong line cord is supplied to connect the power supply to the AC source.

It is recommended that a standard 3-wire grounded electrical outlet be used as the AC source.



The equipment must be installed near an easily-accessible AC source.

The outlet must be connected to an AC source capable of supplying a maximum of 280 W. For a nominal 110/120 V_{AC} input, the AC source must supply 5 A and should be protected by circuit breaker rated at 15 A. For a nominal 220/240 V_{AC} input, the AC source must supply 3 A and should be protected by a circuit breaker rated at 10 A.

1.4.1 Circuit Overloading

Consideration should be given to the effects of overloading on overcurrent protection devices and supply wiring. Appropriate consideration of equipment ratings should be used when addressing this concern.

1.5 Equipment Mounting Methods

The MOTOTRBO Repeater may be mounted in a rack, bracket or cabinet (available as accessories).

1.6 Site Grounding and Lightning Protection



Proper site grounding and lightning protection are vitally important considerations. Failure to provide proper lightning protection may result in permanent damage to the radio equipment.

One of the most important considerations when designing a communications site is the ground and lightning protection system. While proper grounding techniques and lightning protection are closely related, the general category of site grounding may be divided into the following section.

1.6.1 Electrical Ground

Ground wires carrying electrical current from circuitry or equipment at the site is included in the category of electrical ground. Examples include the AC or DC electrical power used to source equipment located at the site, and wires or cables connected to alarms or sensors located at the site.

1.6.2 RF Ground

This type of ground is related to the bypassing of unwanted radio frequency energy to earth ground. An example of RF grounding is the use of shielding to prevent or at least minimize the leakage of unwanted RF energy from communications equipment and cables.

1.6.3 Lightning Ground

Providing adequate lightning protection is critical to a safe reliable communications site. RF transmission cables, and AC and DC power lines must all be protected to prevent lightning energy from entering the site.

Comprehensive coverage of site grounding techniques and lightning protection is not within the scope of this instruction manual, but there are several excellent industry sources for rules and guidelines on grounding and lightning protection at communications sites.

NOTE: Motorola recommends the following reference source:

Motorola Quality Standards Fixed Network Equipment

Installation Manual R56.....6881089E50

1.6.4 Equipment Grounding

The repeater is equipped with a ground screw located on the rear of the repeater power supply module. This screw is used to connect the repeater to the site grounding. All antenna cables, and AC and DC power cabling, should be properly grounded and lightning protected by following the rules and guidelines provided in the above reference. Failure to provide proper lightning protection may result in permanent damage to the radio equipment.

Notes

Chapter 2 Mechanical Installation

This section describes the procedures to unpack and mechanically install the MOTOTRBO Repeater. A variety of mounting methods are possible depending on which type of cabinet or rack (if any) has been selected to house the repeater(s).



Be sure to observe proper electrostatic discharge precautions if modules must be removed from the repeater.

2.1 Unpacking Equipment

The following items are packed together in the box:

- MOTOTRBO Repeater
- AC Line Cord
- MOTOTRBO Repeater Installation Guide
- Product Safety and RF Exposure Booklet



Inspect the equipment for damage immediately after unpacking, and make a report of the extent of any damage to the transportation company and to Motorola.

2.2 Transferring Equipment from Shipping Container to Rack or Cabinet

The repeater is shipped in a box. Upon delivery, the equipment must be removed from the container and transferred to a rack or cabinet.

NOTE: Customer-supplied cabinets and racks must have mounting rail and hole spacing compatible with EIA Universal 48.3 cm (19 inches) specifications. Cabinets must provide adequate ventilation ([see “Environmental Conditions at Intended Installation Site” on page 1-1](#)) and must meet the following minimum criteria:


- 41.3 cm (16.25 inches) deep
- 48.3 cm (19 inches) wide
- 13.4 cm (5.25 inches) high
- Two mounting rails 5 cm (2 inches) from the front of the cabinet with front mounting holes 5.7 cm (2.25 inches) apart (center to center).

Contact Motorola Technical Support for specific question(s) regarding mounting equipment in customer-supplied cabinets.

Notes

Chapter 3 Indicators and Connectors


3.1 Front Panel



3.1.1 LED Indicator Descriptions

LED	Status	Description
Power	Solid GREEN	Repeater powered by AC.
	Solid RED	Repeater powered by backup battery.
	Off	Repeater powered off.
Repeater Disabled	Solid RED	Repeater function disabled.
	Blinking RED	Repeater in self-test mode.
	Off	Repeater in normal operational mode.
Digital	Solid BLUE	Repeater in Digital Mode.
Analog	Solid YELLOW	Repeater in Analog Mode.
Tx-A	Solid GREEN	Repeater transmitting (Analog).
	Solid GREEN	Repeater transmitting on Slot A (Digital).
Rx-A	Solid YELLOW	Repeater receiving (Analog).
	Solid YELLOW	Repeater receiving on Slot A (Digital).
Tx-B	Solid GREEN	Repeater transmitting on Slot B (Digital).
Rx-B	Solid YELLOW	Repeater receiving on Slot B (Digital).

3.2 Rear Panel




3.2.1 Rear Panel Part

No	Item	Description
1	Rx Connector	BNC (Female).
2	Power Supply On/Off Switch	Turns on or off the power to the repeater from AC input.
3	Battery Backup Connector (DC Input)	Backup battery supplies backup power to the repeater. The battery is an optional accessory. The repeater will trickle charge battery, but an external charger is recommended to equalize battery after a prolonged use. Auto switching from AC to battery with loss of AC power is a function of the standard repeater power supply. Supply will automatically switch back to AC operation upon the return of AC power. The front panel power LED switches from green to red when on battery power.
4	Power Supply Fan	Runs continuously to cool the repeater.
5	Main Power Supply Connector (AC Input)	100 – 240 Volts.
6	Rear Accessory Connector	Programming cable plugs in here.
7	Ethernet Connector	100Base-TX (RJ45)
8	Main Fan	Variable speed. Idles at room temperature. Speeds up with extended use of the repeater.
9	Tx Connector	Type-N (Female).
10	Ground Screw	Must be connected to System Ground.

3.2.2 Rear Accessory Connector

The rear accessory connector is located above the ethernet connector. Most of the Motorola-approved accessories are supplied with female terminals crimped to a 20-gauge wire specifically designed to fit the housing of the rear accessory connector.

Insert the female terminal into the accessory connector housing in the appropriate locations. The accessory connector housing is provided together with the accessory. Connect the accessory connector housing to the rear accessory connector on the back of the repeater. Do not use other generic terminals in the housing. Generic terminals can cause electrical intermittences and may cause damage to the housing.

**Table 3-1** Rear Accessory Connector Pin Functions

Pin No.	Pin Name	Pin Function	Pin No.	Pin Name	Pin Function
1	D+	USB + (Data)	14	Rx Audio	Receive Live Audio ²
2	D-	USB - (Data)	15	AUX Audio 2	PUBLIC Address 2
3	VBUS	USB Power (5V from USB accessory/cable)	16	GND	Ground
4	USB/MAP_ID GND	USB/MAP_ID Ground	17	GP5-1 (PTT)	5V Level GPIO, PTT Input ¹
5	MAP_ID_2	Accessory Identifier	18	GND	Ground
6	MAP_ID_1	Accessory Identifier	19	GP5-2 (Monitor)	5V Level GPIO, Monitor Input ³
7	SW B+	Switched Battery Voltage	20	GP5-6	5V Level GPIO
8	PWRGND	Ground	21	GP5-3	5V Level GPIO, Channel Activity Function
9	SPKR-	Speaker - (3.2 ohm minimum impedance)	22	GP5-7	5V Level GPIO
10	SPKR+	Speaker + (3.2 ohm minimum impedance)	23	EMERGENCY	Emergency Switch Input
11	Tx Audio	Rear External Microphone Input ⁴	24	GP5-8	No connection
12	Audio GND	Audio Ground	25	IGN SENSE	No connection
13	AUX Audio 1	PUBLIC Address 1	26	VIP-1	12V Tolerant, 5V GPIO, External alarm

¹ Pulling this line to ground activates the PTT function, thus activating the AUX_MIC input.

² Fixed level (independent of volume level) received audio signal, including alert tones. Flat or de-emphasis are programmed by CPS. Output voltage is approximately 330 mVrms for 1kHz of deviation.

³ This input is used to detect when a rear microphone accessory is taken off-hook.

⁴ This microphone signal is independent of the microphone signal on the front microphone connector. The nominal input level is 80mVrms for 60% deviation. The DC impedance is 660 ohms and the AC impedance is 560 ohms.

Chapter 4 Electrical Connections

After the MOTOTRBO Repeater has been mechanically installed, electrical connections must be made. This involves making the following connections:

- AC power cord, and
- antenna coaxial cables

Figure 4-1 shows the position of the various connectors and connections on the rear panel of the repeater.




Figure 4-1 Locations of Connectors on the Rear Panel of the Repeater

4.1 Power Supply Connections

4.1.1 AC Input Power Connection



Do NOT apply AC power to the repeater at this time. Make sure that the circuit breaker associated with the AC outlet is turned to **OFF**.

NOTE: The AC source must be installed near the equipment and must be easily accessible.

Each repeater ships with a 2.438 m (8 feet) 3-conductor line cord that connects the repeater to a 110/120/220/240 V_{AC} source. Figure 4-1 shows the location where the AC line cord connects to the repeater. Insert the 3-prong plug into a 110/120/220/240 V_{AC} grounded outlet.

If an alternate line cord is required, obtain a suitable line cord, with fittings approved by the safety testing agency in the end-use country, from a certified electrical parts supplier.

4.1.2 Ground Connection

The repeater is equipped with a ground screw located on the rear of the repeater. Connect the site ground cable to the ground screw.



Refer to Motorola Quality Standards Fixed Network Equipment Installation Manual R56 (6881089E50), for complete information regarding lightning protection.



The repeater should only be connected to a battery supply that is in accordance with the applicable electrical codes for the end use country; for example, the National Electrical Code ANSI/NFPA No. 70 in the U.S.

4.1.3 Battery Backup Connection

The MOTOTRBO Repeater offers the capability of connecting to battery backup power in the event of an AC power failure.

The battery backup system is connected to the repeater through the DC connector mounted at the rear of the repeater (see [Figure 4-2](#)).

The repeater power supply will trickle charge the backup battery. If the battery is significantly discharged, it is recommended that an external charger be used to charge the battery.



The repeater is to be connected to a battery charger that is in accordance with the applicable electrical codes for the end use country; for example, the National Electrical Code ANSI/NFPA No.70 in the U.S.



Unplug the battery from the repeater when charging the battery with an external charger.



Figure 4-2 Making Connections to a Backup Battery

4.2 RF Antenna Connections

The transmit and receive antenna RF connection are made using two separate connectors. Coaxial cables from the receive and transmit antenna must be connected to the Type-N (Tx) and BNC (Rx) connectors. The position of these connectors is shown in [Figure 4-1](#). For repeater use, the antennas need adequate isolation between them, or if one antenna is used, the duplexer needs to have adequate isolation between the Tx and Rx ports. The isolation requirements are unique to each band and are shown in the table below:

Frequency Band	Bandwidth	Isolation
UHF 1	403–470 MHz	75 dB
UHF 2	450–512 MHz	85 dB
VHF	136–174 MHz	85 dB

If the duplexer isolation is not adequate, a preselector may also be used. See [“Accessories” on page 6-1](#) for a list of available duplexers and preselectors.



Caution

The repeater can key up at any time due to input from a subscriber unit or a CW ID. Please ensure that all power is switched off before disconnecting the transmit antenna.

4.2.1 Duplexer Selection

The selection of a duplexer is critical to system performance. The use of a notch (band reject) duplexer is possible in some systems that are not located at high RF density sites. See [“Accessories” on page 6-1](#) for a list of available duplexers.

The duplexer must be able to handle at least 50 W continuously. For the best system performance, the insertion loss should be less than 2 dB. If the repeater is used in higher RF density sites, the use of a pass-notch duplexer is recommended.

4.2.2 Antenna Selection

The selection of the antenna is critical to system performance. The selected antenna must be 50 Ohm impedance and capable of at least 50 Watts. Gain antennas may be used to increase system coverage. Please take note of licensing restrictions when selecting gain antennas. Some services or regions may have antenna gain or system ERP limitations.

The antenna must be connected to the duplexer with a high grade 50 Ohm transmission line (hardline). The line must have connectors to match the connectors on the duplexer and antenna. For proper antenna installation, please also consult the Motorola Quality Standards Fixed Network Equipment Installation Manual R56 (6881089E50).



Caution

It is important that all antenna cables are grounded at the point they enter the building.



Caution

The antenna design is the customer's responsibility. All aspects of the antenna design must comply with the relevant local regulations.

Notes

Chapter 5 Post-Installation Checklist

After the MOTOTRBO Repeater has been mechanically installed and all electrical connections have been made, power may now be applied and the repeater checked for proper operation.

5.1 Applying Power

Before applying power to the repeater, make sure all boards are securely seated in the appropriate connectors on the backplane and that all RF cables are securely connected.

Turn ON the circuit breaker controlling the AC outlet that is supplying power to the repeater Power Supply Module.

5.2 Verifying Proper Operation

Operation of the repeater can be verified by:

- observing the state of the 8 LEDs located on the front panel, and
- exercising radio operation.



Some repeater components can become extremely hot during operation. Turn off all power to the repeater and wait until sufficiently cool before touching the repeater.

5.2.1 Front Panel LEDs

After turning ON the repeater power (or after a repeater reset), the 8 LEDs on the repeater front panel:

- Light for about one second to indicate that they are functional, then
- Go off for one second, then
- Indicate the operational status of the repeater.

5.3 Archiving

5.3.1 Copying the Repeater Codeplug Data to a Computer

Backup the repeater's codeplug data by using the Customer Programming Software (CPS) on a computer.

Notes

Chapter 6 Accessories

Antennas

RDD4527_	VHF 3.0 dB Gain Antenna, 150 – 158 MHz
RDE4557_	3.8 dB Gain Omni Antenna 403 – 420 MHz
RDE4556_	3.8 dB Gain Omni Antenna 450 – 470 MHz
RDE4555_	3.8 dB Gain Omni Antenna 470 – 488 MHz
RDE4554_	3.8 dB Gain Omni Antenna 488 – 512 MHz

Cables

PMKN4010_	Mobile and Repeater Rear Programming Cable
PMKN4016_	Mobile and Repeater Rear Accessory Programming and Test Cable
PMKN4018_	Mobile and Repeater Rear Accessory Connector Universal Cable
RKN4152_	Battery Backup Cable

Miscellaneous Accessories

PMLE4476_	Wall Mount Kit for MOTOTRBO Repeater
RRX4032_	Tower Mounting Hardware for RRX4038_
PMLE4548_	Rack Mount for single Duplexer and single Preselector
RRX4038_	RF Surge Suppressor
RFE4000_	Untuned Duplexer, 450 – 470 MHz
HFE8400_	Untuned Duplexer, 406 – 450 MHz
HFE8401_	Untuned Duplexer, 470 – 512 MHz
HFE8454_	Untuned Duplexer, 490 – 527 MHz
HFE8459_	UHF Preselector, 440 – 474 MHz
HFE8460_	UHF Preselector, 474 – 527 MHz
HFD8188_	VHF Duplexer, 144 – 155 MHz
HFD8189_	VHF Duplexer, 155 – 162 MHz
HFD8190_	VHF Duplexer, 162 – 174 MHz
HFD8461_	VHF Preselector, 144 – 160 MHz
HFD8462_	VHF Preselector, 160 – 174 MHz

Notes

Appendix A Replacement Parts Ordering

A.1 Basic Ordering Information

When ordering replacement parts or equipment information, the complete identification number should be included. This applies to all components, kits, and chassis. If the component part number is not known, the order should include the number of the chassis or kit of which it is a part, and sufficient description of the desired component to identify it. The XPR 8300 Repeater Basic Service Manual (Motorola publication part number 6816810H01) includes complete parts lists and parts numbers.

A.2 Motorola Online

Motorola Online users can access our online catalog at

<http://www.motorola.com/businessonline>

To register for online access, please call 1-800-422-4210 (for U.S. and Canada Service Centers only). International customers can obtain assistance at <http://www.motorola.com/businessonline>

A.3 Mail Orders

Mail orders are only accepted by the U.S. Federal Government Markets Division (USFGMD):

Motorola Inc.
7031 Columbia Gateway Drive
3rd Floor - Order Processing
Columbia, MD 21046
U.S.A.

A.4 Telephone Orders

Radio Products and Solutions Organization*
(United States and Canada)
7:00 AM to 7:00 PM (Central Standard Time)
Monday through Friday (Chicago, U.S.A.)
1-800-422-4210
1-847-538-8023 (United States and Canada)

U.S. Federal Government Markets Division (USFGMD)
1-877-873-4668
8:30 AM to 5:00 PM (Eastern Standard Time)

A.5 Fax Orders

Radio Products and Solutions Organization*
(United States and Canada)
1-800-622-6210
1-847-576-3023 (International)

USFGMD
(Federal Government Orders)
1-800-526-8641 (For Parts and Equipment Purchase Orders)

A.6 Parts Identification

Radio Products and Solutions Organization*
(United States and Canada)
1-800-422-4210

A.7 Product Customer Service

Radio Products and Solutions Organization (United States and Canada)
1-800-927-2744

* The Radio Products and Solutions Organization (RPSO) was formerly known as the Radio Products Services Division (RPSD) and/or the Accessories and Aftermarket Division (AAD).

Appendix B Motorola Service Centers

B.1 Servicing Information

If a unit requires further complete testing, knowledge and/or details of component level troubleshooting or service than is customarily performed at the basic level, please send the radio to a Motorola Service Center as listed below.

B.2 Motorola Service Center

45D Butterfield Trail
El Paso, TX 79906
Tel: 1-800-227-6772

B.3 Motorola Federal Technical Center

4395 Nicole Drive
Lanham, MD 20706
Tel: 1-800-969-6680
Fax: 1-800-784-4133

B.4 Motorola Canadian Technical Logistics Center

Motorola Canada Ltd.
8133 Warden Avenue
Markham, Ontario, L6G 1B3
Tel: 1-800-543-3222
Fax: 1-888-331-9872 or 1-905-948-5970

Notes



MOTOROLA

Motorola, Inc.
1301 E. Algonquin Rd.
Schaumburg, IL 60196-1078, U.S.A.

MOTOROLA and the Stylized M Logo are
registered in the U.S. Patent and Trademark Office.
All other product or service names are the property
of their respective owners.
© 2006 — 2009 Motorola, Inc.
All rights reserved. Printed in the U.S.A.
March 2009.

www.motorola.com/mototrbo



6816814H01-G