

MASTR®II

806-870 MHz 90 WATT STATION COMBINATION

MAINTENANCE MANUAL LBI30490 C

DATAFILE FOLDER - DF9033









TABLE OF CONTENTS

SYSTEM SPECIFICATIONS	iii
COMBINATION NOMENCLATURE	iii
DESCRIPTION	1
INITIAL ADJUSTMENT	2
MAINTENANCE	3
SYSTEM DESCRIPTION	4
ReceiverTransmitter	4 4
System Board A901	4
DC Remote Control	4
Tone Remote Control	4 4
10-Volt Regulator/Control Board	5
Intercom Board	5
Built-in Metering	6
Antenna Relay	6
Heatsink Blower Kit	6
Duplexer	6
OUTLINE DIAGRAMS	
System Board A901	7
Intercom Board 19C320671G2	8
Control Shelf Mother Board 19D417214G1 & G2	9
10 Volt Regulator/Control Board 19D417401G1	10 11
Service Speaker 19C320728G1 & G2	12
	~-
SCHEMATIC DIAGRAMS (Includes Parts List & Production Changes) Radio Housing Front Door	13-14
Intercom Board 19C320671G2	15-14
10 Volt Regulator/Control Board 19D417401G1	17-18
Control Shelf Mother Board 19D417214G1 & G2	19-20
Service Speaker 19C320728G1 & G2	21-22
STATION INTERCONNECTION DIAGRAMS	
Station Harness Without Metering	23-24
Station Harness With Metering	25-26
INSTALLATION INSTRUCTIONS	
Antenna Relay Option 9607	27-2 8
Heatsink Blower Options 9609, 9610, 9611	29
Duplexer Option 9606	30
MECHANICAL PARTS BREAKDOWN	
Desk Mate Station	31
Pole Mount Station	32
Floor Mount Station	33 34
Mother Board & Driver Assemblies	35
Desk Mate Cabinet	36
Pole Mount Cabinet	37
Floor Mount Cabinet	38
** * * *******************************	
ILLUSTRATIONS	
Figure 1 - Base Station, Front View	1
Figure 2 - 90 Watt PA Assembly	1 2
rigure 3 - madio modsing and Control Shell	2

- WARNING -

No one should be permitted to handle any portion of the equipment that is supplied with high voltage; or to connect any external apparatus to the units while the units are supplied with power. KEEP AWAY FROM LIVE CIRCUITS.

 $\begin{array}{l} \hbox{High-level RF energy in the transmitter Power Amplifier assembly can cause RF burns.} \\ \hbox{KEEP AWAY FROM THESE CIRCUITS WHEN THE TRANSMITTER IS ENERGIZED!} \end{array}$

SPECIFICATIONS*

DIMENSIONS (HXWXD)

Desk Mate Pole Mount Floor Mount 44-1/4" x 21-1/2" x 15" 45" x 21-1/2" x 21" 69" x 23" x 21"

WEIGHT

Desk Mate Pole Mount Floor Mount 280 lbs. 325 lbs. 388 lbs.

INPUT VOLTAGE

121/242 VAC, 60 Hertz only (50 Hertz Optional)

AC INPUT POWER


550 Watts

TEMPERATURE RANGE

 -30° C to $+60^{\circ}$ C (-22° F to $+140^{\circ}$ F)

* These specifications are intended primarily for the use of the serviceman. Refer to the appropriate Specification Sheet for the complete specifications.

COMBINATION NOMENCLATURE



DESCRIPTION

The General Electric MASTR® II 806-870 MHz 90 Watt Station is a complete two-way radio station designed for receiving in the 806-825 MHz band and transmitting in the 851-870 MHz band. The station is a continuous duty combination capable of being operated locally or with DC or tone remote control. The station may also be operated as a repeater, receiving and retransmitting signals simultaneously. The station transmitter exciter is located in a shielded compartment in the radio housing front door. See Figure 1.

The station receiver is also mounted in a shielded compartment in the radio housing front door, along with a system board which accommodates the Channel Guard board. Jacks are provided on the system board for plug-in interface with options and control functions.

The 90 Watt Power Amplifier is mounted in 4-rack units of the station cabinet. A ceramic PA output tube and its input/output circuitry is contained in an aluminum cavity assembly. The tube is mounted to




Figure 1 - Base Station, Front View

the back aluminum dissipator plate and the finned heat sink sections are bolted to this plate. The entire assembly pulls out on drawer slides for maintenance. See Figure 2.




Figure 2 - 90 Watt PA Assembly

A power supply for operating the 90 Watt PA is mounted directly above the PA tube housing. A drop-down front panel is provided on the supply, allowing easy access to the AC input connections, power switch and fuses. A meter and its selector switch are also mounted on the front of the supply.

The PA driver hinges from the bottom rear of the radio housing. The driver consists of a frame mounted to a heat sink. A cover snaps into the frame to form an RF tight enclosure for the driver board assembly. See Figure 3.

Directly above the driver assembly is the station control shelf. A mother board is mounted to this shelf which accommodates the 10-Volt Regulator, Audio Control, Repeater Control and DC or Tone Remote Control modules. External connections from the remote control console are made to TB1201, located on the back of the mother board. Local control connections are made by means of a 24-conductor cable from the MASTR® Local Controller.

The station power supply is located at the bottom of the station cabinet. A power switch, primary and secondary fuses and two AC outlets are located on the front panel. A high current fuse is located on the back panel of the power supply.




Figure 3 - Radio Housing and Control Shelf

INITIAL ADJUSTMENT

After the Station has been installed, the transmitter and receiver must be adjusted by an electronic technician who holds a First or Second Class FCC Radiotelephone or Radiotelegraph license before the station can be placed in operation.

Make sure that a RADIO TRANSMITTER IDENTIFICATION Form (FCC FORM 452-C or General Electric Form NP270303) has been filled out and attached to the transmitter.

TRANSMITTER ADJUSTMENT

The adjustment for the transmitter includes measuring the forward and reflected power and adjusting the antenna length for optimum ratio, then setting the transmitter to rated power output (or to the specific power output which may be required by the FCC station authorization). Next, measuring the frequency and modulation and entering these measurements on the FCC-required station records.

For the complete transmitter adjustments, refer to the ALIGNMENT PROCEDURE in the MAINTENANCE MANUAL for the transmitter.

RECEIVER ADJUSTMENT

The initial adjustment for the receiver includes tuning the input circuit to match the antenna. Refer to the FRONT END ALIGN-MENT PROCEDURE in the MAINTENANCE MANUAL for the receiver.

To set the station VOLUME control (R3 on the System Board) use the following procedure:

- 1. Apply a 1000 microvolt on-frequency test signal modulated by 1,000 Hertz with ±3 kHz deviation to the receiver antenna jack J937.
- Connect an 8.2 ohm, 1-Watt resistor across METERING jack J905 terminals 1 and 2 on the System Board.
- 3. Connect an AC VTVM across the 8.2 ohm resistor and adjust R3 for a reading of 2.7 Volts RMS on the meter.

-CAUTION-

Adjustment of VOLUME control to settings higher than instructed in the INITIAL AD-JUSTMENT may result in damage to the station service speaker or Local Controller speaker.

1. Disconnect the 8.2 ohm resistor.

To set the station SQUELCH control (R901 on the Receiver/Exciter door) use the following procedure

- 1. Turn the SQUELCH control clockwise (to the right) as far as possible.
- 2. Adjust the VOLUME control on the service speaker (or the VOLUME control on the MASTR® Local Controller in local control installations) until the noise is easily heard in the speaker but is not annoyingly loud.
- 3. Turn the SQUELCH control counter-clockwise (to the left) until the noise just disappears, then advance control another 20 degrees.

REMOTE/REPEAT ADJUSTMENTS

The transmitter modulation gain, the remote audio input and line output, the drop-out delay timing and the 3-minute limit timing must be adjusted before placing the station in operation. Refer to the MASTR II Repeater Station Control Shelf MAINTENANCE MANUAL (LBI-4794) for the Repeater adjustments. Refer to the MASTR II DC Remote Control MAINTENANCE MANUAL (LBI-4792) or the Tone Remote Control MAINTENANCE MANUAL (LBI-4793) for the remote adjustments.

LOCAL MICROPHONE ADJUSTMENTS

In local control and local/remote or local/repeat applications, the local MIC GAIN control (R14) on the 10-Volt Regulator Board should be adjusted. While talking in a normal voice at four to six inches from the station microphone, adjust MIC GAIN control R14 for a deviation of ±3 kHz as measured on the deviation monitor.

MAINTENANCE

To insure high operating efficiency and to prevent mechanical and electrical

	INTERVAL B	ETWEEN CHECKS
MAINTENANCE CHECK	Every 6 Months	As Requ i red
Transmitter Alignment - Compare meter readings at transmitter multiplier metering jacks with voltages read during initial tune up. Touch up multiplier tuning. Check power output. (See Alignment Procedure for Transmitter).		х
Receiver - While receiving an unmodulated signal on the station frequency(s), adjust OSC-1 trimmer for a zero discriminator reading. (See the Receiver Alignment Procedure MAINTENANCE Section).		х
Transmission Line - Check for positive indication of pressure on transmission line pressure gauge (if pressurized line is used).	х	
Antenna - Check antenna & mast for mechanical stability.	Х	
Mechanical Inspection - Visually check cables, plugs, sockets, terminal boards & components for good electrical connections. Check for tightness of nuts, bolts & screws to make sure that nothing is working loose from its mounting.	х	
Cleaning - Use a vacuum cleaner to remove dust which has accumulated inside the cabinet.	х	
Frequency Check - Check transmitter frequency & deviation as required by FCC.		X

failures from interrupting system operations, routine checks should be made of all mechanical and electrical parts at regular intervals. This preventive maintenance should include the checks as listed in the table of Maintenance Checks.

Test and Troubleshooting Procedures

The individual Maintenance Manual for the transmitter and receiver describe standard test procedures which the serviceman can use to compare the actual performance of the transmitter or receiver against the specifications of the unit when shipped from the factory. In addition, specific troubleshooting procedures are available to assist the serviceman in troubleshooting the transmitter and receiver.

REMOVING IC's (and all other solderedin components) can be easily accomplished by using a de-soldering tool such as a SOLDA-PULLT® or equivalent. To remove an IC, heat each lead separately on the solder side and remove the old solder with the de-soldering tool.

An alternate method is to use a special soldering tip that heats all of the pins simultaneously.

SYSTEM DESCRIPTION

Receiver

The station receiver consists of an Oscillator/Multiplier Assembly (OSC/MULT), RF Assembly, IF Detector and an IF-Audio and Squelch Assembly (IFAS). Refer to the Receiver MAINTENANCE MANUAL for a complete description of the station receiver.

Transmitter

The station transmitter consists of an exciter board assembly, a power amplifier driver and a power amplifier output tube assembly. Refer to the Transmitter MAINTENANCE MANUAL for a complete description of the station transmitter.

System Board A901

The station System Board is located on the radio panel front door and the receiver modules plug directly into the board. Along the edge of the System Board are two connectors which interconnect to the Control and Audio modules and to the power supply.

Plug-in Channel Guard and other option jacks are provided. A metering jack is provided for accommodating the General Electric 4EX3A11 Test Set. VOLUME control R3 is located on the System Board. SQUELCH control R901 is located on the receiver/exciter door.

VOLUME/SQUELCH HI from the receiver Audio Pre-Amp is connected via J904-12 to the VOLUME (R3) and SQUELCH (R901) controls. The VOLUME control arm is returned to the receiver IFAS board where the audio is amplified by the receiver Audio Power Amplifier circuit. The audio output of the PA is then connected to the speaker leads at P904-18 and -19.

DC Remote Control

In DC Remote Control systems, the control modules on the control shelf utilize DC currents selectively applied to a telephone pair at a remote control console. These DC currents activate circuits in the control modules to perform the desired functions. Refer to the MASTR II DC Remote Station Control Shelf MAINTENANCE MANUAL (LBI-4792) for a complete description of this system.

Tone Remote Control

A maximum of twelve different functions can be performed in the Tone Remote Control system. This is accomplished by applying two or three tones in sequence at the prescribed level to the transmission medium at a remote control console for detection at the control module on the control shelf. Refer to the MASTR II Tone Remote Station Control Shelf MAINTENANCE MANUAL (LBI-4793) for a complete description of this system.

10-Volt Regulator/Control Board 19D417401G1

This board consists of a 10-Volt, 1/2 Ampere regulator; a 10-Volt, 2 Ampere regulator; a 20-dB preamplifier for providing the proper audio level for the transmitter exciter when using a local desk microphone; a keying switch for sequencing the antenna relay; a receiver muting circuit.

The 13.8 Volts DC from the station power supply low current filter is applied to terminal D5 of the regulator. This current is filtered by choke L1 and applied to the 10-Volt, 1/2 Amp hybrid regulator consisting of A1-Q1 and integrated circuit U1. This regulator feeds the receiver and transmitter oscillators, providing the close tolerance (±1%) required by these modules.

The 13.8 VDC input is also applied to the 10-Volt, 2 Amp regulator consisting of A3-Q1, Q3, Q4 and zener diode VR1. When the output of the regulator starts to increase, Q4 conducts harder. Q3 conducts less, causing A3-Q1 to conduct less. This increases the voltage drop across A3-Q1, keeping the output voltage constant. Potentiometer R4 is used to set the base voltage of Q4 for the desired 10-Volt output. This regulator supplies the station exciter, the receiver control circuits and the station accessories.

Diodes CR2-CR5 form a PTT OR gate. Applying a ground to any one of the PTT inputs forward biases the diode connected to that

input, turning on Q5. Conduction of Q5 operates Q6, applying ground to the antenna relay lead A10. This ground is also applied to the cathode of the Light Emitting Diode (LED) CR15 (TX LIGHT) turning the light on. Pin 8 on the regulator hybrid U1 is also grounded. Capacitor C1 starts to charge. In 15 milliseconds C1 is charged to a voltage high enough to allow the time delay switch in U1 to turn on.

Operation of the time delay switch causes the transmitter oscillator control switch in Ul to turn on. +10 Volts is applied via pin 14 of Ul to the transmitter ICOM(s), keying the transmitter. The 15 millisecond delay in the transmitter oscillator keying circuit allows the antenna relay to energize before RF is applied to the relay. When the PTT is released, CR6 delays the antenna relay from de-energizing unitl the RF is removed from the contacts.

When one of the PTT input leads is grounded, CR8 is also forward biased, turning on Q11. Conduction of Q11 operates Q1 and Q12, applying ground to the RX 1 MUTE and RX 2 MUTE leads. If REPEATER PTT (D3) is grounded, CR9 is forward biased, preventing Q12 from conducting to allow the normal repeater system to function.

When a local desk microphone is used with the station, the microphone audio is connected via B1 to the input of the MIC PRE AMP, consisting of Q2, Q7, Q8 and Q9. The audio is amplified by Q7 and the amplified audio level is adjusted by MIC GAIN control R14. The audio is further amplified by Q2 and Q8 and applied to the source lead of FET Q9. Q10 is normally conducting, keeping the gate of Q9 grounded and preventing the audio from passing. When the LOCAL PTT switch is operated, CR7 is forward biased, turning off Q10. FET Q9 is now allowed to conduct, passing the local audio to the transmitter modulator.

Service switches provided on the Regulator include the TX DISABLE/INTERCOM switch S1 which grounds the TX DISABLE path to permit the serviceman to use the intercom without keying the transmitter; the REMOTE PTT switch S2 which allows the adjustment of remote line levels by keying the remote PTT path in remote control systems.

Channel Guard

In Local/Remote Stations equipped with Channel Guard, the 19D417261G1 Channel Guard Board is plugged into the System Board at P908 and P909. The MASTR II receiver is equipped with a tone reject filter to prevent the CG tone from being heard in the station speaker. In addition, the transmitter has a Channel Guard modulation control to adjust for proper deviation.

Channel Guard is a continuous-tone controlled squelch system that provides communications control in accordance with EIA stan-

dard RS-220. The system utilizes standard tone frequencies from 71.9 to 203.5 Hertz with both the encoder and decoder operating on the same frequency. The STE circuit (Squelch Tail Eliminator) employs a phase shift of approximately 180° in the encode function to eliminate undesirable noise bursts after each transmission.

The CG decoder operates in conjunction with the station receiver to inhibit all calls that are not tone coded with the proper Channel Guard tone frequency. The VOLUME/SQUEICH output of the receiver is applied to the Channel Guard decoder at P908-1. As long as no signal is received properly coded, a ground is supplied through P908-5 to mute the receiver. When a properly coded signal is received, the receiver is unsquelched and the desired signal is heard.

In duplex combinations, a separate encoder is used in the exciter and a separate decoder is used in the receiver. The Encoder (19C321162G1) is located in the transmitter exciter compartment and the CG Decode Board (19D417261G6) is plugged into the System Board at P908 and P909.

A Channel Guard Filter is added to the Audio Board which attenuates frequencies below 203.5 Hertz to prevent the Channel Guard tone from being applied to the transmitter modulator input or the remote audio line.

A Repeater will not key in Channel Guard systems unless the received signal is coded with the proper Channel Guard tone. The CG MON function, when selected at the Local Controller, will not allow the Repeater to key on an uncoded input signal but will allow the Remote Control operator to hear all channel activity.

Intercom Board 19C320671G2

The Intercom Board, when used, plugs into J934 on the A901 System Board. This board allows monitoring of the remote audio line and intercommunication between the base station and the remote control dispatcher. If the station receiver unsquelches, the received audio will be switched to the station speaker and the receiver audio will override the line audio.

When monitoring the line, both the INTERCOM switch S1 on the 10-Volt Regulator/Control Board and LOCAL CONTROLLER are in the OFF (UP) position. The line audio is coupled to the Intercom Board from the compressor amplifier on the Remote Audio Board. FET switch Q6 is normally conducting and the audio is passed to the station receiver audio amplifier through MONITOR LEVEL ADJUST control R15. The amplified audio from the receiver PA is then coupled to the station speaker.

To communicate with the dispatcher from the station, the INTERCOM switch on the MASTR Local Controller is depressed or, when using the station service microphone, it is necessary to depress the INTERCOM switch on the 10-Volt Regulator and key the service microphone. Depressing the INTERCOM switch on the 10-Volt Regulator disables the station transmitter.

Depressing the LOCAL PTT switch applies a ground to J934-1 on the Intercom Board. CR1 is forward biased, turning off normally-conducting Q5. This allows FET Q4 to conduct. Audio from the local microphone is coupled by means of C1 to pre-amplifier Q1. The MIC LEVEL ADJUST Control R33 is in the collector circuit of Q1. The adjusted audio is connected to amplifier Q2-Q3. The INTERCOM AUDIO SWITCH Q4 passes the local microphone audio to the line. The ground from the LPTT lead turns off LOCAL MUTE transistor Q9 to allow Q10 to conduct, grounding the gate of Q6 and disabling the line monitor.

Built-in Metering (Options 9603, 9604, 9605)

Option 9603 provides a TRANSMITTER tuning meter and a RECEIVER tuning meter on vertical mount cabinets. Option 9604 provides TRANSMITTER and RECEIVER tuning meters as well as an AC LINE meter on the vertical mount cabinet. Refer to LBI-4845 for detailed installation instructions for this option.

Option 9605 provides an internal Card Edge Metering Kit. The Card Edge Meter plugs into the Station Control Shelf. A switch assembly is also provided to allow metering the transmitter and receiver test points. LBI-4848 provides detailed installation instructions for this option.

Antenna Relay (Option 9607)

This option provides an Antenna Relay Kit for operating the station simplex. The relay is mounted inside the 90-Watt/Power Amplifier housing. Refer to the Table of Contents for Installation Instructions of this option.

Heatsink Blower Kit


A Heatsink Blower Kit 19D417521Gl is provided when the station is mounted in a Pole Mount Cabinet. The blower kit is available as an option (Options 9609, 9610, 9611) when the station is mounted in a Vertical Mount or Desk Mate cabinet or when the station is operated from a 240 VAC source. Refer to the Table of Contents for installation instructions of these options.

Duplexer (Option 9606)

If duplex operation of the station from a single antenna is required, Option 9606 provides a 19C307190 Duplexer and two 19A136932 coax cables for this application. Refer to the Table of Contents for Installation Instructions of this option.

GENERAL ELECTRIC COMPANY • MOBILE COMMUNICATIONS DIVISION WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.





(19D423147, Rev. 1)

RUNS ON SOLDER SIDE


- RUNS ON COMPONENT SIDE

- RUNS ON BOTH SIDES

REFER TO WIRING DIAGRAM FOR THE FOLLING CONNECTIONS TO FROM H42 .H41 H77 H 50 H45 H46 H48 H47 H69 H68 F.76 H49


OUTLINE DIAGRAM
SYSTEM BOARD A901

Issue 2



(19C321454, Rev. 3) (19C320669, Sh. 2, Rev. 1) (19C320669, Sh. 3, Rev. 1)


LEAD IDENTIFICATION FOR Q4, Q6 & Q12



IN-LINE OR TRIANGULAR
VIEW FROM LEAD END

NOTE: LEAD ARRANGEMENT, AND NOT CASE SHAPE, IS DETERMINING FACTOR FOR LEAD IDENTIFICATION.

LEAD IDENTIFICATION FOR QI-Q3, Q5, Q7-QII QI3 & QI4




IN-LINE TRIAGULAR VIEW FROM LEAD END

NOTE: LEAD ARRANGEMENT, AND NOT CASE SHAPE, IS DETERMINING FACTOR FOR LEAD IDENTIFICATION.


OUTLINE DIAGRAM

INTERCOM BOARD 19C320671G2




-19A129525G3


(19D423897, Rev. 4) (RC-2943) (19D423597, Sh. 1, Rev. 7) (19D423597, Sh. 2, Rev. 6)



OUTLINE DIAGRAM


CONTROL SHELF MOTHER BOARDS 19D417214






REFER TO WIRIN	NG DIAGRAM FOR
THE FOLLOWING	CONNECTIONS.
FROM	то
A3-Q1-B	A2-HII
A3-Q1-C	A2 - HIO
A3-Q1-E	A2 - H12
AI - SI - 3	A2 - H5
AI - SI - 2	A2-H6
AI - S2-3	A2 - H7
A1 - S2 - 2	A2 - H8

10 VOLT REGULATOR/CONTROL BOARD 19D417401G1



REFER TO WIRING	DIAGRAM FOR CONNECTIONS.
FROM	то
H2	HI
Н3	Н9

LEAD IDENTIFICATION FOR QI-Q2,Q4,QIO,QI2



NOTE: LEAD ARRANGEMENT, AND NOT CASE SHAPE, IS DETERMINING FACTOR FOR LEAD IDENTIFICATION.


RUNS ON SOLDER SIDE

RUNS ON BOTH SIDES

RUNS ON COMPONENT SIDE

(19D423132, Rev. 13) (19D417241, Sh. 2, Rev. 15) (19D417241, Sh. 3, Rev. 15) OUTLINE DIAGRAM

10 VOLT REGULATOR/CONTROL COMPONENT BOARD A2



(19C328482, Rev. 3)


NOTES:

 INSTALL TAPE ALONG FLANGE, ONE ON EACH SIDE OF MOUNTING HOLES.

12

Issue 3

SERVICE SPEAKER 19C320728G2



LBI30490

PARTS LIST

LBI-30566

MASTR II 800 MHz STATION RADIO PANEL FRONT DOOR ASSEMBLY 19D417262G4

SYMBOL	GE PART NO.	DESCRIPTION
		DOOR ASSEMBLY 19D417262G4
A901		COMPONENT BOARD 19D417213G1
Cl	19A116080P7	Polyester: 0.1 µf ±20%, 50 VDCW.
C2	19A115680P24	Electrolytic: 400 µf +150% -10%, 18 VDCW; sim to Mallory Type TTX.
СЗ	19A116080P106	Polyester: 0.068 µf ±10%, 50 VDCW.
		JACKS AND RECEPTACLES
J903		Connector, Includes:
	19A116659P1	Connector: 3 contacts; sim to Molex 09-52-32. (Quantity 1).
	19Al16659P4	Connector: 6 contacts; sim to Molex 09-52-3062. (Quantity 2).
J904		Connector, Includes:
	19A116659P1	Connector: 3 contacts; sim to Molex 09-52-3032. (Quantity 1).
	19A116659P4	Connector: 6 contacts; sim to Molex 09-52-3062. (Quantity 3).
J905	19B219374G2	Connector: 9 contacts.
J936	4033513P4	Contact, electrical: sim to Bead Chain L93-3.
J951		Connector. Includes:
	19A116659P13	Connector: 4 contacts; sim to Molex 09-64-1041. (Quantity 5).
J952		Connector, Includes:
	19A116659P11	Connector: 7 contacts; sim to Molex 09-64-1071. (Quantity 2).
	19A116659P12	Connector: 6 contacts; sim to Molex 09-64-1061. (Quantity 1).
P907	19A116779P1	Contact, electrical: sim to Molex 08-50-0404. (Quantity 6).
P908	19A116779P1	Contact, electrical: sim to Molex 08-50-0404. (Quantity 9).
P909	19A116779P1	Contact, electrical: sim to Molex 08-50-0404. (Quantity 8).
P934	19A116779P1	Contact, electrical: sim to Molex 08-50-0404. (Quantity 8).
P935	19A116779P1	Contact, electrical: sim to Molex 08-50-0404. (Quantity 7).
		RESISTORS
R1 and R2	19C314256P22803	Metal film: 280K ohms $\pm 1\%$, $1/4$ w.
R3	19B209358P106	Variable, carbon film: approx 300 to 10K ohms ±10%, 0.25 w; sim to CTS Type X-201.
R4	3R152P222J	Composition: 2.2K ohms ±5%, 1/4 w.
R5	3R152P332J	Composition: 3.3K ohms ±5%, 1/4 w.
R6	7147161P15	Composition: 3.3 ohms ±5%, 1/2 w.
		CADURS
MOUS		
W903		CABLE ASSEMBLY 19D417262G2
		JACKS AND RECEPTACLES
J931 and	19C303426G1	Connector: 20 pin contacts.
J932		
1		

SYMBOL	GE PART NO.	DESCRIPTION
		TVICO.
P951		Connector, Includes:
and P952	19A116659P25	
	19A116781P5	Shell. Contact, electrical: wire No. 16-20 AWG; sim
	19A116781P6	to Molex 08-50-0106.
	194110/8120	Contact, electrical: wire No. 22-26 AWG; sim to Molex 08-50-0108.
		RESISTORS
R901	5496870P31	Variable, carbon film: 10K ohms ±20%; sim to Mallory LC(10K).
W904		EXCITER CABLE 19D417262G3
		JACKS AND RECEPTACLES
J933	19C303426G1	Connector: 20 pin contacts.
P901	104112250	Connector. Includes:
	19A116659P25 19A116781P5	Shell. Contact, electrical: wire No. 16-20 AWG; sim
		to Molex 08-50-0106.
	19A116781P6	Contact, electrical: wire No. 22-26 AWG; sim to Molex 08-50-0108.
W905		CABLE ASSEMBLY 19A136930G2
		JACKS AND RECEPTACLES
J937	19A115938P12	Connector, receptacle: (BNC Series); sim to Amphenol 31-342.
P301	19A134357P8	Cable, RF: approx 21 inches long.
W906		CABLE ASSEMBLY 19A136930G1
		jacks and receptacles
1938	19A115938P1	Connector, receptacle: (BNC Series); sim to Amphenol 31-318.
P101	19A134357P6	Cable, RF: approx 6 inches long.
		MISCELLANEOUS
	19C320679G1 19B218178P1	Door. Pawl. (Part of door latch).
	19C318151P1	Knob. (Part of door latch).
	N193P1208C6	Tap screw: No. 6 x 1/2. (Part of door latch).
	5493361P8	Washer, spring tension. (Part of door latch).
	19A121676P1	Guide pin. (Used with J931-J933).
	19B209519P1 7115130P9	Polarizing tab. (Used with P901, P951, P952). Lockwasher: sim to Shakeproof 1220-2. (Used
		with R901 mounting).
i	7165075P2	Hex nut, brass: No. $3/8-32$. (Used with R901 mounting).
	19A115874P1	Catch, friction. (Latches A901).


14

PRODUCTION CHANGES

Changes in the equipment to improve performance or to simplify circuits are identified by a "Revision Letter," which is stamped after the model number of the unit. The revision stamped on the unit includes all previous revisions. Refer to the Parts List for descriptions of parts affected by these revisions.

 $\frac{19D417213G1}{\text{REV. A - To provide alarm tone capability.}} \quad \text{Added H78 and H79.}$

^{*}COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES



(19D417243, Rev. 3)

LBI30490

PARTS LIST

LB14814C

INTERCOM BOARD 19C320671G1, G2

SYMBOL 	GE PART NO.	DESCRIPTION
		CAPACITORS
C1	19A116080P9	Polyester: 0.22 µf ±20%, 50 VDCW.
C2	5494481P111	Ceramic disc: 1000 pf $\pm 20\%$, 1000 VDCW; sim to RMC Type JF Discap.
СЗ	19A116080P10	Polyester: 0.33 µf ±20%, 50 VDCW.
C4 and C5	5496267P10	Tantalum: 22 μ f $\pm 20\%$, 15 VDCW; sim to Sprague Type 150D.
C6	19A116080P10	Polyester: 0.33 µf ±20%, 50 VDCW.
C7	19A115680P7	Electrolytic: 100 µf +150% -10%, 15 VDCW; sim to Mallory Type TT.
C8	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C9 and	19A116080P10	Polyester: 0.33 μf ±20%, 50 VDCW.
C10	19A116080P111	5-1
		Polyester: 0.47 µf ±10%, 50 VDCW. Tantalum: 15 µf ±20% 20 VDCW: sim to Sprague
C12	5496267P14 5494481P111	Tantalum: 15 µf ±20%, 20 VDCW; sim to Sprague Type 150D. Ceramic disc: 1000 pf +20%, 1000 VDCW; sim to
C13	5494481P111 5494481P107	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
614	U\$277UA. 1.	Ceramic disc: 470 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C15	5496267P9	Tantalum: 3.3 μf ±20%, 15 VDCW; sim to Sprague Type 150D.
C16	19A116080P101	Polyester: 0.01 µf ±10%, 50 VDCW.
C17	5496267P1	Tantalum: 6.8 μ f $\pm 20\%$, 6 VDCW; sim to Sprague Type 150D.
C18	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
	1	DIODES AND RECTIFIERS
CR1 thru CR12	19A115250P1	Silicon.
	1	JACKS AND RECEPTACLES
J934	19A116659P7	Connector: 4 contacts; sim to Molex 09-52-3041. (Quantity 2).
J935	1	Connector. Include:
	19A116659P7	Connector: 4 contacts; sim to Molex 09-52-3041.
	19A116659P5	Connector: 3 contacts; sim to Molex 09-52-3031.
	1	TRANSISTORS
Q1 thru Q3	19A115889P1	Silicon, NPN.
Q 4	19A134137P1	N Type, field effect; sim to Type 2N4416.
Q5	19A115889P1	Silicon, NPN.
પ ાં Q6	19A113889P1 19A134137P1	N Type, field effect; sim to Type 2N4416.
Q 7	19A115889P1	Silicon, NPN.
thru Q11	171110001	Silicon, ara.
Q12	19A134137P1	N Type, field effect; sim to Type 2N4416.
Q13 and Q14	19A115889P1	Silicon, NPN.

	SYMB0L	GE PART NO.	DESCRIPTION
			RESISTORS
	R1	19A700019P65	Deposited carbon: 0.22 megohm ±5%, 1/4 w.
1.	R2	19A700019P53	Deposited carbon: 22K ohms ±5%, 1/4 w
	R3	19A143400P35	Deposited carbon: 750 ohms ±5%, 1/4 w.
	R4	19A700019P37	Deposited carbon: 1K ohms ±5%, 1/4 w.
	R5	19A700019P63	Deposited carbon: 150K ohms ±5%, 1/4 w.
	R6	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
- []	R7	19A700106P63	Composition: 1K ohms ±5%, 1/4 w.
1	R8	19A700019P47	Deposited carbon: 6.8K ohms ±5%, 1/4 w.
	R9	19A700113P63	Composition: 1K ohms ±5%, 1/2 w.
1	R10	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
1	R11	19A700019P62	Deposited carbon: 120K ohms ±5%, 1/4 w.
1	R12	19A700019P69	Deposited carbon: 470K ohms ±5%, 1/4 w.
1	R13	19A143400P23	Deposited carbon: 75 ohms ±5%, 1/4 w.
1	R14	19A700019P47	Deposited carbon: 6.8K ohms ±5%, 1/4 w.
]]	R15	19B209358P105	Variable, carbon film: approx 200 to 5K ohms ±10%, 0.25 w; sim to CTS Type X-201.
	R16	19A143400P42	Deposited carbon: 3K ohms ±5%, 1/4 w.
1	R17 and R18	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w
. 1	R19	19A700019P60	Deposited carbon: 82K ohms ±5%, 1/4 w.
ر ا	R20	19A700019P67	Deposited carbon: 330K ohms ±5%, 1/4 w.
	R21 and R22	19A143400P64	Deposited carbon: 200K ohms ±5%, 1/4 w.
	R23	19A700019P37	Deposited carbon: 1K ohms ±5%, 1/4 w.
۱ ا	R24	19A700019P54	Deposited carbon: 27K ohms ±5%, 1/4 w.
1	R25	19A143400P52	Deposited carbon: 20K ohms ±5%, 1/4 w.
1	R26	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
	R27	19A143400P52	Deposited carbon: 20K ohms ±5%, 1/4 w.
	R28	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
	R29	19A700019P69 19A700019P60	Deposited carbon: 470K ohms ±5%, 1/4 w.
	R30		Deposited carbon: 82K ohms ±5%, 1/4 w.
- 1	R31 R32	19A700019P67 19A700019P61	Deposited carbon: 330K ohms ±5%, 1/4 w. Deposited carbon: 100K ohms ±5%, 1/4 w.
- 1	R33	19B209358P106	Variable, carbon film: approx 300 to 10K ohms ±10%, 0.25 w; sim to CTS Type X-201.
l	R34 and R35	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
- 1	R36*	19A700019P52	Deposited carbon: 18K ohms ±5%, 1/4 w.
-			In G2 earlier than REV A:
		3R152P273J	Composition: 27K ohms ±5%, 1/4 w.
	R37	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
l F	R38	19A700019P37	Deposited carbon: 1K ohms ±5%, 1/4 w.
			VOLTAGE REGULATORS
'	/R1	4036887P4	Zener: 500 mW, 4.4 v. nominal.
			†
1			

16 COMPONENTS ADDED


*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

PRODUCTION CHANGES

Changes in the equipment to improve performance or to simplify circuits are identified by a "Revision Letter," which is stamped after the model number of the unit. The revision stamped on the unit includes all previous revisions. Refer to the Parts List for descriptions of parts affected by these revisions.

REV. A - 19C320671G2

To recenter timing circuit. Changed R36.



NOTES: 10 V REG / CONTROL BD

- FOR CARRIER SQUELCH (NON-CHANNEL GUARD) STATIONS, JUMPER HI-H2 & H3-H9 ARE PRESENT.
- 2. FOR CHANNEL GUARD LOCAL, REMOTE OR LOCAL/REMOTE STATIONS JUMPER H9-H3 & H2-H4 ARE PRESENT.
- 3. FOR CHANNEL GUARD REPEATERS USING DECODE ONLY (NO ENCODE), JUMPER HI-H2 'S PRESENT.
 FOR CHANNEL GUARD REPEATERS USING BOTH ENCODE AND DECODE, JUMPER H2-H4 AND H3-H9 ARE PRESENT.
- 5. WHEN SECOND RECEIVER MUTE ON TRANSMIT IS NOT DESIRED CUT OUT QI.
- IN REPEAT, REMOTE/REPEAT AND LOCAL/REPEAT STATIONS C23 IS NOT PRESENT.
- WHEN OPTIONS 9555, 9556, AND 9589 (BACK TO BACK REPEATERS) ARE APPLIED, JUMPER FROM HI3 TO HI4 IS REMOVED AND A JUMPER FROM HI3 TO HI5 IS ADDED.
- 8. IN DUPLEX, DUPLEX WITH CHANNEL GUARD AND REPEATERS WITH CHANNEL GUARD, THE JUMPER FROM HI6 TO HI7 IS REMOVED.

VOLTAGE READINGS

ALL READINGS MADE WITH 20,000 OHMS-PER-VOLT METER. ALL READINGS TYPICAL.

- ▲ TRANSMITTER KEYED
- TRANSMITTER UNKEYED
- * LPTT KEYED

SCHEMATIC DIAGRAM

10 VOLT REG/CONT BOARD 19D417401G1 LBI30490

PARTS LIST

LBI4802K

10-VOLT REGULATOR/CONTROL 19D417401G1

SYMBOL	GE PART NO.	DESCRIPTION
A1		PANEL 19C320809G1
		TRANSISTORS
Ğ1	19A116375P1	Silicon, PNP.
S1 and S2	19B209261P11	Slide: (DPST, N.O., SR), 2 poles, 2 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switch-craft 46204MR.
A2		REGULATOR BOARD 19D417252G1
C1	19B200240P10	Tantalum: 10 μf ±5%, 15 VDCW.
C2 and C3	19A115680P10	Electrolytic: 200 µf +150% -10%, 18 VDCW; sim to Mallory Type TTX.
C4	5494481P111	Ceramic disc: 1000 pf $\pm 20\%$, 1000 VDCW; sim to RMC Type JF Discap.
C5	19All5680Pl0	Electrolytic: 200 μf +150% -10%, 18 VDCW; sim to Mallory Type TTX.
C6	5496267P28	Tantalum: 0.47 μf $\pm 20\%$, 35 VDCW; sim to Sprague Type 150D.
C7	5496267Pl4	Tantalum: 15 μ f $\pm 20\%$, 20 VDCW; sim to Sprague Type 150D.
C8	19A116080P9	Polyester: 0.22 µf ±20%, 50 VDCW.
С9	19A116080P10	Polyester: 0.33 µf ±20%, 50 VDCW.
C10	19B209233P1	Electrolytic, non-polarized: 25 μf ±20%, 25 VDCW; sim to Sprague 41D.
C11	5496267P10	Tantalum: 22 µf ±20%, 15 VDCW; sim to Sprague Type 150D.
C12 and C13	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C14	5496267P14	Tantalum: 15 µf ±20%, 20 VDCW; sim to Sprague Type 150D.
C15	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C16	5494481P107	Ceramic disc: 470 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C17 and C18	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C19*	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap. Deleted by REV D.
C20 and C21	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C22	19A115680P3	Electrolytic: 20 µf +150% -10%, 25 VDCW; sim to Mallory Type TTX.
C23	5496267P209	Tantalum: 3.3 µf ±10%, 15 VDCW; sim to Sprague Type 150D.
C24	5494481P111	Ceramic disc: 1000 pf ±20%, 1000 VDCW; sim to RMC Type JF Discap.
C25*	19A116080P101	Polyester: 0.01 µf ±10%, 50 VDCW. Added by REV H
		DIODES AND RECTIFIERS
CR1*	19A115775P1	Silicon, fast recovery, 225 mA, 50 PIV.
	1	In REV H & earlier:

SYMBOL	GE PART NO.	DESCRIPTION	SYMBOL	GE PART NO.	DESCRIPTION
CR2	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.	R22	19A700019P51	Deposited carbon: 15K ohms ±5%, 1/4 w.
thru CR5			R23	19A700019P69	Deposited carbon: 470K ohms ±5%, 1/4 w.
CR6	4037822P1	Silicon, 1000 mA, 400 PIV.	R24	19A700019P60	Deposited carbon: 82K ohms ±5%, 1/4 w.
CR7	19A115250P1	Silicon, fast recovery, 225 mA, 50 PIV.	R25	19A700019P67	Deposited carbon: 330K ohms ±5%, 1/4 w.
thru CR12			R26	19A143400P57	Deposited carbon: 51K ohms ±5%, 1/4 w.
CR13	4037822P1	Silicon, 1000 mA, 400 PIV.	R27	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.
CR15	19A134354P6	Diode, optoelectronic: red; sim to Hew. Packard	R28	19A143400P47	Deposited carbon: 7.5K ohms ±5%, 1/4 w.
		5082-4655.	R29	19A143400P54	Deposited carbon: 30K ohms ±5%, 1/4 w.
			R30	19A143400P34	Deposited carbon: 620 ohms ±5%, 1/4 w.
Ll	19A115894P1	Audio freq: 1.0 mh ind., 0.35 ohms DC res.	R31	19A700019P37	Deposited carbon: 1K ohms ±5%, 1/4 w.
			R32	19A700019P38	Deposited carbon: 1.2K ohms ±5%, 1/4 w.
			R33	19A700019P23	Deposited carbon: 68 ohms ±5%, 1/4 w.
P5		(Part of printed board 19D417241P1).	R34	19A700019P50	Deposited carbon: 12K ohms ±5%, 1/4 w.
		TRANSISTORS	R35	19A143400P28	Deposited carbon: 200 ohms ±5%, 1/4 w.
Q1	19A115910P1	Silicon, NPN; sim to Type 2N3904.	R36*	19A700019P31	Deposited carbon: 330 ohms ±5%, 1/4 w. Added by
and Q2				20	REV A.
Q3	19A115300P2	Silicon, NPN; sim to Type 2N3053.	R37*	19A700019P21	Deposited carbon: 47 ohms $\pm 5\%$, $1/4$ w. Added by REV J.
Q4	19A115910P1	Silicon, NPN; sim to Type 2N3904.			
Q5	19A115768P1	Silicon, PNP; sim to Type 2N3702.			INTEGRATED CIRCUITS
Q6	19A115300P2	Silicon, NPN; sim to Type 2N3053.	U1*	19D416564G4	10-Volt Regulator.
Q7	19A116774P1	Silicon, NPN; sim to Type 2N5210.			In REV D & earlier:
and Q8				19D416564G3	10-Volt Regulator.
Q9	19A134137P4	N Type, field effect.			VOLTAGE REGULATORS
Q10	19A115910P1	Silicon, NPN; sim to Type 2N3904.	VR1	4036887P40	Zener: 500 mW, 8.2 v. nominal.
Q11	19A115768P1	Silicon, PNP; sim to Type 2N3702.	VR2	4036887P4	Zener: 500 mW, 4.4 v. nominal.
Q12	19A115910P1	Silicon, NPN; sim to Type 2N3904.	VR3	4036887P6	Zener: 500 mW, 6.5 v. nominal.
		RESISTORS	A3		HEAT SINK ASSEMBLY
R1	19A700019P41	Deposited carbon: 2.2K ohms $\pm 5\%$, 1/4 w.			19B226114G2
R2*	19A700112P45	Composition: 180 ohms ±5%, 1 w.			
		In REV A & earlier:	Q1	19A116758P2	Silicon, PNP; sim to Type 2N4399.
	3R77P301J	Composition: 300 ohms ±5%, 1/2 w.			MISCRELL AVEOUS
R3*	3R77P240J	Composition: 24 ohms ±5%, 1/2 w.			MISCELLANEOUS
		Earlier than REV A:	i I	19B219690G1	Handle assembly.
	3R77P101K	Composition: 100 ohms $\pm 10\%$, 1/2 w.		19A116023P1	Insulator, plate. (Used with Q1 on A1).
R4	19B209358P101	Variable, carbon film: approx 25 to 250 ohms ±10%, 0.2 w; sim to CTS Type X-201.		19A134016P1	Insulator, bushing. (Used with Q1 on A1).
R5	19A700113P59	Composition: 680 ohms ±5%, 1/2 w.	1 1	4036555P1	Insulator, washer: nylon. (Used with Q3 & Q6 on A2).
R6	19A700019P33	Deposited carbon: 470 ohms ±5%, 1/4 w.		7118719P10	Clip, spring tension; sim to Prestole E-50019-003.
R7	19A143400P40	Deposited carbon: 2K ohms ±5%, 1/4 w.			(Used with L1 on A2).
R8	3R77P102K	Composition: 1K ohms ±10%, 1/2 w.		4029974Pl	Insulator, plate. (Used with Ql on A3).
R9	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.		19A121882P1	Washer, shield. (Used with Q1 on A3).
R10	19A143400P34	Deposited carbon: 620 ohms ±5%, 1/4 w.		4036994P1	Terminal, solderless. (Used with Q1 on A3).
1	19A700019P37	Deposited carbon: 1K ohms ±5%, 1/4 w.	11	19B226013G1	Heat sink. (Used with Q1 on A3).
R11	1	Deposited carbon: 220K ohms ±5%, 1/4 w.		19A121175P11	Insulator. (Used with C10 on A2).
R12	19A700019P65	Deposited carbon: 22K ohms ±5%, 1/4 w.	1	5491541P307	Spacer, threaded. (Supports A3).
R13	19A700019P53	Variable, carbon film: approx 300 to 10K ohms		N405P5C	Lockwasher: No. 4. (Secures S1 & S2 on A1).
R14	19B209358P106	±10%, 0.25 w; sim to CTS Type X-201.]]	N80P9004C6	Machine screw: No. 4-40 x 1/4. (Secures S1 & S2 on A1).
R15	19A143400P35	Deposited carbon: 750 ohms ±5%, 1/4 w.		N80P9006C6	Machine screw: No. 4-40 x 3/8. (Secures Q1 on Al
R16	19A700019P63	Deposited carbon: 150K ohms ±5%, 1/4 w.			
R17	19A700019P49	Deposited carbon: 10K ohms ±5%, 1/4 w.			
R18	19A700019P47	Deposited carbon: 6.8K ohms ±5%, 1/4 w.			
R19	19A700019P37	Deposited carbon: 1K ohms ±5%, 1/4 w.			
R20	3R77P102K	Composition: 1K ohms ±10%, 1/2 w.			
R21	19A143400P52	Deposited carbon: 20K ohms ±5%, 1/4 w.			
	1				
1	1	Ī	1 1	1	Í


*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

PRODUCTION CHANGES

Changes in the equipment to improve performance or to simplify circuits are identified by a "Revision Letter," which is stamped after the model number of the unit. The revision stamped on the unit includes all previous revisions. Refer to the Parts/List for descriptions of parts affected by these revisions.

19D417252G1

- REV. A-C Incorporated in original shipment.
- REV. D Deleted C19. To prevent a 150 MHz oscillation. Changed U1.
- REV. E To prevent regulator from sending transmit signal during switch-off delay period.
- REV. F To provide receiver muting. Added H16 and H17.
- REV. G To correct repeater muting. Added H18 and H19.
- REV. H To stop oscillation on the 10 Volt line. Added C25.
- V. J 19041725261
 - To improve operation of 10 Volt Regulator. Changed CR1 and Q1; Added R37.



LBI30490

PARTS LIST

LBI4811B

CONTROL SHELF MOTHER BOARD 19D417214G1, G2

SYN	NBOL	GE PART NO.	DESCRIPTION
			JACKS AND RECEPTACLES
J120	01	19A116647P4	Connector, printed wiring: 12 terminals, sim to Molex 09-18-5121.
J120	02	19A116647P6	Connector, printed wiring: 12 terminals, sim to Molex 09-18-5927.
J120	03	19A116647P4	Connector, printed wiring: 12 terminals, sim to Molex 09-18-5121.
J120	04	19A116647P6	Connector, printed wiring: 12 terminals, sim to Molex 09-18-5927.
J120	05A	19A116446P5	Connector, printed wiring: 14 contacts.
J120	05В	19A116446P5	Connector, printed wiring: 14 contacts.
J120	05D	19A116446P5	Connector, printed wiring: 14 contacts.
J120	06A	19A116446P5	Connector, printed wiring: 14 contacts.
J120	06В	19A116446P5	Connector, printed wiring: 14 contacts.
J120	06D	19A116446P5	Connector, printed wiring: 14 contacts.
J120	07A	19A116446P5	Connector, printed wiring: 14 contacts.
J120	07D	19A116446P5	Connector, printed wiring: 14 contacts.
J120		19A116446P5	Connector, printed wiring: 14 contacts.
J120		19A116446P5	Connector, printed wiring: 14 contacts.
J120		19A116446P5	Connector, printed wiring: 14 contacts.
J120		19A116446P5	Connector, printed wiring: 14 contacts.
1 312	030	10411044010	- Commoder, France and a series of
J12	10A	19A116446P5	Connector, printed wiring: 14 contacts.
J12	10D	19A116446P5	Connector, printed wiring: 14 contacts.
J12	11A	19A116446P5	Connector, printed wiring: 14 contacts.
J12	11D	19A116446P5	Connector, printed wiring: 14 contacts.
J12	12A	19A116446P5	Connector, printed wiring: 14 contacts.
J12	12C	19A116446P5	Connector, printed wiring: 14 contacts.
J12	12D	19A116446P5	Connector, printed wiring: 14 contacts.
J12	13A	19A116446P5	Connector, printed wiring: 14 contacts.
J12	13C	19A116446P5	Connector, printed wiring: 14 contacts.
J12	13D	19A116446P5	Connector, printed wiring: 14 contacts.
J12	14	19A116647P4	Connector, printed wiring: 12 terminals, sim to Molex 09-18-5121.
J12	15	19B219627G1	Connector: 6 contacts.
J12		19A116647P4	Connector, printed wiring: 12 terminals, sim
			to Molex 09-18-5121.
			RESISTORS
R12		19A700112P23	Composition: 22 ohms ±5%, 1 w. Added by REV A.
and R12	02*		
TB1	201	19A116667P3	Plate nut. (Quantity 18).
			MISCELLANEOUS
		19A129525G3	Cable: approx 3 inches long.
		19/1/20/20/03	Caracter of Annual Cong.
		1	
		1	
		1	

20


PRODUCTION CHANGES

Changes in the equipment to improve performance or to simplify circuits are identified by a "Revision Letter," which is stamped after the model number of the unit. The revision stamped on the unit includes all previous revisions. Refer to the Parts List for descriptions of parts affected by these revisions.

- REV. A Incorporated in initial shipment.
- REV. B Added holes and pads to provide outputs in EACOM systems.
- REV. C Changed printed board to provide 4-frequency remote functions.
- REV. D To reduce possibility of falsing on noise. Added a jumper from J1209-D4 to J1208-D4.
- REV. E To make both auxiliary positions functional. Added H32 thru H39.
- REV. F To supply 10 Volts to the 19D417214G1 & G2 boards. Changed printed pattern.

^{*}COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

SI



SEE APPLICABLE PRODUCTION CHANGE SHEETS IN INSTRUCTION BOOK SECTION DEALING WITH THIS UNIT, FOR DESCRIPTION OF CHANGES UNDER EACH REVISION LETTER.

THIS ELEM DIAG APPLIES TO MODEL NO REV LETTER

PL 19C320728G2 G

ALL RESISTORS ARE 5 WATT UNLESS OTHERWISE SPECIFIED AND RESISTOR VALUES IN OHMS UNLESS FOLLOWED BY K=1000 OHMS OR MEG=1,000,000 OHMS CAPACITOR VALUES IN PICOFARADS (EQUAL TO MICROMICROFARADS) UNLESS FOLLOWED BY UF= MICROFARADS. INDUCTANCE VALUES IN MICROHENRYS UNLESS FOLLOWED BY MH= MILLIHENRYS OR H=HENRYS.

(19C320731, Rev. 9)

SCHEMATIC DIAGRAM

21

SERVICE SPEAKER 19C320728G2

Issue 4

LBI30490

PARTS LIST

LBI4816D

SERVICE SPEAKER 19C320728G2


Fi*	SYMBOL	GE PART NO.	DESCRIPTION
1R16P1 In REV E & earlier: 1R16P1 Quick blowing: 1/2 amp at 250 v; sim to Littelfuse 312.500 or Bussmann AGC-1/2. In REV D: Quick blowing: 3/8 amp 250 v; sim to Littelfuse 312.375 or Bussmann AGC-3/8. Added by REV D.			
R16P1 Quick blowing: 1/2 amp at 250 v; sim to Littel- Tuse 312.500 or Bussmann AGC-1/2.	F1*	1R16P3	
Tuse 312,500 or Bussmann AGC-1/2. In REV D: Quick blowing: 3/8 amp 250 v; sim to Littelfuse 312,375 or Bussmann AGC-3/8. Added by REV D. JACKS AND RECEPTACLES Connector. Includes: Shell. S496809P18 Contact, electrical: male; sim to Molex 1380-T. Contact, electrical: male; sim to Molex 1380-T.			In REV E & earlier:
1816P14 Quick blowing: 3/8 amp 250 v; sim to Littelfuse 312.375 or Bussmann ACC-3/8. Added by REV D. JACKS AND RECEPTACLES Connector. Includes: 198209288P22 Shell. Contact, electrical: male; sim to Molex 1380-T.		1R16P1	
198209288P22 Shell. Contact, electrical: male; sim to Molex 1380-T.			In REV D:
198209288P22 Shell.		1R16P14	Quick blowing: 3/8 amp 250 v; sim to Littelfuse 312.375 or Bussmann AGC-3/8. Added by REV D.
198209288P22 Shell. Contact, electrical: male; sim to Molex 1380-T.			JACKS AND RECEPTACLES
S496809P18 Contact, electrical: male; sim to Molex 1380-T.	J1		
LS1		i i	
19A115964P1 Permanent magnet: 3.5 inch, 18 ohms ±10% imp, 15 to 19 ohms ±20% DC res, resonant frequency 290 Hz; sim to Oaktron S-9847.		5496809P18	Contact, electrical: male; sim to Molex 1380-T.
### Page 12 Page 13 Page 14 Page 14 Page 14 Page 14 Page 15 Page 14 Page 15 Pa			i
### R1	LS1	19A115964P1	Permanent magnet: 3.5 inch, 18 ohms ±10% imp, 15 to 19 ohms ±20% DC res, resonant frequency 290 Hz; sim to Oaktron S-9847.
### ### ##############################			RESISTORS
### S493035P53 Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV D. ### Page 18. Deleted by REV D. ### S493035P52 Wirewound: 35 ohms ±20%, 2.25 w; sim to CTS Type 118. Deleted by REV D. ### S493035P52 Wirewound: 8.2 ohms ±10%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV D. ### S493035P53 Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV B. ### Revound: 10 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV C. Deleted by REV D. ### S493035P27 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. ### S493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. ### In REV D: ### S493035P17 Composition: 62 ohms ±5%, 1 w. Added by REV D. ### Revound: 25 ohms ±5%, 1 w; sim to Hamilton Hall Type HR. ### In REV D: ### 198209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to Hamilton Hall Type HR. ### 198209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. ### Added by REV D. ### 198209021P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. ### 198209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	Rl	5493035P53	
### S493035P53 Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV D. ### Page 18. Deleted by REV D. ### S493035P52 Wirewound: 35 ohms ±20%, 2.25 w; sim to CTS Type 118. Deleted by REV D. ### S493035P52 Wirewound: 8.2 ohms ±10%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV D. ### S493035P53 Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV B. ### S493035P27 Wirewound: 10 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV C. Deleted by REV D. ### S493035P17 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. ### S493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. ### In REV D: ### S493035P44 Wirewound: 25 ohms ±5%, 1 w. Added by REV D. ### S493035P44 Wirewound: 25 ohms ±5%, 1 w. Added by REV D. ### In REV D: ### 198209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. ### 198209022P48 Wirewound: 220 ohms ±5%, 1/2 w. Added by REV D. ### 198209021P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. ### 198209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.			
### Hall Type HR. Deleted by REV D. ### 198209490P1 Variable, wirewound: 35 ohms ±20%, 2.25 w; sim to CTS Type 118. Deleted by REV D. ### 5493035P52 Wirewound: 8.2 ohms ±10%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV C. ### S493035P53 Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV B. #### S493035P27 Wirewound: 10 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV C. Deleted by REV D. #### 19A700050P21 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. #### S493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. #### In REV D: ### 3878P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. #### Wirewound: 25 ohms ±5%, 10 w; sim to Hamilton Hall Type HR. ### In REV D: ### 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. ### 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. ### 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. ### 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. ### 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	R2*	5493035P3	Wirewound: 2 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV F.
### Type HR. Deleted by REV D. #### S493035P52 Wirewound: 8.2 ohms ±10%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV C. ###################################		5493035P53	Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV D.
### Hall Type HR. Deleted by REV C. ### S493035P53 Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV B. #### S493035P27 Wirewound: 10 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV C. Deleted by REV D. #### 19A700050P21 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. #### S493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. ### In REV D: ### 3378P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. #### Wirewound: 25 ohms ±5%, 1 w. Added by REV D. ### 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to Hamilton Hall Type HR. #### In REV D: ### 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. ### 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. ### 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. ### 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	R3*	19B209490P1	Variable, wirewound: 35 ohms ±20%, 2.25 w; sim to CTS Type 118. Deleted by REV D.
### R6* 5493035P27 Wirewound: 10 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV C. Deleted by REV D. #### R8* 19A700050P21 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. #### R8* 5493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. In REV D: 3R78P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. ### R9* 5493035P44 Wirewound: 25 ohms ±5%, 10 w; sim to Hamilton Hall Type HR. In REV D: 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. ### R10* 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. ### R10* 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. S1	R4*	5493035P52	Wirewound: 8.2 ohms ±10%, 5 w; sim to Hamilton Hall Type HR. Deleted by REV C.
### R6* 5493035P27 Wirewound: 10 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV C. Deleted by REV D. #### R8* 19A700050P21 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. #### R8* 5493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. In REV D: 3R78P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. ### R9* 5493035P44 Wirewound: 25 ohms ±5%, 10 w; sim to Hamilton Hall Type HR. In REV D: 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. ### R10* 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. ### R10* 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. S1	R5	5493035P53	Wirewound: 18 ohms ±5%, 5 w; sim to Hamilton Hall Type HR. Added by REV B.
### R7* 19A700050P21 Wirewound: 4.7 ohms ±10%, 2 w. Added by REV D. ### S493035P17 Wirewound: 63 ohms ±5%, 5 w; sim to Hamilton ### Hall Type HR. In REV D: 3R78P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. ### S493035P44 Wirewound: 25 ohms ±5%, 10 w; sim to Hamilton ### Hall Type HR. In REV D: 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. ### S493035P44 Added by REV D. ### S493035P44 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. ### S493035P45 S1ide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. *** S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	R6*	5493035P27	
Hall Type HR. In REV D: 3R78P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. 89* 5493035P44 Wirewound: 25 ohms ±5%, 10 w; sim to Hamilton Hall Type HR. In REV D: 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. R10* 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. R11* 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. 51 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	R7*	19A700050P21	
3R78P620J Composition: 62 ohms ±5%, 1 w. Added by REV D. 5493035P44 Wirewound: 25 ohms ±5%, 10 w; sim to Hamilton Hall Type HR. In REV D: 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. R10* 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. R11* 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. S1 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	R8*	5493035P17	
### ### ### ### ######################			In REV D:
Hall Type HR. In REV D: 19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D. R10* 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. R11* 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D.		3R78P620J	<u> </u>
19B209022P48 Wirewound: 24 ohms ±5%, 2 w; sim to IRC Type BWH. Added by REV D.	R9*	5493035P44	Wirewound: 25 ohms $\pm 5\%$, 10 w; sim to Hamilton Hall Type HR.
Added by REV D. 19A700113P47 Composition: 220 ohms ±5%, 1/2 w. Added by REV D. 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D. SWITCHES S1 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.			
R11* 19A700113P33 Composition: 56 ohms ±5%, 1/2 w. Added by REV D.		19B209022P48	
S1	R10*	19A700113P47	i
S1 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.	R11*	19A700113P33	Composition: 56 ohms $\pm 5\%$, 1/2 w. Added by REV D.
S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.			
S2* 19B209261P5 Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. Added by REV D.	S 1	19B209261P5	Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B.
	S2*	19B209261P5	Slide: DPTT, 2 poles, 3 positions, 0.5 amp VDC or 3 amps VAC at 125 v; sim to Switchcraft 11D1033B. Added by REV D.
			1

SYMBOL	GE PART NO.	DESCRIPTION
тві	7775500P44	
XF1*	7141008Pl	Fuseholder: 30 amps at 125 v; sim to Bussman 2863. Added by REV D.
	'4032480P1 19B201074P204 N80P13005C6	Nut, sheet spring: sim to Vector Electronic Co. No. 440. (Secures S1, S2). Tap screw, Phillips POZIDRIV®: No. 4-40 x 1/4. (Secures S1, S2). Machine, screw: No. 6-32 x 5/16. (Secures Service Speaker).
	7141225P3 N404P13C6	Hex nut: 6-32. (Secures Service Speaker). Lockwasher, internal tooth: No. 6. (Secures Service Speaker).

PRODUCTION CHANGES

Changes in the equipment to improve performance or to simplify circuits are identified by a "Revision Letter," which is stamped after the model number of the unit. The revision stamped on the unit includes all previous revisions. Refer to the Parts List for descriptions of parts affected by these revisions.

- REV. A To eliminate factory wiring errors caused by duplication of wire colors. Changed wire colors of J1-1 from Orange to Red and J1-2 from Brown to Black.
- REV. B To provide load for receiver when service speaker switch is in "OFF" position. Added R5 and DA Jumper between S1-1 and S1-3.
- REV. C To prevent oscillation and to protect R3 from overload. Deleted R4 and added R6.
- REV. D To prevent component damage due to excessive voltage. Deleted R2, R3 and R6. Added F1, XF1, R7-11, S2 and TB1.
- REV. E To protect speaker from excessive drive. Changed F1, R8 and R9.
- REV. F To prevent mechanical oscillation of speaker when excessive drive occurs. Changed F1 and added R12.
- REV. G To stop audio oscillation. Relocated R2 in the circuit.



(19R622265, Rev. 4)

INTERCONNECTION DIAGRAM


806-870 MHz, 90 WATT STATION HARNESS WITHOUT METERING 19C320811G1

PARTS LIST


LBI479

MASTR II CONTINUOUS DUT STATION HARNESS 19C320811G1

SYMBOL	GE PART NO.	DESCRIPTION
		JACKS AND RECEPTACLES
J1		Connector. Includes:
-	19B209288P5	Shell.
	19B209288P29	Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 13).
J2		Connector. Includes:
	19B209288P3	Shell.
	19B209288P29	Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 9).
P1		Connector. Includes:
	19B209288P20	Shell.
	19B209288P29	Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 11).
P2		Connector. Includes:
	19B209288P20	Shell. Contact, electrical: female; sim to Molex 02-09-
	19B209288P29	1141. (Quantity 6)
	19B209288P30	Contact, electrical: male; sim to Molex 02-09- 2141. (Quanity 1).
P3		Connector, Includes:
	19B209288P20	Shell.
	19B209288P29	Contact, electrical: female; sim to Molex 02-09- 1141. (Quantity 9).
24		Connector, Includes:
	19B209288P20	Shell. Contact, electrical: female; sim to Molex 02-09-
	19B209288P29	1141. (Quantity 7).
	19B209288P30	Contact, electrical: male; sim to Molex 02-09-2141. (Quantity 1).
P5		Connector, Includes:
	19B209288P23	Shell.
	19B209288P29	Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 2).
P6 thru P8	19C303506P1	Connector, phen: 20 contacts.
P9		Connector. Includes:
	19B209288P4	Shell.
	19B209288P30	Contact, electrical: male; sim to Molex 02-09-2141. (Quantity 1).
	19B209288P2	Contact, electrical: sim to Molex Poducts 1190-T (Quantity 1).
P12	19A115793P1	Contact, electrical: sim to Malco 2700.







INTERCONNECTION DIAGRAM

25

806-870 MHz. 90 WATT STATION HARNESS WITH METERING 19C320811G6 AND EXTENSION HARNESS 19B227805G1 LBI30490

PARTS LIST

LB130485A

STATION HARNESS WITH METERING AND EXTENSION HARNESS


SYMBOL GE PART NO. DESCRIPTION STATION HARNESS WITH METERING 19C320811G6 - - - - - - - - CONDUCTORS - - - - - - -19All5370Pl Conductor, in line splice; sim to AMP 35653. - - - - - - JACKS AND RECEPTACLES - - - - - -Connector. Includes: Contact, electrical: female; sim to Molex 02-09-1141. (J1-1 thru J1-8, J1-10 thru J1-12). 19B209288P29 Connector. Includes: 19B209288P3 Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 7). Connector. Includes: 19B209288P25 Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 9). 19B209288P29 - - - - - - - - - - PLUGS - - - - - - - -Connector. Includes: 19B209288P20 Contact, electrical: female; \sin to Molex 02-09-1141. (Quantity 8). 19B209288P29 Connector. Includes: 19B209288P29 Contact, electrical: female; sim to Molex 02-09-1141. (P2-4 thru P2-9). Contact, electrical: male; sim to Molex 02-09-2141. (P2-3). 198209288**P**30 Connector. Includes: Contact, electrical: female; sim to Molex 02-09-1141. (P3-4 thru P3-8, P3-10, P3-11). 19B209288P29 Contact, electrical: sim to Molex Products 1189-T. (P3-3). Connector. Includes: 19B209288P20 Contact, electrical: female; sim to Molex 02-09-1141. (P4-5, P4-7, P4-10 thru P4-12). 19B209288P29 Contact, electrical: sim to Molex Products 1189-T. (P4-3). 19B209288P1 Contact, electrical: male; sim to Molex 02-09-2141. (P4-3). 19B209288P30 Connector. Includes: 19B209288P23 Contact, electrical: female; sim to Molex 02-09-1141. (Quantity 4). 19B209288P29 19C3O35O6P1 Connector, phen: 20 contacts. Connector. Includes: 19B209288P4 Contact, electrical: sim to Molex Poducts 1190-T. (Quantity 2). 19B209288P2

SYMBOL	GE PART NO.	DESCRIPTION
		EXTENSION HARNESS 19B227805G1
P1		Connector. Includes:
	19B209288P24 5496809P18	Shell. Contact, electrical: sim to Molex Products 1380-T. (Quantity 9).
P2		1380-T. (Quantity 9). Connector. Includes:
	19B209288P31	Shell.
	5496809P17	Contact, electrical: sim to Molex Products 1381-T. (Quantity 9).

*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES.

Contact, electrical: sim to Malco 2700.


19A115793P1




(19C327574, Sh. 1, Rev. 0)

THESE INSTRUCTIONS COVER INSTALLATION OF THE ANTENNA RELAY KIT, PL19C327C33GI INTO THE 900 MHz POWER AMPLIFIER, 19C307185.

- I. REMOVE THE 10-32 X 3/8 RETAINING SCREWS ON EACH SIDE OF THE FRONT PANEL. EXTEND THE POWER AMPLIFIER TO ITS MAX POSITION. SAVE HARDWARE. NOTE, STEP I MAY BE OMITTED IF PWR AMPL IS NOT MOUNTED IN A CABINET.
- 2. DISCONNECT THE MOLEX PLUG ON CABLE FROM REFLECTOMETER AT THE JUNCTION BOX.
- 3. DISCARD THE 19A115828 ADAPTER IF PRESENT.
- 4. CONNECT THE ANTENNA RELAY ONTO THE PLUG ON THE END OF THE LOW PASS FILTER AS SHOWN IN VIEW A.
- 5. SLIDE THE RELAY/FILTER ASSY BACK AND FORTH WITHIN THE CLIP UNTIL THE MOUNTING HOLES ON THE BACK OF THE RELAY ALIGN WITH THE HOLES ON THE FRONT PANEL. MOUNT THE RELAY USING 6-32 X 3/8 SCREWS & ASSOCIATED HARDWARE FURNISHED IN THE RELAY KIT.
- 6. ROUTE THE RED AND WHITE LEADS FROM THE RELAY, UNDER THE BASE OF THE RELAY AND THRU THE MOUNTING BRACKET OF THE REFLECTOMETER. ROUTE THRU THE SPIRAL WOUND CABLE COVERING. INSERT THE RED LEAD INTO CAVITY I OF THE PLUG AND THE WHITE LEAD INTO CAVITY 3.
- 7. PLUG THE CABLE BACK INTO THE JACK ON THE JUNCTION BOX
- 8. REFER TO SH 2 FOR ANTENNA CABLE ROUTING.



VIEW @ C



REAR VIEW

(19C327574, Sh. 2, Rev. 0)

INSTALLATION INSTRUCTIONS

ANTENNA RELAY OPTION 9607


LBI-30490


PARTS LIST

LBI-30492

ANTENNA RELAY KIT 19C327633G1

SYMBOL	GE PART NO.	DESCRIPTION
K1	7479680 P 3	Coaxial: 140 VDC nominal, 7000 ohms ±10% coil res, 1 form C contact; sim to Amphenol 300-11292.
	7777145P4	MISCELLANEOUS Connector, plug: sim to Amphenol 82-98 or UG-27B/U.
	5496809P18	Contact, electrical: sim to Molex Products 1380-T. (Located on red and white wires- Quantity 2).
	N80P13006C6	Machine screw: No. 6-32 x 3/8. (Secures relay assembly).
	7141225P3	Hex nut: No. 6-32. (Secures relay assembly).
	N404P13C6	Lockwasher, internal tooth: No. 6. (Secures relay assembly).





(19D424618, Rev. 1)

THESE INSTRUCTIONS COVER THE INSTALLATION OF THE BLOWER, 190417521 AND THE CABLE KIT 194136978 IN 900 MHz STATIONS.

STEPS

- 1. DISCONNECT ALL POWER SCURCES TO THE 900 MHz CABINET
- 2. REMOVE THE 10-32 X 3/8 RETAINING SCREWS ON EACH SIDE OF THE POWER AMPLIFIED "RONT PANEL, EXTEND THE PWR AMPL TO ITS MAX POSITION, SAVE HARDWARE.
- 3. ASSEMBLE THE THERMCSTAT, 19B22/852GI TC THE DISSIPATOR PLATE ON THE PWR AMPL, USING TWO 19B201074P204, 4:40 x 1/4 SCREWS FURNISHED WITH BLOWER, SEE VIEW B. DISCONNECT THE 9 PIN MOLEX PLUG ON THE JUNCTION BOX OF THE PWR AMPL INSERT ONE BL WIRE FROM THE THERMCSTAT INTO CAVITY 3 OF THE MOLEX CONNECTOR AND THE CHTHER INTO CAVITY 4. (NC POLARITY EXISTS) SEE VIEW . C. RECONNECT THE PUG CNTO THE JACK. SLIDE THE PWR AMPL BACK INTO THE CABINET AND REASSEMBLE THE RETAINING SCREWS.
- 4. ASSEMBLE THE BLOWER, 190417521 TO THE BACK OF THE 900 MHz CABINET AS SHOWN IN THE REAR VIEW, VIEW D-D AND DETAIL E.
- 5. DISCONNECT THE POWER CABLE FROM POWER AMPL AT POWER SUPPLY.
 INSERT THE BL WIRE OF THE 198227852G2 CABLE INTO CAVITY
 5 AND THE COWIRE INTO CAVITY 4 OF THE CONNECTOR. SEE DETAIL F
- RECONNECT POWER CABLE AND ROUTE THE 19B22785261 CABLE DOWN CABINET AS SHOWN.
- 7. CONNECT P2101 TO J2101 ON BLOWER.

NOTE

- I. SUPPLIED WITH FAN 19D417531.
- 2. SUPPLIED AS PART OF 19A136978GI CABLE KIT.





FIG 1
BLOWER INTERCONNECTION DIAGRAM

INSTALLATION INSTRUCTIONS

HEATSINK BLOWER OPTIONS 9609, 9610 AND 9611

LBI-30490



INSTALLATION DIAGRAM

DUPLEXER OPTION 9606


30

Issue 1


THESE INSTRUCTIONS COVER THE INSTALLATION OF THE 19C3O7190 DUPLEXER AND 19A13O785G2 INSTL HARDWARE KIT IN 900 MHz STATIONS.

STEPS:

- USING HARDWARE SUPPLIED IN INSTL KIT, MOUNT DUPLEXER FROM FRONT OF CABINET BETWEEN SYSTEM POWER SUPPLY AND RADIO HOUSING.
- 2. CONNECT 19A136932G1 CABLE BETWEEN RECEIVER PORT ON DUPLEXER AND J945 ON DRIVER CHASSIS.
- 3. CONNECT 19A136932G2 CABLE TO TRANSMITTER PORT ON DUPLEXER. ROLTE UP TO 900 MHz PA, THRU HEAT SINK AS SHOWN AND CONNECT TO OUTPUT OF LOW PASS FILTER




Issue 1 31



806-870 MHz, 90 WATT POLE MOUNT STATION

Issue 1


32



MECHANICAL PARTS BREAKDOWN


806—870 MHz, 90 WATT FLOOR MOUNT STATION

Issue 1 33



MECHANICAL PARTS BREAKDOWN


806-870 MHz, 90 WATT STATION RADIO HOUSING FRONT DOOR



ENLARGED SECTION "A" - "A" (PARTIAL)

TYPICAL OPPOSITE SIDE

806-870 MHz, 90 WATT STATION MOTHER BOARD & DRIVER ASSEMBLIES



MECHANICAL PARTS BREAKDOWN

DESK MATE CABINET

36 Issue 2

PARTS LIST

LBI-4975C

DESK MATE STATION CABINET CONTINUOUS AND INTERMITTANT DUTY (SEE RC-2805)

SYMBOL	GE PART NO.	DESCRIPTION
		30 INCH CABINET
1	19C320655P1	Top.
2	19C320654P1	Screen.
3		(Not Used).
4		(Not Used).
5	5491682P23	Lock, Yale and Towne F6557DX1.
6	5491682P4	Key. Yale and Towne BF-10A.
7	19C320744G7	Front door.
8	19D417231G3	Cabinet. (LESS DOORS). (Includes items 1 and 2).
9	19A134011P1	Tap screw: No. 10-16 x 3/4. (Quantity 52).
10	7160861P32	Nut, sheet spring; sim to Tinnerman C1794-10Z-24. (Quantity 52).
11	19C320744G8	Rear door.
12	19A134032P1	Protective plug. (Quantity 1).
13	19A134014P6	Bushing, strain relief: sim to Heyco UB-1093.
14	19A134015P1	Protective plug: sim to Caplug BPF-1/2. (Quantity 4).
15	19C311298P1	Frame. (Used with monogram).
16	4031053P7	Nut, sheet spring; sim to Tinnerman Cl2046-012-67. (Quantity 1).
17	NP257660	Nameplate.
18	NP276429	Nameplate. (GFNERAL ELECTRIC).
		44 INCH CABINET
1	19C320655P1	Top.
2	19C320654P1	Screen.
3		(Not Used).
4		(Not Used).
5	5491682P23	Lock. Yale and Towne F6557DX1.
6	5491682P4	Key. Yale and Towne BF-10A.
7	19C320744G9	Front door.
8	19D417231G4	Cabinet. (LESS DOORS), (Includes items 1 and 2).
9	19A134011P1	Tap screw: No. 10-16 x 3/4. (Quantity 52).
10	7160861P33	Nut, sheet spring; sim to Tinnerman C19640-10AB-3B. (Quantity 52).
11	19C320744G10	Rear door.
12	19A134032P1	Protective plug. (Quantity 1).
13 14	19A134014P6 19A134015P1	Bushing, strain relief: sim to Heyco UB-1093. Protective plug: sim to Caplug BPF-1/2. (Quantity 4).
15	19C311298P1	Frame, (Used with monogram).
16	4031053P7	Nut, sheet spring; sim to Tinnerman Cl2046-012-67. (Quantity 1).
17	NP257660	Nameplate.
18	NP276429	Nameplate. (GENERAL ELECTRIC).


^{*}COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES

PARTS LIST

LBI4976D


POLE MOUNT STATION CABINET
CONTINUOUS AND INTERMITTANT DUTY
19D417550G1
(SEE RC2806)

SYMBOL	GE PART NO.	DESCRIPTION
1	19D417550G1	Cabinet.
2	19B209531P1	Nameplate. (GENERAL ELECTRIC).
3	4031310P7	Nut, push on: sim to Tinnerman C610-012-24.
4	19D417543G2	Door, left hand.
5	19A134128P1	Door seal. (Front and rear).
6	19A134059P1	Protective plug.
7	19D417543G1	Door, right hand.
8	19A134049P3	Door handle.
9	7150752Pl	Strike catch.
10	N84P15008C6	Machine screw: No. 8-32 x 1/2.
11	N403P16C6	Lockwasher, external tooth: No. 8.
12	N210P15C6	Hex nut: No. 8-32.
13	19A134011P1	Tap screw: No. 10-16 x 3/4. (Quantity 52).
14	7160861P33	Nut, sheet spring; sim to Tinnerman C19640-10AB-36. (Quantity 52).
15	19A134015P2	Protective plug.
16	NP270697	Nameplate.
17	NP196405	Nameplate.
18	N210P21C6	Hex nut: No. 1/4-20.
19	N403P25C6	Lockwasher, external tooth: 1/4 inch.
20	19A115141P2	Solderless terminal: sim to ILSCO SLU70.
21	N22P25016C6	Cap screw: No. 3/8-16 x 1.
22	N405P43C6	Lockwasher, spring type: 3/8 inch.
23	19B226350G1	Outlet strip.
24	19B209103P506	Tap screw: No. 10-32 x 3/8. (Secures outlet strip).
25	19C320942P1	Mounting bracket.
	ĺ	
	1	
	I	



MECHANICAL PARTS BREAKDOWN

POLE MOUNT STATION CABINET



MECHANICAL PARTS BREAKDOWN

FLOOR MOUNT STATION CABINET

38

Issue 3

PARTS LIST

LB14977C

FLOOR MOUNT STATION CABINET CONTINUOUS AND INTERMITTANT DUTY 19D417358G1 (SEE RC2804)

SYMBOL	GE PART NO.	DESCRIPTION
1	19D417623G1	Grille.
2	19B226318P1	Grille plate. (Located under grille).
3	19B219744G2	Strain relief.
4	N80P15008C6	Machine screw: No. 8-32 x 1/2,
5	N210P15C6	Hex nut: No. 8-32.
6	N403P16C6	Lockwasher, external tooth: No. 8.
7	19A126220P1	Gasket, door.
8	19B209539P2	Lock, rear door: sim to Chicago Lock Co. 1703-6T.
9	19B209539P3	Key. Sim to Chicago Lock Co. 1000 GE.
10	19C320756G2	Door, rear. 64 inch.
11	19C320756G1	Door, front. 59 inch.
12	19A134011P1	Tap screw: No. 10-16 x 3/4. (Quantity 52).
13	7160861P33	Nut, sheet spring; sim to Tinnerman C19640-10AB-3B. (Quantity 16).
14	19B226160P2	Support.
15	N80P16008C6	Machine screw: No. 10-32 x 1/2.
16	N403P19C6	Lockwasher, external tooth: No. 10.
17	19B226094P2	Support.
18	N80P21012C6	Machine screw: No. 1/4-20 x 3/4.
19	N403P25C6	Lockwasher, external tooth: 1/4 inch.
20	N402P41C6	Flatwasher: No. 1/4.
21	N80AP16006C6	Machine screw, panhead: No. 8-32 x 3/8.
22	7160861P5	Nut, sheet spring; sim to Tinnerman C1505-1032-157.
23	19B226094P1	Support,
24	19A129902P1	Spring.
25	19B226088P1	Pin hinge.
26	19B226092G1	Frame.
27	19B209539P1	Lock, front. Sim to Chicago Lock Co. 4260-1.
28	N80P16007C6	Machine screw: No. 10-32 x 7/16.
29	N210P16C6	Hexnut: No. 10-32.
30	7160861P33	Nut, sheet spring; sim to Tinnerman C19640-10AB-3B.
31	NP257660	Nameplate. (GE).
32	4031053P7	Nut, sheet spring; sim to Tinnerman Cl2046-012-67.
1		
ł		
	1	

*COMPONENTS ADDED, DELETED OR CHANGED BY PRODUCTION CHANGES