# COMMUNICATIONS

# MAINTENANCE MANUAL

IF Generator MODEL 4EX7A10



#### **SPECIFICATIONS** \*

Combination Number (includes Test Set and Cable)

Dimensions (H x W x D)

Input Power

Output Voltage

Output Frequencies Available (if appropriate crystals are ordered)

Temperature Range

3" x 5-1/2" x 2-1/2"

3 milliamps at 7 volts (one 7-volt mercury battery).

0 to 0.1-volts RMS

285 KC 290 KC 295 KC 450 KC 455 KC 460 KC

**TE41** 

 $0^{\circ}$ C to  $45^{\circ}$ C (+32°F to 113°F)

\*These specifications are intended primarily for the use of the serviceman. Refer to the appropriate Specification Sheet for the complete specifications.



# TABLE OF CONTENTS

SPECIFI	CATI	ONS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	Cover
DESCRIP	<b>FION</b>	••	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	1
OPERATIO	ON.	••	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	1
CIRCUIT	ANA	LYS	IS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	2
MAINTEN	ANCE	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	2
OUTLINE	& S	CHE	MAT	<b>NIC</b>		DIA	GF	AN	1	(Wj	th	ı V	'ol	ta	ge	R	lea	.di	ng	s)	•	•	•	•	•	•	•	5
PARTS L																												
PRODUCT	ION	СНА	NGI	ES	•	•	•	•		•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	6

1

### DESCRIPTION

General Electric Test Set Model 4EX7A10 is a transistorized, battery-operated IF Generator designed for alignment of IF and discriminator circuits in two-way FM receivers.

The generator uses a crystal-controlled oscillator to provide outputs of 285 KC, 290 KC, 295 KC, 450 KC, 455 KC, and 460 KC when the appropriate crystals are installed. Six internally mounted crystal sockets facilitate crystal installation.

Constant & States of Press

All controls and output connections are conveniently located on the front of the IF Generator. Output frequencies are selected by a two-position slide switch and a four-position rotary switch. Slide switch S1002 (fo) selects the center output frequency (290 KC or 455 KC) while rotary switch S1001 (FREQ-KC) permits selection of frequencies 5 kilocycles above and below the selected center frequency. (The rotary switch also turns the generator on). The LEVEL control adjusts the signal level that is available at the OUTPUT jack to any desired level between 0 and 0.1 volts. - <u>1</u> <sup>6</sup> 7 "我我们说,<del>你就想到我的问题的我们,"</del>你是一个人

A four-foot cable is supplied for making connections between the generator and the unit under test. 1961.来《日本·林林》:《新华·古

**OPERATION** 

To use the test set for receiver alignment, refer to the receiver instruction manual for the Lo IF frequency and complete alignment procedure. Operate the IF Generator as follows:

- Make connections (with 4-foot cable supplied) between the test 1. set and receiver Lo IF input. an the second and the second second
- Select the desired output frequency (290 KC or 455 KC) with slide 2. switch.
- Set FREQ-KC switch to  $f_0$  position to turn unit on and obtain 3. 290-KC or 455-KC output.
- Adjust LEVEL control for desired output. 4.

a construction of the second second second

Select output frequencies of 5 kilocycles below and 5 kilocycles 5. above the  $f_0$  frequency (290 KC or 455 KC) with the -5 and +5 positions, respectively, on the FREQ-KC switch as required by receiver alignment procedure.

#### **OPERATION**

#### - NOTE -

If the receiver discriminator adjustment procedure specifies signals 10 KC above and below IF frequency, tune discriminator for 1/2 of the recommended output voltage when applying signals 5 KC above and below IF frequency.

# CIRCUIT ANALYSIS

Output frequencies are generated by a battery-operated, crystalcontrolled, Colpitts oscillator (Q1 & Q2). Q1 and Q2 are compoundconnected to provide necessary drive to the crystal. The desired frequency is obtained by switching the crystals in the oscillator control circuit.

Selecting a frequency with the FREQ-KC switch, connects positive battery voltage to the collectors of Ql and Q2 through R2. Positive base bias is established by R1, causing Q2 and Q1 to conduct. As current flows in the collector circuit of the transistors, regenerative feedback is provided to the crystal controlled base circuit to sustain oscillation at the crystal frequency.

ere a station to a

LEVEL control R1001 adjusts the output signal level present at OUTPUT jack J1001.

## MAINTENANCE

staft fan y klande

#### BATTERY REPLACEMENT

To replace battery, take out the two screws holding the front plate and carefully remove the housing. Then remove the old battery and insert the new battery (Eveready No. El65 or equivalent) being certain to maintain the same polarity.

— WARNING —

Do not dispose of mercury batteries by burning them, since they may explode.

na se en la sense de la serie de la serie da se En la serie da serie Participa da serie da

#### MAINTENANCE

••

3

#### TROUBLESHOOTING PROCEDURE

Troubleshooting procedures are outlined in the following chart. Also refer to voltage and resistance readings on the Outline and Schematic Diagrams.

TROUBLESHOOTI	NG PROCEDURE CHART
SYMPTOM	CHECK THE FOLLOWING
NO OUTPUT	<ol> <li>Battery.</li> <li>Sl001 and Sl002.</li> <li>Q1 and Q2.</li> </ol>
EXCESSIVE CURRENT DRAIN ON BATTERY	Q1 and Q2 for shorts.
CANNOT ADJUST OUTPUT	R1001
WILL NOT OPERATE ON ONE FREQUENCY, BUT OTHER FREQUENCIES OK.	<ol> <li>S1001 and S1002.</li> <li>Associated crystal and crystal socket.</li> </ol>

#### LBI-3791


					$\frac{1}{2} = \frac{1}{2} \left( \frac{1}{2} + \frac{1}{2} \right) \left( \frac{1}{2} + \frac{1}{2} \right) \left( \frac{1}{2} + \frac{1}{2} + \frac{1}{2} + \frac{1}{2} \right) \left( \frac{1}{2} + \frac{1}{2} + \frac{1}{2} + \frac{1}{2} \right) \left( \frac{1}{2} + \frac{1}{2} + \frac{1}{2} + \frac{1}{2} \right) \left( \frac{1}{2} + \frac{1}{2} + \frac{1}{2} + \frac{1}{2} + \frac{1}{2} \right) \left( \frac{1}{2} + 1$					
		PARTS LIST	SYMBOL	G-E PART NO						
	IF MODEL 4	LBI-3797A GENERATOR TEST SET EX7Alo PL-19C311195-G1		198209044-P4 7776570-P1 4033711-P1	PL-19B205487-02 Cable, RF: 48 in; sim to Amphenol 21-199. Connector, BNC: Plug; sim to Military UG-880/U or UG-880/0.					
		and the state state		19A115821-P1	Clip, aligator. (Used with center lead and shield). Sleeving, insulated: Red: sim to Mueller					
YMBOL	G-E PART NO.	DESCRIPTION		194115821-P2	Sleeving, insulated: Red; sim to Mueller Electric 32R. (Used with center lead). Sleeving, insulated: Black; sim to Mueller Electric 32B. (Used with shield).					
				a an an						
1001				7142162-P81	Spacer: (Located between housing and Al001 Board).					
1001		COMPONENT BOARD PL-198205638-G1		PL-4039182-G2	Knob: (For R1001 and S1001).					
		CAPACITORS		19A115793-P1	Contact, electrical: sim to Malco 2700. (Part of XY1 thru XY6).					
Cl thru C3	7489162-P39	Silver mica: 330 pf ±5%, 500 VDCW; sim to Electro Motive Type DM-15.		4033089-P1	Clip. (Part of XY1 thru XY6).					
				19C311172-P1	Socket. (Part of XY1 thru XY6).					
Q1 and Q2	19A115123-P1	5ilicon, NPN; sim to Type 2N2712.								
	•									
RL	3R77-P474K	Composition: 0.47 megohm ±10%, 1/2 w.			이 이 가슴 가슴 가슴 가슴 가슴 가슴. 이 같은 것 같아요. 이 것 같아요. 이 가슴이 가슴이 가슴.					
R2	3R77-P182K	Composition: 1800 ohms ±10%, 1/2 w.			en en antiparte en provinción de la companya de la Companya de la companya de la company					
R3*	3R77-P392K 3R77-P512K	Composition: 3900 ohms ±10%, 1/2 w. In Rev. A & earlier: Composition: 5100 ohms ±10%, 1/2 w.								
R4	3R152-P203J	Composition: 20,000 ohms ±5%, 1/4 w.								
R5*	3R77-P561J	Composition: 560 ohms $\pm 5\%$ , $1/2 = 4$ . Added by Rev. B.								
1				a s	a na anna an an anna anna anna					
Yl thru Y6	198200360-P3 P4 P5 P9 P10 P11	285.000 kcs. 290.000 kcs. 295.000 kcs. 450.000 kcs. 455.000 kcs. 460.000 kcs.								
XY1 thru XY6		SOCKETS								
		BATTERIES								
r1001	5493174-P1	Mercury: 7 v; sim to Mallory Type TR-165. (See Note Below)								
.001	5496218-P41	Fixed ceramic disc: 10 pf ±0.25 pf, 500 VDCW, 0 temp coef.								
1002*	19B209243-P15	Polyester: 0.22 µf ±20%, 250 VDCW. Added by Rev. A.		i i						
1001	7776570-P17									
.001	5496870-P17	Variable: carbon film, 500 ohms ±20%; sim to Mallory LC(500).								
001	19C307060-P4	Rotary: 2 section, 4 position, 6 poles; sim to								
002	71450 <del>98</del> -P1	CTS 222-17254-2. Slide: DPDT, 0.75 amp at 125 VAC or 0.5 amp at 125 VDC; sim to Stackpole SS-150.	-		,					
1	7487424-P22	TERMINAL BOARDS Niniature, phen: 1 terminal.								
BT101	19B200019-P4	Retainer, battery. sim to Keystone Electronics 110.								

•

Note: Other batteries are Eveready E165, NEDA 1500M, Burgess H165, RCA VS165, and Ray-O-Vac T165. These are 7.0 volt, 500 mAh mercury batteries that are 0.662" diameter and 2.18" long.

#### **OUTLINE DIAGRAM**

LBI-3791



#### (19C311192, Rev. 4)

1

## **OUTLINE & SCHEMATIC DIAGRAM**

IF GENERATOR MODEL 4EX7A10

Issue 2

# **PRODUCTION CHANGES**

Changes in the equipment to improve performance or to simplify circuits ar identified by a "Revision Letter", which is stamped after the model number of the unit. The revisions stamped on the unit inculdes all previous revisions. Refer to the Parts List for descriptions of parts affected by these revisions.

<u>ه</u> ...

REV. A - To provide DC blocking capacitor. Added C1002.

REV. B - To stabilize the oscillator. Changed R3 and added R5.