(DF3158, THIS SHEET ONLY)



MASTR[®]II MAINTENANCE MANUAL

406 - 512 MHz, 100 - WATT TRANSMITTER - MOBILE AND STATION




TABLE OF CONTENTS

SPECIFICATIONS	ii
DESCRIPTION AND MAINTENANCE	LBI 30199 (DF3158)
EXCITER	LBI30200 (DF3165)
POWER AMPLIFIER	LBI 3020

SPECIFICATIONS*

Power	Ou	t	pι	ıt
-------	----	---	----	----

406-420 MHz, 450-470 MHz 420-440 MHz, 470-512 MHz 440-450 MHz

Crystal Multiplication Factor

Frequency Stability

5C-ICOM with EC-ICOM 5C-ICOM or EC-ICOM 2C-ICOMS

Spurious and Harmonic Emission

Modulation

Modulation Sensitivity

Audio Frequency Characteristics

Distortion

Deviation Symmetry

Maximum Frequency Spread

406-470 MHz

470-494 MHz

494-512 MHz

Duty Cycle

RF Output Impedance

100 Watts (Adjustable from 30 to 100 Watts)

90 Watts (Adjustable from 30 to 90 Watts)

80 Watts (Adjustable from 30 to 90 Watts)

36

±0.0005% (-40°C to +70°C) ±0.0002% (0°C to +55°C)

 $\pm 0.0002\%$ (-40°C to +70°C)

At least 85 dB below full rated power output.

Adjustable from 0 to ±5 kHz swing with instantaneous modulation limiting.

75 to 120 Millivolts (Mobile)

10 to 120 Millivolts (Station)

Within +1 dB to -3 dB of a 6 dB/octave preemphasis from 300 to 3000 Hz per EIA standards. Post limiter filter per FCC and EIA.

Less than 2% @ 1000 Hz Less than 5% @ 300 Hz Less than 3% @ 3000 Hz

0.6 kHz maximum

Full Specifications

1 dB Degradation 9.00 MHz

5.50 MHz

5.80 MHz

9.50 MHz

6.00 MHz

9.75 MHz

EIA 20% Intermittent (Mobile and Station) Continuous (Stations)

50 Ohms

* These specifications are intended primarily for the use of the Serviceman. Refer to the appropriate Specification Sheet for the complete specifications.

- WARNING -

Although the highest DC voltage supplied to the MASTR II transmitter is +12 Volts DC, high current may be drawn under short circuit conditions. These currents can possibly heat metal objects such as tools, rings, watchbands, etc., enough to cause burns. Be careful when working near energized circuits!

High-level RF energy in the transmitter Power Amplifier assembly can cause RF burns. KEEP AWAY FROM THESE CIRCUITS WHEN THE TRANSMITTER IS ENERGIZED:

> GENERAL ELECTRIC COMPANY . MOBILE COMMUNICATIONS DIVISION WORLD HEADQUARTERS • LYNCHBURG, VIRGINIA 24502 U.S.A.

